Technical Information Cerabar PMP43

Process pressure measurement 4-20 mA analog



Compact digital transmitter with metallic process membrane

Application areas

- Reliable, repeatable and stable pressure measurement and hydrostatic level measurement
- Pressure measuring range: up to 100 bar (1500 psi)
- Process temperature: up to 200 °C (392 °F)
- Accuracy: up to ± 0.075 %

Benefits

- Perfect cleanability thanks to fully welded design
- Easy guided commissioning with intuitive user interface
- Colored display with backlight and touch operation
- Bluetooth[®] wireless technology for commissioning, operation and maintenance
- CIP and SIP capabilities up to protection class IP69



Table of contents

About this document	3
Symbols	. 3
List of abbreviations	3
Iurn down calculation Graphic conventions	4
	J
Function and system design	5
Measuring principle	5
Measuring system	5
Communication and data processing	5
Reliability	6
Device-specific II security	0
Input	6
Measured variable	6
Measuring range	. 6
Output	8
Output signal	8
Signal on alarm for devices with current output	8
Load	8
Damping	8
Ex connection data	8
Power supply	8
Terminal assignment	8
Available device plugs	8
Supply voltage	8
Power consumption	9
Overvoltage protection	. 9
Deutermen en alerra atoriation	0
Reference operating conditions	9
Resolution	. 9
Total performance	. 9
Measurement uncertainty for small absolute pressure	
measuring ranges	11
Total error	11
Response time	11
Warm-up time	12
Installation	17
Mounting position	12
Installation instructions	12
Environment	12
Storage temperature	14
Operating height	14 14
Climate class	14
Degree of protection	14
Pollution degree	14
Vibration resistance	14
SHOCK RESISTANCE	14 14
	14

Process Process temperature Process pressure range Cleaned of oil and grease	14 14 15 15
Mechanical construction	16 17 35 35 35
User interface Languages LED indicator Onsite display Remote operation Supported operating tools	35 36 36 37 37
Certificates and approvals	 37 37 38
Order information	39 39 40
Accessories Device-specific accessories Device Viewer Field Xpert SMT70 Field Xpert SMT77 SmartBlue app	40 40 40 40 40 40
Documentation	41 41 41
Registered trademarks	41

About this document

Sumbola	Safatu gumbala					
Symbols						
	This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.					
	A WARNING This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.					
	A CAUTION This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.					
	NOTICE This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.					
	Communication-specific symbols					
	Bluetooth®: 8 Wireless data transmission between devices over a short distance					
	Symbols for certain types of information					
	Permitted: 🖌					
	Procedures, processes or actions that are permitted.					
	Forbidden: 🔀					
	Procedures, processes or actions that are forbidden.					
	Additional information: 🚹					
	Reference to documentation: 🔟					
	Reference to page: 🗎					
	Series of steps: 1., 2., 3.					
	Result of an individual step: 🖵					
	Symbols in graphics					
	Item numbers: 1, 2, 3					
	Series of steps: 1., 2., 3.					
	Views: A, B, C,					
List of abbreviations	PN Nominal pressure					
	Operating tool					
	The term "operating tool" is used in place of the following operating software:					
	SmartBlue app, for operation using an Android or iUS smartphone or tablet PLC					
	Programmable logic controller (PLC)					



- 1 OPL: The OPL (overpressure limit) for the device depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection must be taken into consideration in addition to the measuring cell. Observe pressure-temperature dependency. The OPL may only be applied for a short period of time.
- 2 *MWP: The MWP (maximum working pressure) for the measuring cells depends on the lowest-rated element,* with regard to pressure, of the selected components, i.e. the process connection also has to be taken into consideration besides the measuring cell. Observe pressure-temperature dependency. The maximum working pressure may be applied at the device for an unlimited period of time. The maximum working pressure can be found on the nameplate.
- 3 The maximum measuring range corresponds to the span between the LRL and URL. This measuring range is equivalent to the maximum span that can be calibrated/adjusted.
- The calibrated/adjusted span corresponds to the span between the LRV and URV. Factory setting: 0 to URL. 4 Other calibrated spans can be ordered as customized spans.
- Pressure р
- LRL Lower range limit
- URL Upper range limit
- LRV Lower range value
- URV Upper range value
- Turn down Example see the following section. ΤD

Turn down calculation



- Calibrated/adjusted span 1
- 2 Zero point-based span
- 3 Upper range limit

Example:

- Measuring cell: 10 bar (150 psi)
- Upper range limit (URL) = 10 bar (150 psi)
- Calibrated/adjusted span: 0 to 5 bar (0 to 75 psi)
- Lower range value (LRV) = 0 bar (0 psi)
- Upper range value (URV) = 5 bar (75 psi)



In this example, the TD is therefore 2:1. This measuring span is based on the zero point.

A002

Graphic conventions	 Installation, explosion and electrical connection drawings are presented in simplified format Devices, assemblies, components and dimensional drawings are presented in reduced-line format
	 Dimensional drawings are not to-scale representations; the dimensions indicated are rounded off to 2 decimal places
	 Unless otherwise described, flanges are presented with sealing surface form EN 1092-1; ASME B16.5, RF.

Function and system design

Measuring principle	Metallic membrane			
	1 Measuring element			
	 2 Wheatstone bridge 3 Channel with fill fluid 4 Metallic membrane p Pressure 			
	The applied pressure deflects the metallic membrane of the measuring cell. A fill fluid transfers the pressure to a Wheatstone bridge (semiconductor technology). The pressure-dependent change in the bridge output voltage is measured and evaluated.			
	Advantages: • Can be used for high process temperatures • Condensate-resistant • High long-term stability • High overload resistance			
Measuring system	A complete measuring system comprises:			

PLC (programmable logic controller) 1

2 3 RMA42/RIA45 (if necessary)

Device

Communication and data processing

Bluetooth (optional)

Endress+Hauser

A0053220

IT security				
The manufacturer warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.				
IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.				
The device offers specific functions to support protective measures by the operator. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. The user role can be changed with an access code (applies to operation via the onsite display, Bluetooth, DeviceCare).				
Access via Bluetooth [®] wireless technology				
Secure signal transmission via Bluetooth [®] wireless technology uses an encryption method tested by the Fraunhofer Institute.				
 Without the SmartBlue app, the device is not visible via Bluetooth[®] wireless technology. Only one point-to-point connection is established between the device and a smartphone or tablet. The Bluetooth[®] wireless technology interface can be disabled via onsite operation or via SmartBlue/DeviceCare. 				

Input

Measured variable	Measured process variables			
	Absolute pressureGauge pressure			
	Calculated process variables			
	Pressure			
Measuring range	Depending on the device configuration, the maximum working pressure (MWP) and the overpressure limit (OPL) can deviate from the values in the tables.			
Absolute pressure				

Absolute	pressure
----------	----------

Measuring cell	Maximum measuring range		Smallest factory-calibratable span	
	lower (LRL) upper (URL) S		Standard	Platinum
	[bar (psi)]	[bar (psi)]	[bar (psi)]	
400 mbar (6 psi)	0	+0.4 (+6)	0.05 (0.75) ¹⁾	80 mbar (1.2 psi)
1 bar (15 psi)	0	+1 (+15)	0.05 (0.75) ²⁾	200 mbar (3 psi)
2 bar (30 psi)	0	+2 (+30)	0.10 (1.50) ²⁾	400 mbar (6 psi)
4 bar (60 psi)	0	+4 (+60)	0.20 (3.00) ²⁾	800 mbar (12 psi)
10 bar (150 psi)	0	+10 (+150)	0.50 (7.50) ²⁾	2 bar (30 psi)
40 bar (600 psi)	0	+40 (+600)	2.00 (30.0) 2)	8 bar (120 psi)
100 bar (1500 psi)	0	+100 (+1500)	5.00 (73) ²⁾	20 bar (300 psi)

1) 2) Largest factory-configurable turn down: 8:1 Largest factory-configurable turn down: 20:1

Absolute pressure

Measuring cell	MWP	OPL	Factory settings ¹⁾
	[bar (psi)]	[bar (psi)]	
400 mbar (6 psi)	1 (14.5)	1.6 (23)	0 to 400 mbar (0 to 6 psi)
1 bar (15 psi)	2.7 (39)	4 (58)	0 to 1 bar (0 to 15 psi)
2 bar (30 psi)	6.7 (97)	10 (145)	0 to 2 bar (0 to 30 psi)
4 bar (60 psi)	10.7 (155)	16 (232)	0 to 4 bar (0 to 60 psi)
10 bar (150 psi)	25 (362)	40 (580)	0 to 10 bar (0 to 150 psi)
40 bar (600 psi)	100 (1450)	160 (2320)	0 to 40 bar (0 to 600 psi)
100 bar (1500 psi)	103.5 (1500)	160 (2320)	0 to 100 bar (0 to 1500 psi)

1) Different measuring ranges (e.g.-1 to +5 bar (-15 to +75 psi)) can be ordered with customized settings. It is possible to invert the output signal (LRV = 20 mA; URV = 4 mA). Prerequisite: URV < LRV

Gauge pressure

Measuring cell	Maximum measuring range		Smallest factory-calibratable span ¹⁾	
	lower (LRL)	upper (URL)	Standard	Platinum
	[bar (psi)]	[bar (psi)]	[bar (psi)]	
400 mbar (6 psi)	-0.4 (-6)	+0.4 (+6)	0.05 (0.75) ²⁾	80 mbar (1.2 psi)
1 bar (15 psi)	-1 (-15)	+1 (+15)	0.05 (0.75) ³⁾	200 mbar (3 psi)
2 bar (30 psi)	-1 (-15)	+2 (+30)	0.10 (1.50) ³⁾	400 mbar (6 psi)
4 bar (60 psi)	-1 (-15)	+4 (+60)	0.20 (3.00) ³⁾	800 mbar (12 psi)
10 bar (150 psi)	-1 (-15)	+10 (+150)	0.50 (7.50) ³⁾	2 bar (30 psi)
25 bar (375 psi)	-1 (-15)	+25 (+375)	1.25 (18.50) ³⁾	5 bar (75 psi)
40 bar (600 psi)	-1 (-15)	+40 (+600)	2.00 (30.00) 3)	8 bar (120 psi)
100 bar (1500 psi)	-1 (-15)	+100 (+1500)	5.00 (73) ³⁾	20 bar (300 psi)

1) Largest factory-configurable turn down: 5:1.

2) Largest factory-configurable turn down: 8:1

3) Largest factory-configurable turn down: 20:1

Gauge pressure

Measuring cell	MWP	OPL	Factory settings ¹⁾
	[bar (psi)]	[bar (psi)]	
400 mbar (6 psi)	1 (14.5)	1.6 (23)	0 to 400 mbar (0 to 6 psi)
1 bar (15 psi)	2.7 (39)	4 (58)	0 to 1 bar (0 to 15 psi)
2 bar (30 psi)	6.7 (97)	10 (145)	0 to 2 bar (0 to 30 psi)
4 bar (60 psi)	10.7 (155)	16 (232)	0 to 4 bar (0 to 60 psi)
10 bar (150 psi)	25 (363)	40 (580)	0 to 10 bar (0 to 150 psi)
25 bar (375 psi)	25.8 (375)	100 (1450)	0 to 25 bar (0 to 375 psi)
40 bar (600 psi)	100 (1450)	160 (2320)	0 to 40 bar (0 to 600 psi)
100 bar (1500 psi)	103.5 (1500)	160 (2320)	0 to 100 bar (0 to 1500 psi)

1) Different measuring ranges (e.g.-1 to +5 bar (-15 to +75 psi)) can be ordered with customized settings. It is possible to invert the output signal (LRV = 20 mA; URV = 4 mA). Prerequisite: URV < LRV



I For further information, see the "Device-specific accessories" section

Supply voltage

12 to 30 V_{DC} on a direct current power unit

	A suitable circuit breaker should be provided for the device in accordance with IEC/EN 61010-1.
	Protective circuits against reverse polarity, HF influences and overvoltage peaks are installed.
Power consumption	Non-hazardous area: To meet device safety specifications according to the IEC 61010 standard, the installation must ensure that the maximum current is limited to 500 mA.
Potential equalization	If necessary, establish potential equalization using the process connection or the grounding clamp supplied by the customer.
Overvoltage protection	The device satisfies the IEC 61326-1 product standard (Table 2 Industrial environment). Depending on the type of connection (DC power supply, input line, output line), different test levels are used to prevent transient overvoltages (IEC 61000-4-5 Surge) in accordance with IEC EN 61326-1: Test level for DC power supply lines and IO lines: 1000 V wire to ground.
	Overvoltage category
	In accordance with IEC 61010-1, the device is intended for use in networks with overvoltage

Performance characteristics

protection category II.

Reference operating conditions	• As per IEC 62828-2 • Ambient temperature T_A = constant, in the range of +21 to +33 °C (+70 to +91 °F) • Humidity φ = constant, in the range of: 5 to 80 % RH ± 5 % • Atmospheric pressure p_A = constant, in the range of: 860 to 1060 mbar (12.47 to 15.37 psi) • Supply voltage: 24 V_{DC} ±3 V_{DC} • Position of the measuring cell: horizontal ±1° • Input of LOW SENSOR TRIM and HIGH SENSOR TRIM for lower range value and upper range value • Zero based span • Turn down (TD) = URL/ URV - LRV
Resolution	Current output: < 1 µA
Total performance	The performance characteristics refer to the accuracy of the device. The factors influencing accuracy can be divided into two groups. Total performance of device Installation factors
	All of the performance characteristics meet the requirement of $\geq \pm 3$ sigma.
	The total performance of the device comprises the reference accuracy and the ambient temperature effect and is calculated using the following formula:
	Total performance = $\pm \sqrt{((E1)^2 + (E2)^2)}$
	E1 = Reference accuracy
	E2 = Temperature effect
	Calculation of E2:
	Temperature effect per ±28 °C (50 °F)
	(corresponds to a range of –3 to +53 $^\circ$ C (+27 to +127 $^\circ$ F))
	$E2 = E2_{M} + E2_{E}$
	$E2_{M} = Main$ temperature error
	$E2_E = Electronics error$
	The values refer to the calibrated span. The span is based on the zero point.
	Reference accuracy [E1]
	The reference accuracy comprises the non-linearity according to the limit point method, pressure hysteresis and non-repeatability in accordance with [IEC 61298-2].

Measuring cell	Standard	Platinum
400 mbar (6 psi)	TD 1:1 = ±0.2 % TD > 1:1 to 10:1 = ±0.5 % · TD	-
1 bar (15 psi)	TD 1:1 = ±0.1 % TD > 1:1 to 10:1 = ±0.3 % · TD	TD 1:1 = ±0.1 % TD > 1:1 to 10:1 = ±0.2 % · TD
2 bar (30 psi)	TD 1:1 to 5:1 = ±0.1 % TD > 5:1 to 10:1 = ±0.2 %	TD 1:1 to 5:1 = ±0.075 % TD > 5:1 to 10:1 = ±0.1 %
4 bar (60 psi) 10 bar (150 psi) 25 bar (375 psi)	TD 1:1 to 10:1 = ±0.1 % TD > 10:1 to 20:1 = ±0.2 %	TD 1:1 to 10:1 = ±0.075 % TD > 10:1 to 20:1 = ±0.1 %
40 bar (600 psi)	TD 1:1 to 10:1 = ±0.1 % TD > 10:1 to 20:1 = ±0.3 %	TD 1:1 to 5:1 = ±0.075 % TD > 5:1 to 10:1 = ±0.15 %
100 bar (1500 psi)	TD 1:1 to 10:1 = ±0.1 % TD > 10:1 to 20:1 = ±0.2 %	TD 1:1 to 10:1 = ±0.075 % TD > 10:1 to 20:1 = ±0.15 %

Platinum not for flush-mounted process connections Clamp DN22, G ¹/₂.

Temperature effect [E2]

E2_M - *Main temperature error*

The output changes due to the effect of the ambient temperature [IEC 62828-1] with respect to the reference temperature [IEC 62828-1]. The values specify the maximum error due to min./max. ambient or process temperature conditions.

Application feature: process temperature +100 °C (+212 °F), process +130 °C (+266 °F)temperature (+150 °C (+302 °F) max. 1h), process temperature +150 °C (+302 °F)

- 400 mbar (6 psi) measuring cell
 - Process connection clamp 1", DIN11851 DN25, NEUMO BioControl DN25, NPT 3/4", NPT 1", G1" flush-mounted, G1" with O-ring, G1" with sealing taper, Aseptoflex: ±(1.05 % · TD + 0.10 %)
 - Process connection SMS 1", ingold fitting: ±(1.55 % · TD + 0.10 %)
 - Process connection MNPT1/2 bore 11.4 mm, MPNT1/2 FNPT1/4, G1/2" EN837, G1/2 bore 11.4 mm, M20 x 1.5: ±(0.20 % · TD + 0.10 %)
 - All other process connections: ± (0.63% · TD +0,10%)
- 1 bar (15 psi) measuring cell
 - Process connection clamp 1", DIN11851 DN25, NEUMO BioControl DN25, NPT 3/4", NPT 1", G1" flush-mounted, G1" with O-ring, G1" with sealing taper, Aseptoflex: ±(0.42 % · TD + 0.10 %)
 Process connection SMS 1", ingold fitting: ±(1.62 % · TD + 0.10 %)
 - Process connection SMS 1, ingola litting: ±(1.62 % · 1D +)
 All other process connections: ± (0.25% · TD +0.10%)
- 2 bar (30 psi) measuring cell
 - Process connection SMS 1", ingold fitting: $\pm (0.35 \% \cdot \text{TD} + 0.10 \%)$
 - All other process connections: $\pm (0.25\% \cdot \text{TD} + 0.10\%)$
- 4 bar (60 psi), 10 bar (150 psi), 25 bar (375 psi), 40 bar (600 psi) and 100 bar (1500 psi) measuring cell
 - ± (0.20% · TD +0.10%

	Application feature: Process temperature +200 °C (+392 °F)
	 400 mbar (6 psi) measuring cell Process connection clamp 1", clamp 1 1/2", DIN11851 DN25, NEUMO BioControl DN25, NPT 3/4", NPT 1", G1" flush-mounted, G1" with O-ring, G1" with sealing taper, Aseptoflex: ±(1.47 % · TD + 0.10 %)
	 Process connection SMS 1": ±(1.75 % · 1D + 0.10 %) All other process connections: + (0.63% · TD +0.10%)
	 1 bar (15 psi) measuring cell
	 Process connection clamp 1", DIN 11851 DN25, NEUMO BioControl DN25, NPT 3/4", NPT 1", G1" flush-mounted, G1" mounting, G1" with sealing taper: ±(0.59 % · TD + 0.10 %) Process connection SMS 1", ingold fitting: ±(0.7 % · TD + 0.10 %) All other process connections: ± (0.25% · TD +0.10%) 2 bar (30 psi) measuring cell
	 Clamp 1", DIN 11851 DN25, NEUMO BioControl DN25, NPT 3/4", NPT 1", G1" flush-mounted, G1" mounting, G1" with sealing taper: ±(0.35 % · TD + 0.10 %) Process connection SMS 1": ±(0.4 % · TD + 0.10 %)
	 All other process connections: ± (0.25% · TD +0.10%) 4 bar (60 psi), 10 bar (150 psi), 25 bar (375 psi), 40 bar (600 psi) and 100 bar (1500 psi) measuring cell ± (0.20% · TD +0.10%)
	<i>E2_E - Electronics error</i>
	Analog output (4 to 20 mA): 0.2 %
Measurement uncertainty for small absolute pressure	The smallest expanded measurement uncertainty that can be passed on by our measurement standards:
measuring ranges	 In the range of 1 to 30 mbar (0.0145 to 0.435 psi): 0.4 % of reading In the range of < 1 mbar (0.0145 psi): 1 % of reading
Total error	The total error of the device comprises the total performance and the long-term stability effect and is calculated using the following formula:
	Total error = total performance + long-term stability
Long-term stability	The specifications refer to the upper range limit (URL).
	 1 year: ±0.2 % 5 years: ±0.4 % 10 years: ±0.5 % 15 years: ±0.6 %
Response time	Dead time, time constant
	Representation of dead time and time constant as per IEC62828-1:



Step response time = dead time (t_1) + time constant T90 (t_3) according to IEC62828-1

Dynamic behavior, current output

- Dead time (t₁): maximum 50 ms
- Time constant T63 (t₂): maximum 40 ms
- Time constant T90 (t3): maximum 50 ms

Warm-up timeThe warm-up time (in accordance with IEC 62828-4) indicates the time required for the device to
reach its maximum accuracy or performance after the supply voltage is energized.

Warm-up time: ≤ 10 s

Installation

Mounting position	The orientation depends on the measuring application and can cause a zero point shift (when the vessel is empty, the measured value does not show zero). The zero point shift can be corrected electronically with the device.
Installation instructions	 During installation, it is important to ensure that the sealing element used has a permanent operating temperature that corresponds to the maximum temperature of the process. Devices are suitable for use in wet environments in accordance with IEC/DIN EN 61010-1 The devices are installed according to the same guidelines as manometers. Protect the housing against impact. Devices with CSA approval are intended for indoor use.

Environment

Ambient temperature range	-40 to +85 °C (-40 to +185 °F)
	The permitted ambient temperature is reduced at higher process temperatures.

The following information only takes into account functional aspects. Additional restrictions may apply for certified device versions.

The permitted process temperature varies, depending on the process connection used. For an overview of the process connections, see Section "Process temperature range".

Maximum process temperature +130 °C (+266 °F)

(Product feature "Application"; order option "B")



 \blacksquare 1 Ambient temperature T_a depending on the process temperature T_p

Р	T _p	T _a
P1	-40 °C (-40 °F)	+85 °C (+185 °F)
P2	+100 °C (+212 °F)	+85 °C (+185 °F)
Р3	+130 °C (+266 °F)	+40 °C (+77 °F)

Р	T _p	T _a
P4	+130 °C (+266 °F)	-40 °C (-40 °F)
P5	-40 °C (-40 °F)	-40 °C (-40 °F)

Maximum process temperature +150 °C (+302 °F)

(Product feature "Application"; order option "C")



 \blacksquare 2 Ambient temperature T_a depending on the process temperature T_p

Р	T _p	T _a
P1	-20 °C (-4 °F)	+85 °C (+185 °F)
P2	+100 °C (+212 °F)	+85 °C (+185 °F)
P3	+150 °C (+302 °F)	+40 °C (+77 °F)
P4	+150 °C (+302 °F)	-20 °C (-4 °F)
P5	-20 °C (-4 °F)	-20 °C (-4 °F)

Maximum process temperature +200 °C (+392 °F)

(Product feature "Application"; order option "D")



 \blacksquare 3 Ambient temperature T_a depending on the process temperature T_p

Р	T _p		T _a
P1	-20 °C (-4 °F)		+85 °C (+185 °F)
P2	+100 °C (+212 °F)		+85 °C (+185 °F)
Р3	+200 °C (+392 °F)		+40 °C (+77 °F)
P4	+200 °C (+392 °F)		-20 °C (-4 °F)
Р5	−20 °C (−4 °F)		-20 °C (-4 °F)
Storage temp	erature	−40 to +85 °C (−40 to +185 °F)	
Operating he	ight	Up to 5000 m (16404 ft) above sea level	
Climate class		According to IEC 60068-2-38 test Z/AD (relative humidity 4 to 100 %).	
Degree of protection		Test as per IEC 60529 Edition 2.2 2013-08/ DIN EN 60529:2014-09 and NEMA 250-2014	
		For mounted M12 connecting cable: IP66/	68/69, NEMA type 4X/6P
		/IP68,: (1.83 mH ₂ O for 24 h))	
Pollution deg	ree	Pollution degree 2 according to IEC/EN 610	010-1.
Vibration resistance Stochastic noise (random sweep) as per IEC/DIN EN 60068-2-64 Case 2 / Guaranteed for 5 to 2 000 Hz: 1.25 (m/s²)²/Hz, ~ 5 g Sinusoidal vibration according to IEC 62828-1:2017 with 10 to 60 Hz ±0.35 n 5 g 		IEC/DIN EN 60068-2-64 Case 2 / ²) ² /Hz, ~ 5 g 328-1:2017 with 10 to 60 Hz ±0.35 mm; 60 to 1000 Hz	
Shock resistance		 Testing standard: IEC/DIN EN 60068-2-27 Case 2 Shock resistance: 30 g (18 ms) in all 3 axes 	
Electromagnetic compatibility (EMC)		 Electromagnetic compatibility as per IEC/DIN EN 61326 series and NAMUR recommendation EMC (NE21) Maximum deviation under interference influence: < 0.5 % 	
		For more details refer to the EU Declaratio	n of Conformity.

Process

Process temperature

Maximum process temperature	Version 1)
+100 °C (+212 °F)	А
+130 °C (+266 °F) (+150 °C (+302 °F) ²⁾)	В
+150 °C (+302 °F)	C
+200 °C (+392 °F)	D

Product Configurator, "Application" feature Temperature for maximum one hour (device in operation but not within measurement specification) 1) 2)

Fill fluid

Fill fluid	Process temperature range	Version ¹⁾
Synthetic oil, FDA	-40 to +130 °C (-40 to +266 °F)(+150 °C (+302 °F) ²⁾)	3
Vegetable oil, FDA	-20 to +200 °C (-4 to +392 °F)	4

1)

Product Configurator, "Fill fluid" feature Temperature for one hour maximum (device in operation but not within measurement specification) 2)

Process pressure range	Pressure specifications					
	A WARNING					
	 The maximum pressure for the device depends on the lowest-rated component with regard to pressure (components are: process connection, optional mounted parts or accessories). Only operate the device within the specified limits for the components! MWP (maximum working pressure): The maximum working pressure is specified on the nameplate. This value refers to a reference temperature of +20 °C (+68 °F) and may be applied to the device for an unlimited time. Note temperature dependence of maximum working pressure. For higher temperatures, refer to the following standards for the permitted pressure values for flanges:EN 1092-1 (materials 1.4435 and 1.4404 are identical with regard to their stability/ temperature property and are grouped together in under 13E0 in EN 1092-1 Tab. 18; the chemical composition of the two materials can be identical), ASME B 16.5a (the latest version of the standard applies in each case). The overpressure limit is the maximum pressure that a device may be subjected to during a test. It exceeds the maximum working pressure by a certain factor. This value refers to a reference temperature of +20 °C (+68 °F). In the case of sensor range and process connection combinations where the overpressure limit (OPL) of the process connection is less than the nominal value of the measuring cell, the device is set at the factory, at the very maximum, to the OPL value of the process connection. If the entire measuring cell range must be used, select a process connection with a higher OPL value (1.5 x 					
	 MWP; MWP = PN). The Pressure Equipment Directive (2014/68/EU) uses the abbreviation "PS". The abbreviation "PS" corresponds to the maximum working pressure of the device. 					
	 For maximum working pressure data that deviate from this, see the "Mechanical construction" section. 					
	 Avoid dynamic-mechanical stress on the membrane. 					
Cleaned of oil and grease	Endress+Hauser also offers devices, cleaned of oil and grease, for special applications. No special restrictions regarding the process conditions apply to these devices.					

Mechanical construction

Design, dimensions

Device height

- The device height is calculated from
- the height of the housing (1)
- configuration-dependent mounted parts (2)
- the height of the relevant process connection (3)



- 1 Housing
- 2 Configuration-dependent mounted parts
- 3 Process connection

The individual heights of the components are listed in the following sections. To calculate the device height, add the individual heights of the components.



Housing



Unit of measurement mm (in)

Important information on the process connections

The design of some process connections is determined by the selection of the following features in the product structure:

- Application feature:
 - Process temperature +100 °C (+212 °F)
 - Process temperature +130 °C (+266 °F), +150 °C (+302 °F) max. 1h
 - Process temperature +150 °C (+302 °F)
 - Process temperature +200 °C (+392 °F)
- "Surface refinement" feature:
 - Standard
 - Hygienic RA 0.38µm/15µin electropolished

These features are described for the relevant process connection if they are required.

Explanation of terms

- DN or NPS = alphanumeric designation of a component
- PN or Class = alphanumeric pressure rating of a component
- d_M: membrane diameter (see following graphic)



Thread ISO 228 G, internal membrane



Designation	Graphic	Weight	Order option
		[kg (lb)]	
Thread ISO 228 G ½" A, EN 837	А	0.22 (0.49)	WBJ
Thread ISO 228 G ½" A, bore 11.4 mm (0.45 in)	В		WWJ

Thread DIN13, internal membrane



Designation	Weight	Order option
	[kg (lb)]	
DIN 13 M20 x 1.5, EN 837, bore 3 mm (0.12 in)	0.22 (0.49)	X4J

Thread ASME, internal membrane



Designation	Graphic	Weight	Order option
		[kg (lb)]	
ASME ½" MNPT, ¼" FNPT (internal)	А	0.23 (0.51)	VXJ
ASME ½" MNPT, bore 11.4 mm (0.45 in)	В		VWJ

Thread ISO 228 G, flush membrane



Name	d _M	Weight	Order option
	[mm (in)]	[kg (lb)]	
Thread ISO 228 G ½" A DIN3852, form E	17.2 (0.68)	0.14 (0.31)	WJJ



Name	d _M	Weight	Order option
	[mm (in)]	[kg (lb)]	
Thread ISO 228 G ½" A O-ring seal, flush-mounted	17.2 (0.68)	0.15 (0.33)	WUJ



Thread MNPT, flush membrane

Unit mm (in)

Designation	Graphic	d _M	Weight	Order option
		[mm (in)]	[kg (lb)]	
MNPT 3/4"	А	22 (0.87)	0.22 (0.49)	VHJ
MNPT 1"	В	28 (1.10)	0.33 (0.73)	VJJ
MNPT 1 1/2"	С	41 (1.61)	0.73 (1.61)	VLJ
MNPT 2"	D	48 (1.89)	1.05 (2.32)	VMJ





Designation	Graphic	d _M	Weight	Order option
		[mm (in)]	[kg (lb)]	
G1" with O-ring	А	22 (0.87)	0.42 (0.93)	WSJ
G1" with sealing taper	В		0.39 (0.86)	WQJ



Designation	Graphic	d _M	Weight	Order option
		[mm (in)]	[kg (lb)]	
G1" with Aseptoflex O-ring made from EPDM	С	22 (0.87)	0.35 (0.77)	45J
G1"	D	28 (1.10)	0.34 (0.75)	WLJ



Designation	Graphic	d _M	Weight	Order option
		[mm (in)]	[kg (lb)]	
G1 1/2"	Е	41 (1.61)	0.72 (1.59)	WNJ
G2"	F	48 (1.89)	1.17 (2.58)	WPJ

DIN11851, flush membrane



Designation	PN	Graphic	d _M	h	Weight kg	Order option
	[bar]		[mm (in)]	[mm (in)]	[kg (lb)]	
DIN11851 DN25	40	А	22 (0.87)	44 (1.73)	0.43 (0.95)	1GJ
DIN11851 DN32	40	А	32 (1.26)	57 (2.24)	0.55 (1.21)	1HJ
DIN11851 DN40	40	А	36 (1.42)	57 (2.24)	0.61 (1.35)	1JJ
DIN11851 DN50	25	А		57 (2.24)	0.76 (1.68)	1DJ
DIN11851 DN80	25	В	61 (2.4)	30 (1.18)	1.9 (4.19)	1FJ

Clamp ISO2852 DN18-22, DIN32676 DN15-20, flush membrane

	A0052793
Unit mm (in)	

Designation	PN	d _M	Weight	Order option
	[bar]	[mm (in)]	[kg (lbs)	1
Clamp ISO2852 DN18-22, DIN32676 DN15-20,	40	17.2 (0.68)	0.09 (0.20)	ЗАЈ

Tri-Clamp ISO2852, flush membrane



Maximum process temperature +130 °C (+266 °F) (+150 °C (+302 °F) for 1 hour) Maximum process temperature +150 °C (+302 °F)										
Designation	PN	Surface	Graphic	d _M	h	Weight	Order option			
	[bar]			[mm (in)]	[mm (in)]	[kg (lb)]				
Tri-Clamp ISO2852	40	Standard	А	22 (0.87)	44 (1.73)	0.21 (0.46)	ЗВJ			
DN25 (1")		Electropolished	А							
Tri-Clamp ISO2852		Standard	А	32 (1.26)		0.21 (0.46)	ЗСJ			
DN38 (1 ⁴ 2")		Electropolished	А							
Tri-Clamp ISO2852		Standard	А	36 (1.42)		0.26 (0.57)	ЗЕJ			
DN51 (2")		Electropolished	А	-						
Tri-Clamp ISO2852		Standard	A	36 (1.42)		0.33 (0.73)	3JJ			
DN63.5 (2 ⁴ 2")		Electropolished	В	61 (2.4)	30 (1.18)					
Tri-Clamp ISO2852		Standard	А	36 (1.42)	44 (1.73)	0.42 (0.93)	3FJ			
DN/6.1 (3")		Electropolished	В	61 (2.4)	30 (1.18)					

Maximum process temperature +200 °C (+392 °F)										
Designation	PN	Surface	Graphic	d _M	h	Weight	Order option			
	[bar]			[mm (in)]	[mm (in)]	[kg (lb)]				
Tri-Clamp ISO2852	40	Standard	С	22 (0.87)	30 (1.18)	0.32 (0.71)	ЗВJ			
DN25 (1")		Electropolished	С	22 (0.87)						
Tri-Clamp ISO2852		Standard	С	36 (1.42)		1 (2.21)	3CJ			
DN38 (1 ⁴ 2")		Electropolished	С	36 (1.42)						
Tri-Clamp ISO2852		Standard	С	41 (1.61)		1.1 (2.43)	3EJ			
DN51 (2")		Electropolished	С	41 (1.61)						
Tri-Clamp ISO2852 DN63.5 (2 ½")		Standard	С	61 (2.4)		0.7 (1.54)	3]]			
Tri-Clamp ISO2852 DN76.1 (3")		Standard	С	61 (2.4)		1.2 (2.65)	3FJ			

Varivent, flush membrane



Maximum process temperature +130 °C (+266 °F) (+150 °C (+302 °F) for 1 hour) Maximum process temperature +150 °C (+302 °F)									
Designation	PN Surface		Graphic	d _M	Weight	Order option			
	[bar]	-		[mm (in)]	[kg (lb)]				
Varivent F for DN25 - DN32 pipes	40	Standard	А	36 (1.42)	0.47 (1.04)	41J			
		Electropolished	В		0.7 (1.54)				
Varivent N for DN40 - DN162 pipes		Standard	А		0.74 (1.63)	42J			
		Electropolished	В	61 (2.4)	0.9 (1.98)				

Maximum process temperature +200 °C (+392 °F)										
Designation	PN	Graphic	d _M	Weight	Order option					
	[bar]		[mm (in)]	[kg (lb)]						
Varivent F for DN25 - DN32 pipes	40	С	36 (1.42)	0.4 (0.88)	41J					
Varivent N for DN40 - DN162 pipes		С	61 (2.4)	0.8 (1.76)	42J					

DRD, flush membrane



Maximum process temperature +130 °C (+266 °F) (+150 °C (+302 °F) for 1 hour) Maximum process temperature +150 °C (+302 °F)									
Designation PN		Surface	Graphic	d _M	Weight kg	Order option			
	[bar]			[mm (in)]	[kg (lb)]				
DRD 65 mm	25	Standard	А	36 (1.42)	0.48 (1.06)	4AJ			
		Electropolished	В	48 (1.89)	0.65 (1.43)				

Maximum process temperature +200 °C (+392 °F)									
Designation	PN	Surface	Graphic	Graphic d _M		Order option			
	[bar]			[mm (in)]	[kg (lb)]				
DRD 65 mm	25	Standard	С	48 (1.89)	0.75 (1.65)	4AJ			
		Electropolished	С						

SMS, flush membrane



Maximum process temperature +130 °C (+266 °F) (+150 °C (+302 °F) for 1 hour) Maximum process temperature +150 °C (+302 °F)									
Designation	Order option								
	[bar]	-	[mm] (in)	[kg (lb)]					
SMS 1	40	А	22 (0.87)	0.13 (0.29)	4PJ				
SMS 1 1/2		В	36 (1.42)	0.25 (0.55)	4QJ				
SMS 2		В		0.32 (0.71)	4RJ				

Maximum process temperature +200 °C (+392 °F)										
Designation	PN	Graphic	d _M	Weight	Order option					
	[bar]	-	[mm] (in)	[kg (lb)]						
SMS 1	40	С	22 (0.87)	0.25 (0.55)	ТбЈ					
SMS 1 1/2		С	36 (1.42)	0.65 (1.43)	Т7Ј					
SMS 2		С	48 (1.89)	1.05 (2.32)	TXJ					

NEUMO BioControl, flush membrane



Maximum process temperature +130 °C (+266 °F)(+150 °C (+302 °F) for 1 hour) Maximum process temperature +150 °C (+302 °F)										
Designation PN		Surface	Graphic	b	h	d _M	Weight	Order option		
	[bar]			[mm (in)]	[mm (in)]	[mm (in)]	[kg (lb)]			
NEUMO BioControl D25	16	Standard	A	11 (0.43)	20 (0.79)	22 (0.87)	0.41 (16.1)	5AJ		
		Electropolished	В				0.6 (1.32)			
NEUMO BioControl D50		Standard	А	17 (0.67)	27 (1.06)	36 (1.42)	0.86 (1.90)	5DJ		
		Electropolished	В			41 (1.61)	1.1 (2.43)			
NEUMO BioControl D80		Standard	В	25 (0.98)	37 (1.46)	61 (2.4)	2.59 (5.71)	5FJ		
		Electropolished	В							

Maximum process temperature +200 °C (+392 °F)										
Designation	PN	Graphic	b	h	d _M	Weight	Order option			
	[bar]		[mm (in)]	[mm (in)]	[mm (in)]	[kg (lb)]				
NEUMO BioControl D80	16	С	25 (0.98)	37 (1.46)	61 (2.4)	2.8 (6.17)	5FJ			

Ingold connection 25x46, flush membrane



Designation	PN	d _M	Weight	Order option
	[bar]	[mm (in)]	[kg (lb)]	
Ingold connection 25x46 with O-ring made from EPDM	25	22 (0.87)	0.3 (0.66)	5RJ

Universal adapter, flush membrane



Designation	Seal	PN	d _M	Weight	Order option
		[bar]	[mm (in)]	[kg (lb)]	
Universal adapter	Silicone form seal	10	32 (1.26)	0.54 (1.19)	52J
	EPDM form seal				50J

Tri-Clamp ISO2852 inline seal, flush membrane



DN	NPS	PN	D	d ₂	d ₃	h	L	Weight	Order option
	[in]	[bar]	[mm]	[mm]	[mm]	[mm]	[mm]	[kg (lb)]	
10	3⁄4	40	10.5	25	34	41.5	140	0.6 (1.32)	3QJ
25	1		22.5	50.5	54	67	126	1.7 (3.75)	3RJ
38	1 1⁄2		35.5	50.5	69	67	126	1.0 (2.21)	3SJ ¹⁾
51	2		48.6	64	78	79	100	1.7 (3.75)	3TJ ¹⁾

1) incl. 3.1 and pressure test in accordance with the Pressure Equipment Directive, category II

Perform CIP (cleaning in place (hot water)) before SIP (sterilization in place (steam)). Frequent use of SIP cleaning increases the stress and strain on the process membrane. Under unfavorable conditions, frequent changes of temperature can lead to process membrane material fatigue and potentially leaks over the long term.

Flange EN1092-1, flush membrane

Connection dimensions according to EN1092-1



Flange						Order option		
DN	PN Form D b g f Ød _M							
			[mm]	[mm]	[mm]	[mm]	[mm]	
25	10-40	B1	115	18	68	3	28	НОЈ
40	10-40	B1	150	18	87		-	E1J
50	10-40	B1	165	20	102		61	НЗЈ
80	10-40	B1	200	24	138		89	Н5Ј

Flange		Boltholes		Weight	Order option	
DN	PN	Quantity	g ₂	k		
			[mm]	[mm]	[kg (lb)]	
25	10-40	4	14	85	2.1 (4.63)	НОЈ
40	10-40	4	18	110	2.2 (4.85)	E1J
50	10-40	4	18	125	3.0 (6.62)	НЗЈ
80	10-40	8	18	160	5.3 (11.69)	Н5Ј

Flange ASME, flush membrane

Connection dimensions in accordance with ASME B 16.5, raised face RF



Flange					Order option		
NPS	Class	D	b	g	f	Ød _M	
[in]	[lb./sq.in]	[in]	[in]	[in]	[in]	[in]	
1	150	4.25	0.56	2	0.06	1.10	AAJ
1 1⁄2	150	5	0.69	2.88		On request	ACJ
2	150	6	0.75	3.62		2.40	ADJ
3	150	7.5	0.94	5		3.50	AFJ

Flange		Boltholes			Weight	Order option
NPS	Class	Quantity	g ₂	k		
[in]	[lb./sq.in]		[in]	[in]	[kg (lb)]	
1	150	4	0.62	3.12	1.2 (2.65)	AAJ
1 1/2	150	4	0.62	3.88	1.5 (3.31)	ACJ
2	150	4	0.75	4.75	2.2 (4.85)	ADJ
3	150	4	0.75	6	5.1 (11.25)	AFJ

Weight	The weights of the individual components must be added together for the total weight.				
	Housing weight including electronics and onsite display: 0.43 kg (0.95 lb)				
	Process connection: See the relevant process connection for weight				
Materials	Materials in contact with process				
	Process connections				
	 EN flanges: 				
	 Material: AISI 316L 				
	 The flange raised face is made of the same material as the membrane. ASME flanges: 				
	 Asive hanges. Material AISI 316/316L: Combination of AISI 316 for required pressure resistance and AISI 316L for required chemical resistance (dual rated) 				
	 The flange raised face is made of the same material as the membrane. All other process connections made of 316L 				
	Membrane material				
	• 316L (1.4435)				
	 AlloyC276 The material of the flange raised face is the same as the material as the membrane. 				
	Delta ferrite content				
	A delta ferrite content of \leq 3% can be guaranteed and certified for the wetted parts if option "KD" is selected in the "Test, certificate, declaration" order code in the Product Configurator.				
	Materials not in contact with process				
	 Housing: 316L (1.4404) 				
	 Display: Polycarbonate Device plug: IPFor more information, see section on "Power supply". 				
	Fill fluid				
	 Synthetic oil as per FDA 21 CFR 178.3620 (b)(1) and NSF H-1 Vegetable oil, FDA 21 CFR 172.856 				
	Accessories				
	For technical data (e.g. materials, dimensions or order numbers), see the accessory document SD01553P.				
Surface roughness	 Housing: Ra <1.6 µm (63 µin), electropolished Wetted parts: Ra < 0.76 µm (29.9 µin) (excluding flanges and threaded process connections) Parts in contact with process: hygienic Ra < 0.38 µm (15 µin) electropolished (Product feature "Surface refinement", order option "E") 				
	User interface				

Languages

The following languages are available on the onsite display.

- Operating languagesEnglish (English is set at the factory if no other language is ordered)
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski

- русский язык (Russian)
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- tiếng Việt (Vietnamese)
- čeština (Czech)
- Svenska

LED indicator

- Functions:
- Display of the operating status (operation or fault)
- Display of Bluetooth connection, locking status and function
- Easy setup of the following functions with one button:
 - Locking On/Off
 - Bluetooth On/Off
 - Position adjustment



- 1 Operating status LED
- 2 Operating key "E"
- 3 Bluetooth LED
- 4 Position adjustment LED
- 5 Keypad lock LED

Onsite display

- Functions:
- Display measured values, also fault and notice messages
- Display a symbol in the event of an error
- Electronically adjustable onsite display (automatic or manual adjustment of display in 90° increments)

The measured value display rotates automatically depending on the orientation when the device is started. ¹⁾

- Basic settings via the onsite display with touch control²⁾
- Locking On/Off
- Select the operating language
- Bluetooth On/Off
- Commissioning wizard for basic settings
- Read the device information, such as the name, serial number and firmware version
- Active diagnosis and status
- Device reset
- Invert colors for bright lighting conditions

The backlighting is automatically adjusted depending on the terminal voltage.

The following figure is an example. The display depends on the settings of the onsite display.

2) For devices without touch control, settings can be made using operating tools (FieldCare, DeviceCare, SmartBlue).

¹⁾ The measured value display only rotates automatically if automatic alignment is switched on.



- Standard display: 1 measured value with unit (adjustable) 2 measured values, each with unit (adjustable) Α
- В
- С Graphic measured value display in %

The standard display can be permanently set via the operating menu.

Remote operation	Operation via Bluetooth® wireless technology (optional)
	 Prerequisite Device with Bluetooth order option Smartphone or tablet with Endress+Hauser SmartBlue app or PC with DeviceCare from version 1.07.07 or FieldXpert SMT70/SMT77
	The connection has a range of up to 25 m (82 ft). The range can vary depending on environmental conditions such as attachments, walls or ceilings.
	The operating keys on the display are locked as soon as the device is connected via Bluetooth.
Supported operating tools	Smartphone or tablet with Endress+Hauser SmartBlue app.

Certificates and approvals

Current certificates and approvals for the product are available at www.endress.com on the relevant product page:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select **Downloads**.

Other certificates and approvals for the product are available under https://www.endress.com-> Downloads.

Material compliance for contact with food	 The device has been developed for food contact applications. Versions can be selected that meet the following requirements: EU Food Contact Material (EC) 1935/2004 US Food Contact Material FDA CFR 21 CN Food Contact Material GB 4806 			
General material compliance	Endress+Hauser guarantees compliance with all relevant laws and regulations, including the current guidelines for materials and substances.			
	Examples: • RoHS • China RoHS • REACH • POP VO (Stockholm Convention)			

	For further information and general declarations of compliance, see the Endress+Hauser website www.endress.com					
Hygienic design compliance	3-A and EHEDG-certified versions of the sensor are suitable for Cleaning-in-Place (CIP) and Sterilization-in-Place (SIP) without removing them from the plant. This means that the sensor does not need to be removed during cleaning. The maximum permitted pressure and temperature values for sensor and adapter must not be exceeded (see notes in this TI).					
	 Notes on installation and certification in accordance with 3-A and EHEDG: SD02503F document "Hygienic approvals" Information on 3-A and EHEDG-certified adapters: TI00426F document "Weld-in adapters, process adapters and flanges" 					
cGMP	The device was developed for life sciences applications. You can select versions with a cGMP declaration (Current Good Manufacturing Practice) for process-wetted parts with the following content in English: Materials of construction Polishing and surface treatment Materials and compounds compliance table: USP, FDA TSE/BSE-compliant based on EMA/410/01 Rev.3					
TSE (BSE) compliance (ADI free - Animal Derived Ingredients)	 Versions can be selected that meet the following requirements: The parts of this product in contact with the process are not made from materials derived from animals or The parts of this product in contact with the process correspond to at least the requirements of the EMA/410/01 Rev. 3 guideline (TSE (BSE) compliant) 					
ASME BPE	The measuring system was developed for life sciences applications. Options can be selected that meet the requirements of the ASME BPE (Bioprocessing Equipment) standard.					
Drinking water certification	The following drinking water certificates can be ordered as options via the Product Configurator: For Germany: UBA assessment criteria For USA/Canada: NSF/ANSI/CAN 61					
CRN approval	Device versions with a CRN approval (Canadian Registration Number) are listed in the corresponding registration documents. CRN-approved devices are marked with a registration number.					
	Any restrictions regarding the maximum process pressure values are listed on the CRN certificate.					
	Product Configurator: feature "Additional approval"					
ASME B31.3/31.1	Versions can be selected that meet the following requirements:					
	The design, the material used, the pressure and temperature ranges and the labeling of the devices meet the requirements of ASME B31.1 (piping for power plants) and/or ASME B31.3 (process piping).					
Test, certificate, declaration	All test reports, declarations and inspection certificates are provided electronically in the <i>Device Viewer</i> : Enter the serial number from the nameplate (https://www.endress.com/de/pages/supporting-tools/device-viewer)					
Pressure Equipment Directive (PED)	Pressure equipment with permitted pressure \leq 200 bar (2900 psi) Pressure equipment (maximum working pressure PS \leq 200 bar (2900 psi)) can be classified as pressure accessories in accordance with the Pressure Equipment Directive. If the maximum working pressure is \leq 200 bar (2900 psi) and the pressurized volume of the pressure equipment is \leq 0.1 l, the pressure equipment is subject to the Pressure Equipment Directive (see Pressure Equipment Directive 2014/68/EU, Article 4, point 3). The Pressure Equipment Directive only requires that the pressure equipment shall be designed and manufactured in accordance with the "sound engineering practice of a Member State".					

Reasons:

- Pressure Equipment Directive (PED) 2014/68/EU Article 4, point 3
- Pressure Equipment Directive 2014/68/EU, Commission's Working Group "Pressure", Guideline A-05 + A-06

Note:

A partial examination shall be performed for sensors that are part of a safety instrumented system for the protection of a pipe or vessel from exceeding allowable limits (equipment with safety function in accordance with Pressure Equipment Directive 2014/68/EU, Article 2, point 4).

The following also applies:

Devices with an inline seal ≥ 1.5"/PN40: suitable for stable gases in group 1, category II, module A2

Order information

Detailed ordering information is available from your nearest sales organization www.addresses.endress.com or in the Product Configurator at www.endress.com:

1. Select the product using the filters and search field.

- 2. Open the product page.
- 3. Select **Configuration**.

Product Configurator - the tool for individual product configuration

Up-to-the-minute configuration data

- Depending on the device: direct input of information specific to the measuring point, such as the measuring range or operating language
- Automatic verification of exclusion criteria
- Automatic creation of the order code and its breakdown in PDF or Excel output format
- Ability to order directly in the Endress+Hauser Online Shop

Identification

Measuring point (TAG)

The device can be ordered with a tag name.

Location of tag name

Select in the additional specification:

- Stainless steel wired-on tag plate
- Paper adhesive label
- Tag provided by the customer
- Nameplate
- IEC 61406 stainless steel tag
- IEC 61406 stainless steel + NFC tag
- IEC 61406 stainless steel, stainless steel tag
- IEC 61406 stainless steel + NFC, stainless steel
- IEC 61406 stainless steel tag, plate provided
- IEC 61406 stainless steel + NFC, plate provided

Definition of tag name

Specify in the additional specification:

3 lines of maximum 18 characters each

The specified tag name appears on the selected plate.

Visualization in SmartBlue app

The first 32 characters of the tag name

The tag name can always be changed specifically for the measuring point via Bluetooth.

Display on the nameplate

The first 16 characters of the tag name

Display in electronic nameplate (ENP)

The first 32 characters of the tag name



Service The following services, among others, can be selected using the Product Configurator.

- Cleaned of oil+grease (wetted)
- Set HART burst mode PV
- Set max. alarm current
- Bluetooth communication is disabled on delivery
- Customized empty/full calibration
- Product documentation on paper
 A printed (hard copy) version of test reports, declarations and inspection certificates can optionally
 be ordered via the Service, Version, Product documentation on paper option. The required
 documents can be selected under the feature Test, certificate, declaration and are then included
 with the device on delivery.

Accessories

Device-specific accessories	M12 socket					
	 M12 socket, straight Material: Body: PA; union nut: stainless steel; seal: EPDM Degree of protection (fully locked): IP69 Order number: 71638191 					
	 M12 socket, elbowed Material: Body: PA; union nut: stainless steel; seal: EPDM Degree of protection (fully locked): IP69 Order number: 71638253 					
	Cables					
	 Cable 4 x 0.34 mm² (20 AWG) with M12 socket, elbowed, screw plug, length 5 m (16 ft) Material: body: TPU; union nut: nickel-plated die-cast zinc; cable: PVC Degree of protection (fully locked): IP68/69 Order number: 52010285 Wire colors 1 = BN = brown 2 = WT = white 3 = BU = blue 4 = BK = black 					
	Welding neck, process adapter and flange					
	For details, refer to TI00426F/00/EN "Weld-in adapters, process adapters and flanges".					
	Mechanical accessories					
	For technical data (e.g. materials, dimensions or order numbers), see the accessory document SD01553P.					
Device Viewer	All the spare parts for the device, along with the order code, are listed in the <i>Device Viewer</i> (www.endress.com/deviceviewer).					
Field Xpert SMT70	Universal, high-performance tablet PC for device configuration in Ex Zone 2 and non-Ex areas					
	For details, see "Technical Information" TI01342S					
Field Xpert SMT77	Universal, high-performance tablet PC for device configuration in Ex Zone 1 areas					
	For details, see "Technical Information" TI01418S					
SmartBlue app	Mobile app for easy configuration of devices on site via Bluetooth wireless technology					

Documentation

1 For an overview of the scope of the associated Technical Documentation, refer to the following:

 Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate

• *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

Standard documentation	Document type: Operating Instructions (BA) Installation and initial commissioning – contains all the functions in the operating menu that are needed for a routine measuring task. Functions beyond this scope are not included.
	Document type: Description of Device Parameters (GP) The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the operating menu.
	Document type: Brief Operating Instructions (KA) Quick guide to the first measured value – includes all essential information from incoming acceptance to electrical connection.
	Document type: Safety Instructions, certificates Depending on the approval, safety instructions are supplied with the device, e.g. XA. This documentation is an integral part of the Operating Instructions. Information on the Safety Instructions (XA) that are relevant for the device is provided on the nameplate.
Supplementary device- dependent documentation	Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

Registered trademarks

Apple®

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android®

Android, Google Play and the Google Play logo are trademarks of Google Inc.

Bluetooth®

The *Bluetooth*[®] word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license. Other trademarks and trade names are those of their respective owners.



www.addresses.endress.com

