Technical Information Indumax CLS50D/CLS50

Inductive conductivity sensor for standard, Ex and high-temperature applications

Digital sensor with Memosens protocol or analog sensor

Application

Indumax CLS50D or CLS50 sensor is particularly suitable for use in the chemical and process technology sectors. The six-decade measuring range and the excellent chemical resistance properties of the materials in contact with the medium (PFA or PEEK) make it possible to use this sensor in a wide range of applications, such as: • Concentration measurement of acids and bases

- Concentration measurement of actus and bases
 Quality manitoring of shamiaal products in tapks and
- Quality monitoring of chemical products in tanks and pipes
- Phase separation of product/product mixtures

The digital sensor CLS50D is used in conjunction with the Liquiline CM44x/R or Liquiline M CM42, while the analog sensor CLS50 is used with the Liquiline M CM42 or Liquisys CLM223/253.

Your benefits

- High durability
 - High chemical resistance thanks to PFA coating
 - PEEK version for temperatures up to 180 °C (356 °F)
- Low risk of soiling
 - Dirt-repellent PFA surface
 - Large sensor opening
- Easy installation
 - Can be installed in pipes \geq DN 80
 - Total cable length up to 55 m (180 ft)
- Large measuring range from 2 µS/cm to 2000 mS/cm
- Integrated, coated Pt 100 temperature sensor, error class A
- Ex approval Ex ia IIC T4/T6

Other advantages of Memosens technology

- Maximum process safety
- Data security thanks to digital data transmission
- Very easy to use as sensor data saved in the sensor
- Recording of sensor load data in the sensor enables predictive maintenance






Function and system design

Measuring principle

Inductive conductivity measurement

An oscillator (1) generates an alternating magnetic field in the primary coil (5), which induces a current flow (4) in the medium. The strength of the current depends on the conductivity and thus on the ion concentration in the medium. The current flow in the medium, in turn, generates a magnetic field in the secondary coil (3). The resulting induced current is measured by the receiver (2) and used to determine the conductivity.



- Oscillator
- Receiver Secondary coil
- *Current flow in the medium*
- Primary coil

Advantages of inductive conductivity measurement:

- No electrodes and therefore no polarization effects
- Accurate measurement in media with a high degree of pollution and a tendency to form buildup
- Complete galvanic isolation of the measurement and the medium


Measuring system

CLS50D

- A complete measuring system comprises:
- A CLS50D inductively measuring conductivity sensor with fixed cable
- A transmitter, e.g. Liquiline CM44x

Optional:

- Weather protection for the field installation of the transmitter
- Assembly to install the sensor in vessels or pipes, e.g. CLA111



E 1 Example of a measuring system

- 1 Liquiline CM44x transmitter
- 2 Protective cover
- *3* Pipe nozzle with flange DN50 PN16
- 4 CLS50D sensor, version with flange DN50 PN16 and fixed cable with M12 connector
- 5 Pipe


CLS50

A complete measuring system comprises:

- A CLS50 inductively measuring conductivity sensor with fixed cable
- A transmitter, e.g. Liquiline M CM42

Optional:

- Weather protection for the field installation of the transmitter
- Assembly to install the sensor in vessels or pipes, e.g. CLA111



E 2 Example of a measuring system

- 1 CLS50 sensor, version with lap joint flange and fixed cable with ferrules
- 2 Liquiline CM42 transmitter
- 3 Protective cover
- 4 Pipe
- 5 Pipe nozzle with flange connection

Communication and data processing (only CLS50D)

Communication with the transmitter

Always connect digital sensors with Memosens technology to a transmitter with Memosens technology. Data transmission to a transmitter for analog sensors is not possible.

Digital sensors can store measuring system data in the sensor. These include the following:

- Manufacturer data
 - Serial number
 - Order code
 - Date of manufacture
- Calibration data
 - Calibration date
 - Cell constant
 - Delta cell constant
 - Number of calibrations
 - Serial number of the transmitter used to perform the last calibration or adjustment
- Operating data
 - Temperature application range
 - Conductivity application range
 - Date of initial commissioning
 - Maximum temperature value
 - Hours of operation at high temperatures


Input

Measured variables	ConductivityTemperature	
Measuring ranges	Conductivity	2 µS/cm to 2000 mS/cm (uncompensated)
	Temperature	-20 to +180 °C (-4 to +350 °F)
Cell constant	$k = 1.98 \text{ cm}^{-1}$	
Measuring frequency	2 kHz	
Temperature measurement	CLS50D	
	Pt1000 (Class A according to	IEC 60751)
	CLS50	
	Pt100 (Class A according to II	EC 60751)

Power supply

Electrical connection

The sensor is supplied with a fixed cable. The cable between the sensor and transmitter can be extended using the CYK11 (CLS50D) or CLK6 (CLS50) measuring cable (does not apply for use in a hazardous environment).




Performance characteristics

Conductivity response time	$t_{95} \le 2 s$		
Temperature response time	PEEK version: PFA version:	$t_{90} \leq 7 \text{ min} \\ t_{90} \leq 11 \text{ min}$	
Maximum measured error	-20 to 100 °C (-4 to 212 °F): > 100 °C (212 °F):	±(5 μS/cm + 0.5 % of reading) ±(10 μS/cm + 0.5 % of reading)	
Repeatability	0.2% of reading		
Linearity	1.9 % (only applies in the 1 to 20 mS/cm measuring range)		

Mounting

Orientation


- ► When installing, align the sensor in such a way that the medium flows through the flow opening of the sensor in the direction of medium flow.
 - └ The sensor head must be completely immersed in the medium.



- ☑ 5 Sensor orientation, dimensions in mm (in)
- 1 Direction of medium flow
- 2 Minimum water level in the pipe
- a Distance from pipe wall

Installation factor

In confined installation conditions, the conductivity measurement is affected by the pipe walls. The installation factor compensates for this effect. The transmitter corrects the cell constant by multiplying by the installation factor. The value of the installation factor depends on the diameter and the conductivity of the pipe nozzle as well as the sensor's distance to the wall. The installation factor f can be disregarded (f = 1.00) if the distance to the wall is sufficient (a > 15 mm (0.59"), from DN 80). If the distance to the wall is smaller, the installation factor increases for electrically insulating pipes (f > 1) and decreases for electrically conductive pipes (f < 1). It can be measured using calibration solutions, or a close approximation determined from the following diagram.



■ 6 Relationship between installation factor f and wall distance

1 Electrically conductive pipe wall

2 Electrically insulating pipe wall

Air set

CLS50D

The digital sensor has already been adjusted at the factory. Onsite compensation is not required.

CLS50

To compensate residual coupling in the cable and between the two sensor coils, zero adjustment in air ("air set") must be performed before installing the sensor. Follow the instructions provided in the Operating Instructions of the transmitter used.

Installation with flange

The sensor is suitable for installation in T-pieces \geq DN 80, with the outgoing diameter reduced to \geq DN 50.


WARNING

Leakage

Risk of injury if medium escapes!

- Tighten sensor nut using a torque of 20 Nm.
- ► To avoid leakages, regularly check the tightness of the nut.

Flange, not in contact with medium




■ 7 Fixed flange, not in contact with medium (for order option: "Process connection" = 5, 6, 7)

1 Flange (stainless steel)

- 2 Nut
- 3 Sealing disk (GYLON)
- 4 O-ring
- 5 Sensor


Flange, in contact with medium



■ 8 Fixed flange, in contact with medium (for order option: "Process connection" = 3, 4)

- 1 Flange (stainless steel)
- 2 Nut
- 3 O-ring
- 4 Sensor


Lap joint flange, not in contact with medium



☑ 9 Lap joint flange, not in contact with medium (for order option: "Process connection" = A, B, C)

- 1 Lap joint flange (PP-GF)
- 2 Nut (stainless steel)
- 3 Flange (PVDF)
- 4 O-ring
- 5 Sensor

Installation in assembly



- 10 Installation of sensor with assembly
- CLA111 with suspension bracket CLA111 with flange connection 1
- 2
- 3 CLA140 with flange connection
- 4 CYA112

Environment

Ambient temperature range	CLS50D	
	-10 to +60 °C (+10 to +140 °F)	
	CLS50	
	-10 to +70 °C (+10 to +160 °F)	
Storage temperature	-20 to +80 °C (0 to +180 °F)	
Degree of protection	IP 68 / NEMA type 6 (sensor in installed state with genuine seal)	

Process

Process temperature

Sensor	CLS50D-*1/2	CLS50D-*3/4/5/6/8	CLS50D-*7	CLS50D-*A/B/C
material	Without flange	DN50, ANSI 2"	JIS	PVDF lap joint flange
PEEK	−20 to 125 °C	−20 to 125 °C	−20 to 125 °C	−20 to 125 °C
	(-4 to 260 °F)	(-4 to 260 °F)	(-4 to 260 °F)	(-4 to 260 °F)
PFA	−20 to 110 °C	−20 to 110 °C	−20 to 110 °C	−20 to 110 °C
	(-4 to 230 °F)	(-4 to 230 °F)	(-4 to 230 °F)	(-4 to 230 °F)


CLS50

Sensor	CLS50-*1/2	CLS50-*3/4/5/6/8	CLS50-*7	CLS50-*A/B/C
material	Without flange	DN50, ANSI 2"	JIS	PVDF lap joint flange
PEEK	−20 to 180 °C	−20 to 180 °C	−20 to 180 °C	−20 to 125 °C
	(-4 to 360 °F)	(-4 to 360 °F)	(-4 to 360 °F)	(-4 to 260 °F)
PFA	−20 to 125 °C	−20 to 125 °C	−20 to 125 °C	−20 to 125 °C
	(-4 to 260 °F)	(-4 to 260 °F)	(-4 to 260 °F)	(-4 to 260 °F)

Process pressure (absolute)


) Max. 21 bar (305 psi), depending on the sensor version, see pressure-temperature ratings

Temperature/pressure ratings



■ 11 Pressure-temperature ratings

- 1 PEEK sensor, without a flange
- *2 PFA sensor, without a flange (blue line)*
- *3 PEEK or PFA sensor, with DN50/ANSI 2" flange (red line)*
- 4 PEEK or PFA sensor, with JIS flange
- 5 PEEK or PFA sensor, with PVDF lap joint flange (green line)



CLS50

■ 12 Pressure-temperature ratings

- 1 PEEK sensor, without a flange
- 2 PFA sensor, without a flange or with DN50/ANSI 2" flange (blue line)
- 3 PEEK sensor, with DN50/ANSI 2" flange (red line)
- 4 PFA sensor, with JIS flange (black line)
- 5 PEEK or PFA sensor, with PVDF lap joint flange (green line)
- 6 PEEK sensor, with JIS flange (gray line)


Dimensions

Ø 49.9 (1.96) (1.38)95 (3.74) <u>с</u> <u>G3/4</u> <u>NPT 1".</u> SW 36 SW 46, 151 (5.94) / 153 (6.02)* Ø 39 (1.54) Ø 23.3 (0.92) Ø 24 (0.94)* Ø 47.5 (1 28 (1.10) A0037977 A0037978 🖻 13 Version with G¾ thread. Unit of Version, NPT 1" thread. Unit of 14 measurement mm (in)

Mechanical construction

Dimension for PEEK version

measurement mm (in)



IS Version, flange EN1092-1 DN50 PN16, 316L welded PFA sensor sealing plate. Unit of measurement mm (in)

Weight	Approx. 0.65 kg (1.43 lbs)	
Materials	Sensor	PEEK, PFA (depending on version)
	Sensor seal	VITON, CHEMRAZ (depending on version)
	Process connections	
	G¾	CLS50D-*1B/C**: PEEK GF30 CLS50D-*1D**: stainless steel (AISI 316Ti) CLS50-*1A*: stainless steel 1.4571 (AISI 316Ti) CLS50-*1B/C/1/2/3: PEEK GF30 CLS50-*1B/C5/6: stainless steel 1.4571 (AISI 316Ti)
	NPT 1"	PEEK
	Fixed flange	Stainless steel 1.4404 (AISI 316L)
	Sealing disk	GYLON (PTFE ceramic-filled)
	Lap joint flange	PP-GF
	Flange combined with lap joint flange	PVDF

Process connections


■ G¾ thread

• NPT 1" thread

Lap joint flange EN 1092 DN50 PN10

- Lap joint flange ANSI 2" 150 lbs
 Lap joint flange JIS 10K 50A
 Flange EN 1092-1 DN50 PN16
- Flange ANSI 2" 300 lbsFlange JIS 10K 50A

Flange dimensions



- 16 Flange dimensions
- Lap joint flange (PP-GF) 1

2 Fixed flange (stainless steel)

Dimensions in mm

Lap joint flange PP-GF	DN50 PN10	ANSI 2" 150 lbs	JIS 10K 50A
D	165	165	152
Øk	125	121	120
d ₂	4 x 18	8 x 19	4 x 19
b	18	18	18
a	78	78	78
Screws	M16	M16	M16

Dimensions in mm

Fixed flange SS 316 L	DN50 PN10	ANSI 2" 300 lbs	JIS 10K 50A
D	165	165.1	155
Øk	125	127	120
d ₂	4 x 18	8 x 19	4 x 19
b	18	22.2	16
а	27	27	27
Screws	M16	M16	M16

Chemical resistance

Medium	Concentration	PEEK	PFA	CHEMRAZ	VITON
Sodium hydroxide solution NaOH	0 to 50 %	20 to 100 °C (68 to 212 °F)	20 to 50 °C (68 to 122 °F)	0 to 150 °C (32 to 302 °F)	Not suitable
Nitric acid HNO ₃	0 to 10 %	20 to 100 °C (68 to 212 °F)	20 to 80 ℃ (68 to 176 ℉)	0 to 150 ℃ (32 to 302 ℉)	0 to 120 °C (32 to 248 °F)
	0 to 40 %	20 °C (68 °F)	20 to 60 °C (68 to 140 °F)	0 to 150 ℃ (32 to 302 ℉)	0 to 120 °C (32 to 248 °F)
Phosphoric acid H ₃ PO ₄	0 to 80 %	20 to 100 °C (68 to 212 °F)	20 to 60 °C (68 to 140 °F)	0 to 150 ℃ (32 to 302 ℉)	0 to 120 °C (32 to 248 °F)
Sulfuric acid H_2SO_4	0 to 2.5 %	20 to 80 °C (68 to 176 °F)	20 to 100 ℃ (68 to 212 ℉)	0 to 150 ℃ (32 to 302 ℉)	0 to 120 °C (32 to 248 °F)
	0 to 30 %	20 °C (68 °F)	20 to 100 ℃ (68 to 212 ℉)	0 to 150 ℃ (32 to 302 ℉)	0 to 120 °C (32 to 248 °F)
Hydrochloric acid	0 to 5 %	20 to 100 °C (68 to 212 °F)	20 to 80 °C (68 to 176 °F)	0 to 150 ℃ (32 to 302 ℉)	0 to 120 °C (32 to 248 °F)
HCI	0 to 10 %	20 to 100 °C (68 to 212 °F)	20 to 80 ℃ (68 to 176 ℉)	0 to 150 ℃ (32 to 302 ℉)	0 to 120 °C (32 to 248 °F)

Certificates and approvals

Current certificates and approvals for the product are available via the Product Configurator at www.endress.com.

- 1. Select the product using the filters and search field.
- 2. Open the product page.

The **Configuration** button opens the Product Configurator.

Ordering information

Product page	www.endress.com/cls50d
	www.endress.com/cls50
Product Configurator	1. Configure : Click this button on the product page.
	2. Select Extended selection .
	└ The Configurator opens in a separate window.
	3. Configure the device according to your requirements by selecting the desired option for each feature.
	└ In this way, you receive a valid and complete order code for the device.
	4. Apply : Add the configured product to the shopping cart.
	For many products, you also have the option of downloading CAD or 2D drawings of the selected product version.
	5. Show details: Open this tab for the product in the shopping cart.
	The link to the CAD drawing is displayed. If selected, the 3D display format is displayed along with the option to download various formats.

Accessories

The following are the most important accessories available at the time this documentation was issued.

► For accessories not listed here, please contact your Service or Sales Center.

Measuring cable	For CLS50D				
	 Memosens data cable CYK11 Extension cable for digital sensors with Memosens protocol Product Configurator on the product page: www.endress.com/cyk11 Technical Information TI00118C 				
	For CLS50				
	 Measuring cable CLK6 Extension cable for inductive conductivity sensors, for extension via VBM junction box Sold by the meter, order number: 71183688 				
	 VBM Junction box for cable extension 10 terminal strips Cable entries: 2 x Pg 13.5 or 2 x NPT ½" Material: aluminum Degree of protection: IP 65 Order numbers Cable entries Pg 13.5 : 50003987 Cable entries NPT ½": 51500177 				
Assemblies	 Dipfit CLA111 Immersion assembly for open and closed vessels with flange DN 100 Product Configurator on the product page: www.products.endress.com/cla111 				
	Technical Information TI00135C				
	 Dipfit CLA140 For the CLS50/CLS50D inductive sensor Immersion assembly with flange connection for very demanding processes Product Configurator on the product page: www.products.endress.com/cla140 				
	Technical Information TI00196C				
	 Flexdip CYA112 Immersion assembly for water and wastewater Modular assembly system for sensors in open basins, channels and tanks Material: PVC or stainless steel Product Configurator on the product page: www.endress.com/cya112 				
	Technical Information TI00432C				
Calibration solutions	 Conductivity calibration solutions CLY11 Precision solutions referenced to SRM (Standard Reference Material) by NIST for qualified calibration of conductivity measuring systems in accordance with ISO 9000 CLY11-B, 149.6 µS/cm (reference temperature 25 °C (77 °F)), 500 ml (16.9 fl.oz) Order No. 50081903 CLY11-C, 1.406 mS/cm (reference temperature 25 °C (77 °F)), 500 ml (16.9 fl.oz) Order No. 50081904 CLY11-D, 12.64 mS/cm (reference temperature 25 °C (77 °F)), 500 ml (16.9 fl.oz) Order No. 50081905 CLY11-E, 107.00 mS/cm (reference temperature 25 °C (77 °F)), 500 ml (16.9 fl.oz) Order No. 50081906 Technical Information TI00162C 				



www.addresses.endress.com

