

Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

1 Type of device

- Field device / signal processing device
 Monitoring- / operation system / hand held terminal etc.

Manufacturer : Endress+Hauser

Device : Liquistation

Type : CSFxx

Fieldbus / Interface : Fieldbus
HART

Device Type
0x119D

2 Firmware, Hardware I

- Firmware
 Hardware I

Old firmware version : 1.05.01

New firmware version : 1.05.02

How can the previous Firmware / Hardware I version number be identified:

Standard Fieldbus communication, FieldCare/DTM, Display

Description of the modification in comparison with the predecessor version:

Sampler:

- Auto continue after power fail
- New sampling mode: VTCV with time override
- Multiple binary outputs for program and subprogram status
- Display of operation time of peristaltic pump
- Calibration of T2 and T3 (inside and outside temperature)
- New bottle configurations for 4 bottles
- Correction of soft key name to 'Mode'

Measuring system:

- New language Vietnamese
- Activation of service mode by dip switch for fixed IP address
- Simple SAC zero point correction implemented
- Integration of CLS82D / 4 pole conductivity sensors
- Integration of COS81D / oxygen sensors
- Entry of correction factor for CUS51D calibration

Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

- Integration of new Ethernet board for simultaneous operation with 6 current outputs
- Flash frequency adjustable for nitrate and SAC for clear water applications
- Field Data Manager Software - online connection implemented
- New process value UVT 10 mm for UV disinfection applications
- Sensor input with HOLD multi-select for multiple cleaning programs
- Conductivity concentration tables editable in % or mg/l
- Simultaneous measurement of conductivity and concentration
- New conductivity concentration table NaOH 25% - 50%
- Menu 'System test' and 'Reset' split into two menus

3 Compatibility (Firmware, Hardware I)

Is the new Firmware version compatible with the previous version, the installed device drivers, the operating tool compatible / is the new Hardware I version compatible with the previous version?

- Yes
 No, description:

Is a Firmware / Hardware I update generally recommended?

- Yes, reason:

The update / exchange can be performed by means of ...

- SD card

- No, reason:

Update only necessary, if function enhancements are desired.

4 Instruction manual

Is a new instruction manual necessary due to the modification of the software?

- Yes
 No

Which manual corresponds to the new firmware and/or hardware I:

CM44x	All	BA00443CEN.pdf	Operating instruction Liquistation
		BA01245CEN.pdf	Operating instruction Memosens

Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

The new instruction manuals can be referred in Internet:

<http://www.endress.com> - area „DOWNLOAD“
- declaration of the device and kind of manual

5 Price

Change in price of device in comparison with the predecessor version?

- Yes, new list price and update costs (without installation) are enclosed
 No