



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services



Solutions

Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

1 Type of device

- ☒ Field device / signal processing device
- ☐ Monitoring- / operation system / hand held terminal etc.
- ☐ Modem / interface

Manufacturer : Endress+Hauser
 Device : Liquiline
 Type : CM442, CM444, CM448
 Previous software version : 1.05.00

How can the previous software version number be identified:

- (a) With standard fieldbus communication
- (b) with FieldCare/DTM
- (c) Display

2 Software

New software version : 1.05.01

Description of the modification in comparison with the predecessor version:

Enhancements & Improvements:

- Support of the optical sensors for fresh water turbidity CUS52D
- improved software stability for the Liquiline device platform
- Corrected diagnostic message F262 "Electronics module no communication"
- For easy commissioning via the Ethernet network the factory setting is DHCP = on

Known issue with this software version

- Update from 1.04.xx to 1.05.00 or 1.05.01 will lose all Profibus settings.
Work around: reset device and set all settings manually new! Copying a stored configuration file will lead to the same issue.
- In some cases the export of the logbooks via the webserver was not complete. In this case please repeat the download or transfer the data with the sd card.

3 Compatibility

Is the operating tool compatible with the installed device software?

- ☒ Yes



Level



Pressure



Flow



Temperature

Liquid
Analysis

Registration

Systems
Components

Services



Solutions

Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

☐ No, description:

Is a software update generally recommended?

☐ Yes, reason:

The software update can be performed by means of ...

- SD card

☒ No, reason:

Update not recommended

4 Instruction manual

Is a new instruction manual necessary due to the modification of the software?

☐ Yes

☒ No

Which manual corresponds to the new software:

Device	Communication options		Manual Marking
CM442/444/448	All	BA00444CEN.pdf	Operation Manual Liquiline
		BA01245CEN.pdf	Operation Manual Memosens

The new instruction manuals can be referred in Internet:

<http://www.endress.com> - area „DOWNLOAD“
- declaration of the device and kind of manual

5 Price

Change in price of device in comparison with the predecessor version?

☐ Yes, new list price and update costs (without installation) are enclosed

☒ No