



Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

1 Type of device

- Field device / signal processing device
- Monitoring- / operation system / hand held terminal etc.
- Modem / interface

Manufacturer : Endress+Hauser Conducta GmbH+Co
 Device : Liquistation
 Type : CSF48
 Previous software version : 1.02.01

How can the previous software version number be identified:

- (a) with Standard HART Command #0
- (b) with Fieldcare/DTM
- (c) local operation display

2 Firmware/Software

New firm-/software version : 1.02.02

Description of the modification in comparison with the predecessor version:

Functional improvements:

general:

- Parameter up/download via service DTM
 - Current output calibration via HART possible
- sampler
- HART device type stays CSF48, no change to device type CM442 any more
 - climate aggregate functions according hysteresis settings
 - Binary output 1 corrected for vacuum pump and peristaltic pump
- ultrasonic interface level
- Optimized sensor start up time (max 4 min.)
 - Linear gain with automatic gain control
 - Improved display of lineplotter according tank configuration
 - Parameter 'sensitivity' editable

ISE

- Improved calibration and standard addition
- Improved display of pH-measurement

conductivity

- Corrected alpha ref. Temperature

pH-ISFET

Corrected temperature over-compensation



Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

3 Compatibility

Is the newly installed firmware/software compatible with the operating tools?

- Yes
 No, description:

Is a firm/software update generally recommended?

- Yes, reasons:

The firm-/software update can be performed by means of ...
 SC-card

- No, reasons:

Update only necessary if functional enhancements are desired

4 Instruction manual

Is a new instruction manual necessary due to the modification of the firm-/software?

- Yes
 No

Which manual corresponds to the new firm-/software:

Device	Communication options Manual	Marking
--------	------------------------------	---------

The new instruction manuals can be referred in Internet:

<http://www.endress.com> - area „DOWNLOAD“
 - declaration of the device and kind of manual

5 Price

Change in price of device in comparison with the predecessor version?

- Yes, new list price and update costs (without installation) are enclosed
 No