

# Technical Information

# Cleanfit P CPA472

Compact retractable plastic assembly for installation of 120 mm electrodes in tanks or pipelines



#### Application

- Water treatment
- Wastewater treatment
- Plant design
- Tanks and process vats
- Pipelines or pipes

This compact retractable assembly permits replacement of the electrode while the tank is full or under process conditions with pressures of up to 6 bar (87 psi). In connection with the complete system Topcal S CPC310 you can automatically clean and calibrate the electrodes.

Solutions

The material in contact with the medium and the housing are plastic.

#### Your benefits

- Compact design
- Electrode can be cleaned and calibrated without interrupting the process; electrode life is extended
- Reliable separation from process by stop bolt and O-ring seals
- Simple removal and installation of electrode during ongoing process
- Cost-effective online measurement for simple applications
- Can be automated with a pneumatic or electric control system



TI00223C/07/EN/13.12 71164981

### Function and system design

#### Function


The retractable assembly Cleanfit P CPA472 is intended for reliable measurement of pH value and ORP in pipes and vats. This assembly has been designed as a compact retractable assembly for water treatment, for plant design and for industrial wastewater treatment. Without having to interrupt the process, the electrode can be

- separated from the process and moved into the rinse chamber manually or pneumatically
- rinsed with water or cleaning solution
- kept moist during interruptions in operation
- removed
- sterilized or
- calibrated.

The Cleanfit P CPA472 assembly is available with polypropylene (PP) or polyvinylidene fluoride (PVDF) as the material in contact with the medium. Depending on the application, you can choose

- the short assembly version (for use with 120 mm gel electrodes or 225 mm liquid KCl electrodes, immersion depth up to 108 mm) or
- the long assembly version (for use with 225 mm gel electrodes, immersion depth up to 215 mm).

The most commonly used process connections are available (see section Process connections).




M = MeasuringS = Service

- M1 Pneumatics "Assembly measuring"
- M2 Limit position switch "Assembly measuring"
- S1 Pneumatics "Assembly Service"
- S2 Limit position switch "Assembly Service"
- 1 Splash protection cap
- 2 Assembly housing (cylinder)
- *3* Seals in contact with medium
- 4 Retractable pipe
- 5 Potential matching
- 6 Stop bolt
- 7 Rinse fitting (optional)
- 8 Sensor holder (= sensor guide)

Operating elements


#### Measuring system without control



Measuring system without control (example)

- 1 Assembly Cleanfit
- 2 Special pH measuring cable, e.g. CYK10
- 3 Transmitter Mycom S CPM153 or 4
  - Transmitter Liquiline M CM42

#### Measuring system with pneumatic control



Measuring system with pneumatic control

- pH/ORP sensor 1
- 2 Assembly Cleanfit
- 3 Transmitter Mycom CPM153
- Special measuring cable 4
- 5 Communication / power supply cable
- Power supply Mycom 6 7
- Power supply CPG310 8 Control unit CPG310


- 9 Canisters for cleaning and buffer solutions
- 10 Superheated steam/water/cleaning solutions (optional)
- 11 Rinse block
- Rinse water valve 12
- 13 Power/signal cables
- Air hoses 14 15
- Media

## Installation

#### Installation conditions

The assembly is designed for installation on tanks and pipes. **Special** welded fittings are necessary for the installation (see chapter "Accessories").

When using standard glass electrodes, only installation positions are permitted in which the middle axis of the assembly lies at an angle greater than 15° from the horizontal (see diagram). Otherwise, there will not be a reliable contact between the inner side of the pH membrane and the inner terminal leads via the electrolytes. Limited permissible angle of the installation position is above 75° from the horizontal, air bubbles can accumulate in the chamber.




Installation angle

A Inadmissible installation angle

*B* Limited permissible angle (air bubbles can build up in the chamber)

C Recommended installation angle

When using an ISFET Tophit sensor, there are, in principle, no restrictions for the installation position. An installation angle of 0 to  $75^{\circ}$  is, however, recommended. An overhead installation is possible.



Installation angle for assemblies with ISFET sensors

*B Limited permissible angle (air bubbles can build up in the chamber)* 

C Recommended installation angle

Pneumatic connections for automatic assembly actuation	<ul> <li>Requirements:</li> <li>air pressure of 4 to 5 bar (58 to 72.5 psi)</li> <li>air must be filtered (40 μm) and be free of water and oil</li> <li>no continuous air consumption</li> <li>minimum nominal diameter of the air lines: 4 mm (0.16 ")</li> </ul>
	Connection thread: 2 x G 1/8
	<b>Caution!</b> There must be a pressure-reducing valve upstream if the air pressure can increase to above 5 bar (72.5 psi) (including any short pressure surges). To ensure a smooth assembly operation the assembly is equipped with a pneumatic throttle.
Rinse water connection	Rinse water pressure: 2 to 6 bar (29 to 87 psi) 2 x G ¼ (inner) 2 x NPT ¼" (inner)


# Environment

Ambient temperature	Ambient temperature not below 0 °C (32 °F). The maximum permissible temperature for electric limit position switches (NAMUR type) is 90 °C (194 °F).
Hazardous areas	The assembly Cleanfit P CPA472 is a plastic assembly (housing and materials in contact with medium are not metallic). The assembly is <b>not</b> suitable for the intrinsically safe operation in hazardous areas according to ATEX regulations. For applications in these areas we recommend the assembly Cleanfit P CPA472D with the housing made of stainless steel 1.4404 (AISI 316L), see TI403C/07/en.

T[°C]

T[°F]

### **Process**




0

32

20

68



Pressure temperature diagram

В

For high temperature applications and pressures up to 10 bar (145 psi) the "heavy duty assembly" CPA472D is recommended (see TI403C/07/EN).

40


104

60

140

80

176



Permissible medium velocity in m/s (ft/s) depending on the medium temperature in °C (°F)


### NOTICE


#### Measuring error due to high medium velocity

To prevent measurable electric potential at the electrode, the medium velocity should not exceed 2 m/s (6.6 ft/s).

# Mechanical construction

#### Dimensions





Short version for gel sensors

\* Stroke

#### **Process connections**




Fig. 1: Process connections short version / long version

Process connection		X short version	X long version
А	G1¼, external	108 mm (4.25")	215 mm (8.46")
В	NPT 1" external	108 mm (4.25")	215 mm (8.46")
С	Dairy fitting DN 50	94 mm (3.70")	201 mm (7.91")
D	Flange DN 50	75 mm (2.95")	182 mm (7.17")
Е	Flange ANSI 2"	75 mm (2.95")	182 mm (7.17")

Sensors	The short version with flange DN 50 is suitable for compact block flanges only. Flanges with nozzle require the long version. Use liquid KCl electrodes with the short version only!	
	Short version	pH glass electrodes, gel, 120 mm pH glass electrodes, KCl, 225 mm pH ISFET sensors, gel, 120 mm
	Long version	pH ISFET sensors, KCl, 225 mm pH glass electrodes, gel, 225 mm pH ISFET sensors, gel, 225 mm
Weight	1.5 to 3 kg (3.3 to 6.6 lb), de	epending on assembly version and additional equipment, see product structure
Materials	in contact with medium Seals Sensor holder not in contact with medium Cylinder El. limit position switch	FPM / Kalrez® PP, PVDF PA fore-part PBT, cable PVC
Limit position switches	conn Electric: indu hous nom	way valve; thread M 12 x 1; nection for hoses with OD = 6 mm (0.24") ctive (NAMUR type); cable length: 10 m (32.8 ft); sing material: stainless steel; thread M 12 x 1; inal voltage: 8 V 1G EEx ia IIC T6; switching distance: 2 mm, flush
	Limit position switches, left: pr	out (2) $\square$ $\square$ $\square$ $\square$ $\square$ $\square$ $\square$ $\square$ $\square$ $\square$
		ut resp. the output may be different from the figure. Please, refer to the marks at h: "1" is the input (in), "2" is the output (out).

# Certificates and approvals

Limit switches


The inductive limit switches meet the requirements of DIN EN 60 947-5-6 (NAMUR).

	Ordering information
Order code	<ul> <li>Enter the following address in your browser to access the product page: www.products.endress.com/cpa472</li> <li>1. You can choose from the following options on the product page located on the right: <ul> <li>Product page function</li> <li>:: Add to product list</li> <li>:: Price &amp; order information</li> <li>:: Compare this product</li> <li>:: Configure this product".</li> </ul> </li> <li>2. Click "Configure this product".</li> <li>3. The configurator opens in a separate window. You can now configure your device and receive the complete order code that applies for the device.</li> <li>4. Afterwards, export the order code as a PDF or Excel file. To do so, click the appropriate button at the top of the page.</li> </ul>
Product structure	Image: Second
	B       NPT 1" external thread         C       Dairy fitting DN 50 (acc to. DIN 11 851)         D       DN 50 flange, PP (acc. to EN 1092)         E       2" ANSI flange, PP         Image: Provide the state of t

Scope of delivery	<ul><li>The scope of delivery comprises:</li><li>Cleanfit assembly (ordered version)</li><li>Operating Instructions (English)</li></ul>
Special materials	Materials like Alloy C4, titanium, stainless steel 14571 (AISI 316 Ti), PEEK and conductive PVDF are available materials for the CPA472D assembly (see TI00403C/07/EN).

#### In the following sections, you find the accessories available at the time of issue of this documentation. For information on accessories that are not listed here, please contact your local service or sales representation. Pressure reducer Pressure reducer kit • complete, incl. manometer and angle bracket; • order no. 51505755 Pneumatic throttle for the reduction of the assembly moving speed, ■ G1/8 threaded connection • order no. 50036864 Welded fittings G1¼ welded fitting, PP; order no.: 51502809 G1¼ welded fitting, PVDF; order no.: 51502810 Dairy pipe welded fitting, PP, with FPM seal; • order no.: 51502811 Dairy pipe welded fitting, PVDF, with FPM seal; • order no.: 51502812

Accessories



Dummy plug


Dummy plug for G1<sup>1</sup>/<sub>4</sub> process connection,

SS 1.4435 (AISI 316L), FPM (Viton<sup>®</sup>) seal, G1<sup>1</sup>/<sub>4</sub> internal thread; order no. 51502800

#### Flow vessel

#### DN 50 flow vessel,

- G 1<sup>1</sup>/<sub>4</sub> internal thread, PP;
- order no.: 51502815
- DN 25 flow vessel,
- Rd 78 external thread, PVDF;
- order no.: 51502816



Flow vessels

- A Flow vessel DN 50, PP
- B Flow vessel DN 25, PVDF, process connection: dairy fitting
- More flow vessels, e.g. with/without view glass, PFA lined, DN 24, DN 50, DN 80 etc., are available on request.

Protection cover	<ul> <li>On request at TSP</li> </ul>	
Limit switches	Set of pneumatic limit position switches (2 pieces); • order no. 51502874	
	Set of electric limit position switches, Ex and non-Ex (2 pieces); order no. 51502873	

#### Sensors

#### Glass electrodes

Orbisint CPS11/CPS11D

- pH sensor for process applications
- Optional SIL version for connection to SIL approved transmitters
- With dirt-repellent PTFE diaphragm
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps11 or www.products.endress.com/cps11d)
- Technical Information TI028C/07/EN

Orbisint CPS12/CPS12D

- ORP electrode for process applications
- With dirt-repellent PTFE diaphragm
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps12 or www.products.endress.com/cps12d)
- Technical Information TI367C/07/EN

Ceraliquid CPS41/CPS41D

- pH sensor
- With ceramics diaphragm and liquid KCl electrolyte
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps41 or www.products.endress.com/cps41d)
- Technical Information TI079C/07/EN

Ceraliquid CPS42/CPS42D

- ORP electrode
- With ceramics diaphragm and liquid KCl electrolyte
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps42 or www.products.endress.com/cps42d)
- Technical Information TI373C/07/EN

Ceragel CPS71/CPS71D

- pH sensor
- With double chamber reference system and integrated bridge electrolyte
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps71 or www.products.endress.com/cps71d)
- Technical Information TI245C/07/EN

Ceragel CPS72/CPS72D

- ORP electrode
- With double chamber reference system and integrated bridge electrolyte
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps72 or www.products.endress.com/cps72d)
- Technical Information TI374C/07/EN

Orbipore CPS91/CPS91D

- pH sensor
- With open aperture for media with high dirt load
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps91 or www.products.endress.com/cps91d)
- Technical Information TI375C/07/EN

Orbipore CPS92/CPS92D

- ORP sensor
- With open aperture for media with high dirt load
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps92 or www.products.endress.com/cps92d)
- Technical Information TI435C/07/EN

#### **ISFET** sensors

Tophit CPS471/CPS471D

- Sterilizable and autoclavable ISFET sensor for food and pharmaceuticals, process technology,
- water treatment and biotechnology;
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps471 or www.products.endress.com/cps471d)
- Technical Information TI283C/07/EN

Tophit CPS441/CPS441D

- Sterilizable ISFET sensor for media with low conductivity, with liquid KCl electrolyte;
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps441 or www.products.endress.com/cps441d)
- Technical Information TI352C/07/EN

Tophit CPS491/CPS491D

- ISFET sensor with open aperture for media with high dirt load;
- Ordering per product structure (-> Online configurator, www.products.endress.com/cps491 or www.products.endress.com/cps491d)
- Technical Information TI377C/07/EN

#### **Instruments International**

Endress+Hauser Instruments International AG Kaegenstrasse 2 4153 Reinach Switzerland

Tel.+41 61 715 81 00 Fax+41 61 715 25 00 www.endress.com info@ii.endress.com



People for Process Automation