



BA 039D/06/en/01.99
No. 50093119
CV 5.0

Valid as of software version
V 4.00.XX (amplifier)

promag 30 (Model '99) Electromagnetic Flow Measuring System

Operating Manual




Endress + Hauser

Nothing beats know-how




Operating overview / Operating matrix



- 1 Access the operating matrix
- 2 Select function group
- 3 Select function
- 4 Select and store parameter setting
- 5 Leave operating matrix ($\text{E} > 3 \text{ s}$) or Select next function

Display of numerical values



Example:

$$9.700 \text{ E } 2 \\ = 9.700 \times 10^{+2} = 970.0 \text{ [m}^3/\text{h]}$$

$$9.700 \text{ E } -2 \\ = 9.700 \times 10^{-2} = 0.097 \text{ [m}^3/\text{h]}$$

Function group "Gr00 / SurFACE"		
Fu01 / PRGCode	Function code	ALPHA = Text code nbr = Number code
Fu02 / u_rRate	Flow rate unit	unit_1 = l/s; unit_2 = m³/h; unit_3 = USgpm
Fu03 / u_totAL	Totalizer unit	unit_4 = USgal x 1000; unit_5 = USgal; unit_6 = m³; unit_7 = l (Litre)
Function group "Gr10 / Curr_out"		
Fu11 / F_SCALE	Full scale current value	Numeric entry: x.xxx E ± x
Fu12 / t_ConSt	Time constant	Numeric entry: xx.x (in steps of 0.5 seconds)
Fu13 / I_rAnGE	Current range	0-20 (mA); 4-20 (mA)
Function group "Gr20 / Puls_out"		
Fu21 / P_FActoR	Pulse value	Numeric entry: x.xxx E ± x
Function group "Gr30 / StAtE_out"		
Fu31 / StAtE_Fct	Status output function	Error = System and process error indication FLo_dir = Flow direction indication
Function group "Gr40 / InPut"		
Fu41 / InP_Fct	Auxiliary input function	SUPPRESS = Positive zero return RES_tot = Totalizer reset to "zero"
Function group "Gr50 / dISPLAy"		
Fu51 / rES_tot	Totalizer reset	CANCEL RES_YES = Totalizer reset activated
Fu52 / dISP_oPt	Display mode	rAtE = Flow rate display; tOtAL = Totalizer display; ALtErnAt = Alternating display of flow rate and totalizer tESt = Display test function
Fu53 / dISP_dR	Display damping	Numeric entry: xx.x (in steps of 0.5 seconds)
Fu54 / tOt_oFL	Totalizer overflows	Display of totalizer overflows
Function group "Gr60 / PrOCeSS"		
Fu61 / LFC	Creep suppression	LFC_oFF = Suppression off LFC_on = Suppression on
Fu62 / EPD	Empty Pipe Detection (EPD)	EPD_oFF = off; EPD_on = on; EPD_Ad_E = Empty pipe adjustment EPD_Ad_F = Full pipe adjustment
Fu63 / ECC	Electrode cleaning (ECC), optional	ECC_oFF = ECC off ECC_on = ECC on
rEturN	E → Return to the Function group (or HOME Position)	

Contents

1	Safety Instructions	5	8	Dimensions	57
1.1	Correct usage	5	8.1	Dimensions Promag 30 A	57
1.2	Dangers and notes	5	8.2	Dimensions Promag 30 H	60
1.3	Personnel for installation, start-up and operation	6	8.3	Dimensions Promag 30 F (DN 15...300)	62
1.4	Repairs and dangerous substances	6	8.4	Dimensions Promag 30 F (DN 350...2000)	63
1.5	Technical improvements	6	9	Technical Data	65
2	Instrument Identification	7	Index		75
3	Mounting and Installation	9			
3.1	Transport instructions (DN > 350/14")	9			
3.2	Mounting location	10			
3.3	Mounting position	12			
3.4	Nominal diameter and flow rate	13			
3.5	Adapters	13			
3.6	Mounting Promag A	14			
3.7	Mounting Promag H	15			
3.8	Mounting Promag F	16			
3.9	Turning the transmitter housing and local display	18			
3.10	Mounting the transmitter (remote version)	19			
4	Electrical Connection	21			
4.1	Degree of protection	21			
4.2	Connecting the transmitter	22			
4.3	Connecting the cable of the remote version	26			
4.4	Cable specifications	28			
4.5	Potential equalisation	29			
4.6	Commissioning	31			
5	Display and Operation	33			
5.1	Display and operating elements	33			
5.2	Operation (operating matrix)	34			
5.3	Operating example	36			
6	Description of Functions	37			
7	Trouble-shooting, Maintenance and Repairs	49			
7.1	Response of the measuring system on faults or alarm	49			
7.2	Trouble-shooting and remedy	50			
7.3	Replacing the measuring electrodes	52			
7.4	Replacing the transmitter electronics	54			
7.5	Replacing the fuse	55			
7.6	Repairs	55			
7.7	Spare parts	55			
7.8	Maintenance	55			

Registered Trademarks

KALREZ[®], VITON[®] and TEFLON[®]

Registered trademark of E.I. Du Pont de Nemours & Co., Wilmington, USA

TRI-CLAMP[®], HASTELLOY[®]

Registered trademark of Ladish & Co., Inc., Kenosha, USA

1 Safety Instructions

1.1 Correct usage

- The Promag 30 is only to be used for measuring the flow of conductive fluids. Most liquids can be measured provided they have a minimum conductivity of $\geq 5 \mu\text{S}/\text{cm}$, e.g.
 - acids, alkalis, pastes, pulps,
 - drinking water, waste water, sewage sludge,
 - milk, beer, wine, mineral water, yoghurt, molasses, etc.
 A minimum conductivity of $\geq 20 \mu\text{S}/\text{cm}$ is required for measuring demineralised water.
- The manufacturer assumes no liability for damage caused by incorrect use of the instrument.
- Instruments which are used in the explosion hazardous area are supplied with a separate "Ex documentation", which is an integral part of this Operating Manual. The instructions and connected loads provided in this supplement must absolutely be observed. An appropriate icon is shown on the front of this document according to the approval given and the test center.



1.2 Dangers and notes

All instruments are designed to meet state-of-the-art safety requirements, have been tested, and have left the factory in an operational perfectly safe condition. The devices were developed according to EN 61010 "Protection Measures for Electronic Equipment for Measurement, Control, Regulation and Laboratory Procedures".

A hazardous situation may occur if the flowmeter is not used for the purpose it was designed for or is used incorrectly.

Please carefully note the information provided in this Operating Manual indicated by the following pictograms:

Warning!

A "warning" indicates actions or procedures which, if not performed correctly, may lead to personal injury or a safety hazard.

Please strictly observe the instructions supplied and proceed carefully.



Warning!

Caution!

A "caution" indicates actions or procedures which, if not performed correctly, may lead to faulty operations or the destruction of the instrument.

Please strictly observe the respective instructions.



Caution!

Note!

A "note" indicates actions or procedures which, if not performed correctly, may indirectly affect operations or lead to an unexpected instrument response.



Note!

1.3 Personnel for installation, start-up and operation

- Mounting, electrical installation, start-up and maintenance of the instrument may only be carried out by trained personnel authorized by the operator of the facility. Personnel must absolutely and without fail read and understand this Operating Manual before carrying out its instructions.
- The instrument may only be operated by personnel who are authorized and trained by the operator of the facility. All instructions in this manual are to be observed without fail.
- With special fluids, incl. those used for cleaning, E+H will be pleased to supply information concerning the chemical resistance properties of wetted parts.
- When welding the piping, the welding machinery must not be grounded through the Promag.
- The installer has to make sure that the measuring system is correctly wired up according to the wiring diagrams. The measuring system is to be grounded.
- Please observe all provisions valid for your country and pertaining to the opening and repairing of electrical devices.



Danger of electrical shock!

With the housing cover removed, protection against accidental contact is no longer present. Components with high voltages are exposed below the local display. When programming according to section 5.1–5.3, avoid any contact with the electronic components which lie below the local display, and do not use any electrically conductive object to depress the operating keys.

1.4 Repairs and dangerous substances

The following procedures must be carried out before a Promag 30 is sent to Endress+Hauser for repair:

- A note must always be enclosed with the instrument, containing a description of the fault, the application, and the chemical and physical properties of the product being measured.
- Remove all residue which may be present. Pay special attention to the gasket grooves and crevices where fluid may be present. This is especially important if the fluid is dangerous to health, e.g. corrosive, carcinogenic, radioactive, etc.
- No instrument should be returned without all dangerous material being removed first (e.g. in scratches or diffused through plastic).

Incomplete cleaning of the instrument may result in waste disposal or cause harm to personnel (burns, etc). Any costs arising from this will be charged to the owner of the instrument.


1.5 Technical improvements

The manufacturer reserves the right to modify technical data without prior notice. Your local E+H Sales Office will supply you with all current information and any updates to this Operating Manual.


2 Instrument Identification

An overview of the complete Promag 30 measuring system is shown below. The technical specifications are stamped on the nameplate and contain the following information:


Promag 30 (Model '99) transmitter



Compact version
(example for Promag H)



Remote version




Promag A

Promag H

Promag F

Sensors
(see next page)



Order code / Serial number
Definition code: see specifications on order confirmation

Identification number ("3") for Promag 30 (Model '99)

Power consumption
15 VA / W

Ingress protection (IP 67)

Power supply / frequency
85...260 V AC (50...60 Hz)

Additional information

- EPD/MSÜ: with Empty Pipe Detection
- ECC: with Electrode Cleaning Circuitry
- 5P-CAL: with 5-point calibration

Outputs
I-OUT: with current output
PULSE-OUT: with pulse output

Special products
Additional information, specifications

Fig. 1
Promag 30 transmitter.
Typical nameplate specifications
(example)

ba039y03




Fig. 2
Promag A, F, H sensors
Typical nameplate specifications
(example)

ba039y04

3 Mounting and Installation

Warning!

- The instructions given in this section are to be observed at all times in order to ensure safe and reliable operation of the measuring system.
- For explosion protected instruments the mounting regulations and the technical data may differ from those stated here. Please refer to the Ex supplement of this Operating Manual for additional information.



3.1 Transport instructions (DN ≥ 350/14")

The pipe lining on the flanges is protected by disks to prevent damage when transporting to the measuring point. These are to be removed when installing. Instruments are to be transported in the containers they are delivered in.

Transporting to the measuring point

- The sensor must not be lifted by the transmitter housing!
- Use only the grips on the flange for lifting out and mounting the sensor in the piping (from DN 350 or 14").

Caution!

The sensor must not be lifted by the metal casing using a fork lift truck! This can buckle the casing and so damage the internal magnetic coils.




Fig. 3 Transport instructions for large diameter sensors (DN ≥ 350)

Base and supports

The sensor is to be mounted on a base which is sufficiently strong enough to withstand its weight.

Caution!

Do not support the sensor by the sheet casing. The casing may be dented and so damage the magnetic coils inside the sensor.




Fig. 4 The proper way to support large diameter sensors (DN ≥ 350)

3.2 Mounting location




Fig. 5
Mounting location

Correct measurement is only possible when the pipe is full. The following locations should therefore be avoided:

- No installation at the highest point (air accumulation).
- No installation immediately before an open pipe outlet in a downward line.

The alternative installation, however, permits a correct measurement.




Fig. 6
Mounting with a partly filled pipe

Partly filled pipes

For inclines a mounting similar to a drain should be adopted. Added security is offered by Empty Pipe Detection in order to detect empty or partly filled pipes (see page 46).

Note!
Danger of solids accumulation!
Do not mount the sensor at the lowest point of the drain. A cleaning valve should also be installed.




Fig. 7
Installation downward pipe

Downward pipe

With the installation suggested opposite, partial vacuum is avoided even with a downward pipe > 5 m long (siphon, vent valve downstream of the sensor).

Installation of pumps

Do not mount the sensors on the suction side of pumps. This prevents low pressure and therefore possible damage to the lining of the measuring tube. Information on the resistance to vacuum of the flowmeter lining can be found on page 74.

Pulse dampers should be installed when using reciprocal, diaphragm or peristaltic pumps.





Fig. 8
Installation of pumps

Vibration

The piping before and after the sensor should be securely fastened if there is excessive vibration. Information on shock and vibration resistance is found on page 67.

Caution!
Excessive vibration necessitates separate mounting of the sensor and transmitter (see pages 19, 67).

Mechanical support of the sensor is recommended for free runs of piping over 10 m long.



Caution!

Fig. 9
Remedies to avoid vibrations

3.3 Mounting position




Fig. 10
Mounting position (horizontal,
vertical)

Vertical mounting:

This is the recommended position with the flow upwards. Entrained solid particles sink and fatty components in the stationary fluid rise away from the measuring electrodes. This is the optimal position in empty pipe system and when using Empty Pipe Detection (see page 46).

Horizontal mounting:

The axis of the electrodes must be horizontal, thus preventing brief insulation of the electrodes by entrained air bubbles.

Electrode axis:

The plane in which the electrode axis lies with regard to the transmitter is identical for the Promag A, H and F sensors.




Fig. 11
Inlet and outlet sections

Inlet and outlet sections

The sensor should be mounted away from fittings such as valves, T-pieces, elbows, etc.

Inlet section: $\geq 5 \times DN$

Outlet section: $\geq 2 \times DN$

The inlet and outlet sections must be observed in order to maintain accuracy.

3.4 Nominal diameter and flow rate

The diameter of the pipe usually governs the nominal diameter of the sensor. The optimum flow velocity range is between $v = 2 \dots 3 \text{ m/s}$. Furthermore, the flow velocity (v) has to be matched to the physical properties of the fluid:

- $v < 2 \text{ m/s}$: with abrasive media (potter's clay, lime milk, ore slurry)
- $v > 2 \text{ m/s}$: with media forming coating (wastewater sludge, etc.)

If it is necessary to increase the flow velocity, this can be done by reducing the nominal diameter of the sensor (see following chapter).

Full scale value and pulse value:

- Minimum / maximum adjustable full scale value → see page 39
- Minimum / maximum adjustable pulse value → see table on page 41
- Factory settings → see page 72

3.5 Adapters

The sensor can also be mounted in a pipe with a larger nominal diameter when suitable adapters (reducers and expanders) to DIN 28545 are fitted. The resultant increase in the rate of flow increases the accuracy of measurement with slowly moving fluids.

The adjacent nomogram can be used to determine the pressure loss caused.

Procedure:

1. Determine the ratio of the diameter d/D .
2. From the nomogram read off the pressure loss at the flow velocity and d/D ratio.

Note!

The nomogram applies to fluids with a viscosity similar to that of water.




Fig. 12
Pressure loss when using adapters

3.6 Mounting Promag A

Various process connections are available for the Promag A sensor. The process connections (adapters) are mounted in two ways:

A. Coupling nut on a 1" threaded stub (mounting set)

- Internal thread
- External thread
- PVC adhesive coupling
- Hose connection
- Weld nipples

B. Screw-in process connections (instead of threaded stub)

These process connections are mounted as standard in the factory before delivery.

- Flange joints
- Tri-Clamp




Fig. 13
Process connections
Promag A

Gaskets / Screw tightening torques (Mounting set)

When fastening the process connections, the O-ring or the flat gasket is pressed fully into the seal groove in the threaded stub. The skirted nut thereby comes to a fixed stop.

Length, dimensions → see pages 57 ff.

3.7 Mounting Promag H

The Promag H sensor is delivered with the process connection already mounted. The various process connections are fastened to the sensor with 4 or 6 screws.




Fig. 14
Process connections
Promag H

Gaskets / Screw tightening torques

When mounting the process connectors, make sure that the gasket is free of dirt and correctly centered. The screws have to be tightened.

The process connector forms a metal connection with the sensor, to guarantee a defined seal compression.

Diameter		Max. tightening torque [Nm]
DIN [mm]	ANSI [inch]	
25	1"	10
40	1 1/2"	10
50	2"	25
65	2 1/2"	25
80	3"	88
100	4"	88

Length and dimensions → see pages 60 ff.

Welding the sensor into the pipework (welded nipple)

If the sensor is directly welded into the pipework, we recommend the following procedure:

Caution!

The electronics may be destroyed! Take care that the welding ground is not via the Promag 30 H sensor or housing.



1. Fasten the Promag H sensor with some spot welds into the pipe.
2. Loosen the screws at the process-connector flange and remove the sensor from the pipe; make sure that the gasket is also removed from the process connector.
3. Weld the process connector into the pipe.
4. Once again install the sensor into the pipe; make sure everything is clean and the gasket is correctly positioned.

Note!

- If the welding process is correctly executed in thin-walled food piping, the gasket will not be damaged by the heat, even when mounted. Nevertheless, we recommend removing the sensor and gasket first.
- For the disassembly, the pipe has to be spread by about 4 mm.



3.8 Mounting Promag F

The sensor is mounted between the flanges of the piping (Fig. 15). Since the lining of the measuring tube also covers the sensor flange, it also performs as a seal.

Caution!

The Teflon (PTFE) lined Promag F is fitted with protective discs to guard the lining which is turned over the flanges. These discs are to be removed just before mounting the sensor. Ensure that the lining on the flange is not damaged or removed. These discs must remain in position during storage.



Caution!




Fig. 15
Mounting Promag 30 F

Gaskets

- If the measuring tube liner is made of soft rubber or Teflon (PTFE), a flange seal is not required.
- With soft rubber lining the mating flange should have a thin film of non-conductive sealing grease applied.
- Use a gasket according to DIN 2690.
- Mounted gaskets must not protrude into the piping section.



Caution!

Caution!

Danger of short-circuit! Do not use sealing materials that are electrically conductive, e.g. graphite. This could result in an electrically conductive layer forming on the inside of the measuring tube and therefore short-circuiting the measuring signal.

Screw tightening torques → see following page!

Length and dimensions → see pages 62, 63

Screw tightening torques (Promag F)

The tightening torques listed apply to greased threads.

Screws tightened up too tightly deform the sealing surface. Special attention should be paid to soft rubber linings.

Note!

The tightening torques given here apply only to those pipes which are not subject to mechanical stress.



Note!

Diameter		Pressure ratings				Screws	Max. tightening torques [Nm]		
[mm]	[inch]	DIN [bar]	ANSI [lbs]	AWWA	JIS		Hard rubber	Soft rubber (EPDM)	PTFE (Teflon)
15	1/2"	PN 40	Class 150	-	20K	4 x M 12	-	-	15
25	1"				20K	4 x M 12	25	5	33
32	-				20K	4 x M 12	40	8	53
40	1 1/2"				20K	4 x M 16	50	11	67
50	2"				10K	4 x M 16	64	15	84
65	-	PN 16	Class 150	-	10K	4 x M 16	87	22	114
80	3"				10K	8 x M 16	53	14	70
100	4"				10K	8 x M 16	65	22	85
125	-				10K	8 x M 16	80	30	103
150	6"				10K	8 x M 20	110	48	140
200	8"	PN 10	Class 150	-	10K	8 x M 20	108	53	137
250	10"				10K	12 x M 20	104	29	139
300	12"				10K	12 x M 20	119	39	159
350	14"	PN 10/16	Class 150	-		16 x M 20	141/193	39/79	188/258
400	16"					16 x M 24	191/245	59/111	255/326
-	18"					20 x M 24	170/251	58/111	227/335
500	20"					20 x M 24	197/347	70/152	262/463
600	24"					20 x M 27	261/529	107/236	348/706
700	28"	PN 10/16	-	Class D		24 x M 27	312/355	122/235	-
800	30"					24 x M 30	417/471	173/330	-
900	32"					28 x M 30	399/451	183/349	-
1000	36"					28 x M 33	513/644	245/470	-
1200	48"	PN 6	-	Class D		32 x M 36	720	328	-
-	54"					36 x M 39	840	432	-
1400	-					36 x M 39	840	432	-
-	60"					40 x M 45	1217	592	-
1600	-					40 x M 45	1217	592	-
-	66"					44 x M 45	1238	667	-
1800	72"					44 x M 45	1238	667	-
-	78"					48 x M 45	1347	749	-
-	-					48 x M 45	1347	749	-
2000	-					48 x M 45	1347	749	-

3.9 Turning the transmitter housing and local display

The transmitter housing and local display can be rotated in steps of 90°. This enables the unit to be adapted to different mounting positions in the piping and so simplifying reading and operation.




Fig. 16
Turning the transmitter housing




Fig. 17
Turning the local display

3.10 Mounting the transmitter (remote version)

The transmitter has to be mounted remote from the sensor when:

- access is difficult,
- space is restricted,
- extreme process and ambient temperatures prevail (for temperature ranges see page 67),
- there is severe vibration (>2 g/2 h per day; 10...100 Hz).

Wall and post mounting

The remote mounted version is delivered with a wall bracket as standard.

A special mounting set can be supplied for post mounting: Order No. 50076905.

Connecting cable

Two different versions are available for remote versions:

FS version:

- The permissible length of cable L_{max} of more than 10 m is governed by the conductivity of the fluid (see Fig. 19).
- The maximum possible cable length is limited to 10 meter for instruments with Empty Pipe Detection (EPD). This function is only available with the FS version.
- The FS cable is recommended only for distances smaller than 20 m.

FL version:

- All fluids with a minimum conductivity of $\geq 5 \mu\text{S/cm}$ (demineralised water $\geq 20 \mu\text{S/cm}$) can be measured. This is not dependent on the distance between transmitter and sensor (see Fig. 19).
- Empty Pipe Detection (EPD) is *not* available with this version.

Please also note the following for obtaining correct readings:

- Fasten the cable gland or lay it in a conduit. When the fluid conductivity is low, cable movements can cause serious changes in capacitance and thereby falsify the measuring signal.
- Do not run the cable in the vicinity of electrical machines or switching elements.
- Ensure potential equalization between the transmitter and the sensor.




Fig. 18
Wall and post mounting




Fig. 19
Fluid conductivity and cable length with the remote version

4 Electrical Connection

Warning!

When connecting Ex-approved instruments, please observe all instructions and wiring diagrams given in the Ex supplement to this Operating Manual. Your E+H representative will be pleased to provide you with more information.



4.1 Degree of protection

The instruments fulfil all the requirements for IP 67. After successful installation in the field or after servicing, the following points must always be observed in order to ensure the degree of protection IP 67:

- Housing gaskets must be clean and undamaged when inserted in the gasket groove. The gaskets may need to be dried, cleaned or replaced.
- All housing screws and the housing cover must be tightened firmly.
- The cables used for connecting must have the correct outer diameter (see page 28).
- The cable gland must be tightened firmly (see Fig. 20).
- The cable must loop down before entering the cable gland to ensure that no moisture can enter it (see Fig. 20).
Install the sensor so that the cable glands first hang down and do not first go upwards.
- Any cable gland not used must be replaced with a blind plug.
- The protective bushing should not be removed from the cable gland.




Fig. 20
Mounting cable entries

Caution!

The screws of the Promag sensor housing must not be loosened or the degree of protection guaranteed by E+H is no longer valid.



Note!

The Promag A and F sensors can optionally be supplied with the IP 68 degree of protection (permanently under water to a depth of 3 m). In this case the transmitter (IP 67) has to be mounted remote from the sensor.




4.2 Connecting the transmitter

Warning!

- Risk of electric shock! Switch off the power supply before opening the instrument. Do not install or wire the unit while connected to the power supply. Failure to comply may also result in damage of electronic components.
- Connect the protective conductor to the ground terminal on the housing before the power supply is switched on.
- Check that local power supply and frequency agree with the information on the nameplate. All relevant national regulations for mounting must also be observed.



Warning!



1. Loosen the Allen screw of the safety grip using a 3 mm Allen key.
2. Unscrew the wiring compartment cover.
3. Feed the power and signal cables into the appropriate cable glands.
4. Wire up according to the wiring diagrams:
→ see Fig. 22
→ Wiring diagram in the screw cover
 - Power supply is connected to terminal 1 (L1, L+), terminal 2 (N, L-) and the ground terminal (3).
 - Fine-wire leads: max. 4 mm²; put sleeve on the end of the cores. Single-core lead: max. 6 mm².
5. Having made the connection, screw the cover tightly again on the transmitter housing.
6. Tighten the Allen screw of the safety grip securely.

Fig. 21
Connecting the transmitter

Connection diagram (Promag 30 transmitter)





Fig. 22
Terminal compartment
Promag 30

Examples for electrical connections (inputs and outputs)




Caution!

Fig. 23
Examples of electrical connections (Promag 30)


ba039y51

Auxiliary input



Current output as a power supply source

If the current output is not required, then this can be used as a power supply. Set the current output to 4-20 mA (see page 40).



Caution!
Carefully note the specifications required for inputs and outputs (see page 23)




Caution!

ba039y52

Fig. 24
Examples of electrical connections (Promag 30)

Wiring diagrams for the remote version (FS/FL)

Remote version "FS"



Remote version "FL"




Fig. 26
Wiring diagrams for the remote versions "FS" and "FL"

4.4 Cable specifications

Remote version "FS"

Coil cable:	2 x 0.75 mm ² PVC cable with common screen *	
	Conductor resistance	≤ 37 Ω/km
	Capacitance: core/core, screen grounded	≤ 120 pF/m
Signal cable:	3 x 0.38 mm ² PVC cable with common screen * and separately screened cores	
	With EPD (Empty Pipe Detection)	4 x 0.38 mm ² PVC cable
	Conductor resistance	≤ 50 Ω/km
	Capacitance: core/screen	≤ 420 pF/m

Permanent operation temperature: -20...+70 °C

* braided copper screening: Ø ~ 7 mm

Remote version "FL"

Coil cable:	2 x 0.75 mm ² PVC cable with common screen *	
	Conductor resistance	≤ 37 Ω/km
	Capacitance: core/core, screen grounded	≤ 120 pF/m
Signal cable:	5 x 0.5 mm ² PVC cable with common screen *	
	Conductor resistance	≤ 37 Ω/km
	Capacitance: core/core, screen grounded	≤ 120 pF/m

Permanent operation temperature: -20...+70 °C

* braided copper screening (coil cable Ø ~ 7 mm; signal cable Ø ~ 9 mm)

Operation in areas with severe electrical interference

The Promag 30 measuring system fulfils all general safety requirements according to EN 61010 and electromagnetic compatibility (EMC) according to EN 50081 Part 1 and 2 / EN 50082 Part 1 and 2 when installed in accordance with the NAMUR recommendations.



Note!

Note!

- With the remote-mounted version the signal and coil cables between sensor and transmitter must always be screened and grounded at both ends.
- The cable must be resistant to an ambient temperature of max. +80 °C if the Promag H sensor is operated at a process temperature of +150 °C.

4.5 Potential equalisation

The sensor and the fluid must have roughly the same electrical potential to ensure that measurement is accurate and no galvanic corrosion takes place at the electrode. Normally the reference electrode in the sensor or the metal pipe ensures that the potentials are equalized.

Reference electrodes:

- Promag A:
always with reference electrode
- Promag F:
optional, depending on material
- Promag H:
no reference electrode, as there is always a metallic connection to the fluid.




Fig. 27
Position of different electrodes
in the measuring tube
(Promag 30 F)

If the reference electrode is correctly grounded and the fluid flows through metallic, unlined and grounded piping, then it is sufficient to connect the grounding terminal of the Promag 30 transmitter housing to the potential equalisation line in order to prevent corrosion. The connection with the remote-mounted version is made at the ground terminal of the connection housing.

Caution!

Danger of permanent damage to the instrument! If the fluid cannot be grounded for operational reasons, ground disks are to be used.



Potential equalisation for some special cases is described below:

Potential equalisation for lined pipes with cathodic protection

When the fluid cannot be earthed for operational reasons, the measuring unit must be installed that it is potential-free (Fig. 28). Ensure that components of the piping are connected to one another (copper wire, 6 mm²).

All national regulations regarding potential free installation are to be observed (e.g. VDE 0100).

Ensure that the mounting material used does not result in a conductive bond with the measuring unit and that the material can withstand the tightening torque used.




Fig. 28
Potential equalisation for lined
pipes with cathodic protection


Plastic or lined piping

Fig. 29
Potential equalisation with plastic
or lined pipings.



Caution!

Caution!

Danger from damage due to electrochemical corrosion!

- Note the corrosion resistance of the ground disks!
- Note the electrochemical potential series in cases where the ground disks and the measuring electrodes are made of different material.


**Equalising currents in unearthed metal pipes /
Earthing in an area with severe interference**

Fig. 30
Potential equalisation with
– equalising currents,
– in areas with severe
interference

Ground disks must always be used with non-conductive piping materials if compensation currents flow through the fluid. They can irreparably damage the reference electrode within a short time due to electrochemical corrosion.

Such conditions occur especially if:

- the piping is insulated with electrically non-conductive materials and
- the piping is made of fibreglass or PVC through which flow highly concentrated acids and alkalis.

The fluid may be earthed. In order to make the most of the electromagnetic compatibility (EMC) of the Promag 30, it is advisable to provide two flange-to-flange links and to connect them jointly with the transmitter housing to earth potential.

4.6 Commissioning

Before switching on the measuring system, the following checks should be carried out again:

- Check the electrical connections and terminal assignments.
- Compare the data on the nameplate with the local mains voltage and frequency.
- Does the direction of the arrow on the nameplate (sensor) agree with the actual direction of flow in the piping?

If the results of these checks are satisfactory, switch on the supply voltage. The unit is now ready for operation.

After switching on, the system performs various self-test routines. During this procedure the following sequence of messages appears on the display:

P r o - 3 _ ' Promag 30 (Model '99)

The actual set display mode is then shown (3 possibilities):

- *r R t E* Flow rate
- *t o t R L* Totalizer
- *R L t E r o n t* Alternating display of flow rate / totalizer
(display changes approx. every 10 seconds)

After successful start-up, normal measurement mode is assumed. Depending on the display mode set, it now shows flow rate and/or totalizer value as well as the actual units ("HOME position").




Fig. 31: Examples of the display (HOME position)

5 Display and Operation

5.1 Display and operating elements

With Promag 30 important variables can be directly read off at the measuring point. Various functions of the E+H matrix can also be selected and configured using the three operating keys.


Warning!

Danger of electrical shock! With the housing cover removed, protection against accidental contact is no longer present. Components with high voltages are exposed below the local display. When programming avoid any contact with the electronic components which lie below the local display, and do not use any electrically conductive object to depress the operating keys!



Warning!

1. Loosen the Allen screw (3 mm) of the safety grip.
2. Unscrew the cover of the electronics compartment.
3. The keys may now be operated by pressing with a thin (non-conductive) pin.
A switching cycle takes about 0.5...0.8 seconds.
4. Firmly screw back the cover of the electronics compartment to the transmitter housing once the settings have been entered. Firmly tighten the Allen screw of the safety grip.



Enter key

- HOME position → access operating matrix
- Leave the operating matrix → HOME position (key is pressed for more than 3 seconds)
- Change operating level: Function group → Function → Input
- Save data or settings

ba039y32


Fig. 32
Display and operating elements

5.2 Operation (operating matrix)



Warning!
 Danger of electrical shock! With the housing cover removed, protection against accidental contact is no longer present.

1. Access the operating matrix
2. Select function group
3. Select functions
4. Select and store parameters (operating example: see page 36)
5. Leave operating matrix → HOME position (from any matrix position) or Select other functions



Note!

- An automatic return to the HOME position will be made if the operating keys are not actuated for 60 seconds (although not from an opened function).
- "rEt urn" + Enter → Return to the next higher operating level (function group, HOME)
- "CRnCEL" + Enter → Return to the function level *without* storing the changed parameter



Fig. 33
 Select functions in the E+H
 operating matrix

ba039y33

Operating matrix / Summary of functions


SURFACE Gr00 <i>Interactive surface</i> → page 37	PAGECODE / Fu01 <i>Function code</i> ALPHA text code * nbr number code CANCEL	u_RATE / Fu02 <i>Flow rate units</i> unit_1 [l/s] * unit_2 [m ³ /h] unit_3 [USgpm] CANCEL	u_TOTAL / Fu03 <i>Totalizer units</i> unit_4 [USgal × 1000] unit_5 [USgal] unit_6 [m ³] unit_7 [l] * CANCEL	rEturN	
Curr_out Gr10 <i>Current output</i> → page 38	F_SCALE / Fu11 <i>Full scale value (current output)</i> Numeric entry: x.xxx E±x Factory setting: page 72	t_ConSt / Fu12 <i>Time constant</i> Numeric entry: xx.x (in steps of 0.5 s) Factory setting = 1.0 s	I_RAnGE / Fu13 <i>Current range</i> 0-20 (mA) 4-20 (mA) * CANCEL	rEturN	
PULS_out Gr20 <i>Pulse output</i> → page 40	P_FACTor / Fu21 <i>Pulse value</i> Numeric entry: x.xxx E±x Factory setting: page 72	rEturN			
StAt_out Gr30 <i>Status output</i> → page 42	StAt_FcT / Fu31 <i>Status output function</i> Error System/process error indication * FlO_dir Flow direction indication CANCEL	rEturN			
InPut Gr40 <i>Auxiliary input</i> → page 43	InP_FcT / Fu41 <i>Auxiliary input function</i> SUPPrESS Positive zero return rES_tOt Reset totalizer * CANCEL	rEturN			
DISPLAy Gr50 <i>Display</i> → page 43	rES_tOt / Fu51 <i>Totalizer reset</i> CANCEL rES_YES reset	dISP_oPt / Fu52 <i>Display mode</i> rAtE Flow rate * tOtAL Totalizer RLtErnAt Flow rate & Totalizer tESt Display test function CANCEL	dISP_dR / Fu53 <i>Display damping</i> Numeric entry: xx.x (in steps of 0.5 s) Factory setting = 1.0 s	tOt_oFl / Fu54 <i>Number of totalizer overflows</i> Display: xxxxxxxx (max. 8 characters)	rEturN
ProCESS Gr60 <i>Process parameters</i> → page 44	LFC / Fu61 <i>Creep suppression</i> LFC_oFF off LFC_on on * CANCEL	EPD / Fu62 <i>Empty Pipe Detection</i> EPd_oFF off * EPd_on on EPd_Ad_E Empty pipe adjustment EPd_Ad_F Full pipe adjustment CANCEL	ECC / Fu63 <i>Electrode cleaning (optional)</i> ECC_oFF off ECC_on on * CANCEL	rEturN	
rEturN	* Factory setting (can be different for instruments with customer specific parameterisation)				

5.3 Operating example



Warning!
 Danger of electrical shock! With the housing cover removed, protection against accidental contact is no longer present. Components with high voltages are exposed below the local display. When programming avoid any contact with the electronic components which lie below the local display, and do not use any electrically conductive object to depress the operating keys!

You would like to set the full scale value for the current output to 600.0 m³/h.
 Proceed as follows:



HOME position
 (display during normal operation)

SURFACE



Curr_out



F_SCALE



4.988 E1



6.088 E1



6.000 E2



F_SCALE

Change flashing number with and store with . The next number to be changed will then flash automatically.

- Remarks:
- Selecting units → see page 37
 - Display of numerical values: → see page 2
 - If the value entered is too high or too low, then the message "E_o_o_H1" or "E_o_o_Lo" is displayed for approx. 2 seconds. The maximum or minimum full scale value (depending on nominal diameter) will then be shown → see page 39.

Terminate entry

- > 3 sec. → HOME position
- next function (E_CoNSt)

Fig. 34
 Operating example
 (E+H operating matrix)



ba039y70

6 Description of Functions

This section describes in detail, along with specifications, the individual functions of the Promag 30. The function designation in the following table shows the two versions available – as well as the text and number codes used (see function “PAGECODE / Fu 01”).

Function groups

Interactive surface	(SURFACE / Gr 00)	→ page 37
Current output	(CURR_out / Gr 10)	→ page 38
Pulse output	(PULS_out / Gr 20)	→ page 40
Status output	(STAT_out / Gr 30)	→ page 42
Auxiliary input	(INPut / Gr 40)	→ page 43
Display	(DISPLAY / Gr 50)	→ page 43
Process parameter	(PROCESS / Gr 60)	→ page 44


Function group	
INTERACTIVE SURFACE – SURFACE / Gr 00	
<p>PAGECODE Fu 01</p> <p>Function code</p>	<p>All functions of the operating matrix can be shown on the display in two different ways – with a function number or a text code.</p> <p> ALPHA Type of display → text code e.g. F_SCALE for function “full scale value current output”</p> <p>nbr Type of display → number code e.g. Fu 11 for function “full scale value current output”</p> <p>CANCEL</p>
<p>u_RATE Fu 02</p> <p>Flow rate</p>	<p>Select the units required for flow rate (volume/time). The units selected here also define those for:</p> <ul style="list-style-type: none"> • creepage • full scale value (current output) <p> unit_1 Display segment “l/s” unit_2 Display segment “m³/h” unit_3 Display segment “USgpm” CANCEL</p>  <p style="text-align: right; font-size: small;">ba039y71</p>
<p>u_tOTAL Fu 03</p> <p>Volume unit</p>	<p>Select the units required for flow volume (totalizer). The units selected here also define those for:</p> <ul style="list-style-type: none"> • pulse value (volume/pulse) • totalizer (counter) <p> unit_4 Display segment “USgal x 1000” unit_5 Display segment “USgal” unit_6 Display segment “m³” unit_7 Display segment “l” CANCEL</p>  <p style="text-align: right; font-size: small;">ba039y72</p>

Function group
CURRENT OUTPUT - Curr_out / Gr 10

F_SCALE
Fu 11

Full scale value

Enter the desired full scale value for the volume flow (in the appropriate units selected). When exceeding the max. possible full scale value, the current output is limited to a maximum of 20.5 mA.



Numeric entry:

Change the flashing number with \pm and store with E . The next number to be changed will then flash automatically. After the last number has been changed and stored, the instrument returns to the function level (all display segments flash).

Note!

The minimum or maximum possible full scale value is given for every nominal diameter in the table on page 39. If the value entered is too high or too low then the display reacts as follows:

1. The value entered is *not* stored.
2. The message "too HI" (value entered is too high) or "too LO" (value entered is too low) is shown on the display.
3. The minimum or maximum possible values are then shown on the display which may be entered for the full scale (see table).

Display of numerical values:

Due to the limited size of the display, values are shown in a special way.



Note!

Basic value	→	Multiplication factor
		E 5 = 10^{+5} = 100000 E 4 = 10^{+4} = 10000 E 3 = 10^{+3} = 1000 E 2 = 10^{+2} = 100 E 1 = 10^{+1} = 10 E 0 = 10^0 = 1 E-1 = 10^{-1} = 0.1 E-2 = 10^{-2} = 0.01 E-3 = 10^{-3} = 0.001 E-4 = 10^{-4} = 0.0001 E-5 = 10^{-5} = 0.00001

Examples:

9.700 E 2	=	9.700 × 10⁺²	=	970.0	[m ³ /h]
9.700 E-2	=	9.700 × 10⁻²	=	0.097	[m ³ /h]

ba009y61

Display limits / Full scale values (current output)						
DN	l/s		m ³ /h		USgpm	
	Min.	Max.	Min.	Max.	Min.	Max.
2	9.424 E-4	3.141 E-2	3.392 E-3	1.130 E-1	1.494 E-2	4.980 E-1
4	3.769 E-3	1.256 E-1	1.357 E-2	4.523 E-1	5.976 E-2	1.992 E 0
8	1.507 E-2	5.026 E-1	5.428 E-2	1.809 E 0	2.390 E-1	7.968 E 0
15	5.301 E-2	1.767 E 0	1.908 E-1	6.361 E 0	8.403 E-1	2.801 E 1
25	1.472 E-1	4.908 E 0	5.301 E-1	1.767 E 1	2.334 E 0	7.781 E 1
32	2.412 E-1	8.042 E 0	8.685 E-1	2.895 E 1	3.824 E 0	1.274 E 2
40	3.769 E-1	1.256 E 1	1.357 E 0	4.523 E 1	5.976 E 0	1.992 E 2
50	5.890 E-1	1.963 E 1	2.120 E 0	7.068 E 1	9.337 E 0	3.112 E 2
65	9.954 E-1	3.318 E 1	3.583 E 0	1.194 E 2	1.578 E 1	5.260 E 2
80	1.507 E 0	5.026 E 1	5.428 E 0	1.809 E 2	2.390 E 1	7.968 E 2
100	2.356 E 0	7.853 E 1	8.482 E 0	2.827 E 2	3.735 E 1	1.245 E 3
125	3.681 E 0	1.227 E 2	1.325 E 1	4.417 E 2	5.836 E 1	1.945 E 3
150	5.301 E 0	1.767 E 2	1.908 E 1	6.361 E 2	8.403 E 1	2.801 E 3
200	9.424 E 0	3.141 E 2	3.392 E 1	1.130 E 3	1.494 E 2	4.980 E 3
250	1.473 E 1	4.908 E 2	5.301 E 1	1.767 E 3	2.334 E 2	7.781 E 3
300	2.120 E 1	7.068 E 2	7.634 E 1	2.544 E 3	3.361 E 2	1.120 E 4
350	2.886 E 1	9.621 E 2	1.039 E 2	3.463 E 3	4.575 E 2	1.525 E 4
400	3.769 E 1	1.256 E 3	1.357 E 2	4.523 E 3	5.976 E 2	1.992 E 4
450	4.771 E 1	1.590 E 3	1.717 E 2	5.725 E 3	7.563 E 2	2.521 E 4
500	5.890 E 1	1.963 E 3	2.120 E 2	7.068 E 3	9.337 E 2	3.112 E 4
600	8.482 E 1	2.827 E 3	3.053 E 2	1.017 E 4	1.344 E 3	4.482 E 4
700	1.154 E 2	3.848 E 3	4.156 E 2	1.385 E 4	1.830 E 3	6.100 E 4
750	1.325 E 2	4.417 E 3	4.771 E 2	1.590 E 4	2.107 E 3	7.003 E 4
800	1.507 E 2	5.027 E 3	5.428 E 2	1.809 E 4	2.390 E 3	7.968 E 4
900	1.908 E 2	6.361 E 3	6.870 E 2	2.290 E 4	3.025 E 3	1.008 E 5
1000	2.356 E 2	7.853 E 3	8.482 E 2	2.827 E 4	3.735 E 3	1.245 E 5
1050	2.597 E 2	8.659 E 3	9.351 E 2	3.117 E 4	4.117 E 3	1.372 E 5
1200	3.392 E 2	1.130 E 4	1.221 E 3	4.071 E 4	5.378 E 3	1.792 E 5
1350	4.294 E 2	1.434 E 4	1.545 E 3	5.153 E 4	6.807 E 3	2.269 E 5
1400	4.618 E 2	1.539 E 4	1.662 E 3	5.547 E 4	7.320 E 3	2.440 E 5
1500	5.301 E 2	1.767 E 4	1.908 E 3	6.361 E 4	8.403 E 3	2.801 E 5
1600	6.031 E 2	2.010 E 4	2.171 E 3	7.238 E 4	9.561 E 3	3.187 E 5
1700	6.809 E 2	2.269 E 4	2.451 E 3	8.171 E 4	1.079 E 4	3.598 E 5
1800	7.634 E 2	2.544 E 4	2.748 E 3	9.160 E 4	1.210 E 4	4.033 E 5
2000	9.424 E 2	3.141 E 4	3.392 E 3	1.130 E 5	1.494 E 4	4.980 E 5

The last figure of the above values can differ by ±1 from the value shown on the display (error in rounding off)!

Minimum full scale → flow rate = 0.3 m/s
Maximum full scale → flow rate = 10 m/s

Factory settings → see page 72



Function group CURRENT OUTPUT - Curr_out / Gr10	
<p>t_Const Fu 12</p> <p>Time constant</p>	<p>Selecting the time constant determines whether the current output signal reacts very quickly to rapidly changing flows (small time constant) or slowly (large time constant).</p> <p>Note! The time constant does not affect the behaviour of the display!</p> <p> Numeric entry: 0.5...95 [s] in steps of 0.5 s</p>
<p>I_Range Fu 13</p> <p>Current range</p>	<p>Set the current range. The current for the scaled full scale value is always 20 mA (see page 38).</p> <p> 0-20 (mA) 4-20 (mA)</p>



Function group PULSE OUTPUT - Puls_out / Gr20	
<p>P_Factor Fu 21</p> <p>Pulse value</p>	<p>Enter that flow quantity for which an output pulse is supplied (pulse width: max. 1s, pulse/pause ratio up to 0.5 Hz approx. 1:1; with pulse frequencies less than 0.5 Hz the pulse width is limited to 1 s; $f_{max} = 400$ Hz). With external totalizers these pulses can be totalized and thus determine the total flow quantity since the start of measurement.</p> <p> Numeric entry: Change flashing number with and store with . The next number to be changed will then flash automatically. After the last number has been changed and stored, the instrument returns back to the function level (all display segments flash).</p> <p>Note! The minimum or maximum possible full scale value is given for every nominal diameter in the table on page 41. If the value entered is too high or too low then the display reacts as follows: 1. The value entered is <i>not</i> stored. 2. The message "too_HI" (value entered is too high) or "too_Lo" (value entered is too low) is shown on the display. 3. The minimum or maximum possible values are then shown on the display which can be entered for the pulse value (see table).</p> <p><i>Display of numerical values:</i> Due to the limited size of the display, values are shown in a special way.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Basic value</p> </div> <div style="text-align: left;"> <p>Multiplication factor</p> <p>E 9 = 10^9 = 1000000000 E 3 = 10^3 = 1000 E 2 = 10^2 = 100 E 1 = 10^1 = 10 E 0 = 10^0 = 1 E-1 = 10^{-1} = 0.1 E-2 = 10^{-2} = 0.01 E-3 = 10^{-3} = 0.001 E-9 = 10^{-9} = 0.000000001</p> </div> </div> <p>Examples:</p> <div style="background-color: #f0f0f0; padding: 5px; margin-top: 10px;"> <p>$4.600\ E-2 = 4.600 \times 10^{-2} = 0.046\ [m^3/pulse]$ $4.600\ E\ 2 = 4.600 \times 10^{+2} = 460.0\ [m^3/pulse]$</p> </div>

Display limits / Pulse value									
DN	Liter		m ³		USgal		USgal × 1000		
	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	
2	7.853 E-5	9.999 E 9	7.853 E-8	9.999 E 6	2.075 E-5	2.641 E 9	2.075 E-8	2.641 E 6	
4	3.141 E-4	9.999 E 9	3.141 E-7	9.999 E 6	8.300 E-5	2.641 E 9	8.300 E-8	2.641 E 6	
8	1.256 E-3	9.999 E 9	1.256 E-6	9.999 E 6	3.320 E-4	2.641 E 9	3.320 E-7	2.641 E 6	
15	4.417 E-3	9.999 E 9	4.417 E-6	9.999 E 6	1.167 E-3	2.641 E 9	1.167 E-6	2.641 E 6	
25	1.227 E-2	9.999 E 9	1.227 E-5	9.999 E 6	3.242 E-3	2.641 E 9	3.242 E-6	2.641 E 6	
32	2.010 E-2	9.999 E 9	2.010 E-5	9.999 E 6	5.312 E-3	2.641 E 9	5.312 E-6	2.641 E 6	
40	3.141 E-2	9.999 E 9	3.141 E-5	9.999 E 6	8.300 E-3	2.641 E 9	8.300 E-6	2.641 E 6	
50	4.908 E-2	9.999 E 9	4.908 E-5	9.999 E 6	1.296 E-2	2.641 E 9	1.296 E-5	2.641 E 6	
65	8.295 E-2	9.999 E 9	8.295 E-5	9.999 E 6	2.191 E-2	2.641 E 9	2.191 E-5	2.641 E 6	
80	1.256 E-1	9.999 E 9	1.256 E-4	9.999 E 6	3.320 E-2	2.641 E 9	3.320 E-5	2.641 E 6	
100	1.963 E-1	9.999 E 9	1.963 E-4	9.999 E 6	5.187 E-2	2.641 E 9	5.187 E-5	2.641 E 6	
125	3.067 E-1	9.999 E 9	3.067 E-4	9.999 E 6	8.105 E-2	2.641 E 9	8.105 E-5	2.641 E 6	
150	4.417 E-1	9.999 E 9	4.417 E-4	9.999 E 6	1.167 E-1	2.641 E 9	1.167 E-4	2.641 E 6	
200	7.853 E-1	9.999 E 9	7.853 E-4	9.999 E 6	2.075 E-1	2.641 E 9	2.075 E-4	2.641 E 6	
250	1.227 E 0	9.999 E 9	1.227 E-3	9.999 E 6	3.242 E-1	2.641 E 9	3.242 E-4	2.641 E 6	
300	1.767 E 0	9.999 E 9	1.767 E-3	9.999 E 6	4.668 E-1	2.641 E 9	4.668 E-4	2.641 E 6	
350	2.405 E 0	9.999 E 9	2.405 E-3	9.999 E 6	6.354 E-1	2.641 E 9	6.354 E-4	2.641 E 6	
400	3.141 E 0	9.999 E 9	3.141 E-3	9.999 E 6	8.300 E-1	2.641 E 9	8.300 E-4	2.641 E 6	
450	3.976 E 0	9.999 E 9	3.976 E-3	9.999 E 6	1.050 E 0	2.641 E 9	1.050 E-3	2.641 E 6	
500	4.908 E 0	9.999 E 9	4.908 E-3	9.999 E 6	1.296 E 0	2.641 E 9	1.296 E-3	2.641 E 6	
600	7.068 E 0	9.999 E 9	7.068 E-3	9.999 E 6	1.867 E 0	2.641 E 9	1.867 E-3	2.641 E 6	
700	9.621 E 0	9.999 E 9	9.621 E-3	9.999 E 6	2.541 E 0	2.641 E 9	2.541 E-3	2.641 E 6	
750	1.104 E 1	9.999 E 9	1.104 E-2	9.999 E 6	2.918 E 0	2.641 E 9	2.918 E-3	2.641 E 6	
800	1.256 E 1	9.999 E 9	1.256 E-2	9.999 E 6	3.320 E 0	2.641 E 9	3.320 E-3	2.641 E 6	
900	1.590 E 1	9.999 E 9	1.590 E-2	9.999 E 6	4.201 E 0	2.641 E 9	4.201 E-3	2.641 E 6	
1000	1.963 E 1	9.999 E 9	1.963 E-2	9.999 E 6	5.187 E 0	2.641 E 9	5.187 E-3	2.641 E 6	
1050	2.164 E 1	9.999 E 9	2.164 E-2	9.999 E 6	5.719 E 0	2.641 E 9	5.719 E-3	2.641 E 6	
1200	2.827 E 1	9.999 E 9	2.827 E-2	9.999 E 6	7.470 E 0	2.641 E 9	7.470 E-3	2.641 E 6	
1350	3.578 E 1	9.999 E 9	3.578 E-2	9.999 E 6	9.454 E 0	2.641 E 9	9.454 E-3	2.641 E 6	
1400	3.848 E 1	9.999 E 9	3.848 E-2	9.999 E 6	1.016 E 1	2.641 E 9	1.016 E-2	2.641 E 6	
1500	4.417 E 1	9.999 E 9	4.417 E-2	9.999 E 6	1.167 E 1	2.641 E 9	1.167 E-2	2.641 E 6	
1600	5.026 E 1	9.999 E 9	5.026 E-2	9.999 E 6	1.328 E 1	2.641 E 9	1.328 E-2	2.641 E 6	
1700	5.674 E 1	9.999 E 9	5.674 E-2	9.999 E 6	1.499 E 1	2.641 E 9	1.499 E-2	2.641 E 6	
1800	6.361 E 1	9.999 E 9	6.361 E-2	9.999 E 6	1.680 E 1	2.641 E 9	1.680 E-2	2.641 E 6	
2000	7.853 E 1	9.999 E 9	7.853 E-2	9.999 E 6	2.075 E 1	2.641 E 9	2.075 E-2	2.641 E 6	

The last figure of the above values can differ by ±1 from the value shown on the display (error in rounding off)!

Min. pulse values at v = 10 m/s and f = 400 Hz

Factory settings → see page 72

Function group STATUS OUTPUT – StAt_out / Gr 30																										
<p>StAt_Fct Fu 31</p> <p>Status output function</p>	<p>Select or assign the function of the status output.</p> <div style="display: flex; align-items: flex-start; margin-top: 10px;"> <div style="margin-right: 10px;"> </div> <div> <p><i>Error</i> Indicates system/process errors (for definition: see page 49)</p> <p><i>FLo_dir</i> Indicates direction of flow</p> <p><i>CANCEL</i></p> </div> </div> <p>Notes!</p> <ul style="list-style-type: none"> The status output acts as a normally closed contact, i.e. in normal operation, free from fault, the output is closed (transistor conducting, see table). The behaviour of the outputs in the event of a fault is described on page 49. Process/system errors are <i>always</i> shown on the local display, independent of the status output configuration. 																									
 Note!	<table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="width: 25%; padding: 5px;">Configuration of status output</th> <th style="width: 25%; padding: 5px;">Status</th> <th style="width: 25%; padding: 5px;">Response Transistor</th> <th style="width: 25%; padding: 5px;"> </th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="padding: 5px; vertical-align: top;">System / process error message (<i>Error</i>)</td> <td style="padding: 5px;">System OK</td> <td style="padding: 5px;">closed</td> <td style="padding: 5px;"> </td> </tr> <tr> <td style="padding: 5px;">Fault indication</td> <td style="padding: 5px;">open</td> <td style="padding: 5px;"> </td> </tr> <tr> <td style="padding: 5px;">Supply failure</td> <td style="padding: 5px;">open</td> <td style="padding: 5px;"> </td> </tr> <tr> <td rowspan="2" style="padding: 5px; vertical-align: top;">Flow direction indication (<i>FLo_dir</i>)</td> <td style="padding: 5px;"> forward </td> <td style="padding: 5px;">open</td> <td style="padding: 5px;"> </td> </tr> <tr> <td style="padding: 5px;"> reverse </td> <td style="padding: 5px;">closed</td> <td style="padding: 5px;"> </td> </tr> <tr> <td colspan="2" style="padding: 5px;"></td> <td colspan="2" style="padding: 5px;"> "closed" → Transistor conductive "open" → Transistor non-conductive </td> </tr> </tbody> </table>	Configuration of status output	Status	Response Transistor		System / process error message (<i>Error</i>)	System OK	closed		Fault indication	open		Supply failure	open		Flow direction indication (<i>FLo_dir</i>)	forward 	open		reverse 	closed				"closed" → Transistor conductive "open" → Transistor non-conductive	
Configuration of status output	Status	Response Transistor																								
System / process error message (<i>Error</i>)	System OK	closed																								
	Fault indication	open																								
	Supply failure	open																								
Flow direction indication (<i>FLo_dir</i>)	forward 	open																								
	reverse 	closed																								
		"closed" → Transistor conductive "open" → Transistor non-conductive																								
<p>“Unidirectional” or “bidirectional” operating mode:</p> <p>Promag 30 measuring system can operate either bidirectionally or in one direction only. Selecting the operating mode is, however, directly coupled with the configuration of the status output.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="width: 33%; padding: 5px;"><i>Status output</i></th> <th style="width: 33%; padding: 5px;"><i>Operating mode</i></th> <th style="width: 33%; padding: 5px;"><i>Current / pulse output</i></th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">“<i>FLo_dir</i>” (Flow direction)</td> <td style="padding: 5px;">bidirectional</td> <td style="padding: 5px;">always active (signal output in both flow directions)</td> </tr> <tr> <td style="padding: 5px;">“<i>Error</i>” (Fault indication)</td> <td style="padding: 5px;">unidirectional</td> <td style="padding: 5px;">active only with positive flow direction (no signal output with negative flow, reverse)</td> </tr> </tbody> </table> <p style="text-align: center; margin-top: 10px;">Negative flows are shown on the display by a negative sign.</p>		<i>Status output</i>	<i>Operating mode</i>	<i>Current / pulse output</i>	“ <i>FLo_dir</i> ” (Flow direction)	bidirectional	always active (signal output in both flow directions)	“ <i>Error</i> ” (Fault indication)	unidirectional	active only with positive flow direction (no signal output with negative flow, reverse)																
<i>Status output</i>	<i>Operating mode</i>	<i>Current / pulse output</i>																								
“ <i>FLo_dir</i> ” (Flow direction)	bidirectional	always active (signal output in both flow directions)																								
“ <i>Error</i> ” (Fault indication)	unidirectional	active only with positive flow direction (no signal output with negative flow, reverse)																								

Function group AUXILIARY INPUT – InPut / Gr40	
<p>InP_Fct Fu 41</p> <p>Auxiliary input function</p>	<p>Select or assign the auxiliary input function. The appropriate function is actuated by applying an external voltage (3...30 V DC) at the auxiliary input.</p> <p> SUPPRESS Measured value suppression (Positive Zero Return): By activating the Positive Zero Return, the measuring mode is interrupted and all output signals are reset to defined values (~zero flow). <i>Examples:</i> Interruption measurement to clean the piping.</p> <p>Response of display with active suppression: "rRtE" → Display with 8 vertical bars. "tOtAL" → Display segment "Low flow cutoff" is shown (if creep suppression is activated).</p> <p>rES_tOt Totalizer is reset to "0". (The totalizer can also be reset by using the function "rES_tOt" resp. "Fu51").</p> <p>CANCEL</p>
Function group DISPLAY – dISPLAY / Gr50	
<p>rES_tOt Fu 51</p> <p>Reset totalizer</p>	<p>Reset the totalizer to '0'.</p> <p>Notes!</p> <ul style="list-style-type: none"> The totalizer and its overruns are set to zero with this function. The totalizer can also be reset using the auxiliary input (see function <i>InP_Fct / Fu 41</i>). <p> CANCEL Cancel  rES_YES Reset totalizer (press [E])</p>
<p>dISP_opt Fu 52</p> <p>Display mode</p>	<p>Select the display mode (e.g. display of flow rate or display of totalizer, etc.).</p> <p> rRtE Display flow  tOtAL Display totalizer (counter status) ALtErnALt Display flow <i>and</i> totalizer (alternating) tEst Display test function * CANCEL</p> <p>* An automatic test of all display elements is carried out with this function (Start with [E]). The following displays are shown one after the other: 1. +θ.θ.θ.θ.θ.θ.θ.θ. (all display segments visible) 2. -θ θ θ θ θ θ θ θ (no display segments visible) 3. No display elements visible at all.</p>
<p>dISP_dR Fu 53</p> <p>Display damping (Flow rate)</p>	<p>Selecting the time constant determines whether the current output signal reacts very quickly to rapidly changing flows or is dampened:</p> <ul style="list-style-type: none"> small time constant → display with quick reaction large time constant → display with dampened reaction <p>Note! The display damping does not affect the response of the current output.</p> <p> Numeric entry: 0.5...20 [s] in steps of 0.5 s</p>



Note!



Note!

Function group DISPLAY - DISPLAY / Gr 50	
<p>tot_ofL Fu 54</p> <p>Totalizer overflows</p>	<p>Display of totalizer overflows. On the display the totalized flow is shown as a max. 8-digit number. Larger numerical values (> 99999999) can be read off in this function as overflows. The effective amount is therefore calculated from the sum of overflows and the actual displayed counter status (display mode → totAL).</p> <p><i>Example:</i> Display of 2 overflows: 2 Actual displayed value for totalized sum: 00004321 [m³] Total amount: 200004321 [m³]</p>
Function group PROCESS PARAMETERS - PROCESS / Gr 60	
<p>LFC Fu 61</p> <p>Creep suppression</p>	<p>Switching on or off the creep suppression (Low flow cutoff). The creep suppression prevents the flow in the lowest measuring range from being detected e.g. with varying liquid head at standstill. With variations in flow in the lower part of the measuring range, the hysteresis (50% of creepage) prevents continual switching on and off of the creep suppression function.</p> <p>Switch-on point (1) When the velocity of the fluid is less than 0.02 m/s creep suppression is then <i>activated</i> and all output signals such as pulse and analogue signals, are set to the fall back value (0/4 mA, logical '0'). The segment for "Low flow cutoff" is then immediately visible on the LC display.</p> <p>Switch-off point (2) When the velocity of the fluid again exceeds $v = 0.04$ m/s, then creep suppression is <i>deactivated</i>.</p> <p> <input type="checkbox"/> LFC_off Switch-off creep suppression <input type="checkbox"/> LFC_on Switch-on creep suppression CRNCEL </p>

ba039y38

Switch-on and switch-off points (creepage)						
Diameter	On	Off	On	Off	On	Off
DIN	[l/s]		[m ³ /h]		[USgpm]	
2	0.00006	0.0001	0.0002	0.0005	0.001	0.002
4	0.0003	0.0005	0.0009	0.0018	0.004	0.008
8	0.001	0.002	0.004	0.007	0.016	0.032
15	0.003	0.007	0.013	0.025	0.056	0.112
25	0.010	0.020	0.035	0.071	0.156	0.311
32	0.016	0.032	0.058	0.116	0.255	0.510
40	0.025	0.050	0.090	0.181	0.398	0.797
50	0.039	0.079	0.141	0.283	0.622	1.245
65	0.066	0.132	0.239	0.478	1.052	2.104
80	0.101	0.201	0.362	0.724	1.593	3.187
100	0.157	0.314	0.565	1.131	2.490	4.980
125	0.245	0.491	0.884	1.767	3.890	7.781
150	0.353	0.707	1.272	2.545	5.602	11.204
200	0.628	1.257	2.262	4.524	9.960	19.918
250	0.982	1.963	3.534	7.069	15.561	31.122
300	1.413	2.827	5.089	10.179	22.408	44.816
350	1.924	3.848	6.927	13.854	30.500	61.000
400	2.513	5.026	9.048	18.096	39.836	79.672
450	3.180	6.362	11.451	22.902	50.418	100.835
500	3.926	7.854	14.137	28.274	62.244	124.488
600	5.654	11.310	20.358	40.715	89.631	179.263
700	7.696	15.394	27.709	55.418	122.000	243.997
750	8.836	17.671	31.809	63.617	140.049	280.098
800	10.053	20.106	36.191	72.382	159.345	318.690
900	12.723	25.447	45.804	91.609	201.671	403.342
1000	15.708	31.416	56.549	113.097	248.976	497.953
1050	17.318	34.636	62.345	124.690	274.496	548.993
1200	22.619	45.239	81.443	162.860	358.526	717.052
1350	28.628	57.255	103.060	206.120	453.759	907.519
1400	30.788	61.575	110.836	221.672	487.994	975.987
1500	35.343	70.686	127.234	254.469	560.197	1120.393
1600	40.212	80.425	144.764	289.528	637.379	1274.759
1700	45.396	90.792	163.425	326.851	719.541	1439.083
1800	50.894	101.788	183.218	366.436	806.683	1613.366
2000	62.832	125.664	226.194	452.388	995.905	1991.810

On and off switch points are fixed values:
 Switch-on point → at v = 0.02 m/s
 Switch-off point → at v = 0.04 m/s

Function group
PROCESS PARAMETERS – PROCESSES / GR60

EPD
Fu 62

Empty Pipe
Detection



Note!

With this function (EPD = Empty Pipe Detection), two procedures can always be activated:

- Carrying out the empty and full pipe adjustment for Empty Pipe Detection
- Switching on/off Empty Pipe Detection (EPD).

Note!

- This function is available only if the sensor is fitted with an extra EPD electrode (see "Technical Data", page 69).
- The EPD function is not available with the remote "FL" version.
- The connection cable with the remote "FS" version may only be a maximum of 10 m long. Only then can correct functioning of the EPD be guaranteed!
- The EPD function is switched off when the flowmeter is delivered and must be switched on manually when required.



EPd_oFF EPD switched off

EPd_on EPD switched on

(This selection is only displayed if the EPD adjustment has already been carried out successfully.

If the adjustment is incorrect then the message "Adj_Err" is shown instead)


EPd_Ad_E Start empty pipe adjustment (confirm with **[E]**)

EPd_Ad_F Start full pipe adjustment (confirm with **[E]**)

CRCEL

Remarks on Empty Pipe Detection (EPD)

Only a completely full measuring tube enables correct readings to be obtained. This can be continuously checked by Empty Pipe Detection. EPD is based on measuring the conductivity of the fluid (see Figure).



Response when partially full

If the EPD is active and responds due to a partially filled or empty pipe, the display segment "Empty Pipe" is shown on the display. The outputs respond in such cases as described on page 49.

When the pipe is partially filled and the EPD is not active, then the response may be different for identical plants:

- varying flow display
- zero flow
- excess flow values

(Continued next page)

Function group PROCESS PARAMETERS – P r o C E S S / G r 6 0	
EPD F u 6 2	<p>Procedure (Empty pipe / full pipe adjustment)</p> <p>Notes!</p> <ul style="list-style-type: none"> • If Promag 30 is fitted with an EPD electrode, then the unit is already calibrated in the factory with drinking water (500 µS/cm). A new empty pipe or full pipe adjustment is to be carried out on site when liquids having different conductivities are used. • Every (new) adjustment automatically switches off the EPD function. • The EPD function can only be switched on (again) if empty or full pipe adjustment has been successfully carried out. <ol style="list-style-type: none"> 1. Empty the piping. For the empty pipe adjustment to be carried out now, the walls of the measuring tube should be wetted with fluid. 2. Start the empty pipe adjustment: Select EPd_Ad_E and confirm with [E]. – Display during adjustment: RDJ_bu5y – Display after adjustment: RDJ_donE 3. Fill the piping with fluid. 4. Start the full pipe adjustment with the fluid stationary: Select EPd_Ad_F and confirm with [E]. – Display during adjustment: RDJ_bu5y – Display after adjustment: RDJ_donE 5. Switch on the Empty Pipe Detection after the adjustment → Select EPd_on and confirm with [E]. <p>Note!</p> <p>The EPD function can only be switched on (again) if empty or full pipe adjustment has been successfully carried out. If the adjustment is not successful then the message RDJ_Err is shown instead of "EPd_on". In such cases the empty or full pipe adjustment must again be carried out.</p> <p><i>Possible sources of error:</i></p> <ul style="list-style-type: none"> – Empty pipe adjustment has been carried out when the pipe was full. – Full pipe adjustment was carried out when the pipe was empty or partially filled.



Note!



Note!


Function group PROCESS PARAMETERS – P r o C E S S / G r 6 0	
<p>ECC F u 6 3</p> <p> Note!</p> <p>Electrode cleaning</p> <p> Note!</p> <p> Caution!</p>	<p>Switching on and off the electrode cleaning circuit (ECC).</p> <p>Note!</p> <ul style="list-style-type: none"> • This function is only available if the Promag 30 is fitted with an electrode cleaning function (optional). • The ECC function is not available with the remote "FL" version. • The ECC is always switched on when first delivered from the factory. <p> ECC_off ECC switched off  ECC_on ECC switched on CRCEL</p> <p>Remarks on ECC: Conductive build-up on the electrodes and the measuring tube walls (e.g. magnetite) can cause measurement errors. The Electrode Cleaning Circuit (ECC) has been developed in order to prevent build-up occurring. The cleaning cycle repeats itself every 30 minutes for approx. 3 seconds. The ECC works in the way described for all electrode materials available except tantalum. If the electrode material is tantalum then the ECC only protects the electrode surface from oxidation.</p> <p>Note! After the electrode cleaning procedure is completed, the signal outputs may be unsteady for a little while. This is due to electrochemical potentials caused by electrostatic charging of the fluid during the cleaning cycle. The set recovery time of approx. 2 seconds is generally sufficient to stabilise the signal output after the cleaning phase. During the recovery time the last value registered before cleaning is given.</p> <p>Caution! If the ECC is switched off for a long period of time in an application where there is a conductive build-up in the measuring tube, then this can lead to errors. If there is a large concentration of build-up at one point, then, under certain circumstances, switching on the ECC may not remove it. In such cases the flowmeter is to be cleaned and the build-up removed.</p>

7 Trouble-shooting, Maintenance and Repairs

7.1 Response of the measuring system on faults or alarm

The Promag 30 distinguishes between two kinds of error:

- System error: instrument failure, power failure (Error)
- Process error: partially filled pipe (Empty Pipe), measuring range exceeded (Overflow)



Errors which occur during normal operation are indicated on the display by appropriate *segment bars* ("Error, Empty Pipe, Overflow").

The error response of the outputs is described in the following table.

Positive Zero Return <i>not</i> activated					
	Current output		Pulse output	Status output (transistor)	
	"0-20"	"4-20"		"Error"	"FLo_dlr"
No System / process error present	measurement OK (signal for flow)	measurement OK (signal for flow)	measurement OK (signal for flow)	conductive (closed)	forward: non-conductive (open) reverse: conductive (closed)
System or process error present	0 mA	2 mA	no signal output (0 Hz) non-conductive (open)	non-conductive (open)	status kept before error occurred: forward: non-conductive (open) reverse: conductive (closed)

Positive Zero Return <i>activated</i>					
	Current output		Pulse output	Status output (transistor)	
	"0-20"	"4-20"		"Error"	"FLo_dlr"
No System and process errors present	0 mA	4 mA	no signal output (0 Hz) non-conductive (open)	conductive (closed)	conductive (closed)
System error only present	0 mA	2 mA		non-conductive (open)	
Process error only present	0 mA	4 mA		conductive (closed)	
System and process error present	0 mA	2 mA		non-conductive (open)	

7.2 Trouble-shooting and remedy

All instruments undergo various stages of quality control during production. The last of these stages is the wet calibration carried out on state-of-the-art calibration rigs.

The following summary helps to identify possible causes of error during normal measurement. An LED on the amplifier board is lit as long as the measuring system is operating normally.



Warning!

Warning!

This error diagnosis cannot be carried out with Ex instruments as they must be opened and thus the ignition protection type is no longer present.

Type of error	Remedy (Steps 1 → 2 → 3)
<p style="text-align: center;">↓</p> <ul style="list-style-type: none"> - No display - No output signal - LED on amplifier board is not lit 	<ul style="list-style-type: none"> 1 Check the power supply → terminals 1, 2 2 Check fuse → see page 23 85...260 V AC: 1 A slow-blow 20...55 V AC and 16...62 V DC: 2.5 slow-blow 3 Replace electronics → see page 54
<p style="text-align: center;">↓</p> <p>The display is blank, with outputs still functioning</p>	<ul style="list-style-type: none"> 1 Check the ribbon cable connector of the display module → see page 54 (No. 3b) 2 Replace display module → see page 54 3 Replace electronics → see page 54
<p style="text-align: center;">↓</p> <p>No signal (current or pulse output) despite display showing value?</p>	<ul style="list-style-type: none"> 1 Check the ribbon cable connector to the terminal compartment → see page 54 (No. 8) 2 Replace electronics → see page 54
<p style="text-align: center;">↓</p> <p>Is the message "Overflow" shown on the display?</p>	<ul style="list-style-type: none"> 1 Is the measuring tube empty? If yes → fill measuring tube 2 Check ground and potential equalisation → see page 29 3 Is the flow velocity >12.5 m/s? If yes → reduce flow
<p style="text-align: center;">↓</p> <p>Is the message "Empty Pipe" shown on the display although the measuring tube is full?</p>	<ul style="list-style-type: none"> 1 Carry out an empty or full pipe adjustment and then switch on Empty Pipe Detection → see page 46 ff. 2 Check the following connections: <ul style="list-style-type: none"> • Electronics: EPD cable → see page 54 (No. 5c) • Remote version: EPD cable → see page 27 (terminals 36 and 37) 3 If the measuring tube is always full (pressure line): → Switch off function EPD / Full 2 → see page 46

↓

Continued next page

Type of error	Remedy (Steps 1 → 2 → 3)
<p>Is the message "Error" shown on the display?</p>	<p>1 Check the following connections on the amplifier board → see page 54:</p> <ul style="list-style-type: none"> • Electrode signal cable → No. 5a • DAT module → No. 5b • Coil current cable → No. 7 <p>2 Replace electronics → see page 54</p>
<p>Does the instrument show negative flow values although the fluid in the piping is flowing forwards?</p>	<p>1 Remote version → switch off power supply and change round terminals 41 and 42.</p> <p>2 Set status output (function <i>5 t R t _ F C t</i>) to <i>"FL o _ d i r"</i> → see page 42</p>
<p>Is the display unsettled despite continuous flow?</p>	<p>1 Check ground and potential equalisation → see page 29</p> <p>2 Check to see if air bubbles are in the fluid.</p> <p>3 Increase the time constant for the current output → see page 40 Increase the display damping for flow → see page 43</p>
<p>Is a low flow indicated despite standstill of the fluid and filled measuring tube?</p>	<p>1 Check ground and potential equalisation → see page 29</p> <p>2 Check to see if air bubbles are in the fluid.</p> <p>3 Activate creep suppression (function <i>L F C / F u 6 1</i>) → see page 44</p>
<p>The error cannot be remedied or else there is another error display.</p> <p>In such cases please contact your local E+H Service organisation.</p>	<p>→ The following solutions are possible:</p> <p>Request an E+H service technician The following information is required when contacting a customer service technician:</p> <ul style="list-style-type: none"> – brief description of the error – order code given on the nameplate → see page 7, 8 <p>Repair Note the procedures on page 55 "Repairs" before returning the instrument for repair. Please state a brief description of the error on the delivery note.</p> <p>Replacing the electronics If a new electronic plug-in board is ordered, we require the full order code which can be taken from the instrument order structure:</p> <p><i>Order structure (Promag 30)</i></p> <p>30 - - - - - - - - -</p> <p style="margin-left: 100px;">└───┬───┘</p> <p>30 X MOD - □ □ □ □ <i>Order code: Electronic plug-in board</i></p> <p>The last four places correspond to the order code on the nameplate of the transmitter → see page 7.</p>

7.3 Replacing the measuring electrodes

The Promag F (DN 350...2000) is available with replacement electrodes as an option. This version enables the measuring electrodes to be cleaned or replaced under process conditions.




Fig. 35
Replacement unit for changing
electrodes

Dismantling the electrode

1. Loosen the Allen screw (a) and remove the cover.
2. Unscrew the electrode cable (c) attached to the rotary arm (b).
3. Undo the knurled nut (d) by hand. This nut is used as a counter nut.
4. Remove the electrode (e) using the rotary arm (b). This can now be taken out from the holder (g) as far as the stop allows.

Warning!

Danger of injury! Under process condition (piping under pressure) the electrode can spring back to the stop. Keep pressing against while loosening.



Warning!

5. Close the shut-off valve (f) after the electrode has been taken out as far as the stop.

Warning!

Do not attempt to open the shut-off valve. Keeping it shut prevents fluid from escaping.



Warning!

6. Unscrew the entire electrode along with the holding cylinder (g).
7. Remove the rotary arm (b) from the electrode (e), while pressing to remove the locking pin (h). Take care not to lose the coil spring (k).
8. Replace the old electrode with a new electrode.
A set of replacement electrodes can be ordered from Endress+Hauser.

Assembling the electrode

1. Slide the new electrode (e) into the holding cylinder (g) from below. Ensure that gaskets at the tip of the electrode are clean.
2. Put the rotary arm (b) on the electrode and secure with the locking pin (h).

Caution!

Ensure that the coil spring (k) is in place. This ensures close electrical contact and thus reliable measuring signals.



Caution!

3. Pull back the electrode as far as possible so that the tip does not protrude out from the holding cylinder (g).
4. Screw the holding cylinder onto the shut-off unit (i) and tighten by hand. Gasket (j) on the holding cylinder must be in place and clean.

Note!

Ensure that the rubber tubes on the holding cylinder (g) and shut-off valve (f) have the same colour (red or blue)



Note!

5. Open the shut-off valve (f) and screw in the electrode using the rotary arm (b) until the stop.
6. Screw the knurled nut (d) onto the holding cylinder. This clamps the electrode tight.
7. Screw the electrode cable (c) to the rotary arm (b) using the Allen screw.

Caution!

Ensure that the Allen screw of the electrode cable is tight. This ensures close electrical contact and thus reliable measuring signals.



Caution!

8. Replace the cover and tighten the Allen screw (a).

7.4 Replacing the transmitter electronics



Warning!

Warning!

- Danger from electric shock! Switch off the power supply before opening the transmitter housing.
 - When using Ex instruments, they must first cool down for at least 10 minutes before opening.
 - The local power supply voltage and frequency must be the same as the technical specifications of the power supply boards.
 - Ensure that the new electronics board is the same as the old one before replacing it (power supply, version of amplifier and software).
1. Loosen the Allen screws of the safety grip (3-mm Allen key).
 2. Unscrew the cover of the electronics area of the transmitter housing.
 3. Remove the local display as follows:
 - a. Loosen the mounting screws of the display module.
 - b. Unplug the ribbon cable of the display from the amplifier board.
 4. Unplug the 2-pole plug of the power supply cable (by pressing down the catch) from the power supply board.
 5. Remove the electrode signal cable from the amplifier board:
 - a. Remove the cable board.
 - b. Remove the blue DAT module.
 - c. Loosen the EPD cable from the screw terminals.
 6. Loosen the two Phillips screws of the board support plate. Carefully remove the support plate approx. 4...5 cm out of the transmitter housing.
 7. Remove the coil current cable plug from the power supply board.
 8. Remove the ribbon cable plug (connection cable to the terminal area) from the amplifier board.
 9. The entire transmitter electronics, together with the board support plate, can now be completely removed from the housing.
 10. Replace the old transmitter electronics with new transmitter electronics.
 11. Reassemble in reverse sequence.

Replacing the DAT module (see 5b):

- Procedure for replacing the transmitter electronics → plug the old DAT onto the new amplifier board.
- Procedure for replacing a defective DAT → plug the new DAT onto the old amplifier board.

DAT = Replaceable data module in which the basic data of the sensor are stored (see page 70).




Fig. 36
Replacing the transmitter electronics:

A Power supply board
B Amplifier board

7.5 Replacing the fuse

Warning!

- Danger from electric shock! Switch off the power supply before unscrewing the cover of the terminal compartment from the transmitter housing.



The instrument fuse can be found in the terminal compartment → see page 23

Exclusively use the following types of fuses:

- Power supply 20...55 V AC / 16...62 V DC → 2.5 A slow-blow / 250 V; 5.2 × 20 mm
- Power supply 85...260 V AC → 1 A slow-blow / 250 V; 5.2 × 20 mm

7.6 Repairs

Please carry out the following procedure before returning the Promag 30 for repair to Endress+Hauser:

- A note must always be enclosed with the instrument, giving the following information:
 - Brief description of the error
 - Description of the application
 - Chemical and physical properties of the fluid
- Remove all residue which may be present. Pay special attention to the gasket grooves and crevices where fluid may be present. This is especially important if the fluid is dangerous to health, e.g. corrosive, carcinogenic, radioactive, etc.

Warning!

We must request you not to return a unit if it is not completely certain that harmful substances can be removed e.g. cracks have been penetrated or substances have diffused through plastics.

Incomplete cleaning of the instrument may result in waste disposal or cause harm to personnel (burns, etc.). Any costs arising from this will be charged to the owner of the instrument.



7.7 Spare parts

The electronics plug-in module of the Promag 30 can be ordered separately as a spare part:

- Replacement → see page 54
- Order code → see page 51

7.8 Maintenance

No special maintenance is necessary for the Promag 30 measuring system.

8 Dimensions

8.1 Dimensions Promag 30 A











Fig. 37
Dimensions Promag 30 A

Weights:

Compact version	5 kg (without process connections)
Promag 30 transmitter	3 kg (5 kg for wall mounted version)
Promag A sensor	2 kg

Dimensions of the process connections for Promag A

Internal thread standard thread: ISO 228/DIN 2999		y43-01...08	<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>L1</th> <th>Thread</th> </tr> </thead> <tbody> <tr> <td>2...15</td> <td>20</td> <td>18</td> <td>1/2"</td> </tr> <tr> <td>2...15</td> <td>20</td> <td>18</td> <td>1/2" NPT</td> </tr> <tr> <td>25</td> <td>45</td> <td>22</td> <td>1"</td> </tr> <tr> <td>25</td> <td>45</td> <td>22</td> <td>1" NPT</td> </tr> </tbody> </table>	DN	L	L1	Thread	2...15	20	18	1/2"	2...15	20	18	1/2" NPT	25	45	22	1"	25	45	22	1" NPT									
			DN	L	L1	Thread																										
2...15	20	18	1/2"																													
2...15	20	18	1/2" NPT																													
25	45	22	1"																													
25	45	22	1" NPT																													
<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>L1</th> <th>di</th> <th>Thread</th> </tr> </thead> <tbody> <tr> <td>2...15</td> <td>35</td> <td>13.2</td> <td>16.1</td> <td>1/2"</td> </tr> <tr> <td>2...15</td> <td>42</td> <td>20.0</td> <td>16.1</td> <td>1/2" NPT</td> </tr> <tr> <td>25</td> <td>50</td> <td>16.8</td> <td>22.0</td> <td>1"</td> </tr> <tr> <td>25</td> <td>60</td> <td>25.0</td> <td>22.0</td> <td>1" NPT</td> </tr> </tbody> </table>	DN	L	L1	di	Thread	2...15	35	13.2	16.1	1/2"	2...15	42	20.0	16.1	1/2" NPT	25	50	16.8	22.0	1"	25	60	25.0	22.0	1" NPT							
DN	L	L1	di	Thread																												
2...15	35	13.2	16.1	1/2"																												
2...15	42	20.0	16.1	1/2" NPT																												
25	50	16.8	22.0	1"																												
25	60	25.0	22.0	1" NPT																												
External thread standard thread: ISO 228/DIN 2999		<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>2...15</td> <td>19</td> <td>20.0</td> <td>20 · 2</td> </tr> <tr> <td>2...15</td> <td>20</td> <td>21.5</td> <td>1/2"</td> </tr> <tr> <td>25</td> <td>66</td> <td>25.0</td> <td>25 · 2</td> </tr> <tr> <td>25</td> <td>69</td> <td>32.0</td> <td>32 · 2.5</td> </tr> <tr> <td>25</td> <td>69</td> <td>33.5</td> <td>1"</td> </tr> </tbody> </table>	DN	L	D	Pipe connection	2...15	19	20.0	20 · 2	2...15	20	21.5	1/2"	25	66	25.0	25 · 2	25	69	32.0	32 · 2.5	25	69	33.5	1"						
		DN	L	D	Pipe connection																											
2...15	19	20.0	20 · 2																													
2...15	20	21.5	1/2"																													
25	66	25.0	25 · 2																													
25	69	32.0	32 · 2.5																													
25	69	33.5	1"																													
<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>di</th> <th>LW</th> </tr> </thead> <tbody> <tr> <td>2...15</td> <td>30</td> <td>14.5</td> <td>8.9</td> <td>13</td> </tr> <tr> <td>2...15</td> <td>30</td> <td>17.5</td> <td>12.6</td> <td>16</td> </tr> <tr> <td>2...15</td> <td>30</td> <td>21.0</td> <td>16.1</td> <td>19</td> </tr> </tbody> </table> <p>LW = Internal diameter hose</p>	DN	L	D	di	LW	2...15	30	14.5	8.9	13	2...15	30	17.5	12.6	16	2...15	30	21.0	16.1	19												
DN	L	D	di	LW																												
2...15	30	14.5	8.9	13																												
2...15	30	17.5	12.6	16																												
2...15	30	21.0	16.1	19																												
PVC adhesive coupling		<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>di</th> <th>LW</th> </tr> </thead> <tbody> <tr> <td>2...15</td> <td>30</td> <td>14.5</td> <td>8.9</td> <td>13</td> </tr> <tr> <td>2...15</td> <td>30</td> <td>17.5</td> <td>12.6</td> <td>16</td> </tr> <tr> <td>2...15</td> <td>30</td> <td>21.0</td> <td>16.1</td> <td>19</td> </tr> </tbody> </table>	DN	L	D	di	LW	2...15	30	14.5	8.9	13	2...15	30	17.5	12.6	16	2...15	30	21.0	16.1	19										
		DN	L	D	di	LW																										
2...15	30	14.5	8.9	13																												
2...15	30	17.5	12.6	16																												
2...15	30	21.0	16.1	19																												
<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>s</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>2...15</td> <td>20</td> <td>21.3</td> <td>2.6</td> <td>1/2"</td> </tr> <tr> <td>2...15</td> <td>20</td> <td>21.3</td> <td>2.6</td> <td>18 · 1</td> </tr> </tbody> </table>	DN	L	D	s	Pipe connection	2...15	20	21.3	2.6	1/2"	2...15	20	21.3	2.6	18 · 1																	
DN	L	D	s	Pipe connection																												
2...15	20	21.3	2.6	1/2"																												
2...15	20	21.3	2.6	18 · 1																												
Hose connection		<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>s</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>2...15</td> <td>20</td> <td>21.3</td> <td>2.6</td> <td>1/2"</td> </tr> <tr> <td>2...15</td> <td>20</td> <td>21.3</td> <td>2.6</td> <td>18 · 1</td> </tr> </tbody> </table>	DN	L	D	s	Pipe connection	2...15	20	21.3	2.6	1/2"	2...15	20	21.3	2.6	18 · 1															
		DN	L	D	s	Pipe connection																										
2...15	20	21.3	2.6	1/2"																												
2...15	20	21.3	2.6	18 · 1																												
<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>di</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>25</td> <td>30</td> <td>33.7</td> <td>26.0</td> <td>1"</td> </tr> <tr> <td>25</td> <td>30</td> <td>33.7</td> <td>26.0</td> <td>28 · 1</td> </tr> <tr> <td>25</td> <td>20</td> <td>25.4</td> <td>22.1</td> <td>25.4 · 1.6 / 1"</td> </tr> </tbody> </table>	DN	L	D	di	Pipe connection	25	30	33.7	26.0	1"	25	30	33.7	26.0	28 · 1	25	20	25.4	22.1	25.4 · 1.6 / 1"												
DN	L	D	di	Pipe connection																												
25	30	33.7	26.0	1"																												
25	30	33.7	26.0	28 · 1																												
25	20	25.4	22.1	25.4 · 1.6 / 1"																												
Welded nipple DN 2...15		<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>di</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>25</td> <td>30</td> <td>33.7</td> <td>26.0</td> <td>1"</td> </tr> <tr> <td>25</td> <td>30</td> <td>33.7</td> <td>26.0</td> <td>28 · 1</td> </tr> <tr> <td>25</td> <td>20</td> <td>25.4</td> <td>22.1</td> <td>25.4 · 1.6 / 1"</td> </tr> </tbody> </table>	DN	L	D	di	Pipe connection	25	30	33.7	26.0	1"	25	30	33.7	26.0	28 · 1	25	20	25.4	22.1	25.4 · 1.6 / 1"										
		DN	L	D	di	Pipe connection																										
25	30	33.7	26.0	1"																												
25	30	33.7	26.0	28 · 1																												
25	20	25.4	22.1	25.4 · 1.6 / 1"																												
<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>di</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>2...8</td> <td>24</td> <td>25.0</td> <td>9.5</td> <td>1/2"</td> </tr> <tr> <td>15</td> <td>24</td> <td>25.0</td> <td>16.0</td> <td>3/4"</td> </tr> <tr> <td>2...8</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>15</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>25</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> </tbody> </table>	DN	L	D	di	Pipe connection	2...8	24	25.0	9.5	1/2"	15	24	25.0	16.0	3/4"	2...8	24	50.4	22.1	1"	15	24	50.4	22.1	1"	25	24	50.4	22.1	1"		
DN	L	D	di	Pipe connection																												
2...8	24	25.0	9.5	1/2"																												
15	24	25.0	16.0	3/4"																												
2...8	24	50.4	22.1	1"																												
15	24	50.4	22.1	1"																												
25	24	50.4	22.1	1"																												
Welded nipple DN 25		<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>di</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>2...8</td> <td>24</td> <td>25.0</td> <td>9.5</td> <td>1/2"</td> </tr> <tr> <td>15</td> <td>24</td> <td>25.0</td> <td>16.0</td> <td>3/4"</td> </tr> <tr> <td>2...8</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>15</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>25</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> </tbody> </table>	DN	L	D	di	Pipe connection	2...8	24	25.0	9.5	1/2"	15	24	25.0	16.0	3/4"	2...8	24	50.4	22.1	1"	15	24	50.4	22.1	1"	25	24	50.4	22.1	1"
		DN	L	D	di	Pipe connection																										
2...8	24	25.0	9.5	1/2"																												
15	24	25.0	16.0	3/4"																												
2...8	24	50.4	22.1	1"																												
15	24	50.4	22.1	1"																												
25	24	50.4	22.1	1"																												
<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>di</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>2...8</td> <td>24</td> <td>25.0</td> <td>9.5</td> <td>1/2"</td> </tr> <tr> <td>15</td> <td>24</td> <td>25.0</td> <td>16.0</td> <td>3/4"</td> </tr> <tr> <td>2...8</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>15</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>25</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> </tbody> </table>	DN	L	D	di	Pipe connection	2...8	24	25.0	9.5	1/2"	15	24	25.0	16.0	3/4"	2...8	24	50.4	22.1	1"	15	24	50.4	22.1	1"	25	24	50.4	22.1	1"		
DN	L	D	di	Pipe connection																												
2...8	24	25.0	9.5	1/2"																												
15	24	25.0	16.0	3/4"																												
2...8	24	50.4	22.1	1"																												
15	24	50.4	22.1	1"																												
25	24	50.4	22.1	1"																												
Tri-Clamp Stainless steel 1.4404/316L		<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>di</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>2...8</td> <td>24</td> <td>25.0</td> <td>9.5</td> <td>1/2"</td> </tr> <tr> <td>15</td> <td>24</td> <td>25.0</td> <td>16.0</td> <td>3/4"</td> </tr> <tr> <td>2...8</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>15</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>25</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> </tbody> </table>	DN	L	D	di	Pipe connection	2...8	24	25.0	9.5	1/2"	15	24	25.0	16.0	3/4"	2...8	24	50.4	22.1	1"	15	24	50.4	22.1	1"	25	24	50.4	22.1	1"
		DN	L	D	di	Pipe connection																										
2...8	24	25.0	9.5	1/2"																												
15	24	25.0	16.0	3/4"																												
2...8	24	50.4	22.1	1"																												
15	24	50.4	22.1	1"																												
25	24	50.4	22.1	1"																												
<table border="1"> <thead> <tr> <th>DN</th> <th>L</th> <th>D</th> <th>di</th> <th>Pipe connection</th> </tr> </thead> <tbody> <tr> <td>2...8</td> <td>24</td> <td>25.0</td> <td>9.5</td> <td>1/2"</td> </tr> <tr> <td>15</td> <td>24</td> <td>25.0</td> <td>16.0</td> <td>3/4"</td> </tr> <tr> <td>2...8</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>15</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> <tr> <td>25</td> <td>24</td> <td>50.4</td> <td>22.1</td> <td>1"</td> </tr> </tbody> </table>	DN	L	D	di	Pipe connection	2...8	24	25.0	9.5	1/2"	15	24	25.0	16.0	3/4"	2...8	24	50.4	22.1	1"	15	24	50.4	22.1	1"	25	24	50.4	22.1	1"		
DN	L	D	di	Pipe connection																												
2...8	24	25.0	9.5	1/2"																												
15	24	25.0	16.0	3/4"																												
2...8	24	50.4	22.1	1"																												
15	24	50.4	22.1	1"																												
25	24	50.4	22.1	1"																												


All dimensions in [mm]

Flange

Stainless steel 1.4404/316L
with joint dimensions to
DIN 2501/ANSI B16.5/JIS B2210

DN 2...15:
with DN 15 or 1/2" flanges

DN 25:
with DN 25 or 1" flanges



Flange to DIN 2501, PN 40

DN	L	D	di	LK
2...8	51.8	95	17.3	65
15	51.8	95	17.3	65
25	51.8	115	28.5	85

Flange to ANSI B16.5

DN	Class 150			di	Class 300		
	L	D	LK		L	D	LK
2...8	61.6	88.9	60.5	15.8	61.6	95.2	66.5
15	61.6	88.9	60.5	15.8	61.6	95.2	66.5
25	67.4	108.0	79.2	26.6	73.8	123.9	88.9

Flange to JIS B2210

DN	L	D	di	LK
2...8	62.5	95	15	70
15	62.5	95	16	70
25	62.5	115	25	90

Face-to-face length to DVGW (200 mm)


Flange

PVDF with joint dimensions to
DIN 2501/ANSI B16.5/JIS B2210

DN 2...15:
with DN 15 or 1/2" flanges

DN 25:
with DN 25 or 1" flanges

Length:
2 x L + 143 mm
2 x L + 95 mm (for flanged or
Tri-Clamp version)




Flange as per DIN 2501/ANSI B16.5/JIS B2210
PN 16/Class 150/10K

DN	L	L1	D	d	di	DIN LK	ANSI LK	JIS LK
2...8	52.7	6	95	34	16.2	65	60.5	70
15	52.7	6	95	34	16.2	65	60.5	70
25	52.7	7	115	50	27.2	85	79.2	90

Face-to-face length as per DVGW (200 mm)

All dimensions in [mm]

Wall mounting kit for Promag A




A = 105 mm
B = 105 mm
C = 115 mm

ba039y59

Fig. 38
Dimensions
Wall mounting kit for Promag A

Dimensions for the process connections for Promag H sensor


Welded nipple



y46-01...06


DN	D	G	di ¹⁾	L	L1	LK
25	75	27	22.6	42	19	56.0
25 DIN	79	31	26.0	42	19	60.0
40	92	40	35.3	42	19	71.0
40 DIN	92	43	38.0	42	19	71.0
50	105	55	48.1	42	19	83.5
50 DIN	105	55	50.0	42	21	83.5
65	121	66	59.9	42	21	100.0
65 DIN	121	72	66.0	42	21	100.0
80	147	79	72.6	42	24	121.0
80 DIN	147	87	81.0	42	24	121.0
100	168	104	97.5	42	24	141.5
100 DIN	168	106	100.0	42	24	141.5

DIN 11851




DN	di ¹⁾	G	D	L	LK
25	26.0	52 x 1/6"	79	68	60.0
40	38.0	65 x 1/6"	92	72	71.0
50	50.0	78 x 1/6"	105	74	83.5
65	66.0	95 x 1/6"	121	78	100.0
80	81.0	110 x 1/4"	147	83	121.0
100	100.0	130 x 1/4"	168	92	141.5

Tri-Clamp




DN	ANSI	di ¹⁾	G	D	L	LK
25	1"	22.1	50.4	75	68.6	56.0
40	1 1/2"	34.8	50.4	92	68.6	71.0
50	2"	47.5	63.9	105	68.6	83.5
65	-	60.2	77.4	121	68.6	100.0
80	3"	72.9	90.9	147	68.6	121.0
100	4"	97.4	118.9	168	68.6	141.5

SMS 1145




DN	di ¹⁾	G	D	L	LK
25	22.5	40 x 1/6"	75	60	56.0
40	35.5	60 x 1/6"	92	63	71.0
50	48.5	70 x 1/6"	105	65	83.5
65	60.5	85 x 1/6"	121	70	100.0
80	72.0	98 x 1/6"	147	75	121.0
100	97.6	132 x 1/6"	168	70	141.5

ISO 2852



DN	di ¹⁾	G	D	L	LK
25	22.6	50.5	75	68.5	56.0
40	35.6	50.5	92	68.5	71.0
50	48.6	64.0	105	68.5	83.5
65	60.3	77.5	121	68.5	100.0
80	72.9	91.0	147	68.5	121.0
100	97.6	119.0	168	68.5	141.5

ISO 2853



DN	di ¹⁾	G	D	L	LK
25	22.6	37.1	75	61.5	56.0
40	35.6	50.6	92	61.5	71.0
50	48.6	64.1	105	61.5	83.5
65	60.3	77.6	121	61.5	100.0
80	72.9	91.1	147	61.5	121.0
100	97.6	118.1	168	61.5	141.5

Length:
 DN 25... 65 = 2 x L + 136 mm
 DN 80...100 = 2 x L + 196 mm

¹⁾ Please note the internal diameter (di, DI) when cleaning the piping with a scraper!

8.3 Dimensions Promag 30 F (DN 15...300)




Fig. 40
Dimensions Promag 30 F
(DN 15...300)

DN		PN			L ¹⁾	A	B	C	K	E	F		H	B1	Weight ²⁾
[mm]	[inch]	DIN	ANSI Class	JIS	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	DIN [mm]	ANSI [mm]	[mm]	[mm]	[kg]
15	1/2"	40	150	20K	200	340.5	256.5	84	120	94	14	11.2	286	202	6.5
25	1"	40	150	20K	200	340.5	256.5	84	120	94	16	14.2	286	202	7.3
32	-	40	-	20K	200	340.5	256.5	84	120	94	18	-	286	202	8.0
40	1 1/2"	40	150	20K	200	340.5	256.5	84	120	94	18	17.5	286	202	9.4
50	2"	40	150	10K	200	340.5	256.5	84	120	94	20	19.1	286	202	10.6
65	-	16	-	10K	200	390.5	281.5	109	180	94	18	-	336	227	12.0
80	3"	16	150	10K	200	390.5	281.5	109	180	94	20	23.9	336	227	14.0
100	4"	16	150	10K	250	390.5	281.5	109	180	94	22	23.9	336	227	16.0
125	-	16	-	10K	250	471.5	321.5	150	260	140	24	-	417	267	21.5
150	6"	16	150	10K	300	471.5	321.5	150	260	140	24	25.4	417	267	25.5
200	8"	10	150	10K	350	526.5	346.5	180	324	156	26	28.4	472	292	35.3
250	10"	10	150	10K	450	576.5	371.5	205	400	156	28	30.2	522	317	48.5
300	12"	10	150	10K	500	626.5	396.5	230	460	166	28	31.8	572	342	57.5

1) The length is always identical independently of the chosen pressure rating.
2) Weights for compact version only.

Weight:
Compact version ²⁾ see table above
Promag 30 transmitter 3 kg (5 kg for wall mounted version)
Sensor connection housing approx. 1 kg

8.4 Dimensions Promag 30 F (DN 350...2000)




Fig. 41
Dimensions Promag 30 F
(DN 350...2000)

DN		PN			L ¹⁾	A	B	C	K	E	F			H	B1	Weight ²⁾
[mm]	[inch]	DIN [bar]	ANSI [Class]	AWWA [Class]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	DIN [mm]	ANSI [mm]	AWWA [mm]	[mm]	[mm]	[kg]
350	14"	10	150	-	550	738	456.0	282.0	564	276	26	34.9	-	683.5	401.5	110
400	16"	10	150	-	600	790	482.0	308.0	616	276	26	36.5	-	735.5	427.5	130
450	18"	-	150	-	650	840	507.0	333.0	666	292	-	39.7	-	785.5	452.5	240
500	20"	10	150	-	650	891	532.5	358.5	717	292	28	42.9	-	836.5	478.0	170
600	24"	10	150	-	780	995	584.5	410.5	821	402	28	47.6	-	940.5	530.0	230
700	28"	10	-	D	910	1198	686.0	512.0	1024	589	30	-	33.3	1143.5	631.5	350
750	30"	-	-	D	975	1198	686.0	512.0	1024	626	-	-	34.9	1143.5	631.5	450
800	32"	10	-	D	1040	1241	707.5	533.5	1067	647	32	-	38.1	1186.5	653.0	450
900	36"	10	-	D	1170	1394	784.0	610.0	1220	785	34	-	41.3	1339.5	729.5	600
1000	40"	10	-	D	1300	1546	860.0	686.0	1372	862	34	-	41.3	1491.5	805.5	720
1050	42"	-	-	D	1365	1598	886.0	712.0	1424	912	-	-	44.5	1543.5	831.5	1050
1200	48"	6	-	D	1560	1796	985.0	811.0	1622	992	28	-	44.5	1741.5	930.5	1200
1350	54"	-	-	D	1755	1998	1086.0	912.0	1824	1252	-	-	54.0	1943.5	1031.5	2150
1400	-	6	-	-	1820	2148	1161.0	987.0	1974	1252	32	-	-	2093.5	1106.5	1800
1500	60"	-	-	D	1950	2196	1185.0	1011.0	2022	1392	-	-	57.2	2141.5	1130.5	2600
1600	-	6	-	-	2080	2286	1230.0	1056.0	2112	1482	34	-	-	2231.5	1175.5	2500
1650	66"	-	-	D	2145	2360	1267.0	1093.0	2186	1482	-	-	63.5	2305.5	1212.5	3700
1800	72"	6	-	D	2340	2550	1362.0	1188.0	2376	1632	36	-	66.7	2495.5	1307.5	3300
2000	78"	6	-	D	2600	2650	1412.0	1238.0	2476	1732	38	-	69.9	2595.5	1357.5	4100




1) Thickness of the flange face includes sealing strip. The length is always identical independently of the chosen pressure rating.

2) Weights of compact DIN PN 10 version. Weights for transmitter: see previous page

9 Technical Data

Application	
<i>Instrument name</i>	Flow measuring system "Promag 30 (Model '99)"
<i>Instrument function</i>	Flow measurement of liquids in closed piping. Applications in measurement, control and regulation processes, for e.g. batching and dosing (> 10 s), etc.
Function and system design	
<i>Measuring principle</i>	Electromagnetic flow measurement according to Faraday's law (Generation of a voltage by induction in a magnetic field).
<i>Measuring system</i>	Instrument family "Promag 30 (Model '99)" consisting of: <ul style="list-style-type: none"> • Transmitter: Promag 30 • Sensor: Promag A (DN 2, 4, 8, 15, 25) Promag H (DN 25, 40, 50, 65, 80, 100) Promag F (DN 15...2000) <p>Two versions are available:</p> <ul style="list-style-type: none"> • Compact version • Remote version (FS or FL version)
Input variables	
<i>Measuring variable</i>	Flow velocity (proportional to induced voltage. Measured by two electrodes in the measuring tube)
<i>Measuring range</i>	Measuring range of electronics within $v = 0 \dots 12.5$ m/s The full scale values for the current output can be selected within the following limits (see also page 39): <ul style="list-style-type: none"> – Minimum full scale value at $v = 0.3$ m/s – Maximum full scale value at $v = 10$ m/s
<i>Operable flow range</i>	Over 1000 : 1 When the flow is pulsating, the amplifier is not overloaded above its set full scale value even with peak velocities of 12.5 m/s. Flow is measured between 0.01...> 10 m/s at the stated accuracy.
<i>Auxiliary input</i>	$U = 3 \dots 30$ V DC, $R_i = 1.8$ k Ω , galvanically isolated Configurable for positive zero return or totalizer reset.
Output variables	
<i>Output signal</i>	<ul style="list-style-type: none"> • <i>Current output:</i> 0/4...20 mA, galvanically isolated, $R_L < 700$ Ω, time constant selectable (0.5...95 s), full scale value freely selectable, temperature coefficient: typical 0.01% o.r./$^{\circ}$C; resolution: 10 μA • <i>Pulse output (transistor output):</i> passive, $f_{max} = 400$ Hz, $U_{max} = 30$ V, $I_{max} = 250$ mA, galvanically isolated, pulse value selectable, pulse/pause ratio up to 0.5 Hz approx. 1:1 (the pulse width is limited to 1 s for pulse frequencies < 0.5 Hz) • <i>Status output (transistor output):</i> passive, $U_{max} = 30$ V, $I_{max} = 250$ mA Can be configured for: <ul style="list-style-type: none"> – indicating system errors (error), process errors (overflow, Empty Pipe) – flow direction indication

Output variables (continued)	
<i>Signal on alarm</i>	<ul style="list-style-type: none"> • Current output: The current is set to a defined value (see page 49) • Pulse output: no signal supplied • Status output: on "Error" → not conducting (open) on "Flow direction" → last status held (forward → not conducting; backward → conducting) <p>Error response of outputs (detailed description) → see page 49</p>
<i>Load</i>	$R_L < 700 \Omega$ (current output)
<i>Creep suppression</i>	<p>Switch-on point at $v = 0.02$ m/s Switch-off point at $v = 0.04$ m/s</p> <p>Further information → see page 44</p>
Accuracy	
<i>Reference conditions</i>	<p>According to DIN 19200 and VDI/VDE 2641:</p> <p>Fluid temperature $+28 \text{ °C} \pm 2 \text{ K}$ Ambient temperature $+22 \text{ °C} \pm 2 \text{ K}$ Warm up period 30 minutes</p> <p>Mounting</p> <ul style="list-style-type: none"> - Inlet section > 10 x DN - Outlet section > 5 x DN - Transmitter and sensor are grounded. - The sensor is build-in centered into the piping.
<i>Measured error</i>	<p>Pulse output: $\pm 0.5\%$ o.r. $\pm 0.01\%$ o.f.s. (full scale value = 10 m/s) Current output: additionally $\pm 10 \mu\text{A}$ (typical)</p> <div style="text-align: center;"> <p>Measured error [% o.r.]</p> <p>Legend: — 0.5 % ----- 0.2 % (Option)</p> <p>ba039y63</p> </div> <p><i>Option:</i> Promag 30 A and F: $\pm 0.2\%$ o.r. $\pm 0.05\%$ of Q_k Q_k = desired reference flow quantity for calibration ($v = 2 \dots 10$ m/s). Q_k has to be noted for ordering.</p> <p>Deviations in power supply voltage have no influence on the specified ranges.</p>
<i>Repeatability</i>	<p>$\pm 0.1\%$ o.r. $\pm 0.005\%$ o.f.s.</p> <p>o.r. = of reading o.f.s. = of max. full scale value (see table on page 39)</p>

Operating conditions	
Installation conditions	
<i>Installation instructions</i>	Orientation: vertical or horizontal Restrictions and other recommendations → see page 10 ff.
<i>Inlet and outlet sections</i>	Inlet section: ≥ 5 x DN Outlet section: ≥ 2 x DN
<i>Connection cable length for remote version</i>	<p><i>FS version:</i> 0... 10 m → min. conductivity ≥ 5 μS/cm 10...200 m → min. conductivity = f (L_{max})</p> <p><i>FL version:</i> 0...200 m → min. conductivity ≥ 5 μS/cm</p> <p><i>Instrument equipped with empty pipe detection (EPD):</i> max. cable length = 10 m</p> <p>Minimum conductivity for demineralised water: generally ≥ 20 μS/cm</p> <div style="display: flex; align-items: center;">  <div> <p style="text-align: center;">Conductivity [μS/cm]</p>  <p style="text-align: center;">Cable length L_{max} [m]</p> </div> <div style="margin-left: 20px; font-size: small;"> <p style="writing-mode: vertical-rl; transform: rotate(180deg);">ba039y76</p> </div> </div>
Ambient conditions	
<i>Ambient temperature</i>	<p>−20...+60 °C (Transmitter and sensor)</p> <ul style="list-style-type: none"> • An all-weather cover should be used to protect the housing from direct sunlight when mounting in the open. This is especially important in warmer climates and with high ambient temperatures. • Due to the danger of the transmitter electronics overheating, the transmitter and sensor are to be mounted separately with high ambient and fluid temperatures (see Figure). <div style="display: flex; align-items: center;">  <div style="margin-left: 20px; font-size: small;"> <p>Temperature range only for the remote version available.</p> <ul style="list-style-type: none"> PTFE (Teflon) Soft rubber (EPDM) Hard rubber </div> <div style="margin-left: 20px; font-size: small;"> <p style="writing-mode: vertical-rl; transform: rotate(180deg);">ba039y54</p> </div> </div>
<i>Storage temperature</i>	−10...+50 °C (preferably at +20 °C)
<i>Degree of protection (EN 60529)</i>	IP 67 (NEMA 4X) Option: IP 68 (NEMA 6P) for sensor A and F
<i>Shock and vibration resistance</i>	Acceleration up to 2 g / 2 h per day; 10...100 Hz
<i>Electromagnetic compatibility (EMC)</i>	According to EN 50081 Part 1 and 2 (interference emission) / EN 50082 Part 1 and 2 (interference immunity) as well as to NAMUR recommendations

Operating conditions (continued)	
Process conditions	
<i>Fluid temperature</i>	<p>The fluid temperature range depends on the sensor lining:</p> <p><i>Promag A</i> -20...+130 °C PFA</p> <p><i>Promag H</i> -20...+130 °C PFA with EPDM gasket -20...+150 °C PFA with Silicone gasket</p> <p><i>Promag F</i> -40...+130 °C PTFE (Teflon), DN 15...600 -20...+120 °C Soft rubber (EPDM), DN 25...2000 0...+ 80 °C Hard rubber, DN 65...2000 (see also Figure on page 67)</p>
<i>Nominal pressure</i>	<p><i>Promag A</i> PN 40</p> <p><i>Promag H</i> PN 16</p> <p><i>Promag F</i> DIN PN 6 (DN 1200...2000) PN 10 (DN 200...1000) PN 16 (DN 65...150) PN 40 (DN 15...50) PN 16/25 (DN 200...300) PN 40 (DN 65...100, optional)</p> <p>ANSI Class 150 (¹/₂...24") Class 300 (¹/₂...6", optional)</p> <p>AWWA Class D (28...48")</p> <p>JIS 10K (DN 50...300) 20K (DN 15...40) 20K (DN 50...300, optional)</p> <p>The material load curves (p-T-load diagrams) for all process connections can be found in the Technical Information TI 043D/06/en "Promag 30 (Model '99)"</p>
<i>Conductivity</i>	<p>Minimum conductivity: ≥ 5 µS/cm (for liquids in general) ≥ 20 µS/cm (for demineralised water)</p> <p>With the remote version "FS" the conductivity required also depends on the length of the cable → see page 67 "Connection cable length"</p>
<i>Pressure loss</i>	<ul style="list-style-type: none"> • No pressure loss if sensor and piping have the same nominal diameter. • Pressure loss specifications when using adapters e.g. reducers or expanders → see page 13. • Vacuum resistance of measuring tube lining → see page 74
Mechanical construction	
<i>Design / Dimensions</i>	<p>Dimensions → see pages 57–63 Internal diameter of measuring tube → see page 73</p>
<i>Weight</i>	See pages 57–63
<i>Materials</i>	<p><i>Transmitter housing:</i> Powder-coated die-cast aluminium</p> <p><i>Sensor housing:</i> <i>Promag A</i> 1.4435 incl. threaded stub <i>Promag H</i> 1.4301 <i>Promag F</i> DN 15...300: Powder-coated die-cast aluminium DN 350...2000: Coated steel</p>
(continued on next page)	

Mechanical construction (continued)	
<i>Materials (continued)</i>	<p><i>Process connections:</i></p> <p>Promag A DIN → Stainless steel 1.4404, PVDF ANSI → 316L, PVDF JIS → 316L, PVDF Threaded stub: 1.4435, PVC 1.4404 / 316L</p> <p>Promag H DIN → Stainless steel 1.4571, St. 37-2 ANSI → A 105, 316L AWWA → A 105, A 36 JIS → S20C, SUS 316L</p> <p><i>Electrodes:</i></p> <p>Promag A 1.4435; Platinum/Rhodium 80/20; Titan; Hastelloy C-22; Tantalum Promag H 1.4435 Promag F 1.4435; Platinum/Rhodium 80/20; Hastelloy C-22; Tantalum</p> <p><i>Gasket material:</i></p> <p>Promag A Viton, Kalrez (optional), Silicone (aseptic version) Promag H EPDM, Silicone Promag F no gaskets (Lining = 'gasket')</p>
<i>Electrodes fitted</i>	<p>Promag A Measuring, reference and empty pipe detection electrodes. As standard with 1.4435, Hastelloy C-22, Tantalum Optional with Platinum/Rhodium</p> <p>Promag H Measuring and empty pipe detection electrodes</p> <p>Promag F Measuring, reference and empty pipe detection electrodes. As standard with 1.4435, Hastelloy C-22, Tantalum</p>
<i>CIP cleanable</i>	<p>Promag A Yes (observe maximum temperature) Promag H Yes (observe maximum temperature) Promag F Yes (observe maximum temperature)</p>
<i>SIP cleanable</i>	<p>Promag A No Promag H Yes (observe maximum temperature) Promag F No</p>
<i>Process connections</i>	<p><i>Promag A:</i> Internal and external thread, PVC adhesive coupling, hose connection, welded nipple, aseptic welded nipples for pipelines according to DIN 11850, Tri-Clamp, flange connection (DIN, ANSI, JIS).</p> <p><i>Promag H:</i> Welded nipples for OD tube, SMS, JIS, ISO and DIN 11850 tubes, DIN 11851 thread, SMS thread, ISO 2853 thread, Tri-Clamp, ISO 2852 connection.</p> <p><i>Promag F:</i> Flange connection (DIN, ANSI, JIS)</p>
<i>Electrical connection</i>	<ul style="list-style-type: none"> • Wiring diagrams: see page 23 ff. • Cable specifications: see page 28 • Galvanic isolation: All circuits for inputs, outputs, power supply and sensors are galvanically isolated from one another.
<i>Cable entries</i>	<p><i>Power supply and signal cable (output):</i> Cable glands PG 13.5 (5...15 mm) or threads for cable glands 1/2" NPT, M20 x 1.5 (8...15 mm), G 1/2"</p> <p><i>Coil current cable and signal cable (remote version)</i></p> <p>Promag A: Cable glands PG 11 (5...12 mm) or threads for cable glands 1/2" NPT, M20 x 1.5 (8...15 mm), G 1/2"</p> <p>Promag H: Cable glands PG 13.5 (5...15 mm) or threads for cable glands 1/2" NPT, M20 x 1.5 (8...15 mm), G 1/2"</p> <p>Promag F: Cable glands PG 13.5 (5...15 mm) or threads for cable glands 1/2" NPT, M20 x 1.5 (8...15 mm), G 1/2"</p>

User interface	
<i>Operation</i>	On-site operation: All functions of the E+H operating matrix can be selected and changed using three keys (E, -, +).
<i>Display</i>	<ul style="list-style-type: none"> - Eight character LC display - 11 display segments for indicating units and instrument status. - Damping of flow display can be adjusted: 0.5...20 s
<i>Communication</i>	none
Power supply	
<i>Supply voltage / Frequency</i>	85...260 V AC, 45...65 Hz 20... 55 V AC, 45...65 Hz 16... 62 V DC
<i>Power consumption</i>	AC: <15 VA (incl. sensor) DC: <15 W (incl. sensor) Current at make (Promag 30 X / 24 V DC): <ul style="list-style-type: none"> - max. 13.5 A (< 100 μs) - max. 6 A (< 5 ms)
<i>Power supply failure</i>	Bridges minimum 1 power cycle (22 ms) <ul style="list-style-type: none"> • EEPROM saves measuring system data on power failure (no batteries required). • DAT = replaceable data memory in which basic data of the sensor are stored: nominal diameter, SAPS (actual values), serial number, calibration factor, zero point, status EPD (yes/no), EPD calibration values.
Certificates and approvals	
<i>Ex approvals</i>	Information on Ex versions (e.g. CENELEC, SEV, FM, CSA) can be supplied by your E+H sales center on request. All explosion protection data are given in separate documentation available on request.
<i>Sanitary version</i>	<ul style="list-style-type: none"> - Sensor Promag A: 3A approval - Sensor Promag H (hygienic version): 3A approval and EHEDG tested
<i>Custody transfer</i>	<p><i>Promag 31 F</i></p> <ul style="list-style-type: none"> - PTB approval for custody transfer with cold water and wastewater (either for approval or approved for custody transfer) - Heat measurement approval, Swiss certification to OIML R72/R75 <p><i>Promag 31 H</i></p> <ul style="list-style-type: none"> - PTB approval to DIN 19217 (OIML 117) for custody transfer with beer, original wort, milk.
<i>CE mark</i>	By attaching the CE mark, Endress+Hauser confirms that the Promag 30 measurement system has been successfully tested and fulfils all legal requirements of the relevant CE directives.

Order information	
<i>Accessories</i>	<ul style="list-style-type: none"> • Post mounting set for transmitter (remote version): Order No. 50076905 • Wall mounting kit for Promag A sensor: Order No. 50064550 • Spare parts: see page 55
<i>Supplementary documentation</i>	<p>System Information Promag (SI 010D/06/en) Technical Information Promag 30 (TI 043D/06/en) * Operating Manual Promag 31 F – Cold water (BA 041D/06/en) * Supplementary Ex documentation: CENELEC, SEV, FM, CSA</p> <p>* Model '99</p>
Other standards and guidelines	
EN 60529	Degree of protection by housing (IP code)
EN 61010	Protection Measures for Electronic Equipment for Measurement, Control, Regulation and Laboratory Procedures
EN 50081	Part 1 and 2 (interference emission)
EN 50082	Part 1 and 2 (interference immunity)
NAMUR	Association of Standards for Control and Regulation in the Chemical Industry

Factory settings (full scale value, pulse values)

DN		Factory settings			
		Full scale value (current output) (I = 20 mA; at v ~ 2.5 m/s)		Pulse value (Imp _{out} = 1 Hz; at v ~ 2.5 m/s)	
[mm]	[inch]	[l/s]	[USgpm]	[l/pulse]	[USgal/pulse]
2	1/12"	0.008	0.1	0.008	0.0020
4	5/32"	0.03	0.5	0.03	0.0085
8	5/16"	0.10	2.0	0.10	0.035
15	1/2"	0.45	7.0	0.45	0.10
25	1"	1.0	20.0	1.0	0.30
32	1 1/4"	2.0	30.0	2.0	0.55
40	1 1/2"	3.0	50.0	3.0	0.85
50	2"	5.0	80.0	5.0	1.0
65	2 1/2"	8.0	150.0	8.0	2.0
80	3"	10.0	200.0	10.0	3.5
100	4"	20.0	300.0	20.0	5.0
125	5"	30.0	500.0	30.0	8.0
150	6"	45.0	700.0	45.0	10.0
200	8"	80.0	1000.0	80.0	20.0
250	10"	100.0	2000.0	100.0	30.0
300	12"	150.0	3000.0	150.0	50.0
350	14"	250.0	4000.0	250.0	65.0
400	16"	300.0	5000.0	300.0	85.0
450	18"	400.0	6500.0	400.0	100.0
500	20"	500.0	8000.0	500.0	150.0
600	24"	700.0	10000.0	700.0	200.0
700	28"	950.0	15000.0	950.0	250.0
750	30"	1000.0	15000.0	1000.0	300.0
800	32"	1000.0	20000.0	1000.0	350.0
900	36"	1500.0	25000.0	1500.0	400.0
1000	40"	2000.0	30000.0	2000.0	500.0
1050	42"	2000.0	35000.0	2000.0	600.0
1200	48"	3000.0	50000.0	3000.0	750.0
1350	54"	3500.0	55000.0	3500.0	950.0
1400	56"	4000.0	60000.0	4000.0	1000.0
1500	60"	4500.0	70000.0	4500.0	1000.0
1600	64"	5000.0	80000.0	5000.0	1500.0
1700	66"	5500.0	90000.0	5500.0	1500.0
1800	72"	6500.0	100000.0	6500.0	1500.0
2000	78"	8000.0	100000.0	8000.0	2000.0

Internal diameter of the measuring tube

Sensor	DN		PN			AWWA	Internal diameter		
	[mm]	[inch]	DIN [bar]	ANSI [lbs]	JIS		PFA	PTFE (Teflon)	Hard rubber Soft rubber (EPDM)
Promag A	2	1/12"	40	-	-	-	2.2	-	-
	4	5/32"		-	-	-	4.6	-	-
	8	5/16"		-	-	-	8.6	-	-
	15	1/2"		-	-	-	16.1	-	-
	25	1"		-	-	-	22.0	-	-
Promag H	25 DIN	-	16	-	-	-	*	-	-
	25	1"		-	-	-	*	-	-
	40	1 1/2"		-	-	-	*	-	-
	50	2"		-	-	-	*	-	-
	65	2 1/2"		-	-	-	*	-	-
	80	3"		-	-	-	*	-	-
	100	4"		-	-	-	*	-	-
* For details see page 61									
Promag F	15	1/2"	40	Class 150	20K	-	15	-	
	25	1"	40	Class 150	20K	-	26	-	
	32	-	40	Class 150	20K	-	35	-	
	40	1 1/2"	40	Class 150	20K	-	41	-	
	50	2"	40	Class 150	10K	-	52	-	
	65	-	16	Class 150	10K	-	68	65	
	80	3"	16	Class 150	10K	-	80	78	
	100	4"	16	Class 150	10K	-	105	100	
	125	-	16	Class 150	10K	-	130	126	
	150	6"	16	Class 150	10K	-	156	154	
	200	8"	10	Class 150	10K	-	207	205	
	250	10"	10	Class 150	10K	-	259	259	
	300	12"	10	Class 150	10K	-	309	310	
	350	14"	10	Class 150	-	-	337	341	
	400	16"	10	Class 150	-	-	387	391	
	-	18"	-	Class 150	-	-	-	436	
	500	20"	10	Class 150	-	-	487	491	
	600	24"	10	Class 150	-	-	593	593	
	700	28"	10	-	Class D	-	-	692	
	-	30"	-	-	Class D	-	-	741	
	800	32"	10	-	Class D	-	-	794	
	900	36"	10	-	Class D	-	-	893	
	1000	40"	10	-	Class D	-	-	995	
	-	42"	-	-	Class D	-	-	1042	
1200	48"	6	-	Class D	-	-	1195		
-	54"	-	-	Class D	-	-	1338		
1400	-	6	-	-	-	-	1401		
-	60"	-	-	Class D	-	-	1491		
1600	-	6	-	-	-	-	1599		
-	66"	-	-	Class D	-	-	1637		
1800	72"	6	-	Class D	-	-	1799		
-	78"	-	-	Class D	-	-	1981		
2000	-	6	-	-	-	-	1995		

Resistance of the lining to vacuum (standard version)

Sensor	DN		Measuring tube lining	Limits for vacuum [mbar] at different fluid temperatures					
	[mm]	[inch]		25 °C	80 °C	100 °C	120 °C	130 °C	150 °C
Promag A	2...25	1/12...1"	PFA	0	0	0	0		
Promag H	25...100	1...4"	PFA	0	0	0	0	0	0
Promag F	65...2000 25...2000	3...78" 1...78"	Hard rubber Soft rubber (EPDM)	0 0	0 0	0 0	0 0		
	15...50 65...80 100 125...150 200 250 300 350 400	1/2...2" 3" 4" 6" 8" 10" 12" 14" 16"	PTFE (Teflon)	0 0 0 135 200 330 400 470 540	0 * * * * * * * *	0 40 135 240 290 400 500 600 670	* * * * * * * * *	100 130 170 385 410 530 630 730 800	
	450...600	18...24"		Vacuum not permitted!					

* No values available

Index

A

Accuracy	
Measured error	66
Reference conditions	66
Repeatability	66
Adapters	13
Ambient temperature	67
Auxiliary input	
Electrical connection	23
Example for electrical connections	25
Functions	43
General technical data	65

B

Bidirectional measurement (flow direction)	42
Build-up (measuring tube, electrodes)	
See ECC	

C

Cable glands	21, 69
Cable specifications	28
Calibration factor (name plate)	8
Cathodic protection	29
CE mark	70
CIP (cleaning in place)	69
Commissioning	31
Conductivity (minimum) of the fluid	68
Connection (electrical)	
See Electrical connections	
Connection cable length	19, 67
Correct usage	5
Creep suppression	44
Current output	
Current range	40
Electrical connection	23
Factory settings (full scale)	72
Full scale value function	38, 39
Technical data	65
Time constant	40

D

Dangerous substances	6
DAT (data storage module)	54, 70
Degree of protection	21, 67
Dimensions	
Internal diameter	73
Process connections Promag A	58
Process connections Promag H	61
Promag 30 A	57
Promag 30 F (DN 15...300)	62
Promag 30 F (DN 350...2000)	63
Promag 30 H	60
Display	
Display and operating elements	33
Display damping (flow rate)	43
Display mode (displayed variables)	43
Display of numerical values	38

Function code	37
Operation (E+H operating matrix)	34
Rotating (4 x 90°)	18
Test function	43
Documentation, supplementary	71
Downward pipe	10

E

ECC (Electrode cleaning circuitry)	48
Electrical connection	
Cable specifications	28
Degree of protection (IP)	21
Example connection diagrams (inputs / outputs)	24
Potential equalisation	29
Remote version (connection cable)	26, 28
Transmitter	22
Electrode axis	12
Electrode cleaning circuitry (ECC)	48
Electrodes fitted	69
Electromagnetic compatibility (EMC)	28, 30
Empty pipe adjustment	47
Empty pipe detection (EPD)	46
Engineering units	
See Unit selection	
EPD (Empty pipe detection)	46
Error	
See Trouble-shooting	
Error correction (remedies)	50
Error limits	
See Accuracy	
Error response (measuring system outputs)	49
Ex approvals	70
Ex instruments (documentation)	5

F

Factory settings (full scale, pulse value)	72
Flow direction indication (status output)	42
Flow range, operable	65
Flow rate / Nominal diameter	13
Fluid conductivity	68
Fluid temperature	68
Full pipe adjustment	47
Full scale value (current output)	38, 39
Function description	37
Functions at a glance	35
Fuse replacing	55

G

Galvanic isolation	69
Gaskets	
See Seals	
Ground disks	29, 30
Grounding, ground terminal	29

I	
Inlet section	12
Input variables	65
Installation	
See Mounting	
Instrument functions (description)	37
L	
Length	
See Dimensions	
Load (current output)	66
Local display	
See Display	
M	
Maintenance	55
Material load curves	68
Materials	68, 69
Matrix (operating matrix)	35
Measured error (error limits)	66
Measuring electrodes	
Positioning	12
Replacement	52
Measuring principle	65
Measuring range	65
Measuring system Promag 30	7
Measuring tube	
Internal diameter	73
Lining	68
Measuring variable	65
Mounting in the pipe	
Adapters	13
Base and supports (from DN 350/14")	9
Downward pipe	10
Inlet and outlet section	12
Installation of pumps	11
Mounting location	10
Mounting position	12
Partly filled pipes	10
Vibration	11
Mounting of the sensor	
Base and supports (DN 350)	9
Promag 30 A	14
Promag 30 F	16
Promag 30 H	15
Promag 30 H with welded nipples	15
Mounting of the transmitter (remote version)	
Connection cable length	19
Wall and post mounting	19
N	
Name plates	
Sensors (Promag A, H, F)	8
Transmitter (Promag 30)	7
NAMUR recommendations	28
Nominal diameter / Flow rate	13
Nominal pressure (material load)	68

O	
Operating and display elements	33
Operating conditions	67
Operating example	36
Operating matrix	35
Operation (E+H operating matrix)	33, 34
Order code	8
Outlet section	12
Output signals	65
Output variables	65
P	
Positive zero return (via auxiliary input)	43
Post mounting (transmitter)	19
Potential equalisation	29
Power consumption	70
Power supply	70
Pressure loss	
Adapters (reducers, expanders)	13
General information	68
Vacuum resistance (lining)	74
Process connections	
Promag A	14
Promag H	15
Process error (empty pipe, meas. range exceeded)	49
Pulse output	
Electrical connection	23
Examples for electrical connection	24
Factory settings (pulse value)	72
Pulse value function	40
Technical data	65
Pulse value	40, 41
Pumps (mounting location)	11
R	
Reference electrode	29
Remote versions	
FL version	19
FS version	19
Repairs	6, 55
Repeatability (accuracy)	66
Replacement of	
DAT module	54
Instrument fuse	55
Measuring electrodes	52
Transmitter electronics	54
S	
Safety instructions	5
Sanitary versions	70
Screw tightening torque	
See Mounting (sensor)	
Seals (sensor)	
Materials	69
Promag A	14
Promag F	16
Promag H	15
Temperature ranges	68

Sensor mounting	
See Mounting	
Serial number	7, 8
Shock resistance	67
Signal on alarm	
See Error response	
SIP cleanable	69
Status output	
Electrical connection	23
Example for electrical connections	24
Functions	42
General technical data	65
Storage temperature	67
Supply	
See Power supply	
System error (instrument fault, supply failure) . . .	49
T	
Technical data	65
Temperature ranges	
Ambient temperature	67
Fluid temperature	68
Storage temperature	67
Time constant (current output)	40
Totalizer	
Connection of external totalizers	24
Display example	44
Overflow	44
Totalizer reset (via auxiliary input)	43
Totalizer reset (via operating matrix)	43
Transmitter	
Connection cable length (remote version)	19
Electrical connection	22
Replacement of the electronics	54
Rotating the housing (4 x 90°)	18
Wall and post mounting	19
Transport of the sensor (from DN 350)	9
Trouble-shooting instructions	50
U	
Unidirectional measurement (flow direction)	42
Unit selection	37
V	
Vacuum resistance (lining)	74
Vibrational resistance	67
Vibrations	11, 67
W	
Wall mounting (transmitter)	19
Wall mounting kit (Promag A sensor)	59
Weather cover	67
Weights	68
Welding	
Grounding	6
Welded nipples (Promag H)	15

Europe

Austria

□ Endress+Hauser Ges.m.b.H.
Wien
Tel. (01) 88056-0, Fax (01) 88056-35

Belarus

□ Belorgsintez
Minsk
Tel. (0172) 508473, Fax (0172) 508583

Belgium / Luxembourg

□ Endress+Hauser N.V.
Brussels
Tel. (02) 2480600, Fax (02) 2480553

Bulgaria

INTERTECH-AUTOMATION
Sofia
Tel. (02) 664869, Fax (02) 9631389

Croatia

□ Endress+Hauser GmbH+Co.
Zagreb
Tel. (01) 6637785, Fax (01) 6637823

Cyprus

I+G Electrical Services Co. Ltd.
Nicosia
Tel. (02) 484788, Fax (02) 484690

Czech Republic

□ Endress+Hauser GmbH+Co.
Praha
Tel. (026) 6784200, Fax (026) 6784179

Denmark

□ Endress+Hauser A/S
Søborg
Tel. (70) 131132, Fax (70) 132133

Estonia

ELVI-Aqua
Tartu
Tel. (7) 441638, Fax (7) 441582

Finland

□ Endress+Hauser Oy
Helsinki
Tel. (0204) 83160, Fax (0204) 83161

France

□ Endress+Hauser S.A.
Huningue
Tel. (389) 696768, Fax (389) 694802

Germany

□ Endress+Hauser Messtechnik GmbH+Co.
Weil am Rhein
Tel. (07621) 975-01, Fax (07621) 975-555

Great Britain

□ Endress+Hauser Ltd.
Manchester
Tel. (0161) 2865000, Fax (0161) 9981841

Greece

I & G Building Services Automation S.A.
Athens
Tel. (01) 9241500, Fax (01) 9221714

Hungary

Mile Ipari-Elektro
Budapest
Tel. (01) 4319800, Fax (01) 4319817

Iceland

BiL ehf
Reykjavik
Tel. (05) 619616, Fax (05) 619617

Ireland

Flomeaco Company Ltd.
Kildare
Tel. (045) 868615, Fax (045) 868182

Italy

□ Endress+Hauser S.p.A.
Cernusco s/N Milano
Tel. (02) 921921, Fax (02) 92107153

Latvia

Rino TK
Riga
Tel. (07) 315087, Fax (07) 315084

Lithuania

UAB "Agava"
Kaunas
Tel. (07) 202410, Fax (07) 207414

Netherland

□ Endress+Hauser B.V.
Naarden
Tel. (035) 6958611, Fax (035) 6958825

Norway

□ Endress+Hauser A/S
Tranby
Tel. (032) 859850, Fax (032) 859851

Poland

□ Endress+Hauser Polska Sp. z o.o.
Warszawa
Tel. (022) 7201090, Fax (022) 7201085

Portugal

Tecnisis, Lda
Cacém
Tel. (21) 4267290, Fax (21) 4267299

Romania

Romconseng S.R.L.
Bucharest
Tel. (01) 4101634, Fax (01) 4112501

Russia

□ Endress+Hauser Moscow Office
Moscow
Tel. (095) 1587564, Fax (095) 1589871

Slovakia

Transcom Technik s.r.o.
Bratislava
Tel. (7) 44888684, Fax (7) 44887112

Slovenia

□ Endress+Hauser D.O.O.
Ljubljana
Tel. (061) 5192217, Fax (061) 5192298

Spain

□ Endress+Hauser S.A.
Sant Just Desvern
Tel. (93) 4803366, Fax (93) 4733839

Sweden

□ Endress+Hauser AB
Sollentuna
Tel. (08) 55511600, Fax (08) 55511655

Switzerland

□ Endress+Hauser AG
Reinach/BL 1
Tel. (061) 7157575, Fax (061) 7111650

Turkey

Intek Endüstriyel Ölçü ve Kontrol Sistemleri
Istanbul
Tel. (0212) 2751355, Fax (0212) 2662775

Ukraine

Photonika GmbH
Kiev
Tel. (44) 26881, Fax (44) 26908

Yugoslavia Rep.

Meris d.o.o.
Beograd
Tel. (11) 4441966, Fax (11) 4441966

Africa

Egypt

Anasia
Heliopolis/Cairo
Tel. (02) 4179007, Fax (02) 4179008

Morocco

Oussama S.A.
Casablanca
Tel. (02) 241338, Fax (02) 402657

South Africa

□ Endress+Hauser Pty. Ltd.
Sandton
Tel. (011) 4441386, Fax (011) 4441977

Tunisia

Controle, Maintenance et Regulation
Tunis
Tel. (01) 793077, Fax (01) 788595

America

Argentina

□ Endress+Hauser Argentina S.A.
Buenos Aires
Tel. (01) 145227970, Fax (01) 145227909

Bolivia

Tritec S.R.L.
Cochabamba
Tel. (042) 56993, Fax (042) 50981

Brazil

□ Samson Endress+Hauser Ltda.
Sao Paulo
Tel. (011) 50313455, Fax (011) 50313067

Canada

□ Endress+Hauser Ltd.
Burlington, Ontario
Tel. (905) 6819292, Fax (905) 6819444

Chile

□ Endress+Hauser Chile Ltd.
Santiago
Tel. (02) 3213009, Fax (02) 3213025

Colombia

Colsein Ltda.
Bogota D.C.
Tel. (01) 2367659, Fax (01) 6104186

Costa Rica

EURO-TEC S.A.
San Jose
Tel. (02) 961542, Fax (02) 961542

Ecuador

Insetec Cia. Ltda.
Quito
Tel. (02) 269148, Fax (02) 461833

Guatemala

ACISA Automatizacion Y Control
Industrial S.A.
Ciudad de Guatemala, C.A.
Tel. (03) 345985, Fax (03) 327431

Mexico

□ Endress+Hauser S.A. de C.V.
Mexico City
Tel. (5) 5682405, Fax (5) 5687459

Paraguay

Incoel S.R.L.
Asuncion
Tel. (021) 213989, Fax (021) 226583

Uruguay

Circular S.A.
Montevideo
Tel. (02) 925785, Fax (02) 929151

USA

□ Endress+Hauser Inc.
Greenwood, Indiana
Tel. (317) 535-7138, Fax (317) 535-8498

Venezuela

Controval C.A.
Caracas
Tel. (02) 9440966, Fax (02) 9444554

Asia

China

□ Endress+Hauser Shanghai
Instrumentation Co. Ltd.
Shanghai
Tel. (021) 54902300, Fax (021) 54902303

□ Endress+Hauser Beijing Office

Beijing
Tel. (010) 68344058, Fax (010) 68344068

Hong Kong

□ Endress+Hauser HK Ltd.
Hong Kong
Tel. 25283120, Fax 28654171

India

□ Endress+Hauser (India) Pvt Ltd.
Mumbai
Tel. (022) 8521458, Fax (022) 8521927

Indonesia

PT Grama Bazita
Jakarta
Tel. (21) 7975083, Fax (21) 7975089

Japan

□ Sakura Endress Co. Ltd.
Tokyo
Tel. (0422) 540613, Fax (0422) 550275

Malaysia

□ Endress+Hauser (M) Sdn. Bhd.
Petaling Jaya, Selangor Darul Ehsan
Tel. (03) 7334848, Fax (03) 7338800

Pakistan

Speedy Automation
Karachi
Tel. (021) 7722953, Fax (021) 7736884

Papua-Neuguinea

SBS Electrical Pty Limited
Port Moresby
Tel. 3251188, Fax 3259556

Philippines

□ Endress+Hauser Philippines Inc.
Metro Manila
Tel. (2) 3723601-05, Fax (2) 4121944

Singapore

□ Endress+Hauser (S.E.A.) Pte., Ltd.
Singapore
Tel. 5668222, Fax 5666848

South Korea

□ Endress+Hauser (Korea) Co., Ltd.
Seoul
Tel. (02) 6587200, Fax (02) 6592838

Taiwan

Kingjarl Corporation
Taipei R.O.C.
Tel. (02) 27183938, Fax (02) 27134190

Thailand

□ Endress+Hauser Ltd.
Bangkok
Tel. (2) 9967811-20, Fax (2) 9967810

Vietnam

Tan Viet Bao Co. Ltd.
Ho Chi Minh City
Tel. (08) 8335225, Fax (08) 8335227

Iran

PATSA Co.
Tehran
Tel. (021) 8754748, Fax (021) 8747761

Israel

Instrumetrics Industrial Control Ltd.
Netanya
Tel. (09) 8357090, Fax (09) 8350619

Jordan

A.P. Parpas Engineering S.A.
Amman
Tel. (06) 4643246, Fax (06) 4645707

Kingdom of Saudi Arabia

Anasia Ind. Agencies
Jeddah
Tel. (02) 6710014, Fax (02) 6725929

Lebanon

Network Engineering
Jbeil
Tel. (3) 944080, Fax (9) 548038

Sultanate of Oman

Mustafa Sultan Science & Industry Co. LLC.
Ruwi
Tel. 602009, Fax 607066

United Arab Emirates

Descon Trading EST.
Dubai
Tel. (04) 2653651, Fax (04) 2653264

Yemen

Yemen Company for Ghee and Soap Industry
Taiz
Tel. (04) 230664, Fax (04) 212338

Australia + New Zealand

Australia

ALSTOM Australia Limited
Milperra
Tel. (02) 97747444, Fax (02) 97744667

New Zealand

EMC Industrial Group Limited
Auckland
Tel. (09) 4155110, Fax (09) 4155115

All other countries

□ Endress+Hauser GmbH+Co.
Instruments International
D-Weil am Rhein
Germany
Tel. (07621) 975-02, Fax (07621) 975345

