

















# Safety Instructions

# Proline Promass 80

**HART** 

Division 1



Ex documentation for the Operating Instructions according to FACTORY MUTUAL standards  $\rightarrow \; \stackrel{\triangle}{=} \; 3$ 



Ex documentation for the Operating Instructions according to CANADIAN STANDARDS ASSOCIATION  $\rightarrow$   $\stackrel{ ext{l}}{=}$  17



XA00099D Proline Promass 80

### Examples for markings according to FM and CSA:


FM APPROVALS

CSA (Canadian Standards Association)



### **Temperature Class**

	Maximum									
surface temperature										
T1	842 °F	450 °C								
T2	572 °F	300 °C								
T2A	536 °F	280 °C								
T2B	500 °F	260 °C								
T2C	446 °F	230 °C								
T2D	419 °F	215 °C								
Т3	392 °F	200 °C								
T3A	356 °F	180 °C								
ТЗВ	329 °F	165 °C								
T3C	320 °F	160 °C								
T4	275 °F	135 °C								
T4A	248 °F	120 °C								
T5	212 °F	100 °C								
T6	185 °F	85 °C								





### **Temperature Class**

sui	Maximum face temperat	ure
T1	450 °C	842 °F
T2	300 °C	572 °F
T2A	280 °C	536 °F
T2B	260 °C	500 °F
T2C	230 °C	446 °F
T2D	215 °C	419 °F
Т3	200 °C	392 °F
T3A	180 °C	356 °F
ТЗВ	165 °C	329 °F
T3C	160 °C	320 °F
T4	135 °C	275 °F
T4A	120 °C	248 °F
T5	100 °C	212 °F
T6	85 °C	185 °F

Class		Example: C	Class I, Division 1, Group
I II III	Class I (Gas) Class II (Dust) Class III (Fibre)		
Division			
1 2	Division 1 Division 2		
Group			
CSA / CSC	Gases, vapours and dust examples	Min. ignition temperature [μJ]	]
A	Acetylene, carbon disulfide (Class I)	0.02	
В	Hydrogen, ethyl nitrate (Class I)	0.02	
С	Ethylene, isoprene (Class I)	0.06	
D	Acetone, ethane, benzene (Class I)	0.18	
Е	Metallic powder (Class II)		
F	Coal dust (Class II)		
G	Mill dust (Class II)		
	Textile fibres (Class III)		
Type of Protect	ion		
Associated Noni Pressurized	uratus with Intrinsically Safe Connections incendive Field Wiring Apparatus surization Systems/Components		

A0005630-en

2



















# Safety Instructions

# Proline Promass 80

# Division 1



# Ex documentation

This document is an integral part of the following Operating Instructions:

■ BA00057D, Proline Promass 80 HART

### Table of Contents FM

Special conditions	4
General warnings	4
Approvals	5
Description of measuring system	5
Nameplate	6
Type code	7
Temperature table compact version	9
Remote version temperature table	10
Design of measuring system	11
Cable entries	
Cable specification	11
Potential equalization	11
Connecting the remote version connecting cable	12
Electrical connection	12
Terminal assignment and connection data: Power supply	13
Terminal assignment and connection data for signal circuits (intrinsically safe circuits)	13
Terminal assignment and connection data for signal circuits (non-intrinsically safe circuits)	14
Service adapter	15
Device fuse	15
Technical Data	15
Control Drawings	15





### Special conditions

- Install per National Electrical Code. Install intrinsically safe circuits per NEC ANSI/ NFPA 70 and ISA RP 12.6 respecting the explosion proof integrity of the enclosure.
- Control room equipment shall not use or generate more than 250 V rms.
- The device must be integrated into the potential equalization system.

- It is not permissible to connect the service adapter whilst the atmosphere is considered to be explosive.
- Use of the devices is restricted to mediums against which the process-wetted materials are adequately resistant.
- Class II Group G: The surface temperature of the apparatus cannot exceed 329 °F.
- Transmitter enclosure G02 explosionproof for use in Class 1 Division 1 Groups A, B, C, D (seals not required) and dust-ignition proof for Class II, III Division 1 Groups E, F, G.
- Sensor circuits intrinsically safe for Cl. I, II, III Div. 1 Group A, B, C, D, E, F, G except Promass M: DN 3" (sensor version Group C-D)
   Promass E: DN 3" (sensor version Group C-D)
   Promass I: DN 1½" FB/2"/2" FB/3" (sensor version Group C-D)
   Promass F: DN 3"/4"/6"/10" (sensor version Group C-D)
  - Promass H, P, S: DN 2" (sensor version Group C-D) which are only suitable for Cl. I, II, III Div. 1 Group C, D, E, F, G. (optionally, a version for Groups A and B is available).
- Substitution of components may impair intrinsic safety.



• Use supply wires suitable for 9 °F above ambient temperature, but at least for 176 °F.

### General warnings

- Installation, connection to the electricity supply, commissioning and maintenance of the devices must be carried out by qualified specialists trained to work on Ex-rated devices.
- Compliance with national regulations relating to the installation of devices in potentially explosive atmospheres is mandatory, if such regulations exist.
- Open the device only when it is de-energized (and after a delay of at least 10 minutes following shutdown of the power supply).
- The housing of the Ex-rated transmitter can be turned in 90° steps. Whereas the non-Ex version has a bayonet adapter, however, the Ex version has a thread. Recesses for centering the worm screw are provided to prevent inadvertent movement of the transmitter housing.
  It is permissible to turn the transmitter housing through a maximum of 180° during operation (in either direction), without compromising explosion protection. After turning the housing the worm screw must be tightened again.
- The screw cap has to be removed before the local display can be turned, and this must be done with the device de-energized (and after a delay of at least 10 minutes following shutdown of the power supply).

### Turning the transmitter housing

- 1. Unscrew the grub screw.
- 2. Rotate the transmitter housing cautiously clockwise until the end stop (end of the thread).
- 3. Rotate the transmitter housing counter-clockwise (max. 360°) in the wanted position.
- 4. Tighten the grub screw again.




Fig. 1: Turning the transmitter housing



### **Approvals**

### General

The system meets the fundamental health and safety requirements for the design and construction of devices and protective systems intended for use in potentially explosive atmospheres in accordance with the National Electrical Code.

### No. / approval type

J.I. 3002554

### Notified body

FM: Factory Mutual Research

### Identification

The identification of the system must contain the following specifications:

- XP-IS-DIP / I, II, III / 1 / ABCDEFG / T6-T1, or XP-IS-DIP / I, II, III / 1 / CDEFG / T6-T1



The installation instructions for the safe use of the system must be observed:  $\rightarrow \stackrel{\triangle}{=} 4$ .

### Description of measuring system

The measuring system consists of transmitters and sensors.

Two versions are available:

- Compact version: transmitters and sensors form a mechanical unit.
- Remote version: transmitters and sensors are separated by open ground when installed and connected to each other via a connecting cable.



### Nameplate

The nameplates, which are mounted in a clearly visible position on the transmitter and sensor, contain all of the relevant information about the measuring system.




Fig. 2: Example for nameplates of a transmitter and of a sensor


- A Transmitter nameplate
- B Sensor nameplate
- 1 Transmitter or sensor type
- 2 Order code and serial number
- 2a Extended order code
- 3 Power supply, frequency and power consumption
- 4 Available inputs/outputs
- 5 Space for additional information on special products
- 6 Space for additional information
- 7 Type of protection
- 8 Space for notes, e.g. delays, etc.
- 9 Ambient temperature range
- 10 C-Tick symbol
- 11 Space for notified body for quality assurance monitoring
- 12 Label of notified body: Factory Mutual Research

- 13 Associated Ex documentation
- 14 Space for other approval specifications and certificates, e.g. PROFIBUS, etc. (only if present)
- 15 Calibration factor/zero point
- 16 Nominal diameter/nominal pressure
- 17 Lining material
- 18 Fluid temperature range
- 19 Pressure range of secondary containment
- 20 Accuracy of density measurement
- 21 Additional information (examples): 5P-CAL = 5-point calibration, 3.1B = 3.1 B certificate for wetted materials
- 22 Nominal diameter device
- 23 Flow direction
- 24 Nominal pressure



### Type code

The type code describes the exact design and the equipment of the measuring system. It can be read on the nameplate of the transmitter and sensor and is structured as follows:



### Housing (Pos. no. 14 in the type code)

*	Туре
A, B <sup>1)</sup> , L <sup>1)</sup> , M <sup>1)</sup> , N <sup>1)</sup>	Compact
E, F, G <sup>1)</sup> , H <sup>1)</sup> , J <sup>1)</sup> , K <sup>1)</sup> , 1 <sup>1)</sup> , 4 <sup>1)</sup> , 7 <sup>1)</sup> , 8 <sup>1)</sup>	Remote

 $<sup>^{1)}</sup>$  Not for Promass F high temperature



### Approvals (Pos. no. 13 in the type code)

	_												
*	Туре	Application/zone											
N	Compact	<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>											
	Remote	Transmitter											
		<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>											
		Sensor											
		Promass A Promass H, I, P, S Promass E, M	DN 1/24" to 1/8" DN 3/8" to 1½" DN 3/8" to 2"	<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> </ul>									
		Promass F Promass F (HT)	DN 3/8" to 2" DN 1", 2"	■ Class III									
P	Compact	<ul> <li>Class I, Groups CD</li> <li>Class I, Zone 1, Group IIB</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>											
	Remote	Transmitter											
		<ul> <li>Class I, Groups CD</li> <li>Class I, Zone 1, Group IIB</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>											
		Sensor											
		Promass H, P, S Promass I Promass M, E	DN 2" DN 1½" FB, DN 2", DN 2" FB, DN 3" DN 3"	<ul> <li>Class I, Groups CD</li> <li>Class I, Zone 1, Group IIB</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>									
		Promass F Promass F (HT)	DN 3/8" to 10" DN 3"										
0	Compact	<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>											
	Remote	Transmitter											
		<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>											
		Sensor											
		Promass H, P, S Promass I Promass M, E	DN 2" DN 1½" FB, DN 2", DN 2" FB, DN 3" DN 3"	<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> </ul>									
		Promass F Promass F (HT)	DN 3/8" to 10" DN 3"	■ Class III									

HT = high temperature FB = full bore

### Note!



### Temperature table compact version

Max. medium temperature [°F] for T1-T6 in relation to the maximum ambient temperature  $T_{\rm a}$ 

	NT	<b>T</b>	T) (	T) C	T 4 A	T.4	T 2 A	T20	TOD	T-1
	Nominal diameter [in]	<b>T<sub>a</sub></b> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
8*A**	1/24" to 1/8"	+140	140	203	239	266	284	392	392	392
	Nominal diameter [in]	<b>T</b> <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
	3/8" to 2"	+113	113	212	248	266	284	284	284	284
8*E**	1" to 2"	+122	122	212	248	266	284	284	284	284
0 L		+140	_	212	248	266	284	284	284	284
	3"	1140	140	167	203	230	284	284	284	284
	Nominal diameter [in]	<b>T</b> <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	, ,	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
	3/8" to 1½"	+122	131	158	185	212	302	365 <sup>3)</sup>	392 <sup>3)</sup>	392 <sup>3)</sup>
8*F**	2" to 10"	T122	140	158	185	221	302	365 <sup>3)</sup>	392 <sup>3)</sup>	392 <sup>3)</sup>
0 1	3/8" to 1½"	+140	131	158	185	212	302 <sup>3)</sup>	365 <sup>3)</sup>	392 <sup>3)</sup>	392 <sup>3)</sup>
	2" to 10"		140	158	185	212	302 <sup>3)</sup>	365 <sup>3)</sup>	392 <sup>3)</sup>	392 <sup>3)</sup>
	Nominal diameter [in]	T <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
8*F**-1 8*F**-2 8*F**-3 8*F**-4	1", 2", 3"	+140	158	185	212	239 <sup>3)</sup>	320 <sup>3)</sup>	401 <sup>3)</sup>	455 <sup>3)</sup>	662 <sup>3)</sup>
	Nominal diameter [in]	T <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
	3/8"	+122	122	149	185	212	284	365	392	392
8*H**	½" to 2"	1122	140	167	212	239	320	392	392	392
0 11	3/8"	+140	122	149	185	212	284	365 <sup>3)</sup>	392 <sup>3)</sup>	392 <sup>3)</sup>
	½" to 2"	1110	140	167	212	239	320	392 <sup>3)</sup>	392 <sup>3)</sup>	392 <sup>3)</sup>
	Nominal diameter [in]	<b>T</b> <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
	3/8" to 1" <sup>1)</sup>	+122	140	203	203	230	302	302	302	302
8*I**	1½" to 3" <sup>2)</sup>	1122	158	185	221	248	302	302	302	302
J 1	3/8" to 1" <sup>1)</sup>	+1/0	140	203	203	230	302 <sup>3)</sup>	302 <sup>3)</sup>	302 <sup>3)</sup>	302 <sup>3)</sup>
	1½" to 3" <sup>2)</sup>	+140	158	185	221	248	302 <sup>3)</sup>	302 <sup>3)</sup>	302 <sup>3)</sup>	302 <sup>3)</sup>
	1/2 10 3		150	105	221	240	302	302	302	302

(FB = full bore)

	Nominal diameter [in]	T <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
8*M**	3/8" to 3"	+122	122	140	185	221	302	302	302	302
0 IVI	3/0 103	+140	-	140	185	212	212	212	212	212
	Nominal diameter [in]	T <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
	3/8"	+122	-	149	185	212	284	365	392	392
	½" to 1"		122	167	212	239	320	392	392	392
0+D++	1½"		131	167	212	239	320	392	392	392
8*P** 8*S**	2"		140	167	203	230	311	392	392	392
0 0	3/8"		_	149	185	212	284	365 <sup>3)</sup>	392 <sup>3)</sup>	392 <sup>3)</sup>
	½" to 1½"	+140	_	167	212	239	320	392 <sup>3)</sup>	392 <sup>3)</sup>	392 <sup>3)</sup>
	2"		140	167	203	230	311	392 <sup>3)</sup>	392 <sup>3)</sup>	392 <sup>3)</sup>

 $<sup>^{3)}</sup>$  The maximum permissible medium temperatures only apply if the transmitter is installed in such a way that the transmitter is not fitted above the sensor and there is free convection on all sides.

The minimum **medium temperature** is -58 °F for Promass A/F/H/I/M/P/S and -40 °F for Promass E.

The minimum ambient temperature  $T_a$  to -4 °F. A version for an ambient temperature  $T_a$  to -40 °F is also optionally available.

 $<sup>^{1)}</sup>$  as well as DN ½" FB  $^{2)}$  as well as DN 1" FB, 1½" FB, 2" FB



# Remote version temperature table

### Sensor

Max. medium temperature [°F] for T1-T6 in relation to the maximum ambient temperature  $T_a$ 

	Nominal diameter [in]	T <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
8*A**	1/24" to 1/8"	+140	140	203	239	266	284	392	392	392

	Nominal diameter [in]	<b>T</b> <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
8*E**	3/8" to 2"	+113	113	212	248	257	266	284	284	284
	1" to 2"	+140	_	212	248	257	266	284	284	284
	3"		140	167	203	230	284	284	284	284

	Nominal diameter [in]	T <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
8*F**	3/8" to 1½"	+140	131	158	185	212	302	365	392	392
	2" to 10"		140	158	185	221	302	365	392	392

	Nominal diameter [in]	<b>T</b> <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
8*F**-1 8*F**-2 8*F**-3 8*F**-4	1", 2", 3"	+140	158	185	212	239	320	401	455	662

	Nominal diameter	Ta	T6	T5	T4A	T4	T3A	T2C	T2B	T1
	[in]	[°F]	(185 °F)	(212 °F)	(248 °F)	(275 °F)	(356 °F)	(446 °F)	(500 °F)	(842 °F)
8*H**	3/8"	+140	122	149	185	212	284	365	392	392
8^H^^	½" to 2"	+140	140	167	212	239	320	392	392	392

	Nominal diameter	Ta	T6	T5	T4A	T4	T3A	T2C	T2B	T1
	[in]	[°F]	(185 °F)	(212 °F)	(248 °F)	(275 °F)	(356 °F)	(446 °F)	(500 °F)	(842 °F)
8*I**	3/8" to 1" <sup>1)</sup>	+140	140	203	203	230	302	302	302	302
	1½" to 3" <sup>2)</sup>		158	185	221	248	302	302	302	302

 $<sup>^{1)}</sup>$  as well as DN  $^{1\!\!/\!2}$  FB

(FB = full bore)

	Nominal diameter	Ta	T6	T5	T4A	T4	T3A	T2C	T2B	T1
	[in]	[°F]	(185 °F)	(212 °F)	(248 °F)	(275 °F)	(356 °F)	(446 °F)	(500 °F)	(842 °F)
8*M**	3/8" to 3"	+140	122	140	185	221	212	302	302	302

	Nominal diameter [in]	<b>T</b> <sub>a</sub> [°F]	<b>T6</b> (185 °F)	<b>T5</b> (212 °F)	<b>T4A</b> (248 °F)	<b>T4</b> (275 °F)	<b>T3A</b> (356 °F)	<b>T2C</b> (446 °F)	<b>T2B</b> (500 °F)	<b>T1</b> (842 °F)
	3/8"		_	149	185	212	284	365	392	392
	½" to 1"	+122	122	167	212	239	320	392	392	392
8*P**	11/2"		131	167	212	239	320	392	392	392
8*S**	3/8"	+140	_	149	185	212	284	365	392	392
	½" to 1½"		_	167	212	239	320	392	392	392
	2"	•	140	167	203	230	311	392	392	392

The minimum **ambient temperature**  $T_a$  to -4 °F.

The minimum **medium temperature** is -58 °F for Promass A/F/H/I/M/P/S and -40 °F for Promass E.

### Transmitter

The transmitter of the remote version is temperature class T6 when installed in the Ex d housing up to an ambient temperature of  $T_a = 140$  °F. The maximum ambient temperature range is -4 to +140 °F.

A version for an  $ambient \ temperature \ T_a$  to  $-40\ ^{\circ}F$  is also optionally available.

 $<sup>^{2)}</sup>$  as well as DN 1" FB, 1½" FB, 2" FB



# Design of measuring system




Fig. 3: Design of the measuring system, compact/remote version

- A Transmitter housing (compact version)
- B Transmitter housing on connection housing, remote version
- C Sensor, connection housing, remote version
- a Screw terminal for connecting to the potential equalization
- b Connection compartment cover
- c Remote version connecting cable
- ① and ② see following chapter "Cable entries"

Note:

### Cable entries

1 Cable entries for transmitter terminal compartment (XP version) power supply/communication cable. Choice of thread for cable entry:  $\cancel{1}$ 2" NPT.

Make sure that the XP cable glands/entries are secured to prevent working loose.

 $\ensuremath{@}$  For remote version connecting cable: Choice of thread for cable entry:  $\ensuremath{^{1}\!\!/\!\!^{2}}$  NPT.

### Cable specification

You can find information about the cable specification in the associated Operating Instructions.

### Potential equalization

The transmitter (compact and remote version) must be safely integrated into the potential equalization via the screw terminal on the outside of the transmitter housing. Alternatively, the transmitter of the compact version as of serial number 4Axxxxxx000 can be integrated into the potential equalization via the pipeline as long as the pipeline provides a ground connection conforming to regulations.

Note!

Further information about potential equalization, screening and grounding can be found in the associated  $Operating\ Instructions$ .



# Connecting the remote version connecting cable




Fig. 4: Connecting the remote version connecting cable

- a Wall-mount housing: Zone 1
- b Remote version flange version

Wire colors (color code according to DIN 47100):

*Terminal number:* 4/5 = gray; 6/7 = green; 8 = yellow; 9/10 = pink; 11/12 = white; 41/42 = brown

### Terminal assignment and connection data

The remote version connection between the sensor and the transmitter is carried out with explosion protection IS.

Caution!


Only connecting cables preterminated and supplied by Endress+Hauser may be used.

### **Electrical connection**

### Connection compartment

Transmitter housing compact/remote version (terminal assignment, connection data  $\rightarrow$   $\stackrel{ }{ }$  13 ff.)

### 4 to 20 mA HART



A0005611

Fig. 5: Electrical connections

- a Power supply cable (terminal assignment, connection data  $\rightarrow$   $\stackrel{\text{\tiny l}}{=}$  13)
- b Signal cable (terminal assignment, connection data  $\rightarrow 13$ )
- c Ground terminal for signal cable shield
- d Ground terminal for protective ground
- e Service adapter for connecting the service interface FXA193 (FieldCheck, FieldCare)



# Terminal assignment and connection data: Power supply

All transmitters	1 L (+)	2 N (-)			
Designation	Supply	Protective earth			
Functional values	AC: U = 2 DC: U = 1	AC: $U = 85$ to 260 V; AC: $U = 20$ to 55 V DC: $U = 16$ to 62 V Power consumption: 15 VA / 15 W			
Intrinsically safe circuit	n	of the system!			
U <sub>m</sub>	260				

Terminal assignment and connection data for signal circuits (intrinsically safe circuits)

### Note!

The following tables contain values/specifications, which are dependent on the type code (type of measuring device). Please compare the following type code to the one shown on the nameplate of your measuring device. For a graphic representation of the electrical connections:  $\rightarrow \boxed{12}$ .

### Terminal assignment of transmitter 80\*\*\*-\*\*\*\*\*\*\*\*S+#\*\*#

T		Terminal no. (inputs/outputs)									
Transmitter	20 (+)	21 (-)	22 (+)	23 (-)	24 (+)	25 (-)	26 (+)	27 (-)			
Assignment				quency output, assive	Current output HART, active						
Electric circuit	-	_	-	_	intrin	sically safe	intrin	sically safe			
Safety-related values	-	-		-	$ \begin{array}{c c} & \text{intrinsically safe} \\ \hline U_i & 30 \text{ V DC} \\ I_i & 500 \text{ mA} \\ P_i & 600 \text{ mW} \\ L_i & \text{negligible} \\ C_i & 6 \text{ nF} \\ \hline \end{array} $		C <sub>o</sub> IIC/IIB  1) L <sub>o</sub> IIC/IIB	21.8 V DC 90 mA 490 mW 4.1 mH/15 mH 150 nF/1160 nF 2 mH/10 mH 80 nF/300 nF 30 V DC <sup>2)</sup> 10 mA <sup>2)</sup> 0.3 W <sup>2)</sup> negligible 6 nF			
Functional values			galvanically is passive: 30 V Open Collect Full scale free 2 to 5000 Hz	DC / 250 mA or juency	galvanically isolated, active: $0/4$ to $20$ mA $R_L < 400 \ \Omega$ $R_L$ HART $\geq 250 \ \Omega$						

<sup>1)</sup> Permitted values if concentrated inductance and capacitance occur simultaneously.

### Terminal assignment of transmitter 80\*\*\*-\*\*\*\*\*\*\*\*T+#\*\*#

Transmitter					Terminal no.	(inputs/outputs)			
Transmitter	20 (+)	21 (-)	22 (+)	23 (-)	24 (+)	25 (–)	26 (+)	27 (-)	
Assignment	-				Pulse/frequency output, passive		Current output HART, passive		
Electric circuit	-	-		_	intrin	intrinsically safe		sically safe	
Safety-related values	-	_		_	$\begin{array}{c} U_i \\ I_i \\ P_i \\ L_i \\ C_i \end{array}$	30 V DC 500 mA 600 mW negligible 6 nF	$\begin{array}{c} U_i \\ I_i \\ P_i \\ L_i \\ C_i \end{array}$	30 V DC 100 mA 1.25 W negligible 6 nF	
Functional values	-	-		_	galvanically isolated, passive: 30 V DC / 250 mA Open Collector Full scale frequency 2 to 5000 Hz		galvanically isolated, passive: 4 to 20 mA voltage drop $\leq$ 9 V $R_L < [(V_{p. \ supply} - 9 \ V) \div 25 \ mA]$		

<sup>&</sup>lt;sup>2)</sup> The interconnection must be assessed according to the valid construction provisions.



Terminal assignment and connection data for signal circuits (non-intrinsically safe circuits)

### Note!

The following tables contain values/specifications, which are dependent on the type code (type of measuring device). Please compare the following type code to the one shown on the nameplate of your measuring device. For a graphic representation of the electrical connections:  $\rightarrow \boxed{12}$ .

### Terminal assignment

Order	Terminal no. (inputs/outputs)									
characteristic "Inputs/outputs"	20 (+)	21 (-)	22 (+) 23 (-)		24 (+)	25 (-)	26 (+)	27 (-)		
A	-	_	-		Pulse/frequency output		Current output HART			
D	Status	input	Relay output		Pulse/frequency output		Current output HART			
8	Status	input	Pulse/frequ	Pulse/frequency output		Current output 2		Current output 1 HART		

### Safety-related and functional values of signal circuits

Signal circuits	Functional values	Safety-related values
Current output HART	galvanically isolated, active/passive can be selected:  active: $0/4$ to $20$ mA $R_L < 700 \Omega$ , $R_L$ HART $\geq 250 \Omega$ passive: 4 to $20$ mA $V_s = 18$ to $30$ V DC, $R_i \geq 150 \Omega$	$\begin{array}{ll} \text{intrinsically} &= \text{no} \\ \text{safe} &= 260 \text{ V} \\ \text{U}_{\text{m}} &= 500 \text{ mA} \\ \text{I}_{\text{m}} \end{array}$
Current output	galvanically isolated, active/passive can be selected:  active: $0/4$ to $20$ mA $R_L < 700 \Omega$ passive: 4 to $20$ mA $V_s = 18$ to $30$ V DC, $R_i \ge 150 \Omega$	
Pulse/frequency output	galvanically isolated, active/passive can be selected:  active: 24 V DC / 25 mA (max. 250 mA during 20 ms) $R_L > 100 \Omega$ passive: 30 V DC / 250 mA Open Collector  Full scale frequency 2 to 10 000 Hz ( $f_{max} = 12500 \text{ Hz}$ )	
Relay output	galvanically isolated, max. 30 V AC / 500 mA max. 60 V DC / 100 mA	
Status input	galvanically isolated, 3 to 30 V DC $R_i = 5 \ k\Omega$	



### Service adapter

The service adapter is only used for connecting service interfaces approved by Endress+Hauser.

⚠ Warning!

It is not permissible to connect the service adapter whilst the atmosphere is considered to be explosive.

### Device fuse

### 

Only use the following fuse types that are mounted on the power unit board:

- Voltage 20 to 55 V AC / 16 to 62 V DC:
   Fuse 2.0 A slow-blow, disconnect capacity 1500 A (Schurter, 0001.2503 or Wickmann, Standard Type 181 2.0 A)
- Voltage 85 to 260 V AC:
   Fuse 0.8 A slow-blow, disconnect capacity 1500 A
   (Schurter, 0001.2507 or Wickmann, Standard Type 181 0.8 A)

### **Technical Data**

### **Dimensions**

Please refer to the respective Technical Information for these dimensions:

- Promass 80A, 83A → TI00054D
- Promass 80E, 83E  $\rightarrow$  TI00061D
- Promass 80F, 83F  $\rightarrow$  TI00101D
- Promass  $80\dot{M}$ ,  $83M \rightarrow TI10002D$
- Promass 80H, 83H  $\rightarrow$  TI00074D
- Promass 80I, 83I  $\rightarrow$  TI00075D
- Promass 80P, 83P → TI00078D
- Promass 80S, 83S → TI00076D

### Weight

- The weight of the XP version is approx. 4.4 lbs greater than that of the standard version.
- The weight of the XP version in stainless steel is approx. 20 lbs greater than that of the standard version.

### **Control Drawings**

Endress+Hauser Reinach hereby declares that the product is in conformity with the requirements of the FACTORY MUTUAL standard.

Note!

The "Documentation/Important Information" folder provided with the measuring device contains a CD-ROM with all the Control Drawings.





















# Safety Instructions

# Proline Promass 80

# Division 1

# **®** Ex documentation

### This document is an integral part of the following Operating Instructions:

■ BA00057D, Proline Promass 80 HART

### **Table of Contents CSA**

Special conditions	18
General warnings	18
Approvals	19
Description of measuring system	19
Nameplate	20
Type code	21
Temperature table compact version	23
Remote version temperature table	24
Design of measuring system	25
Cable entries	25
Cable specification	25
Potential equalization	25
Connecting the remote version connecting cable	26
Electrical connection	26
Terminal assignment and connection data: Power supply	27
Terminal assignment and connection data for signal circuits (intrinsically safe circuits)	27
Terminal assignment and connection data for signal circuits (non-intrinsically safe circuits)	28
Service adapter	29
Device fuse	29
Technical Data	29
Control Drawings	2.9





### Special conditions

- Install per Canadian Electrical Code.
- Control room equipment shall not use or generate more than 250 V rms.
- The device must be integrated into the potential equalization system.

- It is not permissible to connect the service adapter whilst the atmosphere is considered to be explosive.
- Use of the devices is restricted to mediums against which the process-wetted materials are adequately resistant.
- Use supply wires suitable for 5 °C above ambient temperature, but least for 80 °C.
- Transmitter enclosure G02 explosionproof for use in Class 1 Division 1 Groups A, B, C, D (seals not required) and dust-ignition proof for Class II, III Division 1 Groups E, F, G.
- Sensor circuits intrinsically safe for Cl. I, II, III Div. 1 Group A, B, C, D, E, F, G except Promass M: DN 80 (sensor version Group C-D)
   Promass E: DN 80 (sensor version Group C-D)

Promass I: DN 40FB/50/50FB/80 (sensor version Group C-D)

Promass F: DN 80/100/150/250 (sensor version Group C-D)

Promass H, P, S: DN 50 (sensor version Group C-D)

which are only suitable for Cl. I, II, III Div. 1 Group C, D, E, F, G. (optionally, a version for Groups A and B is available)

• Substitution of components may impair intrinsic safety.



Use supply wires suitable for 5 °C above ambient temperature, but at least for 80 °C.

### General warnings

- Installation, connection to the electricity supply, commissioning and maintenance of the devices must be carried out by qualified specialists trained to work on Ex-rated devices.
- Compliance with national regulations relating to the installation of devices in potentially explosive atmospheres is mandatory, if such regulations exist.
- Open the device only when it is de-energized (and after a delay of at least 10 minutes following shutdown of the power supply).
- The housing of the Ex-rated transmitter can be turned in 90° steps. Whereas the non-Ex version has a bayonet adapter, however, the Ex version has a thread. Recesses for centering the worm screw are provided to prevent inadvertent movement of the transmitter housing.

  It is permissible to turn the transmitter housing through a maximum of 180° during operation (in either direction), without compromising explosion protection. After turning the housing the worm screw must be tightened again.
- The screw cap has to be removed before the local display can be turned, and this must be done with the device de-energized (and after a delay of at least 10 minutes following shutdown of the power supply).

### Turning the transmitter housing

- 1. Unscrew the grub screw.
- 2. Rotate the transmitter housing cautiously clockwise until the end stop (end of the thread).
- 3. Rotate the transmitter housing counter-clockwise (max. 360°) in the wanted position.
- 4. Tighten the grub screw again.




Fig. 1: Turning the transmitter housing



### **Approvals**

### General

The system meets the fundamental health and safety requirements for the design and construction of devices and protective systems intended for use in potentially explosive atmospheres in accordance with the Canadian Electrical Code.

### No. / approval type

160686-1132623

### Notified body

CSA: Canadian Standard Association

### Identification

The identification of the system must contain the following specifications: or

- Class I, Groups ABCD
- Class I, Zone 1, Group IIC
- Class II, Groups EFG
- Class III

- Class I, Groups CD
- Class I, Zone 1, Group IIB
- Class II, Groups EFG
- Class III



The installation instructions for the safe use of the system must be observed  $\rightarrow 18$ .

### Description of measuring system

The measuring system consists of transmitters and sensors.

Two versions are available:

- Compact version: transmitters and sensors form a mechanical unit.
- Remote version: transmitters and sensors are separated by open ground when installed and connected to each other via a connecting cable.



### Nameplate

The nameplates, which are mounted in a clearly visible position on the transmitter and sensor, contain all of the relevant information about the measuring system.




Fig. 2: Example for nameplates of a transmitter and of a sensor


- Transmitter nameplate
- В Sensor nameplate
- Transmitter or sensor type
- 2 Order code and serial number
- 2a Extended order code
- Power supply, frequency and power consumption
- 4 Available inputs/outputs
- Space for additional information on special products
- Space for additional information
- Type of protection
- Space for notes, e.g. delays, etc.
- Ambient temperature range
- 10 C-Tick symbol
- 11 Space for notified body for quality assurance monitoring

- 13 Associated Ex documentation
- 14 Space for other approval specifications and certificates, e.g. PROFIBUS, etc. (only if present)
- 15 Calibration factor/zero point
- 16 Nominal diameter/nominal pressure
- 17 Lining material
- 18 Fluid temperature range
- 19 Pressure range of secondary containment
- 20 Accuracy of density measurement
- 21 Additional information (examples): 5P-CAL = 5-point calibration, 3.1B = 3.1 B certificate for wetted materials
- 22 Nominal diameter device
- 23 Flow direction
- 12 Label of notified body: Canadian Standards Association 24 Nominal pressure



### Type code

The type code describes the exact design and the equipment of the measuring system. It can be read on the nameplate of the transmitter and sensor and is structured as follows:



### Housing (Pos. no. 14 in the type code)

*	Туре
A, B $^{1)}$ , L $^{1)}$ , M $^{1)}$ , N $^{1)}$	Compact
$E, F, G^{(1)}, H^{(1)}, J^{(1)}, K^{(1)}, I^{(1)}, 4^{(1)}, 7^{(1)}, 8^{(1)}$	Remote

 $<sup>^{1)}</sup>$  Not for Promass F high temperature



### Approvals (Pos. no. 13 in the type code)

*	Туре	Application/zone								
N	Compact	<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>								
	Remote	Transmitter								
		<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>								
		Sensor								
		Promass A Promass H, I, P, S Promass E, M	DN 1 to 4 DN 8 to 40 DN 8 to 50	<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> </ul>						
		Promass F Promass F (HT)	DN 8 to 50 DN 25, DN 50	Class III						
P	Compact	<ul> <li>Class I, Groups CD</li> <li>Class I, Zone 1, Group IIB</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>								
	Remote	Transmitter								
		<ul> <li>Class I, Groups CD</li> <li>Class I, Zone 1, Group IIB</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>								
		Sensor								
		Promass H, P, S Promass I Promass M, E	DN 50 DN 40 FB, DN 50, DN 50 FB, DN 80 DN 80	<ul> <li>Class I, Groups CD</li> <li>Class I, Zone 1, Group IIB</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>						
		Promass F Promass F (HT)	DN 80 to 250 DN 80							
0	Compact	<ul> <li>Class I, Groups ABCD</li> <li>Class I, Zone 1, Group IIC</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>								
	Remote	Transmitter								
		<ul> <li>Class I, Groups CD</li> <li>Class I, Zone 1, Group IIB</li> <li>Class II, Groups EFG</li> <li>Class III</li> </ul>								
		Sensor								
		Promass H, P, S Promass I Promass M, E	DN 50 DN 40 FB, DN 50, DN 50 FB, DN 80 DN 80	<ul> <li>Class I, Groups CD</li> <li>Class I, Zone 1, Group IIB</li> <li>Class II, Groups EFG</li> </ul>						
		Promass F Promass F (HT)	DN 80 to 250 DN 80	■ Class III						

 $HT = high\ temperature$ 

 $FB = full\ bore$ 

### Note!

For a detailed explanation of these values with regard to the outputs and inputs available, as well as a description of the associated terminal assignment and connection data:  $\rightarrow \stackrel{\text{\tiny $\square$}}{=} 26$ .



### Temperature table compact version

Max. medium temperature [°C] for T1–T6 in relation to the maximum ambient temperature  $T_{\text{a}}$ 

	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	T5	<b>T4A</b> (120 °C)	T4	T3A	T2C	<b>T2B</b>	T1
8*A**	1 to 4	+60	60	95	115	130	140	200	` ′	200
8^A^^	1 to 4	+00	00	95	115	130	140	200	200	200
	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
	8 to 50	+45	45	100	120	130	140	140	140	140
8*E**	25 to 50	+50	50	100	120	130	140	140	140	140
0 L	23 10 30	+60	_	100	120	130	140	140	140	140
	80	100	60	75	95	110	140	140	140	140
	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)		<b>T1</b> (450 °C)
	8 to 40	. 50	55	70	85	100	150	185 <sup>3)</sup>	200 <sup>3)</sup>	200 <sup>3)</sup>
8*F**	80 to 250	+50	60	70	85	105	150	185 <sup>3)</sup>	200 3)	200 <sup>3)</sup>
8^F^^	8 to 40	+60	55	70	85	100	150 <sup>3)</sup>	185 <sup>3)</sup>	200*	200 <sup>3)</sup>
	50 to 250	+00	60	70	85	100	150 <sup>3)</sup>	185 <sup>3)</sup>	200 <sup>3)</sup>	200 <sup>3)</sup>
	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
8*F**-1 8*F**-2 8*F**-3 8*F**-4	25, 50, 80	+60	70	85	100	115 <sup>3)</sup>	160 <sup>3)</sup>	205 <sup>3)</sup>	235 <sup>3)</sup>	350 <sup>3)</sup>
	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
	8	+50	50	65	85	100	140	185	200	200
8*H**	15 to 50	+30	60	75	100	115	160	200	200	200
0 11	8	+60	50	65	85	100	140	185 <sup>3)</sup>	200 <sup>3)</sup>	200 <sup>3)</sup>
	15 to 50	+00	60	75	100	115	160	200 <sup>3)</sup>	200 <sup>3)</sup>	200 <sup>3)</sup>
	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
	8 to 25 <sup>1)</sup>	+50	60	95	95	110	150	150	150	150
8*I**	40 to 80 <sup>2)</sup>	T30	70	85	105	120	150	150	150	150
0 1	8 to 25 <sup>1)</sup>	+60	60	95	95	110	150 <sup>3)</sup>	150 <sup>3)</sup>	150 <sup>3)</sup>	150 <sup>3)</sup>
	40 to 80 <sup>2)</sup>	+00	70	85	105	120	150 <sup>3)</sup>	150 <sup>3)</sup>	150 <sup>3)</sup>	150 <sup>3)</sup>

(FB = full bore)

	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
8*M**	8 to 80	+50	50	60	85	105	150	150	150	150
0 101	0 10 00	+60	_	60	85	100	100	100	100	100

	Nominal diameter [mm]	<b>T</b> <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
	8		_	65	85	100	140	185	200	200
	15 to 25	+50	50	75	100	115	160	200	200	200
0+D++	40	<del>+</del> 30	55	75	100	115	160	200	200	200
8*P** 8*S**	50		60	75	95	110	155	200	200	200
0 0	8		_	65	85	100	140	185 <sup>3)</sup>	200 <sup>3)</sup>	200 <sup>3)</sup>
	15 to 40	+60	_	75	100	115	160	200 <sup>3)</sup>	200 <sup>3)</sup>	200 <sup>3)</sup>
	50		60	75	95	110	155	200 <sup>3)</sup>	200 <sup>3)</sup>	200 <sup>3)</sup>

 $<sup>^{3)}</sup>$  The maximum permissible medium temperatures only apply if the transmitter is installed in such a way that the transmitter is not fitted above the sensor and there is free convection on all sides.

The minimum **medium temperature** is -50 °C for Promass A/F/H/I/M/P/S and -40 °C for Promass E.

The minimum ambient temperature  $T_a$  to -20 °C. A version for an ambient temperature  $T_a$  to -40 °C is also optionally available.

 $<sup>^{1)}</sup>$  as well as DN 15 FB  $^{2)}$  as well as DN 25 FB, 40 FB, 50 FB



# Remote version temperature table

### Sensor

Max. medium temperature [ ${}^{\circ}$ C] for T1-T6 in relation to the maximum ambient temperature  $T_a$ 

	Nominal diameter	Ta	T6	T5	T4A	T4	T3A	T2C	T2B	T1
	[mm]	[°C]	(85 °C)	(100 °C)	(120 °C)	(135 °C)	(180 °C)	(230 °C)	(260 °C)	(450 °C)
8*A**	1 to 4	+60	60	95	115	130	140	200	200	200

	Nominal diameter [mm]	<b>T</b> <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
	8 to 50	+45	45	100	120	130	140	140	140	140
8*E**	25 to 50	+60	_	100	120	130	140	140	140	140
	80	+00	60	75	95	110	140	140	140	140

	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
8*F**	8 to 40	+60	55	70	85	100	150	185	200	200
O 1	50 to 250	+00	60	70	85	105	150	185	200	200

	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
8*F**-1 8*F**-2 8*F**-3 8*F**-4	25, 50, 80	+60	70	85	100	115	160	205	235	350

	Nominal diameter	a	T6	T5	T4A	T4	T3A	T2C	T2B	T1
	[mm]	[°C]	(03 C)	(100 C)	(120 C)	(135 °C)	(100 C)	(230 C)	(200 C)	(430 C)
8*H**	8	+60	50	65	85	100	140	185	200	200
8^H^^	15 to 50	100	60	75	100	115	160	200	200	200

	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
8*I**	8 to 25 <sup>1)</sup>	+60	60	95	95	110	150	150	150	150
0 1	40 to 80 <sup>2)</sup>	+00	70	85	105	120	150	150	150	150

<sup>1)</sup> as well as DN 15 FB

(FB = full bore)

	Nominal diameter	Ta	T6	T5	T4A	T4	T3A	T2C	T2B	T1
	[mm]	[°Č]	(85 °C)	(100 °C)	(120 °C)	(135 °C)	(180 °C)	(230 °C)	(260 °C)	(450 °C)
8*M**	8 to 80	+60	50	60	85	105	150	150	150	150

	Nominal diameter [mm]	T <sub>a</sub> [°C]	<b>T6</b> (85 °C)	<b>T5</b> (100 °C)	<b>T4A</b> (120 °C)	<b>T4</b> (135 °C)	<b>T3A</b> (180 °C)	<b>T2C</b> (230 °C)	<b>T2B</b> (260 °C)	<b>T1</b> (450 °C)
	8		_	65	85	100	140	185	200	200
	15 to 25	+50	50	75	100	115	160	200	200	200
8*P**	40		55	75	100	115	160	200	200	200
8*S**	8		_	65	85	100	140	185	200	200
	15 to 40	+60	_	75	100	115	160	200	200	200
	50		60	75	95	110	155	200	200	200

The minimum ambient temperature  $T_a$  to  $-20~^{\circ}C$ .

The minimum **medium temperature** is -50 °C for Promass A/F/I/M/H/P/S and -40 °C for Promass E.

### Transmitter

The transmitter of the remote version is temperature class T6 when installed in the Ex d housing up to an ambient temperature of  $T_a = 60$  °C. The maximum ambient temperature range is -20 to +60 °C.

A version for an  $ambient \ temperature \ T_a$  to  $-40\ ^{\circ}C$  is also optionally available.

<sup>&</sup>lt;sup>2)</sup> as well as DN 25 FB, 40 FB, 50 FB



# Design of measuring system




Fig. 3: Design of the measuring system, compact/remote version

- A Transmitter housing (compact version)
- B Transmitter housing on connection housing, remote version
- C Sensor, connection housing, remote version
- a Screw terminal for connecting to the potential equalization
- b Connection compartment cover
- c Remote version connecting cable
- ① and ② see following chapter "Cable entries"

Note Note

For connecting the remote version connecting cable  $\rightarrow$   $\stackrel{ }{=}$  26

### Cable entries

1 Cable entries for transmitter terminal compartment (XP version) power supply/communication cable. Choice of thread for cable entry:  $\cancel{1}$ 2" NPT.

Make sure that the XP cable glands/entries are secured to prevent working loose.

 $\ensuremath{@}$  For remote version connecting cable: Choice of thread for cable entry:  $\ensuremath{^{1}\!\!/\!\!^{2}}$  NPT.

### Cable specification

You can find information about the cable specification in the associated Operating Instructions.

### Potential equalization

The transmitter (compact and remote version) must be safely integrated into the potential equalization via the screw terminal on the outside of the transmitter housing. Alternatively, the transmitter of the compact version as of serial number 4Axxxxxx000 can be integrated into the potential equalization via the pipeline as long as the pipeline provides a ground connection conforming to regulations.

### Note!

Further information about potential equalization, screening and grounding can be found in the associated  $Operating\ Instructions$ .



# Connecting the remote version connecting cable




Fig. 4: Connecting the remote version connecting cable

- a Wall-mount housing: Zone 1
- b Remote version flange version

Wire colors (color code according to DIN 47100):

Terminal number: 4/5 = gray; 6/7 = green; 8 = yellow; 9/10 = pink; 11/12 = white; 41/42 = brown

### Terminal assignment and connection data

The remote version connection between the sensor and the transmitter is carried out with explosion protection IS.




Only connecting cables preterminated and supplied by Endress+Hauser may be used.

### **Electrical connection**

### Connection compartment

Transmitter housing compact/remote version (terminal assignment, connection data  $\rightarrow \stackrel{\triangle}{=} 27 \text{ ff.}$ )

### 4 to 20 mA HART



A0005611

Fig. 5: Electrical connections

- a Power supply cable (terminal assignment, connection data  $\rightarrow$   $\stackrel{\text{\tiny l}}{=}$  27)
- b Signal cable (terminal assignment, connection data  $\rightarrow 27$ )
- c Ground terminal for signal cable shield
- d Ground terminal for protective ground
- e Service adapter for connecting the service interface FXA193 (FieldCheck, FieldCare)



# Terminal assignment and connection data: Power supply

All transmitters	1 L (+)	2 N (-)	
Designation	Supply	voltage	Protective earth
Functional values	AC: U = 2 DC: U = 3	5 to 260 V; 20 to 55 V 16 to 62 V on: 15 VA / 15 W	Caution! Observe the grounding concepts
Intrinsically safe circuit	n	10	of the system!
U <sub>m</sub>	260	V AC	

Terminal assignment and connection data for signal circuits (intrinsically safe circuits)

### Note!

The following tables contain values/specifications, which are dependent on the type code (type of measuring device). Please compare the following type code to the one shown on the nameplate of your measuring device. For a graphic representation of the electrical connections:  $\rightarrow \stackrel{\text{le}}{=} 26$ .

### 

Tananamittan		Terminal no. (inputs/outputs)								
Transmitter	20 (+)	21 (-)	22 (+)	23 (-)	24 (+)	25 (-)	26 (+)	27 (-)		
Assignment	-		-		Pulse/frequency output, passive		Current output HART, active			
Electric circuit	-	_		-	intrinsically safe		intrinsically safe			
Safety-related values	-	-	-	-	$\begin{array}{c} U_i \\ I_i \\ P_i \\ L_i \\ C_i \end{array}$	30 V DC 500 mA 600 mW negligible 6 nF	C <sub>o</sub> IIC/IIB  1) L <sub>o</sub> IIC/IIB	21.8 V DC 90 mA 490 mW 4.1 mH/15 mH 160 nF/1160 n 2 mH/10 mH 80 nF/300 nF 30 V DC <sup>2)</sup> 10 mA <sup>2)</sup> 0.3 W <sup>2)</sup> negligible 6 nF		
Functional values	-	if concentrated industance and co		_	Open Collect Full scale free 2 to 5000 Hz	DC / 250 mA or quency	galvanically isolated, active: $0/4$ to $20$ mA $R_L < 400~\Omega$ $R_L$ HART $\geq 250~\Omega$			

<sup>1)</sup> Permitted values if concentrated inductance and capacitance occur simultaneously.

### Terminal assignment of transmitter 80\*\*\*-\*\*\*\*\*\*\*\*T+#\*\*#

Transmitter	Terminal no. (inputs/outputs)							
Transmitter	20 (+)	21 (-)	22 (+)	23 (-)	24 (+)	25 (-)	26 (+)	27 (-)
Assignment			Pulse/frequency output, passive		Current output HART, passive			
Electric circuit			intrinsically safe		intrinsically safe			
Safety-related values			_	$\begin{array}{lll} U_i & 30 \text{ V DC} \\ I_i & 500 \text{ mA} \\ P_i & 600 \text{ mW} \\ L_i & \text{negligible} \\ C_i & 6 \text{ nF} \end{array}$		$\begin{array}{lll} U_i & 30 \text{ V DC} \\ I_i & 100 \text{ mA} \\ P_i & 1.25 \text{ W} \\ L_i & \text{negligible} \\ C_i & 6 \text{ nF} \end{array}$		
Functional values	-	_		_	galvanically is passive: 30 V Open Collect Full scale free 2 to 5000 Hz	DC / 250 mA or juency	galvanically isolated, passive: 4 to 20 mA voltage drop $\leq$ 9 V $R_L < [(V_{p. \ supply} - 9 \ V) \div 25 \ mA$	

 $<sup>^{2)}\ \</sup>mbox{The interconnection}$  must be assessed according to the valid construction provisions.



Terminal assignment and connection data for signal circuits (non-intrinsically safe circuits)

### Note!

The following tables contain values/specifications, which are dependent on the type code (type of measuring device). Please compare the following type code to the one shown on the nameplate of your measuring device. For a graphic representation of the electrical connections:  $\rightarrow \stackrel{\text{le}}{=} 26$ .

### Terminal assignment

Order	Terminal no. (inputs/outputs)								
characteristic "Inputs/outputs"	20 (+)	21 (-)	22 (+)	23 (-)	24 (+)	25 (–)	26 (+)	27 (-)	
A	_		_		Pulse/frequency output		Current output HART		
D	Status input		Relay output		Pulse/frequency output		Current output HART		
8	Status input		Pulse/frequency output		Current output 2		Current output 1 HART		

### Safety-related and functional values of signal circuits

Signal circuits	Functional values	Safety-related values		
Current output HART	galvanically isolated, active/passive can be selected:  active: $0/4$ to $20$ mA $R_L < 700 \Omega$ , $R_L$ HART $\geq 250 \Omega$ passive: 4 to $20$ mA $V_S = 18$ to $30$ V DC, $R_i \geq 150 \Omega$	$\begin{array}{lll} & \text{intrinsically safe} & = \text{no} \\ & & & \\ & U_m & & = 260 \text{ V} \\ & & & \\ & I_m & & = 500 \text{ mA} \end{array}$		
Current output	galvanically isolated, active/passive can be selected:  active: $0/4$ to $20$ mA $R_L < 700 \Omega$ passive: 4 to $20$ mA $V_s = 18$ to $30$ V DC, $R_i \ge 150 \Omega$			
Pulse/frequency output	galvanically isolated, active/passive can be selected:  active: 24 V DC / 25 mA (max. 250 mA during 20 ms) $R_L > 100 \Omega$ passive: 30 V DC / 250 mA Open Collector  Full scale frequency 2 to 10 000 Hz ( $f_{max} = 12500 \text{ Hz}$ )			
Relay output	galvanically isolated, max. 30 V AC / 500 mA max. 60 V DC / 100 mA			
Status input	galvanically isolated, 3 to 30 V DC $R_i = 5 \ k\Omega$			



### Service adapter

The service adapter is only used for connecting service interfaces approved by Endress+Hauser.

⚠ Warning!

It is not permissible to connect the service adapter whilst the atmosphere is considered to be explosive.

### Device fuse

### 

Only use the following fuse types that are mounted on the power unit board:

- Voltage 20 to 55 V AC / 16 to 62 V DC:
   Fuse 2.0 A slow-blow, disconnect capacity 1500 A (Schurter, 0001.2503 or Wickmann, Standard Type 181 2.0 A)
- Voltage 85 to 260 V AC:
   Fuse 0.8 A slow-blow, disconnect capacity 1500 A
   (Schurter, 0001.2507 or Wickmann, Standard Type 181 0.8 A)

### **Technical Data**

### **Dimensions**

Please refer to the respective Technical Information for these dimensions:

- Promass 80A, 83A → TI00054D
- Promass 80E, 83E  $\rightarrow$  TI00061D
- Promass 80F, 83F  $\rightarrow$  TI00101D
- Promass  $80\dot{M}$ ,  $83M \rightarrow TI00102D$
- Promass 80H, 83H  $\rightarrow$  TI00074D
- Promass 80I, 83I  $\rightarrow$  TI00075D
- Promass 80P, 83P → TI00078D
- Promass 80S, 83S → TI00076D

### Weight

- The weight of the XP version is approx. 2 kg greater than that of the standard version.
- The weight of the XP version in stainless steel is approx. 9 kg greater than that of the standard version.

### **Control Drawings**

Endress+Hauser Reinach hereby declares that the product is in conformity with the requirements of the CANA-DIAN STANDARDS ASSOCIATION.

Note!

The "Documentation/Important Information" folder provided with the measuring device contains a CD-ROM with all the Control Drawings.



www.endress.com/worldwide



People for Process Automation