Safety Instructions iTHERM SurfaceLine TM611

ATEX, IECEx: Ex db IIC T6 Gb Ex tb IIIC Txxx °C Db







iTHERM SurfaceLine TM611

Table of contents

About this document	3
Associated documentation	3
Supplementary documentation	3
Certificates and declarations	3
Manufacturer address	3
Safety instructions	4
Safety instructions: Installation of protection flameproof	4
Safety instructions: Installation of Dust ignition protection	5
Safety instructions: Specific conditions of use	6
Temperature tables	7
Electrical connection data	8

About this document	The document number of these Safety Instructions (XA) must match the information on the nameplate.		
Associated documentation	All documentation is available on the Internet: www.endress.com/Deviceviewer (enter the serial number from the nameplate).		
	ordered.		
	To commission the device, please observe the Operating Instructions pertaining to the device: www.endress.com/ <product code="">, e.g. iTHERM TM611</product>		
Supplementary	Explosion protection brochure: CP00021Z		
documentation	The explosion protection brochure is available on the Internet: www.endress.com/Downloads		
Certificates and	IECEx certificate		
declarations	Certificate number: IECEx DEK 24.0034X		
	Affixing the certificate number certifies conformity with the following standards (depending on the device version)		
	 IEC 60079-0: 2017 IEC 60079-1: 2014 IEC 60079-31: 2013 		
	ATEX certificate		
	Certificate number: DEKRA 24ATEX0055 X		
	EU Declaration of Conformity		
	Declaration number: EC_01229		
	The EU Declaration of Conformity is available on the Internet: www.endress.com/Downloads		
	UKCA Declaration of Conformity		
	Declaration number: UK_00602		
Manufacturer address	Endress+Hauser Wetzer GmbH + Co. KG Obere Wank 1 87484 Nesselwang, Germany		

Safety instructions



Safety instructions: Installation of protection flameproof

- Comply with the installation and safety instructions in the Operating Instructions.
- Install the device according to the manufacturer's instructions and any other valid standards and regulations (e.g. EN/IEC 60079-14).
- The housing of the thermometer must be connected to the potential matching line.
- Only the approved wire entries as specified in paragraph 10 of IEC/EN 60079-14, paragraph 16 of IEC/EN 60079-0, paragraph 13 of IEC/EN 60079-1 must be used.
- For connection through a conduit entry approved for this purpose the associated sealing facility shall be mounted directly to the housing.
- Seal the cable entries with certified cable glands and or blanking elements which have at least type of protection Ex db and Ex tb suitable for Group IIC and IIIC (degree of protection IP6X).

- The maximum specified ambient temperature Ta at terminal head not be exceeded.
- For operating the thermometer housing at an ambient temperature under -20 °C appropriate cables and cable entries permitted for this application must be used.
- For ambient temperatures higher than +65 °C, use suitable heatresisting cables or wires, cable entries and sealing facilities for Ta +5 K above surrounding.
- During operation, the cover must be screwed all the way in and the cover's safety catch must be fastened.
- The thermometer must be installed and maintained so, that even in the event of rare incidents, an ignition source due to impact or friction between the enclosure and iron/steel is excluded

WARNING

Potentially explosive atmospheres

- ► Do not open the electrical connection of the supply circuit when energized if there is a potentially explosive atmosphere.
- Safety instructions: Installation of Dust ignition protection
- Comply with the installation and safety instructions in the Operating Instructions.
- Install the device according to the manufacturer's instructions and any other valid standards and regulations (e.g. EN/IEC 60079-14).
- Seal the cable entries tight with certified cable which have at least type of protection Ex tb suitable for Group IIIC (degree of protection IP6X).
- For assure that the temperature assembly has a degree of protection of IP6X the user shall provide a thermowell or equivalent component at the process side.
- The housing of the thermometer must be connected to the potential matching line.
- For ambient temperatures higher than +65 °C, use suitable heatresisting cables or wires, cable entries and sealing facilities for Ta +5 K above surrounding.

WARNING

Explosive atmosphere

In an explosive atmosphere, do not open the device when voltage is supplied (ensure that the IP6x housing protection is maintained during operation).

Safety instructions: Specific conditions of use

- The flameproof joints are not intended to be repaired.
- It shall be verified, taking into account the worst case process and ambient temperatures,
 - that the temperature of the enclosure at the process connection point does not exceed the ambient temperature range of the assembly and
 - the temperature of the coupling element does not exceed the service temperature range for following option:

d	Material coupling element	Service temperature range
xx	1.4404	−50 to +450 °C
xx	AISi 1MgMn	−50 to +150 °C
ΥΥ	1.4529, 2.4816, 2.4819	−50 to +450 °C
ΥΥ	1.4547	−20 to +400 °C
ΥΥ	1.4539	−50 to +425 °C
ҮҮ	1.4462	−30 to +300 °C
ҮҮ	1.4410	−35 to +260 °C

ТМ611-а b с d.....

- Temperature assemblies with flying leads (type iTHERM TM611 suffix code h = 0A) shall be provided with a round transmitter of max. 2.2 W with a main diameter not exceeding 45 mm and a sensor signal of max 10 V_{DC} and 1 mA.
- iTHERM TM611 temperature sensor is to be protected by its provided coupling element, type TT611.

Temperature tables

The relation between the type, electrical connection, temperature class, maximum surface temperature, ambient temperature range and process temperature range is shown in the following table.

Temperature assemblies with RTD temperature sensors			
Electrical connection ¹⁾	Temperature class/ Maximum surface temperature	Ambient	Process temperature range
		temperature range	Insert diameter 3 mm
	Type iTHERM TM611		
	T6/T85 ℃	−50 to +70 °C	−50 to +55 °C
	T5/T100 °C	–50 to +80 °C	−50 to +70 °C
Terminal block (1A) ²⁾	T4/T135 °C	−50 to +120 °C	−50 to +105 °C
	T3/T200 °C	−50 to +120 °C	–50 to +170 °C
	T2/T300 °C	−50 to +120 °C	−50 to +265 °C
	T1/T450 °C	–50 to +120 °C	–50 to +415 °C
Type iTHERM TM611			
Flying leads (0A)	T6/T85 ℃	−40 to +65 °C	−50 to +55 °C
Transmitter iTEMP TMT31 (2H, 2I) iTEMP TMT71 (2C) iTEMP TMT72 (3A) iTEMP TMT82 (3C, 3D, 3F, 3I)	T5/T100 °C	−40 to +80 °C	−50 to +70 °C
	T4/T135 °C	−40 to +85 °C	−50 to +105 °C
	T3/T200 °C	−40 to +85 °C	−50 to +170 °C
iTEMP TMT84 (5A) iTEMP TMT85 (4A)	T2/T300 °C	−40 to +85 ℃	−50 to +265 ℃
iTEMP TMT86 (6B, 6C)	T1/T450 °C	−40 to +85 °C	−50 to +415 °C

1) iTHERM TM611 suffix code j

2) in an enclosure with a blind cover; iTHERM TM611 suffix code k = A1, D1, H1, H3.

The relation between the type, electrical connection, temperature class, maximum surface temperature, ambient temperature range and process temperature range is shown in the following table.

Temperature assemblies with thermocouple temperature sensors			
Electrical connection ¹⁾	Temperature class/ Maximum surface temperature	Ambient temperature range	Process temperature range
Type iTHERM TM611			
Terminal block (1A) ²⁾	T6/T85 ℃	–50 to +70 °C	−50 to +85 °C
	T5/T100 °C	−50 to +80 °C	−50 to +100 °C

Endress+Hauser

Temperature assemblies with thermocouple temperature sensors			
Electrical connection ¹⁾	Temperature class/ Maximum surface temperature	Ambient temperature range	Process temperature range
	T4/T135 ℃	–50 to +120 °C	−50 to +135 °C
	T3/T200 °C	–50 to +120 °C	–50 to +200 °C
	T2/T300 °C	–50 to +120 °C	–50 to +300 °C
	T1/T450 °C	–50 to +120 °C	−50 to +450 °C
Type iTHERM TM611			
Flying leads (DA)	T6/T85 °C	−40 to +65 °C	–50 to +85 °C
Transmitter	T5/T100 °C	−40 to +80 °C	–50 to +100 °C
ITEMP TMT71 (2C) ITEMP TMT72 (3A) ITEMP TMT82 (3C, 3D, 3F, 3I) ITEMP TMT84 (5A) ITEMP TMT85 (4A) ITEMP TMT86 (6B, 6C)	T4/T135 ℃	−40 to +85 °C	−50 to +135 ℃
	T3/T200 °C	−40 to +85 °C	–50 to +200 °C
	T2/T300 °C	−40 to +85 °C	−50 to +300 °C
	T1/T450 °C	−40 to +85 °C	–50 to +450 °C

1) 2)

iTHERM TM611 suffix code j in an enclosure with a blind cover; iTHERM TM611 suffix code k = A1, D1, H1, H3.

Electrical connection data

Туре	Electrical data
iTHERM TM611	$\begin{array}{l} U_b \leq 42 \; V_{DC} \\ \text{Current consumption} \leq 23 \; \text{mA} \\ \text{Remote installation:} \\ \text{Voltage max. 10 } V_{DC} \\ \text{Measuring current I} \leq 1 \; \text{mA} \end{array}$

Category	Type of protection (ATEX/IECEx)	Туре
II 2G	Ex db IIC T6T1 Gb	iTHERM TM611
II2D	Ex tb IIIC T85 °CT450 °C Db	



71645336

www.addresses.endress.com

