

















# Operating Instructions

# Turbimax W CUS65

Turbidity sensor





## Table of contents

1	Safety instructions 4
1.1	Designated use
1.2	Installation, commissioning and operation 4
1.3	Operational safety 4
1.4	Return
1.5	Notes on safety icons and symbols 5
1.6	Notes on document symbols
2	Identification 6
2.1	Product structure 6
2.2	Scope of delivery 6
3	Installation
3.1	Incoming acceptance, transport, storage 7
3.2	Installation conditions
3.3	Installation instructions
3.4	Post-installation check
4	Wiring 11
4.1	Connection to the transmitter
4.2	Post-connection check
5	Commissioning
5.1	Function check
5.2	Calibration
6	Maintenance
7	Accessories
7.1	Assemblies
7.2	Wall mounting
7.3	Transmitter
7.4	Connection accessories
8	Troubleshooting
8.1	Troubleshooting instructions
8.2	Return
8.3	Disposal
9	Technical data
<b>9</b> 9.1	Technical data         16           Input         16
	Input
9.1 9.2 9.3	Input16Performance characteristics16Environment16
9.1 9.2 9.3 9.4	Input16Performance characteristics16Environment16Process17
9.1 9.2 9.3	Input16Performance characteristics16Environment16
9.1 9.2 9.3 9.4	Input16Performance characteristics16Environment16Process17

Safety instructions Turbimax W CUS65

## 1 Safety instructions

## 1.1 Designated use

The Turbimax W CUS65 sensor is used for optical turbidity and solids content measurement. Due to various sensor heads the sensor is suitable for use from low to high concentration ranges.

- Wastewater clarification / sludge treatment
- Boiler feedwater monitoring
- Condensate monitoring
- Service water monitoring

Any other use than the one described here compromises the safety of persons and the entire measuring system and is, therefore, not permitted.

The manufacturer is not liable for damage caused by improper or non-designated use.

## 1.2 Installation, commissioning and operation

Please note the following items:

- Installation, commissioning, operation and maintenance of the measuring system must only be carried out by trained technical personnel.
- The technical personnel must be authorized for the specified activities by the system operator.
- Electrical connection must only be carried out by a certified electrician.
- Technical personnel must have read and understood these Operating Instructions and must adhere to them.
- Before commissioning the entire measuring point, check all the connections for correctness. Ensure that electrical cables and hose connections are not damaged.
- Do not operate damaged products and secure them against unintentional commissioning. Mark the damaged product as being defective.
- Measuring point faults may only be rectified by authorized and specially trained personnel.
- If faults can not be rectified, the products must be taken out of service and secured against unintentional commissioning.
- Repairs not described in these Operating Instructions may only be carried out at the manufacturer's or by the service organization.

## 1.3 Operational safety

The sensor has been designed and tested according to the state of the art and left the factory in perfect functioning order.

Relevant regulations and European standards have been met.

As the user, you are responsible for complying with the following safety conditions:

- Installation instructions
- Local prevailing standards and regulations.

Turbimax W CUS65 Safety instructions

#### 1.4 Return

If the sensor has to be repaired, please return it *cleaned* to the sales center responsible. Please use the original packaging, if possible.

Please enclose the completed "Declaration of Hazardous Material and De–Contamination" (copy the second last page of these Operating Instructions) with the packaging and the transportation documents.

No repair without completed declaration!

## 1.5 Notes on safety icons and symbols



Warning

This symbol alerts you to hazards. They can cause serious damage to the instrument or to persons if ignored.



Caution!

This symbol alerts you to possible faults which could arise from incorrect operation. They could cause damage to the instrument if ignored.



Note!

This symbol indicates important items of information.

## 1.6 Notes on document symbols



This symbol indicates a cross reference to a defined page (e.g. p. 1).



This symbol indicates a cross reference to a defined figure (e.g. fig. 2).

Identification Turbimax W CUS65

## 2 Identification

## 2.1 Product structure

	Measuring range, application							
	Α	0 to	0 to 12 g/l, activated sludge, centrate					
	В	0 to	0 to 40 g/l, return sludge					
	С	0 to	50 g/l,	primary sludge, digested sludge				
	D	1 to	1000 F	NU, wastewater effluent, service water, condensate, boiler feedwater				
	Е	10 t	o 150 g	/l, centrifuge inlet, press inlet				
		Cer	tificates	s				
		1	Factory	calibration certificate				
			Proces	s connection				
			A G1	+ NPT 3/4 thread				
			Y Spe	ecial version acc. to customer specification				
			Connecting cable					
			1	7 m (23 ft), SXP plug				
			2	15 m (49 ft), SXP plug				
			3	1 m (3.3 ft) + extension cable 10 m (32 ft), both with SXP plug				
				A Viton				
				Y Special version acc. to customer specification				
CUS65-				complete order code				

## 2.2 Scope of delivery

The scope of delivery comprises:

- lacktriangleq 1 CUS65 sensor, cable length depending on version
- 1 extension cable (only version CUS65-xxx3)
- 1 Quality certificate
- 1 Operating Instructions BA370C/07/en

If you have any questions, please contact your supplier or your sales center responsible.

Turbimax W CUS65 Installation

#### Installation 3

#### 3.1 Incoming acceptance, transport, storage

- Make sure the packaging is undamaged! Inform the supplier about damage to the packaging. Keep the damaged packaging until the matter has been settled.
- Make sure the contents are undamaged! Inform the supplier about damage to the delivery contents. Keep the damaged products until the matter has been settled.
- Check that the scope of delivery is complete and agrees with your order and the shipping documents.
- The packaging material used to store or to transport the product must provide shock protection and humidity protection. The original packaging offers the best protection. Also, keep to the approved ambient conditions (see "Technical data").
- If you have any questions, please contact your supplier or your sales center responsible.

#### 3.2 Installation conditions

#### 3.2.1 **Dimensions**




Fig. 1: Dimensions dependend on the sensor version (see ordering information)

Installation Turbimax W CUS65

#### 3.2.2 Wall distance

Installing the sensor in pipework or very close to the wall can cause backscatter which results in a higher sensor signal.

The effective wall or bottom distance can be optimized by aligning the flat sensor side.




Fig. 2: Effect of the distance from the wall or bottom

A Dark wall or bottom (non-reflective)

B Bright wall or bottom (reflective)



#### Note!

The following generally applies: The lower the turbidity to be measured, the darker the vessel walls should be and the greater the wall distance should also be.

#### 3.2.3 Pipe installation

The following figure illustrates various installation positions in pipes and indicates whether they are permitted or not.




Fig. 3: Orientation and installation positions (with retractable assembly CUA451)

■ The pipeline diameter must be at least 100 mm (4") if reflective materials (e.g. stainless steel) are used.

- Install the sensor in places with uniform flow conditions.
- The best installation location is in the ascending pipe (it. 1). Installation is also possible in the horizontal pipe (it. 5).
- Do not install the sensor in places where air may collect or foam bubbles form (it. 3) or where suspended particles may settle (it. 2).
- Avoid installation in the down pipe (it. 4).
- lacksquare Pay attention to the correct installation angle lpha (s. below).

Turbimax W CUS65 Installation




Fig. 4: Installation with retractable assembly

Arrow = flow direction of the medium

Installation angle  $\alpha$  dependent on sensor version:

- CUS65-A: 80°
- CUS65-B: 90°
- CUS65-C, E: 100°
- CUS65-D: 110°

### 3.2.4 Immersion operation



Note!

- Observe the required mounting clearance for the installation mode selected. Installing the sensor in pipes or close to a wall can lead to backscattering resulting in signal increase, mainly with measurements in low turbidity ranges (<100 FNU).
- Make sure the sensor is completey immersed at changing water levels.




Fig. 5: Wall distance with immersion pipe




Fig. 6: Immersion pipe angles

Arrow = flow direction of the medium

- CUS65-A: 45 °
- CUS65-D: 90 °
- CUS65-B, -C, -E: 180 ° (straight)


Installation Turbimax W CUS65


#### 3.3 Installation instructions

### 3.3.1 Measuring system

A complete measuring system comprises:

- Turbidity transmitter CUM740
- Turbidity sensor Turbimax W CUS65
- Immersion pipe CYY105 or
- Retractable assembly Cleanfit CUA451
- Extension cable (optional)
- Junction box (optional)





- 1 Turbidity sensor Turbimax W CUS65-C
- 2 Immersion pipe CYY105
- 3 Turbidity transmitter CUM740
- 4 Basin or channel




Abb. 8: Measuring system with retractable assembly

- 1 Turbidity sensor Turbimax W CUS65-A
- 2 Turbidity transmitter CUM740
- 3 Retractable assembly Cleanfit CUA451
- 4 Pip

#### 3.3.2 Notes on installation

Proceed as follows for complete installation of a measuring point:

- 1. Install the retractable (if used) into the process.
- 2. Connect the water to the rinsing nozzles (if using assembly with cleaning).
- 3. Install and connect the turbidity sensor.
- 4. Install the immersion assembly (if used) into the process.



#### Caution!

- Please follow national grounding regulations when using metal assemblies and installation devices.
- The sensor must be installed in an immersion assembly for immersion operation. Do not use the sensor suspended freely from the cable.
- Screw the sensor into the assembly in such a way that the cable does not become twisted.
- Avoid large traction (e.g. by tugging) on the cable.



#### Note:

- Select a mounting location which can be easily accessed for later calibrations.
- When installing without an assembly, the sensor optics must be immersed **at least 4 cm** (1.5") into the medium.
- Please pay special attention to the installation instructions in the Operating Instructions of the assembly used.

Turbimax W CUS65 Wiring

### 3.4 Post-installation check

Checks	Info
In general: Optical windows free of film? Permissible orientation observed? Medium present?	If no: cleaning (—> "Maintenance") —> "Installation conditions" Is the assembly or piping completely filled with medium?
Immersion assembly: Sensor installed in immersion assembly? Protection cap on immersion assembly?	Do not use the sensor suspended freely from the cable. Prevent moisture penetrating the assembly!
Retractable assembly: Sensor installed in flow or retractable assembly?	Ensure the sensor is aligned correctly to the flow direction!

## 4 Wiring



#### Warning!

- The electrical connection must only be carried out by a certified electrician.
- Technical personnel must have read and understood the instructions in this manual and must adhere to them.
- Ensure that there is no voltage at the power cable before beginning the connection work.

### 4.1 Connection to the transmitter

Connect the sensor directly to the transmitter by using the special measuring cable with SXP plug.




Fig. 9: SXP plug

## 4.2 Post-connection check

Instrument status and specifications	Remarks	
Are the sensor, assembly, junction box or cable damaged?	Visual inspection	
Electrical connection	Remarks	
Does the supply voltage of the transmitter match the specifications on the nameplate?	110/230 V AC 24 V AC/DC	
Are the installed cables strain-relieved and not twisted?		
Is the cable type route completely isolated?	Power cable/signal cable	
Are the power supply and signal cable correctly connected to the transmitter?	Use the connection diagram of the transmitter.	
Are all the screws terminals properly tightened?		
Are all the cable entries installed, tightened and sealed?	For lateral cable entries : cable loops	
Are all the cable entries installed downwards or lateral?	downwards for water to be able to drip off.	

Commissioning Turbimax W CUS65

## 5 Commissioning

#### 5.1 Function check

Before first commissioning, check if:

- the sensor is correctly installed
- the electrical connection is correct.



#### Warning!

Danger of medium leaking off

Before applying compressed air to an assembly with cleaning facility, make sure the connections are correctly fitted. Otherwise, the assembly may not be inserted into the process.

### 5.2 Calibration

The sensor CUS65–D is calibrated in the factory acc. to standard procedures (ISO 7027/EN 27027). The sensor zero point adjustment relates to almost particle-free water (particles  $<0.2~\mu m$ ).

The versions CUS65-A/B/C/E are factory-calibrated to  $SIO_2$  as function test. When commissioning these sensors, you must calibrate them using the medium for your application, e.g. activated sludge.

Calibration modes:

- Two-point-calibration (normal case)
- Multi-point-calibration (recommended for CUS65-A)



#### Votel

- CUS65-E is designated for thickened sludge. To achieve representative measuring results, you must use a sludge concentration of at least 1% for the first calibration point.
- To obtain reliable calibration results, record the raw signal of the sensor (process measurement) over a defined period (e.g. a week) and relate the signals to corresponding laboratory measurements.
- Follow the calibration instructions in the Operating Instructions of the transmitter.

## 6 Maintenance

Contamination of the sensor can impact the measurement up to the point that measurement no longer functions.

The sensor must be cleaned regularly to ensure reliable measurement. The frequency and intensity of the cleaning depend on the medium.

The sensor must be cleaned:

- prior to every calibration
- $\blacksquare$  if necessary, regularly during the operation
- prior to returning the sensor for repair.

Type of contamination	Cleaning measures	
Lime deposits	Immerse the sensor in 1–5 % hydrochloric acid (a few minutes).	
Dirt particles on the optics	Mechanically clean the sensor head with water and a suitable brush or sponge.	



#### Caution!

After cleaning, rinse the sensor with water.

Turbimax W CUS65 Accessories

## 7 Accessories

### 7.1 Assemblies

Retractable assembly Cleanfit CUA451

- retractable assembly with ball valve; for turbidity sensors; material: stainless steel
- ordering acc. to product structure (Technical Information TI369C/07/en)

Immersion assembly CYY105

- For sensor immersion in basins
- Materials:
  - pipe: SS 1.4404 (AISI 316L)
  - fitting: SS 1.4571 (AISI 316Ti)
- Ordering acc. to product structure (Technical Information TI092C/07/en)

## 7.2 Wall mounting

Wall attachment for immersion pipes

- Material: stainless steel 1.4301 (AISI 304)
- order no. 51503581

#### Counter plate

- Material: stainless steel 1.4301 (AISI 304)
- order no. 51512992




Fig. 10: Wall mounting




Fig. 11: Counter plate

#### 7.3 Transmitter

#### CUM740

- Transmitter for turbidity and solids content measurement
- see Technical Information (TI232C/07/en)

Accessories Turbimax W CUS65

## 7.4 Connection accessories

#### Extension cable

■ Extension cable length 10m (32 ft)

■ Shielded, with SXP plug and SXK coupling

■ Ingress protection IP 67

■ Order No.: 51503633

#### Plugs

■ SXP plug

- 7-pole

- Order No.: 51504027

■ SXK coupling

- 7-pole

- Order No.: 51504025

#### Junction box

■ Junction box for extension of cable connection between sensor and instrument

■ Sensor cable input SXB socket, cable output Pg 11 cable gland

■ Material: Makrolon®

■ Ingress protection IP 67

■ Order No.: 51503632

Turbimax W CUS65 Troubleshooting

## 8 Troubleshooting

## 8.1 Troubleshooting instructions

Troubleshooting must take account of the whole measuring system:

- Transmitter
- Electrical leads and connectors
- Assembly
- Sensor

The possible causes of failure listed in the following table primarily refer to the sensor.

Problem	Check	Remedy
No display, no sensor reaction	Mains voltage at transmitter? Sensor connected correctly? Film formation on optical windows?	Connect mains voltage. Set up correct connection. Clean the sensor.
Reading too high or too low	Film formation on optical windows? Sensor calibrated?	Clean the sensor. Calibrate.
Reading greatly fluctuating	Check mounting location.	Select other mounting location.



#### Note!

Please pay special attention to the instructions on handling errors in the Operating Instructions of the transmitter. Check the transmitter, if necessary.

### 8.2 Return

If the sensor has to be repaired, please return it *cleaned* to the sales center responsible. Please use the original packaging, if possible.

Please enclose the completed "Declaration of Hazardous Material and De-Contamination" (copy the second last page of these Operating Instructions) with the packaging and the transportation documents.

No repair without completed declaration!

## 8.3 Disposal

The device contains electronic components and must therefore be disposed of in accordance with regulations on the disposal of electronic waste.

Please observe local regulations.

Technical data Turbimax W CUS65

## 9 Technical data

10 to 150 g/l

## 9.1 Input

CUS65-E

IP 68

Ingress protection

Measured variable	Turbidity			
Measuring range	Version	Measuring range	Application	
	CUS65-A CUS65-B CUS65-C CUS65-D	0 to 12 g/1 0 to 40 g/1 0 to 50 g/1 1 to 1000 FNU	Activated sludge, centrate Return sludge Primary sludge, digested sludge Wastewater outlet, service water, condensate, boiler feedwater	

Centrifuge inlet, press inlet

	9.2	Performa	ance characteristics
Maximum measured error	$<\!1\%$ of measuring range end (system measured error related to the primary formazine standard / tracing according to ISO 5725 and ISO 7027 / EN 27027)		
Wavelength	880 nm		
Reference measurement	by four-beam pulsed light method		
Factory calibration	CUS65-A, CUS65-D:	, -B, -C, -E:	$\mathrm{SiO}_2$ Formazine acc. to ISO 7027 / EN 27027
	9.3	Environr	ment
Ambient temperature	-20 to 60 °C (0 to 140 °F)		
Storage temperature	-20 to 60	°C (0 to 140 °F	<del>(</del> 3)
Humidity	5 to 95 %		

Turbimax W CUS65 Technical data

### 9.4 Process

**Process temperature range** 0 to 50 °C (32 to 120 °F)

Process pressure

1 to 6 bar (15 to 87 psi)

# Temperature pressure diagram




Fig. 12: Temperature pressure diagram

Flow

No minimum flow required.

Make sure that there is a sufficient turbulence for solids with a tendency to sedimentation.

## 9.5 Mechanical construction

Design, dimensions	see "Installation conditions"	
Weight	approx. 1 kg (2.2 lbs)	
Materials	Sensor Optical windows	Stainless steel 1.4404 (AISI 316L) CUS65-A, -C, -E: Epoxy resin
	O-rings	CUS65-B, -D: Polyoxymethylene (POM) Viton®

# Index

A
Accessories
Transmitter
Ambient temperature
Assemblies
C
Cable length
Calibration
Checking
Connection
Function
Commissioning
Connection
Checking 11
D
Design, dimensions
Designated use
Dimensions
Disposal
Document symbols 5
r.
E Statistical compation
Electrical connection
Environment
F
Factory calibration
Flow
Flow mode
Н
<del></del>
Humidity
I
Immersion operation
Incoming acceptance
Ingress protection
Installation
Measuring system
Installation instructions
M
Maintenance
Materials
Maximum measured error
Measured value
Measured variable
Measuring range
Measuring system
0
Operation
oporadona baroty 4

Performance characteristics. 16 Pipework 8 Process 17 Process pressure 17 Process temperature range 17 Product structure 6
Reference measurement
Safety icons 5 Scope of delivery. 6 Storage . 7 Storage temperature . 16 Symbols . 5
Γ
Fechnical data16Femperature compensation17Femperature pressure diagram17Fransport7Froubleshooting instructions15
<b>J</b> Jse4
Wall distance
миния



People for Process Automation

# **Declaration of Hazardous Material and De-Contamination**

T 1 1	<i>T</i>	1 D
L 11/1/11/11/11/11/11/11/11/11/11/11/11/1	Kontamination ι	111 d U 1111111111111111111111111111111
CIKIAHIHO ZIH I	X ( )   I   A   I   I   I   A   I   I   I   I	πητι κριπισιπισ
Linualuie Zui i		ilia Kollilizaliz

RA No.		lease reference the F learly on the outside Bitte geben Sie die v uuch außen auf der V	of the box. If this p	procedure is not fo	ollowed, it may	result in the refus	al of the package	at our facility.	
and De-Contamina packaging.  Aufgrund der gese	gulations and for the safety of ation", with your signature, l etzlichen Vorschriften und z ntamination und Reinigung	pefore your orderum Schutz unse	er can be handl erer Mitarbeite	ed. Please ma r und Betriebs	ke absolutely seinrichtung	y sure to attac en, benötigen	h it to the ou	tside of the	
Type of instrume Geräte-/Sensortyp		Serial number Seriennummer							
Used as SIL d	levice in a Safety Instrum	ented System	/ Einsatz als S	SIL Gerät in So	chutzeinrich	tungen			
Process data/Pro.	ratur [°F]	°F][°C] Pressure / <i>Druck</i> [psi]				[ Pa ]			
Conductivity / Leitfähigkeit				[μS/cm]	Viscosity	/Viskosität _	[cp] _	[mm <sup>2</sup> /s]	
Medium and war Warnhinweise zun	_					×			
	Medium /concentration Medium /Konzentration	Identification CAS No.	flammable entzündlich	toxic giftig	corrosive ätzend	harmful/ irritant gesundheits- schädlich/ reizend	other * sonstiges *	harmless unbedenklich	
Process medium  Medium im Prozess  Medium for process cleaning  Medium zur Prozessreinigung									
Returned part cleaned with Medium zur Endreinigung									
Zutreffendes ankre  Description of fai	one of the above be applicab nuzen; trifft einer der Warnh ilure / Fehlerbeschreibung Angaben zum Absender	* le, include safet inweise zu, Sich	nerheitsdatenbi	dfördernd; um d, if necessary latt und ggf. s	nweltgefährli , special han pezielle Han	ich; biogefährl dling instructi dhabungsvors	ich; radioakti ons. cchriften beile	/	
Company / Firma			Phone	Phone number of contact person / Telefon-Nr. Ansprechpartner:					
Address / Adresse			Fax /	Fax / E-Mail					
			Your o	order No. / Ih	nre Auftragsr	nr			
parts have been car "Wir bestätigen, di	that this declaration is filled refully cleaned. To the best of ie vorliegende Erklärung nad urückgesandten Teile sorgfän	of our knowledg ch unserem bes	ge they are free ten Wissen wa	of any residu hrheitsgetreu	es in dangero <i>und vollstät</i>	ous quantities. Indig ausgefüllt	." t zu haben. W	<sup>7</sup> ir bestätigen	
(place, date / Ort.	Datum)	Name dent	/ Aht. (please prin	nt / hitte Drucksch	hrift)	Sional	ture / Unters	chrift	

www.endress.com/worldwide



People for Process Automation

