Special Documentation **Proline t-mass 300**

Functional safety manual HART







Proline t-mass 300 HART Table of contents

8.1 8.2 8.3 8.4 8.5

9.1 9.2 9.3 9.4

Table of contents

1	Manufacturer's declaration 4
1.1	Safety-related characteristic values 5
2	Certificate 7
3	About this document 7
3.1	Document function
3.2	Using this document 7
3.3	Symbols
3.4	Supplementary device documentation 9
4	Design 10
4.1	Permitted device types
4.2	Marking
4.3	Notes on the redundant use of multiple sensors
4.4	Basic conditions for use in safety-
	related applications
4.5	Safety measured error
4.6	Useful lifetime of electrical components
5	Commissioning (installation
	and configuration) 19
5.1	Requirements for the personnel 19
5.2	Installation
5.3	Commissioning
5.4	Operation
5.5	Device configuration for safety-related
J.J	applications
6	Operation 32
6.1	Device behavior during power-up 32
6.2	Device behavior in safety function
0.2	demand mode
6.3	Safe states
6.4	Device behavior in event of alarms and
6.5	warnings
7	Proof testing 33
7.1	Test sequence A (PTC = 99 %)
7.2	Test sequence C (PTC = 98 %)
7.3	Test sequence D (PTC = 36 %)
7.4	Test sequence E (PTC = 19 %) 42
7.5	Test sequence F (PTC = 0 %) 44
7.6	Verification criterion

Repair and error handling 4 Maintenance 4 Repair 4 Modification 4 Taking out of service 4 Disposal 4	46 46 47 47
Appendix 4	17
Structure of the measuring system	
Commissioning or proof test report	
Verification or calibration	
Version history	52

1 Manufacturer's declaration

Products Solutions Services

HE 61508 tmass 300 500 de en.docx

Herstellererklärung - Manufacturer Declaration Funktionale Sicherheit / Functional Safety (IEC 61508)

Endress+Hauser Flowtec AG, Kägenstrasse 7, 4153 Reinach

erklärt als Hersteller, dass die Durchflussmessgeräte aus der Serie declares as a manufacturer, that the flow meters of the product line

Proline t-mass 300 (6F3B, 6I3B) Proline t-mass 500 (6F5B, 6I5B)

in sicherheitsrelevanten Anwendungen SIL 2 (HFT=0) bzw. SIL 3 (HFT=1) nach IEC 61508:2010 eingesetzt werden können.

are suitable for use in safety relevant applications up to SIL 2 (HFT=0) resp. SIL 3 (HFT=1) acc. IEC 61508:2010.

Für einen Einsatz in sicherheitsrelevanten Anwendungen entsprechend IEC 61508 sind die Angaben des Handbuches zur Funktionalen Sicherheit zu beachten. Die Installation muß konform zu diesem Handbuch ausgeführt werden und die Sicherheitshinweise sind zu beachten.

For safety relevant applications according to IEC 61508, we refer to our hand-book named functional safety. The installation has to be conform to our descriptions in our handbook in consideration of our safety instructions.

Die Kenngrößen für die Verwendung des Produktes in sicherheitsrelevanten Anwendungen können dem Handbuch zur Funktionalen Sicherheit entnommen werden.

The characteristics for use of these products in safety relevant applications can be found in the functional safety manual.

Reinach, 18. Dezember 2020

Endress+Hauser Flowtec AG

Ullrich Schinle Managing Director Michael Karolzak

Senior Expert Functional Safety

Endress + Hauser 4

People for Process Automation

A0046114-EN

Proline t-mass 300 HART Manufacturer's declaration

1.1 Safety-related characteristic values

General			
Device designation and permitted versions	6F3B (t-mass F 300) 6I3B (t-mass I 300)		
	Order code for "Output; input 1": Option BA "4-20mA HART" Option CA "4-20mA HART Ex-i passive" Option CC "4-20mA HART Ex-i active"		
	Order code for "Output; input 2": All options		
	Order code for "Output; input 3": All options		
	Order code for "Additional approval": Option LA "SIL"		
Safety-related output signal	4 to 20 mA (output; input 1)		
Failure current	≤ 3.6 mA or ≥ 21 mA		
Assessed measured variable/function	Monitoring of mass flow for gaseous media		
Safety function(s)	Min., Max., Range		
Device type according to IEC 61508-2	□ Type A ☑ Type B		
Mode of operation	☑ Low Demand ☑ High ☐ Continuous Mode 1) Mode Demand Mode		
Valid hardware version (main electronics)	From delivery date 31.07.2020		
Valid firmware version	01.00.zz and higher (HART; from delivery date July 31, 2020)		
Safety manual	SD02483D		
Type of assessment (only 1 version can be selected)	☑ Complete HW/SW assessment in the context of development including FMEDA and change process according to IEC 61508-2, 3		
	$\hfill\Box$ Assessment of evidence for proven-in-use HW/SW including FMEDA and change process according to IEC 61508-2, 3		
	$\hfill\Box$ Analysis of HW/SW field data for evidence of "prior use" according to IEC 61511		
	$\hfill \square$ Assessment by FMEDA according to IEC 61508-2 for devices without software		
Test documents	Development documents, test reports, data sheets		

1) No continuous mode according to IEC 61508: 2011 (Section 3.5.16)

SIL integrity			
Systematic safety integrity		\square SIL 2 capable	☑ SIL 3 capable

Manufacturer's declaration Proline t-mass 300 HART

Hardware safety integrity	Single-channel service (HFT = 0)	☑ SIL 2 capable	□ SIL 3 capable
	$\begin{array}{l} \text{Multi-channel service} \\ \text{(HFT} \geq 1) \end{array}$	□ SIL 2 capable	☑ SIL 3 capable

FMEDA	
Safety function(s)	Min., Max., Range
$\lambda_{DU}^{1)}$	195 FIT
$\lambda_{DD}^{1)}$	2112 FIT
λ _{SU} ¹⁾	2021 FIT
λ_{SD}^{-1}	3085 FIT
SFF - Safe Failure Fraction	97 %
PFD_{avg} for $T_1 = 1$ year ²⁾ (single-channel architecture)	8.6 · 10 ⁻⁴
PFH	9.8 · 10 ⁻⁸
PTC 3)	Up to 99 %
MTBF _{tot} 4)	51 years
Diagnostic test interval ⁵⁾	30 min
Fault response time ⁶⁾	30 s
Recommended test interval T ₁	2 years
MTTF _d ⁷⁾	49 years

- 1) FIT = Failure In Time, number of failures per 10⁹ h
- 2) Valid for averaged ambient temperatures up to 40 $^{\circ}$ C (104 $^{\circ}$ F) in accordance with the general standard for devices with SIL capability.
- 3) PTC = Proof Test Coverage (diagnostic coverage achieved by device failure detection during manual proof testing)
- 4) This value takes into account all failure types of the electronic components as per Siemens SN29500
- 5) All diagnostic functions are executed at least once during this time. For operation in high demand mode according to IEC 61508, the safe use of the devices is limited to a safety function demand rate of ≤ 1/50 h.
- 6) Maximum time between fault detection and fault response.
- 7) MTTF_d as per ISO 13849/IEC 62061 also includes soft errors (sporadic bit errors in data memories).

Note

The measuring device has been developed for use in "Low Demand" and "High Demand" mode.

Explanation

 $\ensuremath{\square}$ Our in-house quality management system saves information on safety-related systematic errors that will become known in the future.

Proline t-mass 300 HART Certificate

2 Certificate


Certificate can be accessed at www.endress.com:

- 1. Downloads
- 2. Approvals
- 3. Type: Functional safety (SIL)
- 4. Product root: e.g. 5H3B
- 5. Press the "Search" button

3 About this document

3.1 Document function

This document is part of the Operating Instructions and serves as a reference for applicationspecific parameters and notes.



General information about functional safety SIL is available in the Download Area of the Endress+Hauser website: www.endress.com/SIL.

3.2 Using this document

3.2.1 Information on the document structure



For additional information regarding the arrangement of the parameters, along with a short description, according to the **Operation** menu, **Setup** menu, **Diagnostics** menu and the operating concept, see the Operating Instructions, "Supplementary device documentation" section

3.3 **Symbols**

3.3.1 Safety symbols

A DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

▲ WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

▲ CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

About this document Proline t-mass 300 HART

3.3.2 Symbols for certain types of Information

Symbol	Meaning
✓	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
X	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
>	Notice or individual step to be observed
1., 2., 3	Series of steps
L	Result of a step
A0028662	Operation via local display
A0028663	Operation via operating tool
A0028665	Write-protected parameter

3.3.3 Symbols in graphics

Symbol	Meaning
1, 2, 3	Item numbers
A, B, C,	Views
A-A, B-B, C-C,	Sections

Proline t-mass 300 HART About this document

3.4 Supplementary device documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- Endress+Hauser Operations app: Enter serial number from nameplate or scan matrix code on nameplate.

Standard documentation 3.4.1

Operating Instructions

Measuring device	Documentation code
t-mass F 300	BA01992D
t-mass I 300	BA01993D

Description of Device Parameters

Measuring device	Documentation code
t-mass 300	GP01143D

Technical Information

Measuring device	Documentation code
t-mass F 300	TI01500D
t-mass I 300	TI01501D

3.4.2 Supplementary device-dependent documentation

Safety instructions

Safety instructions for electrical equipment for hazardous areas.

Contents	Documentation code
ATEX/IECEx Ex d/Ex de	XA01965D
ATEX/IECEx Ex ec	XA01966D
cCSAus XP	XA01969D
cCSAus Ex d/ Ex de	XA01967D
cCSAus Ex nA	XA01968D

Design Proline t-mass 300 HART

Remote display and operating module DKX001

Contents	Documentation code
ATEX/IECEx Ex i	XA01494D
ATEX/IECEx Ex ec	XA01498D
cCSAus IS	XA01499D
cCSAus Ex nA	XA01513D
INMETRO Ex i	XA01500D
INMETRO Ex ec	XA01501D
NEPSI Ex i	XA01502D
NEPSI Ex nA	XA01503D

Functional safety manual

Contents	Documentation code
Proline t-mass 300	SD02483D

Special documentation

Installation instructions

Contents	Note
Installation instructions for spare part sets and accessories	Overview of accessories available for order: see the Operating Instructions for the device

4 Design

4.1 Permitted device types

The information on functional safety contained in this manual relates to the device versions listed below and are valid as of the specified software and hardware version.

Unless otherwise specified, all subsequent versions can also be used for safety functions.

A modification process according to IEC 61508 is applied for any device modifications.

Valid device versions for safety-related use:

Proline t-mass 300 HART Design

4.1.1 Order codes

Feature	Designation	Option selected	
-	Order code	6F3B (t-mass F 300) 6I3B (t-mass I 300)	
000	Nominal diameter	All	
010	Approval; transmitter + sensor	All	
015	Power supply	All	
020	Output; input 1 1)	 Option BA "4-20mA HART" Option CA "4-20mA HART Ex-i passive" Option CC "4-20mA HART Ex-i active" 	
021	Output; input 2	All	
022	Output; input 3	All	
030	Display; operation	All	
040	Housing	All	
050	Electrical connection	All	
060	Sensor version; sensor; measuring tube	 HA "Unidirectional; Alloy; stainless steel" SA "Unidirectional; stainless steel; stainless steel" 	
070	Process connection	All	
080	Calibration flow	All	
480	Device model	All	
500	Display operating language	All	
520	Sensor option	CS "1x flow conditioner"	
530	Customer-specific configuration	 DA "Output 1" DB "Output 2" DG "Totalizer" DH "Display; totalizer" 	
540	Application package	EA "Extended HistoROM"EB "Heartbeat Verification + Monitoring"	
570	Service	All	
580	Test, certificate	All	
590	Additional approval	LA (= SIL) ²⁾	
610	Accessory mounted	All	
620	Accessory enclosed	All	

Design Proline t-mass 300 HART

Feature	Designation	Option selected	
850	Firmware version	Firmware with SIL capability, e.g. 01.01.zz (HART)	
895	Marking	All	

- In devices with several outputs, only current output 1 (terminals 26 and 27) is suitable for safety functions. The
 other outputs can, if necessary, be connected for non-safety-oriented purposes.
- 2) Additional selection of further approvals is possible.

4.1.2 Suitability of the measuring device

- 1. Carefully select the nominal diameter of the measuring device in accordance with the application's expected flow rates.
 - The maximum flow rate during operation must not exceed the specified calibrated maximum value for the sensor.
- 2. In safety-related applications, it is advisable to select the limit value for monitoring a minimum flow such that this limit is at least twice the smallest specified flow that can still be measured, with the actual medium and the selected nominal diameter.
 - ightharpoonup For further information, see the Technical Information ightharpoonup ightharpoonup 9

4.1.3 Restrictions

- Valid single gases:
 - Air
 - Methane (CH₄)
 - Carbon dioxide (CO₂)
 - Nitrogen (N₂)
 - Oxygen (O₂)
- Valid 4-component natural gas composition in mol%:
 - CH₄ 80 to 99 %
 - N₂ 0.3 to 12 %
 - \bullet C₂H₆ 0.3 to 12 %
 - CO₂ 0.3 to 12 %
- Extended natural gas spectrum I: the 4-component natural gas composition specified may be extended by a selection of the following components up to a maximum proportion shown in the following table:

Additional natural gas components	Max. mol% proportion
Propane (C ₃ H ₈)	2 %
Butane (i-C ₄ H ₁₀ , n-C ₄ H ₁₀)	1 %
Pentane (i-C ₅ H ₁₂ , n-C ₅ H ₁₂)	0.2 %
Hexane (i-C ₆ H ₁₄ , n-C ₆ H ₁₄)	0.2 %
Oxygen (O ₂)	0.2 %

Proline t-mass 300 HART Design

• Extended natural gas spectrum II: Natural gas mixtures corresponding to the 4-component natural gas composition or extended natural gas spectrum I, with CO₂ and/or N₂ contents of less than 0.3 mol% each (as defined in the 4-component mixture) are possible in accordance with the special configuration instructions outlined in the section on configuring the extended natural gas spectrum.

- Temperature range: -30 to +150 °C (-22 to +302 °F)
- Pressure range: 0.8 to 30 bar (11.6 to 435 psi)
- Nominal diameters: Up to internal diameters 320 mm (12.6 in)
- Circular pipe for insertion version (cannot be used in rectangular ducts)
- The maximum flow rate during operation must not exceed the specified calibrated maximum value for the sensor 1).
- Measuring uncertainty in the SIL mode (see the "Guidelines for minimum measured error" section $\rightarrow \blacksquare 17$).

NOTICE

Use the measuring device according to the specifications.

- ▶ Pay attention to the medium properties and the environmental conditions.
- ► Carefully follow instructions pertaining to critical process situations and installation conditions.



Detailed information on:


- Mounting
- Electrical connection
- Medium properties
- Environment
- Process

Operating Instructions $\rightarrow \triangleq 9$

A CAUTION

Pay particular attention to the following:

- ▶ Observe the mounting requirements \rightarrow \triangleq 9.
- ▶ Only suitable for dry gases.
- ▶ Turbulences can occur at high flow velocity rates, e.g. if valves are half-closed. This can cause the measured values to fluctuate.
- ► Avoid applications that cause buildup, corrosion or abrasion at the sensor.
- Avoid proximity to sources that radiate heat.




4.2 Marking

SIL certified devices are marked with the SIL logo on the nameplate.

See "Technical Information/Input/Measuring range"→

9

Design Proline t-mass 300 HART



A0031473

1 SIL logo

4.3 Notes on the redundant use of multiple sensors

This section provides additional information regarding the use of homogeneously redundant sensors, e.g. in 1002 or 2003 architectures.

The common cause factors β and β_D indicated below are minimum values for the device. These must be used when designing the sensor subsystem:

- Minimum value β for homogeneously redundant use: 2 %
- Minimum value β_D for homogeneously redundant use: 1 %

The device meets the requirements for SIL 3 in homogeneously redundant applications (e.g., dualsens/quadsens version or two sensors with an identical design in series).

To fully rule out potential interference, it is recommended to install the sensors at different points of the pipe.

NOTICE

Note the following if a fault is detected in one of the redundantly operated devices during the proof test:

▶ Check the other devices to see if the same fault occurs there.

4.3.1 Safety-related output signal


The device's safety-related signal is the 4 to 20 mA analog output signal as per NAMUR NE43. All safety measures refer to this signal exclusively.

The device additionally communicates for information only via HART and contains all HART features with additional device information. HART communication is not part of the safety function.

Proline t-mass 300 HART Design

The safety-related output signal is fed to a downstream logic unit, e.g. a programmable logic controller or a limit signal transmitter, where it is monitored for the following:


- Overshooting and/or undershooting of a specified limit value
- The occurrence of a fault: e.g. failure current (≤ 3.6 mA, ≥ 21 mA, signal cable open circuit or short-circuit)



The safety-related errors are broken down in accordance with IEC/EN 61508 into different categories and implications for the safety-related output signal

Safety-related error	Explanation	Item Impact on measuring uncertainty	Implication for safety-related output signal
No device error	Safe: No error	1 Within specification	None
λ_{SD}	Safe detected: Safe, detectable failure present	3 No implications	Causes a failure current at the output signal
λ _{SU}	Safe undetected: Safe, undetectable failure present	2 May be outside specifications	Is within the defined error range
$\lambda_{ m DD}$	Dangerous detected: Dangerous but detectable failure present (diagnosis in device)	3 No implications	Causes a failure current at the output signal
λ_{DU}	Dangerous undetected: Dangerous, undetectable failure present	4 May be outside the defined error range	May be outside the defined error range

Design Proline t-mass 300 HART



A0034924

- ₩ 1 Safety-related output signal
- Α Failure current $\geq 21 \text{ mA}$
- В Measuring uncertainty according to device's technical data
- Failure current ≤ 3.6 mA

Basic conditions for use in safety-related applications 4.4


- The measuring device must be used correctly for the specific application, taking into account the medium properties and ambient conditions.
- 2. Carefully follow safety instructions pertaining to critical process situations and installation conditions, which can be found in the device documentation.
- 3. Observe application-specific limits.
- 4. Do not exceed technical specifications of measuring device.

Information on the safety-related signal

For detailed information on the technical specifications, see the device documentation $\rightarrow \blacksquare 9$.

4.4.1 Additional restrictions for safety-related use

An incorrect output signal that deviates from the value specified in the Operating Instructions but is still in the range of 4 to 20 mA, is considered a dangerous, undetected failure.



For detailed information on the maximum measured error, see the Technical Information → 🖺 9

Proline t-mass 300 HART Design

4.5 Safety measured error

When the measured value is transmitted via the 4–20 mA current output, the measuring device's relative measured error is made up of the contribution of the digitally determined measured value and the accuracy of the analog current output. These contributions, which are listed in the device documentation, apply under reference operating conditions and can depend on the sensor version ordered.



For detailed information on the maximum measured error, see the Technical For usuance ...
Information → 🖺 9

Guidelines for minimum measured error 4.5.1

Limit value monitoring: Depending on the process dynamics, the current value of the unfiltered 4–20 mA output signal can temporarily exceed the specified error range. The device can optionally provide damping of the current output via a parameter that only affects the measured value output.



Device-internal diagnostics or the output of a failure current (\leq 3.6 mA, \geq 21 mA) are not affected by this damping.

Furthermore, in the event of an error in safety-related applications, an additional measuring uncertainty percentage applies when the SIL mode is switched on; typical component failures are taken into consideration for this value. This additional uncertainty is specifically due to limited diagnostic capabilities. The additional measured error to the specified measured error 2) is:

- +2 % for air
- \pm 4 % for the single gases:
 - Methane (CH₄)
 - Carbon dioxide (CO₂)
 - Nitrogen (N₂)
 - Oxygen (O₂)
- \pm 4 % for the 4-component gas mixture:
 - CH₄ 80 to 99 %
 - N₂ 0.3 to 12 %
 - \bullet C₂H₆ 0.3 to 12 %
 - CO₂ 0.3 to 12 %
- ± 5.5 % for the extended natural gas spectrum I and II (see "Restrictions" $\rightarrow \blacksquare 12$).

4.5.2 Power supply to the 4–20 mA current output

Overvoltages at the 4–20 mA current output (passive, output; input 1) - caused by a fault in the supply unit, for example - can result in a leak current in the device's input protection unit. This may lead to falsification of the output signal by more than the specified error or the minimum failure current (3.6 mA) can no longer be set due to the leak current.

▶ Use a 4-20 mA power supply unit with either voltage limitation or voltage monitoring.

See "Technical Information/Performance characteristics/Maximum measured error" → 🖺 9

Design Proline t-mass 300 HART

NOTICE

The safety-related connection values depend on the Ex approval.

▶ Pay attention to the safety-related connection values.



4.5.3 HART communication

The measuring device also communicates via HART or WirelessHART in the SIL mode. This comprises all the HART features with additional device information.

NOTICE

The measuring device's safety-related signal is the 4-20 mA analog output signal (output; input 1).

All safety measures refer to this signal exclusively.

▶ Please note the following: \rightarrow 🗎 14.

NOTICE

When the SIL locking code is entered, the device parameters that affect the safety-related output signal are locked and write-protected. It is still possible to read the parameters.

When SIL locking is enabled, restrictions apply on all communication options, such as the service interface (CDI-RJ45), HART protocol and WirelessHART protocol, local display and WLAN

▶ Deactivation of the SIL mode \rightarrow \implies 31.

4.6 Useful lifetime of electrical components

The established failure rates of electric components apply for a useful lifetime of 12 years as per IEC 61508-2: 2010, Section 7.4.9.5, Note 3. Once a device has exceeded its useful lifetime, it should be replaced.

The device's year of manufacture is coded in the first character of the serial number (\rightarrow table below).

Example: serial number R5ABBF02000 \rightarrow year of manufacture 2020

ASCII character	Meaning	ASCII character	Meaning
R	2020	Х	2025
S	2021	Z	2026
Т	2022		2027
V	2023		2028
W	2024		2029

5 Commissioning (installation and configuration)

5.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

5.2 Installation

The mounting and wiring of the device and the permitted orientations are described in the Operating Instructions pertaining to the device.

5.3 Commissioning



5.4 Operation



For detailed information on the operating options, see the Operating Instructions. → 🖺 9

5.5 Device configuration for safety-related applications

5.5.1 Calibration of the measuring point

The measuring point is calibrated via the operating interfaces. A wizard guides you systematically through all the submenus and parameters that have to be set for configuring the measuring device.



For detailed information on the operating options, see the Operating Instructions. $\rightarrow \bigcirc 9$



For detailed information on configuring the measuring device, see the Operating Instructions and Description of Device Parameters $\rightarrow \stackrel{\frown}{\boxtimes} 9$

Configuration of the extended natural gas spectrum I and II

Natural gas mixtures that satisfy the definition of the extended natural gas spectrum I (see "Restrictions" $\rightarrow \stackrel{\text{\tiny \square}}{=} 12$) can be configured using the 4-component natural gas mixture in the

operating menu of the measuring device. When configuring the natural gas mixture, the proportions in mol% of propane, butane, pentane, hexane and/or oxygen must be added to the proportion of ethane (C_2H_6). The maximum proportions of these gas components in mol% are shown in the following table.

Additional natural gas components	Max. mol% proportion
Propane (C ₃ H ₈)	2 %
Butane (i-C ₄ H ₁₀ , n-C ₄ H ₁₀)	1 %
Pentane (i-C ₅ H ₁₂ , n-C ₅ H ₁₂)	0.2 %
Hexane (i-C ₆ H ₁₄ , n-C ₆ H ₁₄)	0.2 %
Oxygen (O ₂)	0.2 %



Gas contents that are lower than 0.01 mol% can be ignored during configuration. However, the total gas composition must result in 100 mol%. Negligible gas contents (lower than 0.01 mol%) can be added to the ethane content in order to reach 100% again.

Example

The natural gas mixture corresponds to the definition of the *extended natural gas spectrum I* and has the following gas composition in mol%:

- 97 % CH₄
- 0.8 % N₂
- 1.2 % C₂H₆
- 0.3 % CO₂
- 0.4 % C₃H₈
- 0.3 % C₄H₁₀

This gas mixture is configured as follows in the device:



A0054621


 \blacksquare 2 Web browser view of the configuration of the natural gas composition in the SIL mode

1
$$C_2H_6$$
 (1.2 %) + C_3H_8 (0.4 %) + C_4H_{10} (0.3 %)

Example

The natural gas mixture corresponds to the definition of the *extended natural gas spectrum II* and has the following gas composition in mol%:

- 97 % CH₄
- 0.8 % N₂
- 1.4 % C₂H₆
- 0.5 % C₃H₈
- 0.1 % C₄H₁₀
- 0.2 % CO₂



№ 3 Web browser view of the configuration of the natural gas composition in the SIL mode

 C_2H_6 (1.4 %) + C_3H_8 (0.5 %) + C_4H_{10} (0.1 %) - CO_2 (0.1 %) \rightarrow CO₂: 0.3 % (lowest possible entry) - 0.2 % (actual value) = 0.1 % CO₂

Device protection

The devices can be protected against external influences as follows:

- Hardware write protection
- Software write protection

The application of these methods is described below.

5.5.2 Activation of SIL mode

To activate the SIL mode, the device must run through a confirmation sequence. While running through this sequence, critical parameters are either set automatically by the device to standard values or transferred to the local display/operating tool to enable verification of the setting. On completion of parameter configuration, the SIL mode of the device must be enabled with a SIL locking code.

Availability of the SIL mode function

NOTICE

The SIL confirmation sequence is only visible on the local display and in the operating tools for devices with the order code for "Additional approval", option LA "SIL".

- ▶ For this reason, the SIL mode can also only be activated on these measuring devices.
- ▶ If the LA "SIL" option was ordered for the flowmeter ex works, this option is available when the measuring device is delivered to the customer. Access is via the operating interfaces of the measuring device.
- ▶ If the order option cannot be accessed in the measuring device, the function cannot be retrofitted during the life cycle of the device. If you have any questions please contact your Endress+Hauser service or sales organization.

Ways to check function availability in the measuring device:

Using the serial number:

Device viewer $^{3)} \rightarrow$ Order code for "Additional approval", option LA "SIL"

Detailed information concerning the SIL label:

- Permitted device types \rightarrow \triangleq 10
- SIL marking on the transmitter nameplate → 🗎 13

Overview of the SIL mode

The SIL mode enables the following steps:

- 1. Makes sure that the preconditions are met.
 - The measuring device checks whether the user has correctly configured a predefined set of parameters for the safety function.

 If the result is positive, the device continues with the activation of the SIL mode. If the result is negative, the sequence is not permitted or is aborted, and the device does not continue with the activation of the SIL mode.
- Automatically switches a predefined set of parameters to the default values specified by the manufacturer.
 - └ This parameter set ensures that the flowmeter works in the safety mode.
- 3. Guides the user through the preconfigured parameters for checking.
 - This ensures that the user actively checks all the important pre-settings.
- 4. Activates write protection for all the relevant parameters in the SIL mode.

All this ensures that the parameter settings that are required for the safety function are configured correctly. (These settings cannot be circumvented either deliberately or by accident.)

5.5.3 Locking a SIL device

When locking a SIL device, all safety-related parameter settings are shown to the operator individually and must be confirmed explicitly. Parameter settings not permitted in the locked SIL mode are reset to their default values where necessary. A SIL locking code is then entered to lock the device software to ensure that parameters cannot be changed. Non-safety-related parameters remain unchanged.


³⁾ www.endress.com/deviceviewer

NOTICE


Once the SIL device has been locked, the process-related parameters are write protected, and thereby locked, for security reasons.

It is still possible to read the parameters. When SIL locking is enabled, restrictions apply on all communication options, such as the service interface, HART protocol and WirelessHART protocol, local display and WLAN.

- ► Follow the specified locking sequence.
- 1. Check preconditions are met.



A0042068-EN



A0042069-EN

2. In the **Setup** menu → **Advanced setup** submenu, select the **SIL confirmation** wizard.

- 3. Select the **Set write protection** parameter.
- 4. Enter the SIL locking code **7452**.
 - ► The device first checks the preconditions listed under item 1.

NOTICE

If these preconditions are not met, the message "SIL preparation = failed" appears on the display along with the parameter that failed to meet the preconditions under 1.

The SIL confirmation sequence is not continued.

► Check preconditions.

If the preconditions are met, the message **SIL preparation = finished** appears on the display.


Once the preconditions have been met, the device automatically switches the following parameters to safety-oriented settings:

NOTICE


If the Assign current output has not been set to the Mass flow option measured variable, this is automatically changed to Mass flow option in the SIL confirmation sequence.

The 4 mA value and 20 mA value are reset to the factory setting.


- ► Cancel the SIL confirmation sequence.
- ▶ Check the settings of the current output and change them if necessary.



A0042070-EN




A0042071-EN



A0021506-EN


The diagnostic behavior is set in such a way that the measuring device is set to the safe state when an error occurs. This means that the diagnostic messages listed in the graphic are set to alarm and the current output adopts the configured failsafe mode .




A0042073-EN

Diagnostic number and short text:


- 834 Process temperature too high diagnostic message
- 835 Process temperature too low diagnostic message
- △S976 Mass flow out of calibrated range



A0031495-EN




A0042074-EN



A0042075-EN

To check that values are displayed correctly, the following string appears on the device display or operating tool: **0123456789+-.**

- 5. The user must confirm that the values are displayed correctly.
 - The device displays the current settings for the following parameters one after another for the user to confirm each of them:




A0042076-EN

- 1) Display depends on the gas type selected.
- 2) Only available for the insertion version (t-mass I 300/500).
- Only displayed if low flow cutoff is activated.
- 6. At the end of the verification, the SIL locking code 7452 must be entered in the Set write protection parameter again to confirm that all the parameter values have been defined correctly.
- 7. Press the E key to confirm.

The SIL mode is now activated.

Recommendation:



40020620

- 1. Check the write protection switch (WP) in the connection compartment.
- 2. If necessary, set this switch to the **ON** position.
 - ► Hardware write protection enabled.
- 3. Restart the device on completion of the SIL confirmation sequence.

NOTICE

If the SIL confirmation sequence is aborted before the "End of sequence" message is displayed, the SIL device is not locked. The safety-oriented parameter settings have been made but the SIL device has not been locked.

▶ Perform SIL device locking again.

5.5.4 Unlocking a SIL device

A device in the locked SIL mode is protected against unauthorized operation by means of a SIL locking code and, where applicable, by means of a user-specific release code and a hardware write protection switch. The device must be unlocked in order to change parameters, for proof-tests as well as to reset self-holding diagnostic messages.

NOTICE

Unlocking the device deactivates diagnostic functions, and the device may not be able to carry out its safety function in the unlocked SIL mode.

► Therefore, independent measures must be taken to ensure that there is no risk of danger while the SIL device is unlocked.

Unlocking procedure:

- 1. Check the write protection switch (WP) in the connection compartment.
- 2. If necessary, set this switch to the **OFF** position.
- 3. Enter the user-specific release code if necessary.
- 4. In the **Setup** menu → **Advanced setup** submenu, select the **Deactivate SIL** wizard.
- 5. Select the **Reset write protection** parameter.

Operation Proline t-mass 300 HART

- 6. Enter the SIL locking code **7452**.
- 7. Press the E key to confirm.

The SIL mode is now deactivated.

6 Operation

6.1 Device behavior during power-up

Once switched on, the device runs through a start-up phase. The current output is set to failure current during this time. This current is ≤ 3.6 mA in the initial seconds of this start-up phase.

After that, depending on the setting of the "Start-up mode" parameter, the current is:

- At the value MIN: ≤ 3.6 mA
- At the value MAX: ≥ 21 mA

No communication with the device is possible via the interfaces during the start-up phase. After the start-up phase the device switches to the normal mode (measuring operation).

6.2 Device behavior in safety function demand mode

The device outputs a current value corresponding to the limit value to be monitored. This value must be monitored and processed further in a connected logic unit.

6.3 Safe states

The system adopts one of the three states depending on the error detected:

- Application error
 - Application errors are detected by the device and a fixed failure current is output. The device can continue communicating via HART (device state: "temporarily safe"). This state persists until the application error is resolved and the device can again supply a valid measured value at the current output. All parameters can be read.
 - Example: A cable open circuit is detected in the sensor.
- Safe state / output current:
 - $I \le 3.6 \text{ mA}$ (low alarm)
 - $I \ge 21 \text{ mA}$ (high alarm)

6.4 Device behavior in event of alarms and warnings

The output current on alarm can be set to a value ≤ 3.6 mA or ≥ 21 mA.

In some cases (e.g. a cable open circuit or faults in the current output itself, where it is not possible to set the failure current \geq 21 mA) output currents of \leq 3.6 mA occur irrespective of the configured failure current.

Proline t-mass 300 HART Proof testing

In some other cases (e.g. short circuit of cabling), output currents of ≥ 21 mA occur irrespective of the configured failure current.

For alarm monitoring, the downstream automation system must be able to recognize both maximum alarms (\geq 21 mA) and minimum alarms (\leq 3.6 mA).

6.5 Alarm and warning messages

Additional information is provided by the alarm and warning messages output in the form of diagnostic events and associated event texts.

NOTICE

A diagnostic message is displayed even though the diagnostic event is no longer active in the unlocked SIL mode.

When SIL mode is activated, additional diagnostics are activated. If a diagnostic event is pending and the locked SIL mode is deactivated, the diagnostic message remains as long as the error is still present.

- ► In this case, the device must be disconnected briefly from the power supply.
- ▶ When the device is then restarted, a self-check is carried out, and the diagnostics event is reset where applicable.

This behavior occurs in the event of the following diagnostic message:

803 Current loop diagnostic message



After a period of 20 to 30 s, the diagnostic message changes from **803 Current loop** diagnostic message to **\$F375 I/O-1** to n communication failed diagnostic message. If a check run in the device's event logbook confirms the previous **803 Current loop** diagnostic message diagnostic message, the installation must be checked for a cable break.

7 Proof testing



The functional integrity of the device in the SIL mode must be verified during commissioning, when changes are made to safety-related parameters, and also at appropriate time intervals. The time intervals must be specified by the operator.

A CAUTION

The safety function is not guaranteed during a proof test.

Suitable measures must be taken to guarantee process safety during the test.

- ► The safety-related output signal 4 to 20 mA must not be used for the safety instrumented system during testing.
- ▶ The operator specifies the test interval and this must be taken into account when determining the probability of failure PFD_{avg} of the sensor system.

If no operator-specific proof testing requirements have been defined, the following is a possible alternative for testing the transmitter depending on the measured variable used for

Proof testing Proline t-mass 300 HART

the safety function. The individual proof test coverages (PTC) that can be used for calculation are specified for the test sequences described below.

Flexible testing of field devices

NAMUR Worksheet NA106 "Flexible proof testing of field devices in safety instrumented systems" explains how to optimize testing activities on existing installations. Heartbeat Verification enables the documentation of the current device diagnostic or device status as proof of testing. This supports the documentation of proof tests according to IEC 61511-1, Section 16.3.3, "Documentation of proof tests and inspections". The Heartbeat Technology developed by Endress+Hauser can be used to implement the "Flexible testing" test strategy of field devices under NA106.

Heartbeat Verification is not a substitute for a proof test. Test sequences with Heartbeat Verification can contribute to the detection of systematic errors within the context of proof testing. In this case, Heartbeat Verification is one step in the proof test sequence.

Device verification (Heartbeat Verification) is based on device-specific test sequences that are performed automatically. Heartbeat Verification also enables the detection of systematic errors in the sensor system (e.g. formation of buildup in the sensor).

Heartbeat Verification is based on device-specific test sequences that are performed automatically. Formation of buildup in the sensor: Heartbeat Technology is a methodological design concept based on IEC 61508 consisting of the Heartbeat Diagnostic, Verification and Monitoring modules

For more information on Heartbeat Technology, see the associated documentation in the Operating Instructions.

Proof testing of the device can be performed as follows:

- Test sequence A: Testing with a secondary standard 1 (mass flow) and current output $1 \rightarrow$ PTC = 99 %
- Test sequence C: Testing with a secondary standard 1 (mass flow) → PTC = 98 %
- Test sequence D: Device restart (verification of RAM memory), verification of current output 1 with Heartbeat Verification → PTC = 36 % + systematic errors (depending on the device version)
- Test sequence E: Device restart (verification of RAM memory), Heartbeat Verification → PTC = 19 % + systematic errors (depending on the device version)
- Test sequence F: Heartbeat Verification → PTC = 0 % + systematic errors

Note the following for the test sequences:

- The individual proof test coverages (PTC) that can be used for calculation are specified in the Declaration of Conformity.
- Test sequence C is not permitted for a commissioning test.
- The transmitter can be tested without a sensor using an appropriate sensor simulator (resistance decade, reference voltage source, etc.).
- The accuracy of the measuring device used must meet the transmitter specifications.
- A three-point calibration must be performed when customized linearization (e.g. with CvD coefficients) is used. The upper sensor limit and the lower sensor limit must also be checked.

Proof testing and optimization of subsystems

Proline t-mass 300 HART Proof testing

NAMUR Worksheet NA106 "Flexible proof testing of field devices in safety instrumented systems" explains how to optimize testing activities in safety instrumented systems with regard to interrupting operation while maintaining the necessary safety integrity of the installed safety instrumented systems.

The Heartbeat Technology developed by Endress+Hauser can be used to implement the "Flexible testing" test strategy of field devices under NA106.

Device verification (Heartbeat Verification) enables the documentation of the current device diagnostic or the device status as proof of testing. This supports the documentation of proof tests according to IEC 61511-1, Section 16.3.3, "Documentation of proof tests and inspections". Device verification (Heartbeat Verification) is based on device-specific test sequences that are performed automatically. The verification also enables the detection of systematic errors in the sensor system (e.g. formation of buildup in the sensor).

7.1 Test sequence A (PTC = 99 %)

- Testing with a secondary standard (mass flow)
- Verification of current output 1
- Inspection and on-site visual check

Preparation

By assing of safety function of process control system, to prevent accidental activation of the safety function.

► Deactivate the locked SIL mode → 🖺 31.

7.1.1 Test sequence: Testing with a secondary standard (mass flow)

The measured values (3 to 5 measuring points) are checked with a secondary standard on an installed device (mobile calibration rig or calibrated reference device) or on a factory calibration rig following device removal.

The measured values of the secondary standard and the device under test (DUT) are compared using one of the following methods:

Comparison by reading off the digital measured value

 Compare the digital measured value of the secondary standard against the measured value display of the DUT at the logic subsystem (process control system or safety-related PLC).

Comparison of the measured value by measuring the current

Requirements for the measuring equipment:

- DC current measuring uncertainty ±0.2 %
- DC current resolution 10 µA
- 1. Measure the current at the DUT using an external, traceably-calibrated ammeter.
- Measure the current of the DUT at the logic subsystem (process control system or safety-related PLC).

Proof testing Proline t-mass 300 HART

Evaluation of results: Testing with a secondary standard (mass flow)

The amount of deviation between the measured flow rate and the set point must not exceed the measured error specified for the safety function.

For information on the required measured error for the device, see the "Performance characteristics" section of the Operating Instructions

► Follow the information in the section on "Restrictions for use in safety-related applications, information on measured errors" → 🖺 16

7.1.2 Test sequence: Testing of current output 1

The **Simulation** submenu (Diagnostics \rightarrow Simulation) enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Performing the test

- For proof testing, use only the **Current output simulation** parameter ($\rightarrow \cong 37$) and the **Value current output** parameter ($\rightarrow \cong 37$), as these are the only parameters approved for testing the safety-related characteristics.
- In the Value current output parameter, select the defined default values one after the other.
- 2. Compare current at output 1 with this default value.


Comparing the current values

The current values can be compared using one of the following methods:

- Measure the current of the DUT at the logic subsystem (process control system or safetyrelated PLC).
- Measure the current at the DUT using an external, traceably-calibrated ammeter.
- ► Compare the current values.

Connecting the measuring equipment and external testing

- Connecting the measuring equipment in the measuring circuit
- $\ \ \, \blacksquare$ External check of the passive or active current output
- Requirements for the measuring equipment:
 - \blacksquare DC current measuring uncertainty ±0.2 %
 - DC current resolution 10 μA



- ₩ 4 External verification taking the example of a passive current output
- Automation system with current input (e.g. PLC) 1
- Power supply unit
- Ammeter
- Transmitter
- 1. Connect the ammeter to the transmitter by looping it in series into the circuit.
- Connect the power supply unit.

Evaluation of results: Testing of current output 1

The amount of deviation between the measured current and the set point must not exceed the measured error specified for the safety function. The deviation should not exceed $\pm 1~\%$ / ±300 µA.

▶ Follow the information in the section on "Restrictions for use in safety-related applications, information on measured errors" $\rightarrow \blacksquare 16$.

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry
Current output 1 to n simulation	-	Switch the simulation of the current output on and off.	On
Value current output 1 to n	In the Current output 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	 1. Default value: Select 4.0 mA. 2. Default value: Select 20.0 mA. 3.59 to 22.5 mA

7.1.3 Test sequence: Inspection and on-site visual check

At the transmitter, check the correct sealing function of all the electronics compartment cover seals and cable entries.

7.1.4 Connecting the test

- 1. Re-activate the locked SIL mode $\rightarrow \triangle$ 23.
- Deactivate bypassing of safety function of process control system.

3. Document results of proof test in accordance with the safety management guidelines applicable to the system.

NOTICE

At least 99 % of dangerous, undetected failures can be detected using the test sequences described (PTC = 0.99). The influence of systematic errors on the safety function is not fully covered by the test. Systematic errors can be caused, for example, by medium properties, operating conditions or buildup.

- ▶ If one of the test criteria from the test sequences described above is not fulfilled, the device may no longer be used as part of a protective system.
- ► Take measures to reduce systematic errors. For detailed information on the orientation, medium properties and operating conditions, see the "Operating Instructions" → 🖺 9

7.2 Test sequence C (PTC = 98 %)

- Testing with a secondary standard (mass flow)
- Inspection and on-site visual check

Preparation

Byassing of safety function of process control system, to prevent accidental activation of the safety function.

▶ Deactivate the locked SIL mode → ■ 31.

7.2.1 Test sequence: Testing with a secondary standard (mass flow)

Testing with a secondary standard (mass flow): Verification of the measured value for liquid and gaseous mass flow by comparing with a secondary standard.

The measured values (3 to 5 measuring points) are checked with a secondary standard on an installed device (mobile calibration rig or calibrated reference device) or on a factory calibration rig following device removal.

The measured values of the secondary standard and the device under test (DUT) are compared using one of the following methods:

Comparison by reading off the digital measured value

► Compare the digital measured value of the secondary standard against the measured value display of the DUT at the logic subsystem (process control system or safety-related PLC).

Comparison of the measured value by measuring the current

Requirements for the measuring equipment:

- \blacksquare DC current measuring uncertainty ±0.2 %
- ullet DC current resolution 10 μA
- 1. Measure the current at the DUT using an external, traceably-calibrated ammeter.
- 2. Measure the current of the DUT at the logic subsystem (process control system or safety-related PLC).

Evaluation of results: Testing with a secondary standard (mass flow)

The amount of deviation between the measured flow rate and the set point must not exceed the measured error specified for the safety function.

For information on the required measured error for the device, see the "Performance characteristics" section of the Operating Instructions

► Follow the information in the section on "Restrictions for use in safety-related applications, information on measured errors" → 🖺 16

7.2.2 Test sequence: Inspection and on-site visual check

At the transmitter, check the correct sealing function of all the electronics compartment cover seals and cable entries.

7.2.3 Connecting the test

NOTICE

At least 98 % of dangerous, undetected failures can be detected using the test sequences described (PTC = 0.98). The influence of systematic errors on the safety function is not fully covered by the test. Systematic errors can be caused, for example, by medium properties, operating conditions or buildup.

- ► If one of the test criteria from the test sequences described above is not fulfilled, the device may no longer be used as part of a protective system.
- ► Take measures to reduce systematic errors. For detailed information on the orientation, medium properties and operating conditions, see the "Operating Instructions" → 🖺 9

7.3 Test sequence D (PTC = 36 %)

- Device restart (Verification of RAM memory)
- Verification of current output 1
- Heartbeat Verification
- Inspection and on-site visual check

Detection of additional systematic errors with Heartbeat Verification: influence of the process on the device (e.g. formation of buildup in the sensor).

Preparation

Byassing of safety function of process control system, to prevent accidental activation of the safety function.

▶ Deactivate the locked SIL mode → ■ 31.

7.3.1 Test sequence: Device restart

The device restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

The device can be restarted using one of the following methods:

- Disconnecting and reconnecting the terminal voltage.
- In the Device reset parameter, select the Restart device option. Setup → Advanced setup → Administration
- ▶ Restart the device.

NOTICE

Wrong option selected in the "Reset device" parameter.

If the "To factory defaults" or "To delivery settings" option is selected, the device configuration is reset and the device must be reconfigured!

▶ In the **Device reset** parameter, select only the **Restart device** option.

Evaluation of results: Device restart

- ► Test restart of device.
 - → After a successful startup, the local display switches automatically from the startup display to the operational display. If the device restarts and no diagnostic message is displayed, this step has been completed successfully. If nothing appears on the local display or a diagnostic message is displayed, refer to the "Diagnostics and troubleshooting" section of the "Operating Instructions"

7.3.2 Test sequence: Testing of current output 1

The **Simulation** submenu (Diagnostics \rightarrow Simulation) enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Performing the test

- For proof testing, use only the **Current output simulation** parameter ($\rightarrow \implies 37$) and the **Value current output** parameter ($\rightarrow \implies 37$), as these are the only parameters approved for testing the safety-related characteristics.
- In the Value current output parameter, select the defined default values one after the other.
- 2. Compare current at output 1 with this default value.

Comparing the current values


The current values can be compared using one of the following methods:

- Measure the current of the DUT at the logic subsystem (process control system or safetyrelated PLC).
- $\ \blacksquare$ Measure the current at the DUT using an external, traceably-calibrated ammeter.
- ► Compare the current values.

Connecting the measuring equipment and external testing

- Connecting the measuring equipment in the measuring circuit
- External check of the passive or active current output
- Requirements for the measuring equipment:

 DC current measuring uncertainty ±0.2 %
 - DC current resolution 10 μA



A0034446

- 5 External verification taking the example of a passive current output
- 1 Automation system with current input (e.g. PLC)
- 2 Power supply unit
- 3 Ammeter
- 4 Transmitter
- 1. Connect the ammeter to the transmitter by looping it in series into the circuit.
- 2. Connect the power supply unit.

Evaluation of results: Testing of current output 1

The amount of deviation between the measured current and the set point must not exceed the measured error specified for the safety function. The deviation should not exceed $\pm 1~\%$ / $\pm 300~\mu A$.

► Follow the information in the section on "Restrictions for use in safety-related applications, information on measured errors" → 🖺 16.

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry
Current output 1 to n simulation	-	Switch the simulation of the current output on and off.	On
Value current output 1 to n	In the Current output 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	 1. Default value: Select 4.0 mA. 2. Default value: Select 20.0 mA. 3.59 to 22.5 mA

7.3.3 Test sequence: Heartbeat Verification

- 1. Select Heartbeat Verification (standard).
- 2. Initiate Heartbeat Verification.
- 3. Verification is performed automatically in the device: see the "Standard verification" section of the "Special Documentation for Heartbeat Technology".

Acceptance criteria: Heartbeat Verification

- 1. Check whether the result of the verification is **Passed** or **Failed**.
 - The check is completed successfully if the result of the Heartbeat Verification is **Passed**.
- 2. To document the test, print the verification report. Device diagnostics or device status as proof of testing.
- The following systematic errors can be detected: Buildup in the sensor pipes

7.3.4 Test sequence: Inspection and on-site visual check

At the transmitter, check the correct sealing function of all the electronics compartment cover seals and cable entries.

7.3.5 Connecting the test

- 1. Re-activate the locked SIL mode $\rightarrow \triangleq 23$.
- 2. Deactivate bypassing of safety function of process control system.
- 3. Document results of proof test in accordance with the safety management guidelines applicable to the system.
- At least 36 % of the dangerous, undetected failures (PTC = 0.36) can be detected with the test sequences described.

NOTICE

The influence of systematic errors on the safety function is not fully covered by the test. Systematic errors can be caused, for example, by medium properties, operating conditions or buildup.

- ▶ If one of the test criteria from the test sequences described above is not fulfilled, the device may no longer be used as part of a protective system.
- ► Take measures to reduce systematic errors. For detailed information on the orientation, medium properties and operating conditions, see the "Operating Instructions" → 🖺 9

7.4 Test sequence E (PTC = 19 %)

- Device restart (Verification of RAM memory)
- Heartbeat Verification
- Inspection and on-site visual check

Detection of additional systematic errors with Heartbeat Verification: influence of the process on the device (e.g. formation of buildup in the sensor).

Preparation

Byassing of safety function of process control system, to prevent accidental activation of the safety function.

▶ Deactivate the locked SIL mode \rightarrow 🗎 31.

7.4.1 Test sequence: Device restart

The device restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

The device can be restarted using one of the following methods:

- Disconnecting and reconnecting the terminal voltage.
- In the **Device reset** parameter, select the **Restart device** option.
 Setup → Advanced setup → Administration
- Restart the device.

NOTICE

Wrong option selected in the "Reset device" parameter.

If the "To factory defaults" or "To delivery settings" option is selected, the device configuration is reset and the device must be reconfigured!

▶ In the **Device reset** parameter, select only the **Restart device** option.

Evaluation of results: Device restart

- ► Test restart of device.
 - After a successful startup, the local display switches automatically from the startup display to the operational display. If the device restarts and no diagnostic message is displayed, this step has been completed successfully.
 If nothing appears on the local display or a diagnostic message is displayed, refer to
 - If nothing appears on the local display or a diagnostic message is displayed, refer to the "Diagnostics and troubleshooting" section of the "Operating Instructions"

7.4.2 Test sequence: Heartbeat Verification

- 1. Select Heartbeat Verification (standard).
- 2. Initiate Heartbeat Verification.
- 3. Verification is performed automatically in the device: see the "Standard verification" section of the "Special Documentation for Heartbeat Technology".

Acceptance criteria: Heartbeat Verification

- 1. Check whether the result of the verification is **Passed** or **Failed**.
 - The check is completed successfully if the result of the Heartbeat Verification is **Passed**.
- To document the test, print the verification report. Device diagnostics or device status as proof of testing.
- The following systematic errors can be detected: Buildup in the sensor pipes

7.4.3 Test sequence: Inspection and on-site visual check

At the transmitter, check the correct sealing function of all the electronics compartment cover seals and cable entries.

7.4.4 Connecting the test

- 1. Re-activate the locked SIL mode $\rightarrow \square$ 23.
- 2. Deactivate bypassing of safety function of process control system.
- 3. Document results of proof test in accordance with the safety management guidelines applicable to the system.
- At least 19 % of the dangerous, undetected failures (PTC = 0.19) can be detected with the test sequences described.

NOTICE

The influence of systematic errors on the safety function is not fully covered by the test. Systematic errors can be caused, for example, by medium properties, operating conditions or buildup.

- ► If one of the test criteria from the test sequences described above is not fulfilled, the device may no longer be used as part of a protective system.
- ► Take measures to reduce systematic errors. For detailed information on the orientation, medium properties and operating conditions, see the "Operating Instructions" → 🖺 9

7.5 Test sequence F (PTC = 0%)

- Heartbeat Verification
- Inspection and on-site visual check

Detection of additional systematic errors with Heartbeat Verification: influence of the process on the device (e.g. formation of buildup in the sensor).

Preparation

Byassing of safety function of process control system, to prevent accidental activation of the safety function.

▶ Deactivate the locked SIL mode → 🗎 31.

7.5.1 Test sequence: Heartbeat Verification

- 1. Select Heartbeat Verification (standard).
- 2. Initiate Heartbeat Verification.
- 3. Verification is performed automatically in the device: see the "Standard verification" section of the "Special Documentation for Heartbeat Technology".

Acceptance criteria: Heartbeat Verification

- 1. Check whether the result of the verification is **Passed** or **Failed**.
 - The check is completed successfully if the result of the Heartbeat Verification is **Passed**.

2. To document the test, print the verification report. Device diagnostics or device status as proof of testing.

The following systematic errors can be detected: Buildup in the sensor pipes

7.5.2 Test sequence: Inspection and on-site visual check

At the transmitter, check the correct sealing function of all the electronics compartment cover seals and cable entries.

7.5.3 Connecting the test

- 1. Re-activate the locked SIL mode $\rightarrow \triangleq 23$.
- 2. Deactivate bypassing of safety function of process control system.
- Document results of proof test in accordance with the safety management guidelines applicable to the system.

NOTICE

No dangerous, undetected failures can be detected using the test sequences described (PTC = 0). The influence of systematic errors on the safety function is not fully covered by the test. Systematic errors can be caused, for example, by medium properties, operating conditions or buildup.

- ► If one of the test criteria from the test sequences described above is not fulfilled, the device may no longer be used as part of a protective system.
- ► Take measures to reduce systematic errors. For detailed information on the orientation, medium properties and operating conditions, see the "Operating Instructions" → 🖺 9

7.6 Verification criterion

If one of the test criteria from the test sequences described above is not satisfied, the device may no longer be used as part of a safety instrumented system.

- The purpose of proof-testing is to detect dangerous undetected device failures (λ_{du}).
- The impact of systematic errors on the safety function is partially covered by this test and must be assessed separately.
- Systematic errors can be caused, for example, by substance properties, operating conditions or buildup.
- As part of the visual inspection, for example, ensure that all of the seals and cable entries
 provide adequate sealing.

8 Repair and error handling

8.1 Maintenance





Alternative monitoring measures must be taken to ensure process safety during configuration, proof-testing and maintenance work on the device.

8.2 Repair



Repair means restoring functional integrity by replacing defective components.

Only original Endress+Hauser spare parts may be used for this purpose.

We recommend that you document the repair. This includes documenting the:

- Serial number of the device
- Date of the repair
- Type of repair
- Person who performed the repair

Components may be repaired/replaced by the customer's technical staff if original Endress+Hauser spare parts are used (they can be ordered by the end user), and if the relevant installation instructions are followed.



8.2.1 Replacing device components

The following components may be replaced by the customer's technical staff if genuine spare parts are used and the appropriate installation instructions are followed:

- Sensor
- Transmitter without a sensor
- Display module
- Power unit
- Main electronics module
- Sensor electronics module (ISEM)
- I/O modules
- Terminals
- Connection compartment cover
- Electronics compartment cover
- Seal sets for electronics compartment cover
- Securing clamps for electronics compartment cover
- Cable glands

Installation Instructions: see the Download Area under www.endress.com.

The replaced component must be sent to Endress+Hauser for the purpose of fault analysis if the device has been operated in a protective system and a device error cannot be ruled out. In this case, always enclose the "Declaration of Hazardous Material and Decontamination" with

8.3 Modification

Modifications are changes to devices with SIL capability already delivered or installed.

- Modifications to devices with SIL capability are usually performed in the Endress+Hauser manufacturing center.
- ▶ Modifications to devices with SIL capability onsite at the user's plant are possible following approval by the Endress+Hauser manufacturing center. In this case, the modifications must be performed and documented by an Endress+Hauser service technician.
- ▶ Modifications to devices with SIL capability by the user are not permitted.

8.4 Taking out of service

The requirements of IEC 61508-1:2010 Section 7.17 must be observed when taking the device out of service.

8.5 Disposal



For detailed information on the device disposal, see the Operating Instructions $\rightarrow~ \stackrel{ riangle}{=}~ 9$


9 Appendix

9.1 Structure of the measuring system

9.1.1 System components

An example of the devices in the measuring system is shown in the following graphic.

Appendix Proline t-mass 300 HART



Δ0015443

№ 6 System components

- 1 Pump
- 2 Measuring device
- 3 Valve
- 4 Automation system

An analog signal (4-20 mA) proportional to the flow is generated in the transmitter. This is sent to a downstream automation system where it is monitored to determine whether it falls below or exceeds a specified limit value. The safety function (mass flow monitoring) is implemented in this way.

For fault monitoring, the logic unit must recognize both HI alarms (\geq 21 mA) and LO alarms (\leq 3.6 mA).

9.1.2 Description of use of protective system

The measuring device can be used in protective systems to monitor the following (Min., Max. and range):


Mass flow

NOTICE

The device must be correctly mounted to guarantee safe operation.

▶ Observe the mounting instructions.





Δ0015277

- 7 Monitoring options in protective systems
- A Min. alarm
- B Max. alarm
- C Range monitoring
- **⋈** = *Safety function is triggered*
- **▼** = Permitted operating status

Appendix Proline t-mass 300 HART

9.2 Commissioning or proof test report

9.2.1 Test report - Page 1

	eite 1		
Geräteinformation			
Anlage			
Messstellen / TAG-Nr.			
Seriennummer			
Informationen zur Prüfung	0		
Datum / Uhrzeit	2		
Durchgeführt von:			
			1
Prüfablauf	PTC		
Delifonessanahula			
Prüfungsergebnis			
Bestanden:		Nicht bestanden	
Firma / Ansprechpart Ausführender:	ner:		

A0049162

9.2.2 Test report – Page 2

Geräteinformation				
Anlage				
Messstellen / TAG-N	r.			
Seriennummer				
Informationen zur Pr	üfung			
Datum / Uhrzeit				
Sicherneitsfunktio	n - Grenzwertübe	rwacnung		
Min		Max		
Teil Prüfabläufe	Soll	lst	Teil-E ▽	rgebnis
Teil Prüfabläufe	Soll			
Teil Prüfabläufe	Soll			
Teil Prüfabläufe	Soll			
Teil Prüfabläufe	Soll			
Teil Prüfabläufe	Soll			
Teil Prüfabläufe	Soll			
Teil Prüfabläufe	Soll			
Teil Prüfabläufe	Soll			
Teil Prüfabläufe	Soll			

A0049163

Appendix Proline t-mass 300 HART

9.2.3 Parameter settings for the SIL mode

Parameter-Einstellungen für den SIL-Mode

Parametername	Werkseinstellung	Eingestellter Wert	Geprüft
Freigabecode eingeben	0		
Anfang Messbereich (4mA)	0		
Sensortyp			
Druckkompensation	= Aus		
Zuordnung Stromausgang 1	= Massefluss		
Strombereich	= 420 mA		
Fehlerverhalten	= Min.		
Schleichmengenunterdrückung	= Aus		
Überwachung teilgefülltes Rohr	= Aus		
Messmodus (4 mA-Wert)*	= Förderricht.		
Ansprechzeit teilgefülltes Rohr*	= 0		
Zuordnung Simul. Prozessgr.*	= Aus		
Simulation Stromausgang 1*	= Aus		
Diagnosenr. 046; 140; 274; 374; 830; 831; 834; 835; 913*	= Alarm		

^{*} Das Gerät schaltet nach Erfüllung der Vorbedingungen selbsttätig diese Parameter auf sicherheitsgerichtete Einstellungen.

A0049164

9.3 Verification or calibration

The SIL mode must be disabled in order to verify the measuring point with Heartbeat Technology or calibrate the measuring point.

NOTICE

To use the device in a safety function again following a verification or calibration, the configuration of the measuring point must be checked and the SIL mode must be enabled again.

▶ Activate the SIL mode \rightarrow 🗎 23.

9.4 Version history

Version	Changes	Valid as of firmware version		
SD02483D/06/xx/04.24	Expansion of scope for natural gas mixtures	01.00.zz (HART; from delivery date July 31, 2020)		
SD02483D/06/xx/03.22	Adjustments following the TÜV audit	01.00.zz (HART; from delivery date July 31, 2020)		

Version SD02483D/06/xx/02.21		Changes	Valid as of firmware version		
		Second version	01.00.zz (HART; from delivery date July 31, 2020)		
	SD02483D/06/xx/01.20	First version	01.00.zz (HART; from delivery date July 31, 2020)		





www.addresses.endress.com