


Special Documentation

Proline Prowirl 200

Functional Safety Manual



Application

Monitoring of maximum and/or minimum flow in systems which are required to comply with the particular safety circuit requirements of IEC 61508.

The measuring device fulfills the requirements concerning:

- Functional safety as per IEC 61508
- Explosion protection (depending on the version)
- Electromagnetic compatibility as per IEC 61326-3-2 and NAMUR recommendation NE 21
- Electrical safety as per IEC 61010-1

Your benefits

- Use for volume flow monitoring up to SIL 2 (single-channel architecture) or SIL 3 (multi-channel architecture with homogeneous redundancy) - independently assessed and certified by TÜV in accordance with IEC 61508
- Measurement is virtually independent of the process properties
- Permanent self-monitoring
- Easy installation and commissioning
- Integrated proof-testing
- Heartbeat verification for the documentation of diagnostic checks in accordance with IEC 61511

Table of contents

Declaration of Conformity	3
Safety-related characteristic values	4
Useful lifetime of electric components	6
SIL certificate	7
Document information	8
Document function	8
Using this document	8
Symbols used	8
Documentation	9
Permitted devices types	11
SIL label on the transmitter nameplate	12
Safety function	12
Definition of the safety function	12
Restrictions for use in safety-related applications	12
Use in protective systems	14
Device behavior during operation	14
Parameter configuration for safety-related applications	15
Proof-testing	20
Life cycle	22
Requirements for personnel	22
Installation	22
Commissioning	22
Operation	22
Maintenance	22
Repairs	22
Modification	23
Decommissioning	23
Appendix	24
Structure of the measuring system	24
Verification or calibration	25
Notes on the redundant use of multiple sensors	25
Version history	25

Declaration of Conformity

KE_FS_Pwirl200_e.docx

Endress+Hauser 
People for Process Automation

Declaration of Conformity

Functional Safety according to IEC 61508:2010
Supplement 1 / NE130 Form B.1

Endress+Hauser Flowtec AG, Kägenstrasse 7, CH-4153 Reinach

declares as manufacturer, that the Flowmeter

Prowirl 200


is suitable for the use in safety-instrumented systems according to IEC61508:2010.

In safety instrumented systems according IEC 61508 and IEC 61511, the instructions of the Safety Manual have to be followed.

Reinach, 09. Juni. 2015


Endress+Hauser Flowtec AG

ppa.



Dr.-Ing. Christian Jarms
Head of Quality Management

i.V.



Dipl.-Ing. Michael Karolzak
Project Manager Functional
Safety

Safety-related characteristic values

General	
Device designation and permitted versions	7C2B (Prowirl C 200) 7D2B (Prowirl D 200) 7F2B (Prowirl F 200) 7O2B (Prowirl O 200) 7R2B (Prowirl R 200) Order code for "Output": <ul style="list-style-type: none"> ▪ Option A "4-20mA HART" ▪ Option B "4-20mA HART, pul./freq./switch output" ▪ Option C "4-20mA HART + 4-20mA analog" Order code for "Additional approval": Option LA "SIL"
Safety-related output signal	4 to 20 mA
Failure current	≤ 3.6 mA or ≥ 21 mA
Assessed measured variable/function	Volume flow monitoring
Safety function(s)	Min., Max., Range
Device type according to IEC 61508-2	<input type="checkbox"/> Type A <input checked="" type="checkbox"/> Type B
Mode	<input checked="" type="checkbox"/> Low Demand Mode <input checked="" type="checkbox"/> High Demand Mode <input type="checkbox"/> Continuous Mode ¹⁾
Valid hardware version (main electronics)	From delivery date 10.01.2013
Valid firmware version	01.00.zz (HART; from delivery date 10.01.2013), 01.02.zz (HART; from delivery date 06.01.2015)
Safety manual	SD01162D
Type of assessment (only 1 version can be selected)	<input checked="" type="checkbox"/> Complete HW/SW assessment in the context of development including FMEDA and change process according to IEC 61508-2, 3 <input type="checkbox"/> Assessment of evidence for proven-in-use HW/SW including FMEDA and change process according to IEC 61508-2, 3 <input type="checkbox"/> Analysis of HW/SW field data for evidence of "prior use" according to IEC 61511 <input type="checkbox"/> Assessment by FMEDA according to IEC 61508-2 for devices without software
Assessment by (including report no. + FMEDA data source)	TÜV Rheinland Industrie Service GmbH – Certificate No. 968/EZ 645.01/19
Test documents	Development documents, test reports, data sheets

1) No continuous operation in accordance with IEC 61508: 2011 (Section 3.5.16).

SIL integrity			
Systematic safety integrity		<input type="checkbox"/> SIL 2 capable	<input checked="" type="checkbox"/> SIL 3 capable
Hardware safety integrity	Single-channel service (HFT = 0)	<input checked="" type="checkbox"/> SIL 2 capable	<input type="checkbox"/> SIL 3 capable
	Multi-channel service (HFT ≥ 1)	<input type="checkbox"/> SIL 2 capable	<input checked="" type="checkbox"/> SIL 3 capable

FMEDA ¹⁾		
Safety function(s)	Min., Max., Range	
Order code for "Output"	Option A, B	Option C
λ_{DU} ²⁾	87 (87) FIT	70 (70) FIT
λ_{DD}	1588 (1604) FIT	1413 (1428) FIT

λ_{SU}	651 (659) FIT	1266 (1273) FIT
λ_{SD}	381 (381) FIT	381 (381) FIT
SFF - Safe Failure Fraction	97 %	98 %
PFD _{avg} for T ₁ = 1 year ³⁾ (single-channel architecture)	$3.8 \cdot 10^{-4}$	$3.1 \cdot 10^{-4}$
PFD _{avg} for T ₁ = 5 years (single-channel architecture)	$1.9 \cdot 10^{-3}$	$1.5 \cdot 10^{-3}$
PFH	$8.7 \cdot 10^{-8} \cdot 1/h$	$7.0 \cdot 10^{-8} \cdot 1/h$
PTC ⁴⁾	Up to 98 %	
MTBF _{tot} ⁵⁾	41 years	36 years
Diagnostic test interval ⁶⁾	30 min	
Fault response time ⁷⁾	30 s	
Process safety time ⁸⁾	50 h	
Recommended test interval T ₁	5 years	
MTTF _d ⁹⁾	66 years	76 years

- 1) Values in brackets apply to remote version.
- 2) FIT = Failure In Time, number of failures per 10⁹ h.
- 3) Valid for averaged ambient temperatures up to 40 °C (104 °F) in accordance with general standard for devices with SIL capability.
- 4) PTC = Proof Test Coverage (diagnostic coverage achieved by device failure detection during manual proof testing).
- 5) This value takes into account all failure types of the electronic components as per Siemens SN29500.
- 6) All diagnostic functions are carried out at least once during this time.
- 7) Maximum time between fault detection and fault response.
- 8) The process safety time amounts to the diagnostic test interval * 100 (calculation as per IEC 61508).
- 9) MTTF_d as per ISO 13849/IEC 62061 also includes soft errors (sporadic bit errors in data memories).

Note
The measuring device has been developed for use in "Low Demand" and "High Demand" mode.
Explanation
<input checked="" type="checkbox"/> Our in-house quality management system saves information on safety-related systematic errors that will become known in the future.

Useful lifetime of electric components

The established failure rates of electric components apply for a useful lifetime of 12 years as per IEC 61508-2: 2010, section 7.4.9.5, note 3.

The device's year of manufacture is coded in the first character of the serial number (→ table below).

Example: Serial no. E5ABBF02000 → Year of manufacture 2011

ASCII character	Meaning	ASCII character	Meaning	ASCII character	Meaning
D	2010	K	2015	R	2020
E	2011	L	2016	S	2021
F	2012	M	2017	T	2022
H	2013	N	2018	V	2023
J	2014	P	2019	W	2024

SIL certificate

Certificate



Product Safety
Functional
Safety

www.tuv.com
ID 060000000

Nr./No.: 968/EZ 645.01/19

Prüfgegenstand Product tested	Durchflussmessgerät für die sichere Messung von Volumendurchfluss Flow rate meter for the safe measurement of volume flow	Zertifikatsinhaber Certificate holder	Endress + Hauser Flowtec AG Kägenstr. 7 4153 Reinach BL 1 Switzerland
Typbezeichnung Type designation	Proline Prowirl 200 with the IO-Modules: "IO211 Ex-i, 212 Ex-d" (Option A, B) or "IO216 Ex-i, 217 Ex-d" (Option C) or "IO218 Ex-i, 219 Ex-d" (Option D)		
Prüfgrundlagen Codes and standards	IEC 61508 Parts 1-7:2010		
Bestimmungsgemäße Verwendung Intended application	Das Gerät erfüllt die Anforderungen der Prüfgrundlagen (HW Sicherheitsintegrität SIL 2 und systematische Sicherheitsintegrität SC 3 nach IEC 61508) und kann in Anwendungen bis SIL 2 (HFT = 0) bzw. SIL 3 (HFT = 1) nach IEC 61508 für die Sicherheitsfunktion Messung von Volumendurchfluss mit proportionaler sicherheitsgerichteter Ausgabe an der ersten 4-20mA Stromschnittstelle. The device complies with the requirements of the relevant standards (HW Safety Integrity SIL 2 and Systematic Capability SC 3 acc. to IEC 61508) and can be used in applications up to SIL 2 (HFT = 0) resp. SIL 3 (HFT = 1) acc. to IEC 61508 for the safety function measurement of volume flow rate with proportional safety related output at the first 4-20mA current interface.		
Besondere Bedingungen Specific requirements	Die Hinweise in der zugehörigen Installations- und Betriebsanleitung sind zu beachten. The instructions of the associated Installation and Operating Manual shall be considered.		

Gültig bis / Valid until 2024-07-31

Der Ausstellung dieses Zertifikates liegt eine Prüfung zugrunde, deren Ergebnisse im Bericht Nr. 968/EZ 645.01/19 vom 31.07.2019 dokumentiert sind.

Dieses Zertifikat ist nur gültig für Erzeugnisse, die mit dem Prüfgegenstand übereinstimmen.
The issue of this certificate is based upon an examination, whose results are documented in Report No. 968/EZ 645.01/19 dated 2019-07-31.

This certificate is valid only for products which are identical with the product tested.

TÜV Rheinland Industrie Service GmbH
Bereich Automation
Funktionale Sicherheit
Am Grauen Stein, 51105 Köln

Köln, 2019-07-31

Certification Body Safety & Security for Automation & Grid

Dipl.-Ing. Gebhard Bouwer

TÜV Rheinland Industrie Service GmbH, Am Grauen Stein, 51105 Köln / Germany
Tel.: +49 221 866-1730, Fax: +49 221 866-1539, E-Mail: industrie-service@de.tuv.com

10/201 4.08 E A4 © TÜV, TÜEV and TUV are registered trademarks. Utilisation and application requires prior approval.

www.fs-products.com


www.tuv.com

TÜVRheinland®
Precisely Right.

Document information



Document function

The document is part of the Operating Instructions and serves as a reference for application-specific parameters and notes.

-  General information about functional safety: **SIL**
- General information about SIL is available:
In the Download Area of the Endress+Hauser Internet site: www.de.endress.com/SIL





Using this document

Information on the document structure








-  For the arrangement of the parameters as per the **Operation** menu, **Setup** menu, **Diagnostics** menu, along a short description, see the Operating Instructions for the device.
-  For information about the operating philosophy, see the "Operating philosophy" chapter in the device's Operating Instructions

Symbols used

Safety symbols

Symbol	Meaning
	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation Refers to the corresponding device documentation.
	Reference to page Refers to the corresponding page number.
	Reference to graphic Refers to the corresponding graphic number and page number.
	Operation via local display Indicates navigation to the parameter via the local display.
	Operation via operating tool Indicates navigation to the parameter via the operating tool.
	Write-protected parameter Indicates a parameter that can be locked against changes by entering a user-specific code.

Symbols in graphics

Symbol	Meaning
1, 2, 3 ...	Item numbers
A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections

Documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer* : Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

Standard documentation

Operating Instructions

Measuring device	Documentation code
Prowirl C 200	BA01152D
Prowirl D 200	BA01153D
Prowirl F 200	BA01154D
Prowirl O 200	BA01155D
Prowirl R 200	BA01156D

Description of device parameters

Measuring device	Documentation code
Prowirl 200	GP01019D

Technical Information

Measuring device	Documentation code
Prowirl C 200	TI01082D
Prowirl D 200	TI01083D
Prowirl F 200	TI01084D
Prowirl O 200	TI01085D
Prowirl R 200	TI01086D

Supplementary device-dependent documentation

Safety Instructions

Contents	Documentation code
ATEX/IECEX Ex d, Ex tb	XA01148D
ATEX/IECEX Ex ia, Ex tb	XA01151D
ATEX/IECEX Ex ic, Ex nA	XA01152D
cCSA _{US} XP	XA01153D
cCSA _{US} IS	XA01154D
NEPSI Ex d	XA01238D
NEPSI Ex i	XA01239D
NEPSI Ex ic, Ex nA	XA01240D
INMETRO Ex d	XA01250D
INMETRO Ex i	XA01042D
INMETRO Ex nA	XA01043D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01163D
Heartbeat Technology	SD01204D
Natural gas	SD01194D
Air + Industrial Gases (Single Gas + Gas Mixtures)	SD01195D
Wet steam detection	SD01193D
Wet steam measurement	SD01315D
Inlet run correction	SD01226D
ERCB Dir. 017	SD01213D

Installation Instructions

Contents	Documentation code
Installation Instructions for spare part sets	For an overview of the accessories available for order, see the Operating Instructions for the device


Permitted devices types

The details pertaining to functional safety in this manual relate to the device versions listed below and are valid as of the specified software and hardware versions. Unless otherwise specified, all subsequent versions can also be used for safety functions. For device modifications, a modification process compliant with IEC 61508 is used.

Feature	Designation	Selected option
-	Order code	7C2B (Prowirl C 200) 7D2B (Prowirl D 200) 7F2B (Prowirl F 200) 7O2B (Prowirl O 200) 7R2B (Prowirl R 200)
000	Nominal diameter	C: DN 50 to 150 (2 to 6") D: DN 15 to 150 (½ to 6") F: DN 15 to 300 (½ to 12") O: DN 15 to 150 (½ to 6") R: DN 25 to 250 (1 to 10")
010	Approval	All
020	Output; input ^{1) 2)}	Option A "4-20mA HART" Option B "4-20mA HART, pul./freq./switch output" Option C "4-20mA HART, 4-20mA"
030	Display; operation	All
040	Housing	All
050	Electrical connection	All
060	Sensor version ³⁾	1, 2, 4, 5 ⁴⁾
070	Process connection	All
080	Calibration flow	All
500	Display operating language	All
520	Sensor option	All
530	Customer-specific configuration	All
540	Application package	All
570	Service	All
580	Test, certificate	All
590	Additional approval	LA (= SIL) ⁵⁾
610	Accessory mounted	All
620	Accessory enclosed	All
850	Firmware version	SIL firmware, e.g. 01.02.zz (HART)
895	Tagging	All

- 1) In devices with 2 outputs, only current output 1 (terminals 1 and 2) is suitable for safety functions. Output 2 (terminals 3 and 4) can be connected for non-safety related purposes where needed.
- 2) Option D is available only for the "Mass flow" measured variable. As the Prowirl 200 is certified only for the "Volume flow monitoring" safety function, this output version is not available.
- 3) SIL available only with order code for "Sensor version", option "Volume flow"
- 4) Sensor versions are not available for the "Mass flow" option, as the device is certified only for the "Volume flow monitoring" safety function.
- 5) Additional selection of further approvals is possible.

- Valid hardware version (main electronics): from delivery date 10.01.2013
- Valid firmware version:
 - 01.00.zz (HART; from delivery date 10.01.2013)
 - 01.02.zz (HART; from delivery date 06.01.2015)

SIL label on the transmitter nameplate

A0021056

1 SIL logo

Safety function

Definition of the safety function

The measuring device's permitted safety functions are:

- Monitoring of a maximum or minimum volume flow for liquid or gaseous media
- Monitoring of a volume flow range for liquid or gaseous media

Safety-related output signal

The measuring device's safety-related signal is the 4 to 20 mA analog output signal. All safety measures refer to this signal exclusively.

In devices with 2 outputs (order code for "Output, input", option B "4-20mA HART, pulse/frequency/switch output" or option C "4-20mA HART, 4-20mA" → 11) only current output 1 (terminals 1 and 2) is suitable for safety functions. Output 2 (terminals 3 and 4) can be connected for non-safety related purposes where needed.

The safety-related output signal is fed to a downstream automation system where it is monitored for the following:

- Overshooting and/or undershooting of a specified limit value for the volume flow
- The occurrence of a fault, e.g. error current ($\leq 3.6 \text{ mA}$, $\geq 21 \text{ mA}$), interruption or short-circuit of the signal line

Dangerous undetected failures in this scenario

An incorrect output signal that deviates from the value specified in the Operating Instructions but is still in the range of 4 to 20 mA, is considered a dangerous, undetected failure.

For detailed information about the measured error, refer to the "Information on measured errors" section → 13





For detailed information about the maximum measured error, see the Operating Instructions for the device → 9

Restrictions for use in safety-related applications

Do not exceed the values specified in the device documentation: see the "Supplementary documentation" section → 9.

Suitability of the measuring device


1. Carefully select the nominal diameter of the measuring device in accordance with the application's expected flow rates.
 - ↳ The maximum flow rate during operation must not exceed the specified maximum value for the sensor.
2. In safety-related applications, it is advisable to select the limit value for monitoring a minimum flow such that this limit is at least twice the smallest specified flow that can still be measured, with the actual medium and the selected nominal diameter.
 - ↳ For detailed information, see the Technical Information for the device → 9

3. To achieve the best possible measuring performance in the lower measuring range (comparable to measuring performance under reference operating conditions), configure the density and viscosity that is suited to the medium. The Applicator can be used to determine the medium properties accurately.
 - ↳ For more detailed information on reference operating conditions and the Applicator, see the Technical Information for the device →  9
4. If there is a sudden change in diameter between the process connecting pipe and the internal diameter of the flange, the difference in diameter must be corrected using the **Mating pipe diameter** parameter.
 - ↳ For more detailed information, see the Operating Instructions for the device →  9

NOTICE**Use the measuring device according to the specifications.**

- ▶ Pay attention to the medium properties and the environmental conditions.
- ▶ Carefully follow instructions pertaining to critical process situations and installation conditions.



For detailed information about the installation and electrical connection, as well as information about the medium properties, the environment and the process, see the Operating Instructions and Technical Information for the device →  9

CAUTION**For liquids that readily boil or in the case of suction lines:**

- ▶ Ensure that the vapor pressure is not undershot and that the liquid does not start to boil.
- ▶ Please ensure that there is never any outgassing of the gases naturally contained in many liquids. Sufficiently high system pressure prevents the occurrence of these effects.
- ▶ In order to guarantee correct measurement, ensure that no cavitation occurs.
- ▶ Avoid applications that cause buildup, corrosion or abrasion at the bluff body.




Detailed information on the suitability of the measuring device for safety-related operation is available from your Endress+Hauser sales center.

Information on measured errors

When the measured value is transmitted via the 4–20 mA current output, the measuring device's relative measured error is made up of the contribution of the digitally determined measured value and the accuracy of the analog current output. These contributions, which are listed in the device documentation, apply under reference operating conditions and can depend on the sensor version ordered. If process or ambient conditions are different, there are additional contributions, e.g. temperature or pressure, which are also listed.



For detailed information on calculating the measured error, see the Technical Information for the device →  9

Guidelines for minimal measured errors:


- Where process pressure is high, set the typical process pressure in the measuring device.
- Limit value monitoring: Depending on the process dynamics, the current value of the unfiltered 4–20 mA output signal can temporarily exceed the specified tolerance range. The device can optionally provide damping of the current output via a parameter that only affects the measured value output. Device-internal diagnostics or the outputting of an error current (≤ 3.6 mA, ≥ 21 mA) are not affected by this damping.

Power supply for the 4–20 mA interface

Overvoltages at the 4–20 mA interface (caused by a fault in the supply unit for example) can result in a leak current in the device's input protection circuit. This may lead to falsification of the output signal by more than the specified error or the minimum error current (3.6 mA) can no longer be set due to the leak current.

Therefore, it is necessary to use a 4–20 mA power supply unit with either voltage limitation or voltage monitoring.

NOTICE**The safety-related connection values depend on the Ex approval.**

- ▶ Pay attention to the safety-related connection values. For detailed information, see the section on "Safety-related values" in the Technical Information →  9

HART communication

The measuring device also communicates via HART in the SIL mode. This comprises all the HART features with additional device information.

NOTICE

The measuring device's safety-related signal is the 4 to 20 mA analog output signal.

All safety measures refer to this signal exclusively.

- ▶ Pay attention to information in the "Safety-related output signal" section →  12.

NOTICE

When the SIL locking code is entered, the device parameters that affect the safety-related output signal are locked and write-protected. It is still possible to read the parameters.

When SIL locking is enabled, restrictions apply on all communication options, such as the service interface (CDI), the HART protocol and the onsite display.

- ▶ Deactivation of the SIL mode .

Use in protective systems

Device behavior during operation

Device behavior during power-up

Once switched on, the device runs through a start-up phase. The current output is set to error current during this time. This current is ≤ 3.6 mA in the initial seconds of this start-up phase.

No communication is possible via the service interface (CDI) or via the HART protocol during the start-up phase. After the start-up phase the device switches to the normal mode (measuring operation).

Behavior of device during operation

The device outputs a current value which corresponds to the measured value to be monitored. This value must be monitored and processed further in an attached automation system.

Device behavior in safety function demand mode

Depending on the setting of the **Failure mode** parameter, the current is as follows in demand mode:

- For **Min.** option: ≤ 3.6 mA
- For **Max.** option: ≥ 21 mA

Device response in the event of alarms or warnings

The output current on alarm can be set to a value ≤ 3.6 mA or ≥ 21 mA.

In some cases (e.g. a cable open circuit or faults in the current output itself, where the error current ≥ 21 mA cannot be set) output currents of ≤ 3.6 mA occur irrespective of the configured error current.

In some other cases, (e.g. short-circuit of the line) output currents of ≥ 21 mA occur irrespective of the configured error current.

For alarm monitoring, the downstream automation system must be able to recognize both maximum alarms (≥ 21 mA) and minimum alarms (≤ 3.6 mA).

Alarm and warning messages

The alarm and warning messages output on the device display or in the operating tool in the form of diagnostic events and the associated event text are additional information.



For an overview of the diagnostic events, see the Operating Instructions

NOTICE

When SIL mode is activated, additional diagnostics are activated.

If a diagnostic event occurs and the locked SIL mode is deactivated, the error message remains while the error persists, even if the diagnostic event is no longer active in the unlocked state.

- ▶ In this case, the device must be disconnected briefly from the power supply (e.g. by unplugging the terminals). When the device is then restarted, a self-check is carried out, and the diagnostics event is reset where applicable.

Parameter configuration for safety-related applications

Configuration of the measuring point

Either the device display or an operating tool (e.g. FieldCare) is used to carry out basic configuration of the measuring point. A wizard guides you through the **Setup** menu.



For detailed information on operation, see the Operating Instructions for the device → 9

After the operating language has been selected, the following can be configured:

- Selection and configuration of the medium
- Configuration of the current outputs
- Configuration of the pulse/frequency output and switch output
- Configuration of the local display
- Configuration of the output behavior
- Configuration of the low flow cutoff

For the further configuration of the measuring device in special applications, a wide range of other configuration parameters are available via the **Diagnostics** menu and **Expert** menu.



For detailed information on the further configuration of the measuring device, see the "Description of Device Parameters" documentation.

To activate the SIL mode, the device must run through a confirmation sequence. Operation can be via the local display or an operating tool (e.g. FieldCare). While running through this sequence, critical parameters are either set automatically by the device to standard values or transferred to the local display/operating tool to enable verification of the setting. On completion of parameter configuration, the SIL mode of the device must be enabled with a SIL locking code.

Availability of the SIL mode function

NOTICE

The SIL confirmation sequence is only visible on the local display and in operating tools for devices with the order code for "Additional approval", option LA "SIL".

- ▶ For this reason, the SIL mode can also only be activated on these measuring devices.
- ▶ If the LA "SIL" option was ordered for the flowmeter ex works, this function is available when the measuring device is delivered to the customer. The function is accessed via the operating interfaces of the measuring device or via the operating tool (e.g. FieldCare).
- ▶ If the order option cannot be accessed in the measuring device, the function cannot be retrofitted during the life cycle of the device. If you have any questions please contact your Endress+Hauser service or sales organization.

Ways to check function availability in the measuring device:

Using the serial number:

W@M Device viewer¹⁾ → Order code for "Additional approval", option LA "SIL"

Additional information on SIL labeling:

- Permitted device types → 11
- SIL label on the transmitter nameplate → 12

Overview of the SIL mode

The SIL mode enables the following steps:

1. Makes sure that the preconditions are met.
 - ↳ The measuring device checks whether the user has correctly configured a predefined set of parameters for the safety function. If the result is positive, the device continues with the activation of the SIL mode. If the result is negative, the sequence is not permitted or is aborted, and the device does not continue with the activation of the SIL mode.
2. Automatically switches a predefined set of parameters to the default values specified by the manufacturer.
 - ↳ This parameter set ensures that the flowmeter works in the safety mode.
3. Guides the user through the preconfigured parameters for checking.
 - ↳ This ensures that the user actively checks all the important pre-settings.
4. Activates write protection for all the relevant parameters in the SIL mode.

1) www.endress.com/deviceviewer

All this ensures that the parameter settings that are required for the safety function are configured correctly. (These settings cannot be circumvented either deliberately or by accident.)

Activating SIL mode (= locking)


When SIL mode is activated, all safety-related parameter settings are shown to the operator individually and must be confirmed explicitly. Parameter settings not permitted in the locked SIL mode are reset to their default values where necessary. A SIL locking code is then entered to lock the device software to ensure that parameters cannot be changed. Non-safety-related parameters remain unchanged.

NOTE!

Once the SIL mode has been activated, the process-related parameters are write protected, and thereby locked, for security reasons. It is still possible to read the parameters. When SIL locking is enabled, restrictions apply on all communication options, such as the service interface, the HART protocol and the local display.

Locking procedure:

1. Check preconditions.



A0021062-EN

2. In the **Setup** menu → **Advanced setup** submenu, select the **SIL confirmation** wizard.
3. Select **Set write protection** parameter.

4. Enter the SIL locking code **7452**.

↳ **NOTE!**

The device first checks the preconditions listed under item 1.

If these preconditions are not met, the message **"SIL preparation = failed"** appears on the display along with the parameter that failed to meet the preconditions under 1. The SIL confirmation sequence is not continued.

If the conditions are met, the message **"SIL preparation = finished"** appears on the display.


Once the preconditions have been met, the device automatically switches the following parameters to safety-oriented settings:

NOTE!


If the measuring device has been configured for mass flow, the **Assign current output** parameter in the SIL confirmation sequence is automatically switched to the **Volume flow** option. The **4 mA value** parameter and the **20 mA value** parameter are reset to default values here.

▶ Cancel the SIL confirmation sequence.


▶ Check the settings of the current output and change them if necessary.



A0021070-EN



A0021506-EN



A0021521-EN

NOTE!

The diagnostic behavior is set in such a way that the measuring device is set to the safe state when an error occurs. This means that the diagnostic messages listed in the graphic are set to alarm and the current output adopts the configured failsafe mode → 14.


350: diagnostic message **Pre-amplifier defective**

828: diagnostic message **△S828 Ambient temperature too low**


829: diagnostic message **△S829 Ambient temperature too high**

832: diagnostic message **△S832 Electronic temperature too high**

833: diagnostic message **△S833 Electronic temperature too low**



A0021522-EN




A0021523-EN

To check that values are displayed correctly, the following string appears on the device display or operating tool: **0123456789+-.,.**

5. The user must confirm that the values are displayed correctly.
 - ↳ The device displays the current settings for the following parameters one after another for the user to confirm each of them:

NOTE!

For detailed information on the parameters provided in the following graphic, see the Operating Instructions for the device → 9



6. At the end of the check, the SIL locking code **7452** must be entered again in the **Set write protection** parameter to confirm that all the parameter values have been defined correctly.
 - ↳ If the SIL locking code has been entered correctly, the message **"End of sequence"** appears on the display.

7. Press the key to confirm.

The SIL mode is now activated.

Recommendations:

- Check the position of the hardware write protection switch (dip switch marked "WP 2") on main electronics), and set this switch to **On** if necessary.
- Restart the device on completion of the SIL confirmation sequence.

NOTICE

If the SIL confirmation sequence is aborted before the "End of sequence" message is displayed, the SIL mode is not activated. The safety-oriented parameter settings have been made but SIL locking has not been enabled.

- ▶ Perform SIL mode activation once more.

Deactivating SIL mode (= unlocking)

A device in the locked SIL mode is protected against unauthorized operation by means of a SIL locking code and, where applicable, by means of a user-specific release code and a hardware write protection switch. The device must be unlocked in order to change parameters, for proof-tests as well as to reset self-holding diagnostic messages.

NOTICE

Unlocking the device deactivates diagnostic functions, and the device may not be able to carry out its safety function in the unlocked SIL mode.

- ▶ Therefore, independent measures must be taken to ensure that there is no risk of danger while the SIL mode is deactivated.

Unlocking procedure:

1. Check the position of the hardware write protection switch and set this switch to **Off** if necessary.
2. Enter the user-specific release code if necessary.
3. In the **Setup** menu → **Advanced setup** submenu, select the **Deactivate SIL** wizard.
4. Select **Reset write protection** parameter.
5. Enter the SIL locking code **7452**.
 - ↳ If the SIL locking code has been entered correctly, the message **"End of sequence"** appears on the display.

6. Press the key to confirm.

The SIL mode is now deactivated.

2) Write Protection

Proof-testing

NOTICE

The safety function is not guaranteed during a proof test.

Nevertheless, process safety must be guaranteed during proof testing.

- ▶ The safety-related output signal 4 to 20 mA may not be used for the protection unit.
- ▶ Take alternative monitoring measures if necessary.

Proof testing the safety function of the entire system

1. Check the functional integrity of the safety function at appropriate intervals.
2. The operator specifies the testing interval and this must be taken into account when determining the probability of failure PFD_{avg} of the sensor system.
 - ↳ In the case of a single-channel system architecture, the average probability of failure (PFD_{avg}) of the sensor is derived from the proof-test interval T_i , the failure rate for dangerous undetected failures λ_{du} , the proof test coverage PTC and the assumed mission time by close approximation as follows:

$$PFD_{avg} \approx \lambda_{du} \times (PTC/2 \times T_i + (1 - PTC) / 2 \times MT)$$

A0023571

MT Mission time
PTC Proof test coverage
T_i Test interval


3. The operator also specifies the procedure for proof-testing.

↳ **NOTE!**

In accordance with IEC 61511, as an alternative to testing the safety function of the entire system an independent proof test of the subsystems, → 20 e.g. the sensor, is permitted.

Average probability of failure and useful lifetime

PFD_{avg} for a single-channel system:



A0023404

t Mission time in years
A, B, C Output versions → 11
PFD_{avg} Average probability of dangerous failure on demand
1001 Single-channel architecture

Proof testing the sensor subsystem

If there are no operator-specific requirements for the proof test, the following alternative is available for testing the sensor subsystem³⁾ depending on the measured variable "volume flow" used for the safety function.

Check of the measured value for liquid and gaseous volume flow

3) Under IEC 61508 the sensor is synonymous with the entire flowmeter.

I. Test sequence:

The measured values (3 to 5 measuring points) are checked with a secondary standard on an installed device (mobile calibration rig or calibrated reference device) or on a factory calibration rig following device removal.

The measured values of the secondary standard and the device under test (DUT) are compared using one of the following methods:

a. Comparison by reading off the digital measured value

Compare the digital measured value of the secondary standard against the measured value display of the DUT at the logic subsystem (process control system or safety-related PLC).

b. Comparison of the measured value by measuring the current

1. Measure the current at the DUT using an external, traceably-calibrated ammeter.
 - ↳ Note: measuring equipment requirements:
 - DC current measuring uncertainty $\pm 0.2\%$
 - DC current resolution $10\ \mu\text{A}$
2. Measure the current of the DUT at the logic subsystem (process control system or safety-related PLC).

II. Assessment of the results:

The amount of deviation between the measured flow rate and the set point must not exceed the measured error specified for the safety function.

- ▶ Follow the information in the section on "Restrictions for use in safety-related applications – information on measured errors" →  12.

Other recommendations

It is advisable to perform a visual inspection on site.


- ▶ As part of the visual inspection of the transmitter, ensure that all of the electronics compartment cover seals and cable entries are providing adequate sealing.

NOTICE

At least 98 % of dangerous, undetected failures are detected using these test sequences (PTC = 0.98). The influence of systematic errors on the safety function is not fully covered by the test. Systematic faults can be caused, for example, by medium properties, operating conditions, build-up or corrosion.

- ▶ If one of the test criteria from the test sequences described above is not fulfilled, the device may no longer be used as part of a protective system.
- ▶ Take measures to reduce systematic errors.



For detailed information on the orientation, medium properties and operating conditions, refer to the Operating Instructions for the device →  9

Heartbeat Technology

Heartbeat continuously diagnoses whether failures have occurred. The scope of the diagnostics in the SIL mode corresponds to the SFF.

Heartbeat also allows operators to create documented proof that diagnostic checks have been carried out and thereby supports the documentation of proof testing in accordance with IEC 61511-1, Section 16.3.3, "Documentation of proof testing and inspections".

NOTICE

The SIL mode needs to be disabled temporarily in order to perform heartbeat verification.


- ▶ On completion of the verification, the SIL mode must be enabled again.



The **Heartbeat Verification** application package is available as an order option and can be retrofitted on all measuring devices.

Please contact your Endress+Hauser service or sales organization to retrofit the device.



For detailed information on the verification of the measuring device with **Heartbeat Verification**, refer to the Special Documentation for the device →  9

Life cycle

Requirements for personnel

The personnel for installation, commissioning, diagnostics, repair and maintenance must meet the following requirements:



- Trained, qualified specialists must have a relevant qualification for this specific function and task
- Are authorized by the plant owner/operator
- Are familiar with federal/national regulations
- Before beginning work, the specialist staff must have read and understood the instructions in the manuals and supplementary documentation as well as in the certificates (depending on the application)
- Follow instructions and comply with basic conditions

The operating personnel must meet the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator
- Follow the instructions in this manual

Installation



Installation and electrical connection

 For detailed information about the installation and electrical connection, as well as information about the medium properties, the environment and the process, see the Operating Instructions and Technical Information for the device →  9



Orientation

 For detailed information on the orientation, see the Operating Instructions for the device →  9



Commissioning


 For detailed information on commissioning, see the Operating Instructions for the device →  9

Operation


 For detailed information on operation, see the Operating Instructions for the device →  9



Maintenance

 For detailed information on maintenance, see the Operating Instructions for the device →  9

 Alternative monitoring measures must be taken to ensure process safety during configuration, proof-testing and maintenance work on the device.

Repairs

 Repair means restoring functional integrity by replacing defective components. Components of the same type must be used for this purpose. We recommend documenting the repair. This includes specifying the device serial number, the repair date, the type of repair and the individual who performed the repair.

 For detailed information on device returns, see the Operating Instructions for the device →  9


Replacing device components

The following components may be replaced by the customer's technical staff if genuine spare parts are used and the appropriate installation instructions are followed:

- Calibrated sensor component
- Transmitter without a sensor
- Display module
- Main electronics module
- I/O modules
- Terminals for I/O modules
- Electronics compartment cover
- Seal sets for electronics compartment cover
- Securing clamps for electronics compartment cover
- Pressure compensation vent
- Cable glands

Installation Instructions: see the Download Area at www.endress.com.

The replaced component must be sent to Endress+Hauser for the purpose of fault analysis if the device has been operated in a protective system and a device error cannot be ruled out. In this case,

always enclose the "Declaration of Hazardous Material and Decontamination" with the note "Used as SIL capable device in protection system" when returning the defective device. Please also refer to the "Return" section in the Operating Instructions →  9..

Modification



Modifications are changes to SIL capable devices already delivered or installed.


Modifications to SIL capable devices are usually performed in the Endress+Hauser manufacturing center.

Modifications to SIL capable devices onsite at the user's plant are possible following approval by the Endress+Hauser manufacturing center. In this case, the modifications must be performed and documented by an Endress+Hauser service technician.

Modifications to SIL capable devices by the user are not permitted.

Decommissioning




For detailed information on decommissioning, see the Operating Instructions for the device →  9

Appendix

Structure of the measuring system

System components



A0015443

2 System components

- 1 Pump
- 2 Measuring device
- 3 Valve
- 4 Automation system

An analog signal (4–20 mA) proportional to the volume flow is generated in the transmitter. This is sent to a downstream automation system where it is monitored to determine whether it falls below or exceeds a specified limit value. The safety function (volume flow monitoring) is implemented in this way.

Description of use of protective system

The measuring device can be used in protective systems to monitor the following (Min., Max. and range):
Volume flow


NOTICE

The device must be correctly mounted to guarantee safe operation.

- ▶ Observe the mounting instructions.



For detailed information on mounting, see the Operating Instructions for the device



3 Monitoring options in protective systems

- A Min. alarm
- B Max. alarm
- C Range monitoring

= Safety function is triggered

= Permitted operating status

Verification or calibration

Verification or calibration

The SIL mode must be disabled in order to verify the measuring point with Heartbeat Technology or calibrate the measuring point.

NOTICE

To use the device in a safety function again following a verification or calibration, the configuration of the measuring point must be checked and the SIL mode must be enabled again.

- ▶ Activation of the SIL mode .

Notes on the redundant use of multiple sensors

This section provides additional information regarding the use of homogeneously redundant sensors e.g. 1oo2 or 2oo3 architectures.

The common cause factors β and β_D indicated below are minimum values for the device. These must be used when designing the sensor subsystem:

- Minimum value β for homogeneously redundant use: 2 %
- Minimum value β_D for homogeneously redundant use: 1 %

The device meets the requirements for SIL 3 in homogeneously redundant applications. When installing identical sensors, i.e. the same type and nominal diameter, the sensors must not be connected directly flange to flange but at different locations in the pipe. This is to prevent the sensors from affecting each other acoustically.

NOTICE

Note the following if a fault is detected in one of the redundantly operated devices during the proof test:

- ▶ Check the other devices to see if the same fault occurs there.

Version history

Version	changes	Valid as of firmware version
SD01162D/06/xx/01.13	First version	01.00.zz (HART; from delivery date 10.01.2013)
SD01162D/06/xx/03.15	Firmware	01.02.zz (HART; from delivery date 06.01.2015)

www.addresses.endress.com
