

ProbFit CUA 461 Retractable Assembly for Turbidity Measurement

Operating Instructions









BE0UA461.CHP

Table of contents

1 1.1 1.2	General information. Symbols used. Safety notes.	2
2.1 2.2 2.3 2.4 2.5	Description Areas of application Design of CUA 461 assembly Function Assembly variants Accessories	3 3 4 4
3.1 3.2 3.3 3.4 3.5	Installation Unpacking Dimensions Installation and application notes Installation of turbidity sensor in assembly Rinse ports.	6 6 7 8
4 4.1 4.2 4.3	Operation Moving the sensor into the process space, measurement. Withdrawing the sensor from the ongoing process Calibration	10 10
5.1 5.2 5.3	Maintenance Cleaning of turbidity sensor and assembly Seals and spare parts Repairs	11 11
6 6.1 6.2	Appendix Technical data Index	12

1 General information

1.1 Symbols used



1

Warning:

This symbol alerts to hazards which may cause irreparable damage.



Caution:

This symbol alerts to possible malfunction due to operator error.



Note:

This symbol indicates important items of information.

1.2 Safety notes



Warning:

Operating the assembly in any way other than as intended may compromise the safety and function of the assembly and corresponding measuring system and is therefore impermissible.

This device may only be installed, commissioned, operated and serviced by properly trained specialist personnel authorised by the system operator.

The specialist personnel must be familiar with and adhere to these operating instructions.

ProbFit CUA 461 2 Description

BE2UA461.CHP

2 Description

2.1 Areas of application

The retractable assembly ProbFit CUA 461 is primarily used in the water and sewage treatment areas.

It can be used to install a turbidity sensor CUS 1 or CUS 4 on a pipe or tank in such a manner as to permit sensor checks and cleaning without interrupting the process.

This manually operated assembly permits the sensor to be moved into and withdrawn from the process space under process conditions (up to 2 bar at 20 °C, up to 1 bar at 50 °C). All parts in contact with the medium are made of polypropylene (PP), the seals consist of EPDM or Viton. The process connection is established via a DN 50 DIN flange or a 2" ANSI flange.

2.2 Design of CUA 461 assembly

The following drawing shows the design of the CUA 461 assembly:




Fig. 2.1 Design of assembly ProbFit CUA 461

3


2 Description ProbFit CUA 461

2.3 Function

The sensor guide with the built-in turbidity sensor CUS 1 or CUS 4 is moved into the process space by hand for measurement.


The sensor guide can be withdrawn to the service position without interrupting the process. The interior of the assembly is sealed off from the process by closing the ball valve. The turbidity sensor can then be cleaned, calibrated or replaced.

2.4 Assembly variants



The order code on the rating plate can be used to identify the assembly variant by comparison with the following chart:

Fig. 2.2 Rating plate of CUA 461



ProbFit CUA 461 2 Description

BE2UA461.CHP

2.5 Accessories

Adapter for process connection: Welded fitting for pipe diameters of more than 80 mm, with DN 50 / 2" ANSI combination flange, flange seal, 4 M16x60 screws, 4 M16 nuts and 4 M16 washers

Version	Order number
Special steel 1.4571	50080249
Polyvinyl chloride PVC	50080250
Polypropylene PP	50080251




Fig. 2.3: Process connection adapter for CUA 461

3 Installation ProbFit CUA 461

3 Installation


3.1 Unpacking

- Verify that the contents are undamaged!
 Inform the post office or freight carrier as well as the supplier of any damage.
- Check that the delivery is complete and agrees with the shipping papers and your order.
 - Quantity delivered
 - Assembly type and version according to rating plate (cf. chapter 2.4)
 - Operating instructions
- Accessories (process connection adapter)

• Keep the original packaging materials for future storage or shipping of the assembly.

If you have any questions, consult your supplier or the Endress+Hauser sales agency in your area (see back cover of these operating instructions for addresses).

3.2 Dimensions






Fig. 3.1: Dimensions of ProbFit CUA 461

→ Process connection: DIN flange DN 50 or 2" ANSI

→ Process connection adapter (accessory)

Fig. 3.2 Flange dimensions

ProbFit CUA 461 3 Installation

BE3UA461 CHP

3.3 Installation and application notes

The CUA 461 assembly with the built-in turbidity sensor should preferably be installed in places with uniform flow conditions. The minimum pipe diameter should be DN 80.

Optimal installation conditions can be obtained by using the process connection adapter (see chapter 2.5 'Accessories').



Caution:

Do not install the assembly in places where air may collect, where foam bubbles are likely to form or where constituents may settle.

Inaccurate measurement may result if the sensor is not completely immersed in the medium or if the measuring optics are covered up by deposits.

Align the inclined measuring surface of the turbidity sensor installed in the assembly in the flow direction to obtain optimal measuring results and the desired self-cleaning effect.

Unscrew the upper union of the ball valve housing one quarter turn, align the measuring surface by rotating the guide body, and hand-tighten the union when finished.



Warning:

The sensor must only be aligned when the pipe is empty and unpressurised.

Proper access to the place of installation must be assured. To remove the sensor in its guide, a clearance of at least 650 mm, measured from the lower flange edge, is required. The ball valve locking handle, the locking ring and its handles and the places where the safety ropes are attached must also be easily accessible.

When mounting the assembly, the screws are to be inserted from the flange side towards the assembly. Adequate clearance is required.



Note:

After an appropriate period of time following the initial start-up, the sensor should be checked for soiling and deposits.

The sensor must be removed from the assembly for checks and cleaning. See chapter 5.1 for sensor cleaning.




Fig. 3.3: Recommended mounting positions for ProbFit CUA 461




Fig. 3.4: Insertion of screws for process connection from the flange to the assembly


Endress+Hauser

7

3 Installation ProbFit CUA 461

3.4 Installation of turbidity sensor in assembly

Turbidity sensors CUS 1 or CUS 4 can be installed.



Proceed as follows to install the turbidity sensor in the unmounted assembly:

- → Loosen the knurled screws that are used to attach the safety ropes to the assembly.
- Push the locking ring down slightly by exerting pressure on its two handles and turn clockwise all the way (top view of assembly).
 - Hold the assembly by the process connection flange and pull the sensor guide out all the way by the locking ring handles.
- ⇒ Remove the screws that hold together the two parts of the sensor guide.
 Unscrew the cap from the Pg 29 cable gland and remove the split clamping insert.
- → Insert the sensor cable through the top of the guide and the cable gland from below and screw the sensor into the sensor holding thread. Make sure the O-ring on the sensor is properly seated.
 - Place the two halves of the cable gland clamping insert around the sensor cable and insert in the union. Do not pull the sensor cable tight!
 - Install and tighten the top part of the cable gland.
- ⇒ Screw the bottom of the sensor guide back on. Make sure the O-rings are properly seated.
 - Carefully insert the sensor guide in the assembly and push down approx. 100 mm.
- Reattach the safety ropes with the knurled screws.
 - Close the vent valve before mounting the assembly.

The turbidity sensor is now installed, and the assembly can be mounted.

Fig. 3.5: First installation of turbidity sensor

ProbFit CUA 461 3 Installation

BE3UA461.CHP

3.5 Rinse ports

Remove the blind screw and the vent valve to use the resulting two openings (G 1/8") as rinse ports. These can be used to pass water, cleaning agent or flushing air through the assembly.

4 Operation ProbFit CUA 461

4 Operation

4.1 Moving the sensor into the process space, measurement



Warning:

Make sure that the turbidity sensor has been properly installed before moving the assembly into the process space. Fasten the safety ropes properly and close the vent valve before opening the ball valve.

- To open the ball valve, push down on the locking lever on the ball valve handle.
- Push the sensor guide all the way in by the locking ring handles.
- Push the locking ring down vertically and turn counterclockwise to latch the locking ring in under the locking bolts.

4.2 Withdrawing the sensor from the ongoing process

Withdrawal from the process space

Warning:

Before retracting the assembly, make sure that the safety ropes are properly fastened. When you loosen the locking ring, the

When you loosen the locking ring, the process pressure may push out the sensor guide.

- Push the locking ring down slightly by its two handles and turn clockwise all the way (top view of assembly).
- Pull out the sensor guide until the safety ropes are tight.
- Close the ball valve. It is locked in the closed position.
- Open the vent valve and wait until the overpressure is released, then close the valve once more.

Sensor removal and cleaning

Now you can remove and clean or calibrate the sensor guide and the turbidity sensor as described in chapter 3.4.



Caution:

Flush the assembly with water after sensor guide removal.

Do not allow medium residue, e.g. activated sludge, to dry on the assembly and turbidity sensor.

Dried-up residue may impair the function of the assembly and the sensor and is difficult to remove.

4.3 Calibration

To assure the reliability of the turbidity measurement, the measuring system must be calibrated regularly and carefully. The calibration intervals depend on individual operating conditions and the desired accuracy.

The turbidity sensor must be removed from the assembly for calibration (see chapters 4.2 and 3.4).

Calibrate the sensor as described in the operating instructions for the turbidity sensor.

ProbFit CUA 461 5 Maintenance

BE5UA461 CHP

5 Maintenance

5.1 Cleaning of turbidity sensor and assembly

Deposits on the sensor optics can render the measurement inaccurate. Therefore the sensor must be cleaned at specific time intervals. These intervals depend on each individual system and are to be determined based on operator experience.

Caution:

Do not scratch the optics with sharp objects.

The sensor optics and assembly are to be cleaned with the following agents according to the type of soiling:

- Short-term treatment with a commercially available deliming agent in the case of deposits containing calcium.
- Remove general soiling with water and a brush.
- Oily and greasy soiling can be removed with a cleaning agent based on watersoluble surfactants, e.g. household dish detergents.

5.2 Seals and spare parts

A spare parts kit comprising four O-ring seals and one vent valve is available for the

CUA 461 assembly.

Version	Order number
EPDM	50082663
Viton	50082665
Viton	50082665

To replace the O-ring seals, dismantle the assembly as described in chapters 4.2 and 3.4.

Lubricate the seals and sensor guide with a suitable assembly grease during assembly.

5.3 Repairs

Repairs may be performed at the manufacturer's works or by the Endress+Hauser Service Organization only. Refer to the back cover of these operating instructions for an overview of the Endress+Hauser service network.

6 Appendix ProbFit CUA 461

6 Appendix

6.1 Technical data

Materials in contact with medium O-ring seals in contact with medium Dimensions of O-rings in sensor guide	EPDM / Viton
Dimensions of O-rings in sensor sleeve Locking ring, bolts Safety ropes Process connection Process pressure	special steel 1.4301, tensile strength 200 kp DN 50 DIN flange / 2" ANSI flange
Temperature Rinse ports	max. 50 °C
Sensor moved out Sensor retracted	installation height: 300 mm required clearance above flange: 650 mm

6.2 Index

A		0	
Accessories	5 - 6	O-ring seals	11
Accuracy and reliability	10	Operation	10
Adapter for process connection	5	Optics	11
Alignment of measuring surface	7	Order code	4
Application notes	7	Overpressure	10
Areas of application	3	P	
Assembly variants	4	Packaging materials	6
В		Place of installation	7
Ball valve	10	Pressure	10
C		Process connection adapter	7
Cable gland	8	Process space	10
Calibration	10	R	
Cleaning	7, 11	Rating plate	4
Compressed air		Retraction of sensor	10
Connection	2	Rinse port	ξ
D		S	
Deposits	7, 11	Safety	2
Description of assembly	3 - 5	Safety ropes	3
Design of CUA 461 assembly	3	Scope of delivery	6
Dimensions	6	Sensor guide	8, 10
F		Service	
Function	4	Soiling	7, 1
G		Symbols	2
General information	2	<u>T</u>	
<u>l</u>		Technical data	12
Installation	6 - 9	U	
Installation notes	7	Unpacking	6
Installation of turbidity sensor	8	V	_
K		Vent valve	3
Knurled screws	8	W	_
L	4.0	Welded fitting	5
Locking lever	10		
Locking ring	10		
M	0 11		
Maintenance	2, 11		
Materials	12 7		
Measuring surface			
Mounting clearance	6 10		
Moving sensor into medium	10		

Europe

☐ Endress+Hauser Ges.m.b.H. Wien

Tel. (0222) 88056-0, Fax (0222) 88056-35

Belarus

Belorgsintez

Tel. (0172) 263166, Fax (0172) 263111

Belgium

Endress+Hauser S.A./N.V. Brussels Tel. (02) 248 06 00, Fax (02) 248 05 53

Bulgaria INTERTECH-AUTOMATION Sofia Tel. (02) 65 28 09, Fax (02) 65 28 09

Croatia
☐ Endress+Hauser GmbH+Co. Zagreb Tel. (01) 41 58 12, Fax (01) 44 78 59

Cyprus
I+G Electrical Services Co. Ltd.
Nicosia Tel. (02) 48 47 88, Fax (02) 48 46 90

Czech Republic

☐ Endress+Hauser GmbH+Co. Ostrava Tel. (069) 661 1948, Fax (069) 661 2869

Denmark
☐ Endress+Hauser A/S
Søborg
Tel. (31) 67 31 22, Fax (31) 67 30 45

Estonia

Elvi-Aqua-Teh Tartu Tel. (7) 422726, Fax (7) 422726

Finland

☐ Endress+Hauser Ov Espoo Tel. (90) 8596155, Fax (90) 8596055

France
☐ Endress+Hauser

Tel. (03)89 69 67 68, Fax (03)89 69 48 02

Germany Endress+Hauser Meßtechnik GmbH+Co.

Weil am Rhein Tel. (07621) 975-01, Fax (07621) 975-555

Great Britain

☐ Endress+Hauser Ltd. Manchester Tel. (01 61) 286 50 00, Fax (01 61) 9 98 18 41

I & G Building Services Automation S.A. Tel. (01) 924 15 00, Fax (01) 922 17 14

Hungary Mile Ipari-Elektro Budapest Tel. (01) 261 55 35, Fax (01) 261 55 35

Iceland Vatnshreinsun HF

Reykjavik Tel. (05) 88 96 16, Fax (05) 33 20 22

Flomeaco Company Ltd. Kildare Tel. (045) 868615, Fax (045) 868182

Italy
☐ Endress+Hauser Italia S.p.A. Cernusco s/N Milano Tel. (02) 92 10 64 21, Fax (02) 92 10 71 53

Latvia Raita Ltd.

Riga Tel. (02) 25 47 95, Fax (02) 7 25 89 33

Lithuania Agava Ltd. Kaunas

Tel. (07) 2024 10, Fax (07) 2074 14

Luxembourg
☐ Endress+Hauser S.A./N.V. Tel. (02) 248 06 00, Fax (02) 248 05 53 Netherlands

Endress+Hauser B.V. Naarden Tel. (035) 695 8611, Fax (035) 695 8825

□ Endress+Hauser A/S Tel. (032) 851085, Fax (032) 851112

Poland Endress+Hauser Polska Sp. z o.o.

Tel. (022) 651 01 74. Fax (022) 651 01 78

Portugal Tecnisis - Tecnica de Sistemas Industriais Linda-a-Velha Tel. (01) 4172637, Fax (01) 4185278

Romania

Romconseng SRL Bucharest Tel. (01) 4101634, Fax (01) 4101634

Russia Avtomatika-Sever Ltd. St. Petersburg Tel. (08 12) 5 55 07 00, Fax (08 12) 5 56 1321

Slovak Republic Transcom technik s.r.o

Tel. (7) 521 31 61, Fax (7) 521 31 81

Slovenia

Endress+Hauser D.O.O. Ljubljana Tel. (061) 1592217, Fax (061) 1592298

Spain
☐ Endress+Hauser S.A. Tel. (93) 473 46 44, Fax (93) 473 38 39

Sweden

□ Endress+Hauser AB
Sollentuna Tel. (08) 6261600, Fax (08) 6269477

Switzerland

☐ Endress+Hauser AG
Reinach/BL 1
Tel. (061) 7156222, Fax (061) 7111650

Turkey Intek Endüstriyel Ölcü ve Kontrol Sistemleri Tel. (02 12) 275 13 55, Fax (02 12) 2 66 27 75

Ukraine Industria Ukraïna

Kyiv Tel. (44) 2685213, Fax (44) 2685213

Africa

Tel. (02) 3616117, Fax (02) 3609676

Morocco Oussama S.A.

Casablanca Tel. (02) 24 13 38, Fax (02) 40 56 02

Nigeria
J F Technical Invest. Nig. Ltd. Lagos Tel. (1) 62234546, Fax (1) 62234548

South Africa

Endress+Hauser Pty. Ltd. Tel. (011) 4441386, Fax (011) 4441977

TunisiaControle, Maintenance et Regulation Tel. (01) 79 30 77, Fax (01) 78 85 95

America

Tel. (01) 331 01 68, Fax (01) 334 01 04

Bolivia

Bolivia Tritec S.R.L. Cochabamba Tel. (042) 50981, Fax (042) 50981

Tel. (011) 5363455, Fax (011) 5363457

Canada
□ Endress+Hauser Ltd. Burlington, Ontario Tel. (905) 681 9292, Fax (905) 681 94 44

Chile
DIN Instrumentos Ltda

Santiago Tel. (02) 2 05 01 00, Fax (02) 2 25 81 39

Colombia Colsein Ltd.

Santafe de Bogota D.C. Tel. (01) 2367659, Fax (01) 6107868

Costa Rica EURO-TEC S.A.

Tel. 296 15 42, Fax 2 96 15 42

Ecuador Insetec Cia. Ltda Quito

Tel. (02) 46 18 33, Fax (02) 46 18 33

El Salvador

ACISA San Salvador, C.A. Tel. (02) 84 07 48

ACISA Automatiziacion Y Control Ciudad de Guatemala, C.A. Tel. (02) 327432, Fax (02) 327431

Mexico Maquinaria y Accesorios S.A. de C.V. Mexico D.F Tel. (5) 5638188, Fax (5) 3932937

Paraguay Incoel S.R.L.

Asuncion Tel. (021) 203465, Fax (021) 26583

Lima Tel. (01) 471 4661, Fax (01) 471 09 93

Uruguay Circular S.A.

Tel. (02) 92 57 85, Fax (02) 92 91 51

USA
☐ Endress+Hauser Inc.
Greenwood, Indiana
Tel. (317) 535-7138, Fax (317) 535-1489

Venezuela

H. Z. Instrumentos C.A. Caracas Tel. (02) 9798813, Fax (02) 9799608

Asia

China Endress+Hauser Beijing Beijing Tel. (010) 4072120, Fax (010) 4034536

Hong Kong
☐ Endress+Hauser (H.K.) Ltd. Hong Kong Tel. 25 28 31 20, Fax 28 65 41 71

☐ Endress+Hauser India Branch Office Bombay Tel. (022) 6045578, Fax (022) 6040211

Indonesia PT Grama Bazita Tel. (21) 7975083, Fax (21) 7975089

Japan
☐ Sakura Endress Co., Ltd. Tel. (0422) 540611, Fax (0422) 550275 Malavsia

□ Endress+Hauser (M) Sdn. Bhd.
Petaling Jaya, Selangor Darul Ehsan
Tel. (03) 7 33 48 48, Fax (03) 7 33 88 00

Philippines

Brenton Industries Inc. Tel. (2) 8430661, Fax (2) 8175739

Singapore
Indicate the state of Singapore Tel. 468 82 22. Fax 466 68 48

South Korea Hitrol Co. Ltd. Kyung Gi-Do Tel. (032) 6723131, Fax (32) 6720090

Kingjarl Corporation Taipei R.O.C. Tel. (02) 7 18 39 38, Fax (02) 7 13 41 90

Thailand

Endress+Hauser Ltd.

Bangkok Tel. (2) 2723674, Fax (2) 2723673

Vietnam Tan Viet Bao Co. Ltd. Ho Chi Minh City Tel. (08) 8335225, Fax (08) 8335227

Telephone Technical Services Co. Ltd. Tehran Tel. (021) 8827426, Fax(021) 8827336

Instrumetrics Industrial Control Ltd. Tel. (03) 648 02 05, Fax (03) 647 1992

Jordan A.P. Parpas Engineering S.A. Tel. (06) 83 92 83, Fax (06) 83 92 05

Kingdom of Saudi Arabia Intrah

Dammam Tel. (03) 8347879, Fax (03) 8344832 Kuwait Kuwait Maritime & Mercantile Co. K.S.C.

Safat Tel. 2434752, Fax 2441486

Lebanon Network Engineering Co. Jbeil Tel. (3) 25 40 52, Fax (9) 94 40 80

Sultanate of Oman Mustafa&Jawad Sience&Industry Co. L.L.C. Ruwi Tel. 60 20 09, Fax 60 70 66

United Arab Emirates Descon Trading EST. Dubai Tel. (04) 35 95 22, Fax (04) 35 96 17

Yemen Company for Ghee and Soap Industry Taiz Tel. (04) 23 06 65, Fax (04) 21 23 38

Australia + New Zealand

Australia GEC Alsthom LTD.

Sydney Tel. (02) 645 07 77, Fax (02) 743 70 35

New Zealand EMC Industrial Instrumentation Auckland Tel. (09) 444 92 29, Fax (09) 444 11 45

All other countries

□ Endress+Hauser GmbH+Co. Instruments International Weil am Rhein Tel. (07621) 975-02, Fax (07621) 975345

☐ Members of the Endress+Hauser group



50076561

