

# Installation Instructions

## Spare parts

### FMA90 Housing front + display

## 1 Overview of spare part sets

The Installation Instructions apply to the following spare part sets:

Order number	Original spare parts set	Contents
71706846	Housing front + display	1x Housing front + display 1x Installation Instruction

## 2 Intended use

- A defective unit can only be replaced with a functioning unit of the same type.
- Use only original parts from Endress+Hauser.

## 3 Personnel authorized to carry out repairs

Authorization to carry out repairs depends on the measuring device's approval type. The table below shows the authorized group of people in each case.



Whoever carries out the repairs has full responsibility to ensure that work is carried out safely and to the required quality standard. He/she must also guarantee the safety of the device following repair.

Measuring device approval	Personnel authorized to carry out repairs <sup>1)</sup>
Without approval	1, 2, 3
With approval (e.g. IECEx)	1, 2, 3
For custody transfer	4

1) 1 = Qualified specialist on customer side,

2 = Service technician authorized by Endress+Hauser,

3 = Endress+Hauser (return measuring device to manufacturer)

4 = Check with local approval center if installation/conversion must be performed under upervision.




## 4 Safety instructions

- The spare part set and the Installation Instructions are used to replace a defective unit with a functioning unit of the same type.
  - Only use original parts from Endress+Hauser.
- Comply with national regulations regarding mounting, electrical installation, commissioning, maintenance and repair.
- The following requirements must be met with regard to specialized technical staff for the mounting, electrical installation, commissioning, maintenance and repair of the measuring devices:
  - Specialized technical staff must be trained in instrument safety.
  - They must be familiar with the individual operating conditions of the devices.
  - In the case of Ex-certified measuring devices, they must also be trained in explosion protection.
- The measuring device is energized! Risk of fatal injury from electric shock. Open the measuring device only when the device is de-energized.
- For measuring devices intended for use in hazardous locations, please observe the guidelines in the Ex documentation (XA).
- For measuring devices in safety-related applications in accordance with IEC 61508 or IEC 61511: following repair, re-commission the device in accordance with the Operating Instructions. Document the repair.
- Before removing the device: set the process to a safe state and purge the pipe of dangerous process substances.
- Danger of burns due to heated surfaces! Before commencing work: allow the system and measuring device to cool down to a touchable temperature.
- In the case of devices in custody transfer, the custody transfer status no longer applies once the seal has been removed.
- The Operating Instructions for the device must be followed.
- Risk of damaging the electronic components! Ensure you have a working environment protected from electrostatic discharge.
- After removing the electronics compartment cover: risk of electrical shock due to missing touch protection! Turn the measuring device off before removing internal covers.
- Modifications to the measuring device are not permitted.
- Only open the housing for a brief period. Avoid foreign objects, moisture or dirt entering the housing.
- Replace defective seals only with original seals from Endress+Hauser.
- If threads are defective the measuring device must be repaired.
- If, during repair work, spacing is reduced or the dielectric strength of the measuring device cannot be guaranteed, perform a test on completion of the work (e.g. high-voltage test in accordance with the manufacturer's instructions).
- Service plug:
  - Do not connect in potentially explosive atmospheres.
  - Only connect to Endress+Hauser service devices.



Contact Endress+Hauser Service if you have questions: [www.addresses.endress.com](http://www.addresses.endress.com)


# 5 Symbols used

Symbol	Meaning
	<b>Permitted</b> Procedures, processes or actions that are permitted.
	<b>Forbidden</b> Procedures, processes or actions that are forbidden.
	<b>Tip</b> Indicates additional information.
1., 2., 3....	Series of steps

# 6 Tool list

Only one TX20 is required

# 7 Replacing the Housing front + display of the FMA90



## Procedure:

1. **Remove the front cover**

Unscrew the four Torx screws located on the front of the device (4e).

2. **Ensure the device is voltage-free**

Disconnect the device from the power supply and verify that there is no residual voltage.

3. **Remove the cover**

Carefully lift the locking tab of the cover (4d) with your fingers. Slowly tilt the cover (4c) backward, taking care to gently guide the flat ribbon cable (4a) out of the guide rail (4f).

4. **Remove the front housing**

Press the locking tabs of the lower housing section (4g) together and pull the front section completely upward.

5. **Disconnect the flat ribbon cable from the CPU board**

Gently release the locking mechanism of the connector (see Detail 1) using a fingernail.

**⚠ Caution:** Pay attention to the ribbon cable connected to the CPU board. (4b).

6. **Remove the CPU board**

Gently press the two lower retaining tabs of the CPU board holder to the side. Slightly lift the CPU board and remove it for installation in the new front housing.

7. **Install the CPU board in the new front housing**

Mount the CPU board into the new front housing.

8. **Reassemble the device**

Reassemble the device in reverse order.

9. **Recommission the device**

Reconnect the device to the power supply and put it back into operation.

## 8 Disposal



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

[www.addresses.endress.com](http://www.addresses.endress.com)