# Technical Information **RMA42**

## Process transmitter with control unit



# 4-wire process transmitter with control unit as DIN rail device with up to two universal sensor inputs and optional SIL approval

#### Application

- Plant and apparatus engineering
- Control rooms and cabinets
- Process recording and monitoring
- Process control
- Signal adjustment and conversion
- WHG-compliant limit signal transmitter

#### Your benefits

- 5-digit, 7-segment backlit LC display
- User-configurable dot matrix display range for bar graph, units and tag name
- 1 or 2 universal inputs
- 2 relays (optional)
- Min./max. value saved
- 1 or 2 calculated values
- One linearization table with 32 points for each calculated value
- 1 or 2 analog outputs
- Digital status output (open collector)
- Operation using 3 keys
- Configuration via interface and FieldCare or DeviceCare software



# Table of contents

J J	<b>3</b> 3 3 3
Measured variable	<b>4</b> 4 4 4 4
Output	<b>5</b> 5 5 5 5
Terminal assignment	<b>6</b> 6 6 6
Performance characteristics	<b>7</b> 7 7
Mounting location	<b>8</b> 8 8
Ambient temperature range	<b>8</b> 8 9 9 9 9 9 9 9 9
Mechanical construction	<b>9</b> 9 9 9
On-site operation       1         Local display       1	LO LO LO
Certificates and approvals 1	.1

Ordering information	11
Accessories	11
Documentation	12

## Measuring principle Analog in 2 Analog in 1 -88888 向向向 ü A001176 • 1 Example of a "differential pressure" application The RMA42 process transmitter powers the transmitter and processes analog signals from transmitters, particularly from the area of process instrumentation. These signals are monitored, evaluated, calculated, saved, separated, linked, converted and displayed. The signals and results of calculations are communicated by analog means, as a switch output and displayed digitally. Measuring system The RMA42 is a process transmitter that is controlled by a microcontroller and features a display, analog inputs for process and status signals, analog and digital outputs, as well as a configuration interface. Connected sensors (e.g. temperature, pressure) can be powered by the integrated transmitter power supply system. These signals are monitored, evaluated, calculated, saved (min/max values) and provided at the various outputs. All measured values, and values calculated in any way, are available as a signal source for the display, all outputs, relays and the interface. It is possible to make multiple use of the signals and results (e.g. a signal source as an analog output signal and limit value for a relay). **Mathematics functions** The following mathematics functions are available in the RMA42: Sum Difference Multiplication Mean value Linearization Linearization function Up to 32 user-definable points are available in the device per calculated value to linearize the input, e.q. for tank linearization. With the two-channel device (option), the mathematics channel M2 can be used to linearize mathematics channel M1.

## Function and system design

Linearization is also available in the FieldCare configuration software.

Measured variable	Current, voltage, resistance, resistance thermometer, thermocouples
Measuring range	Current: • 0/4 to 20 mA +10% overrange • Short-circuit current: max. 150 mA • Load: 10 Ω
	Voltage: • 0 to 10 V, 2 to 10 V, 0 to 5 V, 0 to 1 V, 1 to 5 V, $\pm 1$ V, $\pm 10$ V, $\pm 30$ V, $\pm 100$ mV • Max. permitted input voltage: Voltage $\geq 1$ V: $\pm 35$ V Voltage $< 1$ V: $\pm 12$ V • Input impedance: $> 1000$ k $\Omega$
	Resistance: 30 to $3000 \Omega$
	RTD assembly: Pt100 as per IEC60751, GOST, JIS1604 Pt500 and Pt1000 as per IEC60751 Cu100, Cu50, Pt50, Pt46, Cu53 as per GOST Ni100, Ni1000 as per DIN 43760
	Thermocouple types: • Type J, K, T, N, B, S, R as per IEC60584 • Type U as per DIN 43710 • Type L as per DIN 43710, GOST • Type C, D as per ASTM E998
Number of inputs	One or two universal inputs
Measuring cycle	200 ms
Galvanic isolation	Towards all other circuits


# Input

# Output

Output signal	Output signal         One or two analog outputs, galvanically isolated		
	Current/voltage output		
	Current output: • 0/4 to 20 mA • Overrange up to 22 mA		
	Voltage: • 0 to 10 V, 2 to 10 V, 0 to 5 V, 1 to 5 V • Overrange: up to 11 V, short-circuit proof, I <sub>max</sub> < 25 mA		
	HART <sup>®</sup>		
	HART <sup>®</sup> signals are not affected		
Loop power supply	<ul> <li>Open-circuit voltage: 24 V<sub>DC</sub> (+15% /-5%)</li> <li>Hazardous area version: &gt; 14 V at 22 mA</li> <li>Non-hazardous area version without SIL: &gt; 16 V at 22 mA</li> <li>Non-hazardous area version with SIL: &gt; 14 V at 22 mA</li> <li>Maximum 30 mA short-circuit-proof and overload-resistant</li> <li>Galvanically isolated from system and outputs</li> </ul>		
Switching output	Open collector for monitoring the device state as well as open circuit and alarm notification. The C output is closed in the fault-free operating state. In error state, the OC output is opened.		
	<ul> <li>I<sub>max</sub> = 200 mA</li> <li>U<sub>max</sub> = 28 V</li> <li>U<sub>on/max</sub> = 2 V at 200 mA</li> </ul>		
	Galvanic isolation to all circuits, test v	oltage 500 V	
Relay output Relay output for limit monitoring			
	Relay contact	Change-over contact	
	Maximum contact load DC	30 V / 3 A (permanent state, without destruction of the input)	
	Maximum contact load AC	250 V / 3 A (permanent state, without destruction of the input)	
	Minimum contact load	500 mW (12 V/10 mA)	
	Galv. isolation towards all other circuits	Test voltage 1500 V <sub>AC</sub>	
	Switching cycles	> 1 million	

## Power supply

Terminal assignment



■ 2 Terminal assignment of the process transmitter (relay (terminals Rx1-Rx3) and channel 2 (terminals 21-28 and 025/026) optional). Note: Illustrated contact position of the relays if the power supply fails.

Supply voltage	Wide range power supply 24 to 230 V AC/DC (-20 % / +10 %) 50/60 Hz
Power consumption	Max. 21.5 VA / 6.9 W
Interface connection data	Commubox FXA291 PC USB interface
	<ul> <li>Connection: 4-pin socket</li> <li>Transmission protocol: FieldCare</li> <li>Transmission rate: 38,400 baud</li> </ul>
	Interface cable TXU10-AC PC USB interface
	<ul> <li>Connection: 4-pin socket</li> <li>Transmission protocol: FieldCare</li> <li>Order configuration: interface cable with FieldCare Device Setup DVD incl. all Comm DTMs and</li> </ul>

Device DTMs

# Performance characteristics

Reference operating	Power supply: 230 V <sub>AC</sub> , 50/60 Hz
conditions	Ambient temperature: 25 °C (77 °F) $\pm$ 5 °C (9 °F)
	Humidity: 20 %60 % rel. humidity

Maximum measured error Universal input:

Accuracy	Input:	Range:	Maximum measured error of measuring range (oMR):
	Current	0 to 20 mA, 0 to 5 mA, 4 to 20 mA; Overrange: up to 22 mA	±0.05%
	Voltage ≥ 1 V	0 to 10 V, 2 to 10 V, 0 to 5 V, 1 to 5 V, 0 to 1 V, ±1 V, ±10 V, ±30 V	±0.1%
	Voltage < 1 V	±100 mV	±0.05%
	Resistance measurement	30 to 3 000 Ω	4-wire: ± (0.10% oMR + 0.8 Ω) 3-wire: ± (0.10% oMR + 1.6 Ω) 2-wire: ± (0.10% oMR + 3 Ω)
	RTD	$\begin{array}{c} \mbox{Pt100, -200 to 850 °C (-328 to 1562 °F)} \\ (IEC60751, a=0.00385) \\ \mbox{Pt100, -200 to 850 °C (-328 to 1562 °F)} \\ (JIS1604, w=1.391) \\ \mbox{Pt100, -200 to 649 °C (-328 to 1200 °F) (GOST, a=0.003916)} \\ \mbox{Pt500, -200 to 850 °C (-328 to 1562 °F)} \\ (IEC60751, a=0.00385) \\ \mbox{Pt1000, -200 to 600 °C (-328 to 1112 °F)} \\ (IEC60751, a=0.00385) \\ \end{array}$	4-wire: ± (0.10% oMR + 0.3 K (0.54 °F)) 3-wire: ± (0.10% oMR + 0.8 K (1.44 °F)) 2-wire: ± (0.10% oMR + 1.5 K (2.7 °F))
		$\begin{array}{c} Cu100, -200 to 200 °C (-328 to 392 °F) (GOST, $$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$$	4-wire: ± (0.10% oMR + 0.3 K (0.54 °F)) 3-wire: ± (0.10% oMR + 0.8 K (1.44 °F)) 2-wire: ± (0.10% oMR + 1.5 K (2.7 °F))
		Cu53, -50 to 200 °C (-58 to 392 °F) (GOST, w=1.426)	4-wire: ± (0.10% oMR + 0.3 K (0.54 °F)) 3-wire: ± (0.10% oMR + 0.8 K (1.44 °F)) 2-wire: ± (0.10% oMR + 1.5 K (2.7 °F))
	Thermocouples	Typ J (Fe-CuNi), -210 to 1 200 °C (-346 to 2 192 °F) (IEC60584)	± (0.10% oMR +0.5 K (0.9 °F)) from -100 °C (-148 °F)
		Typ K (NiCr-Ni), -200 to 1 372 °C (-328 to 2 502 °F) (IEC60584)	± (0.10% oMR +0.5 K (0.9 °F)) from -130 °C (-202 °F)
		Typ T (Cu-CuNi), -270 to 400 °C (-454 to 752 °F) (IEC60584)	± (0.10% oMR +0.5 K (0.9 °F)) from −200 °C (−328 °F)
		Typ N (NiCrSi-NiSi), –270 to 1 300 °C (–454 to 2 372 °F) (IEC60584)	± (0.10% oMR +0.5 K (0.9 °F)) from −100 °C (−148 °F)
		Typ L (Fe-CuNi), −200 to 900 °C (−328 to 1652 °F) (DIN43710, GOST)	± (0.10% oMR +0.5 K (0.9 °F)) from −100 °C (−148 °F)
		Typ D (W3Re/W25Re), 0 to 2 495 °C (32 to 4 523 °F)(ASTME998)	± (0.15% oMR +1.5 K (2.7 °F)) from 500 °C (932 °F)
		Typ C (W5Re/W26Re), 0 to 2 320 °C (32 to 4 208 °F) (ASTME998)	± (0.15% oMR +1.5 K (2.7 °F)) from 500 °C (932 °F)

Accuracy	Input:	Range:	Maximum measured error of measuring range (oMR):
		Typ B (Pt30Rh-Pt6Rh), 0 to 1 820 °C (32 to 3 308 °F) (IEC60584)	± (0.15% oMR +1.5 K (2.7 °F)) from 600 °C (1112 °F)
		Typ S (Pt10Rh-Pt), −50 to 1768 °C (−58 to 3214 °F) (IEC60584)	± (0.15% oMR +3.5 K (6.3 °F)) for -50 to 100 °C (-58 to 212 °F) ± (0.15% oMR +1.5 K (2.7 °F)) from 100 °C (212 °F)
		Typ U (Cu-CuNi), -200 to 600 °C (-328 to 1112 °F) (DIN 43710)	± (0.15% oMR +1.5 K (2.7 °F)) from 100 °C (212 °F)
AD converter resolu	tion	16 bit	
Temperature drift		Temperature drift: ≤ 0.01%/K (0.1%/18 °F) oMR ≤ 0.02%/ K (0.2%/18 °F) oMR for Cu100, Cu50, Cu53, Pt50 and Pt46	

### Analog output:

Current	0/4 to 20 mA, overrange up to 22 mA	±0.05% of measuring range
	Max. load	500 Ω
	Max. inductivity	10 mH
	Max. capacity	10 µF
	Max. ripple	10 mVpp at 500 Ω, frequency < 50 kHz
Voltage	0 to 10 V, 2 to 10 V 0 to 5 V, 1 to 5 V Overrange: up to 11 V, shortcircuit proof, I <sub>max</sub> < 25 mA	±0.05% of measuring range ±0.1 % of measuring range
	Max. ripple	10 mVpp at 1000 $\Omega$ , frequency < 50 kHz
Resolution	13 bit	
Temperature drift	$\leq$ 0.01%/K (0.1%/18 °F) of measuring range	
Galvanic isolation	Testing voltage of 500 V towards all other circuits	


## Installation

Mounting location	Mounting on top-hat rail as per IEC 60715.	
Orientation	Vertical or horizontal.	
	NOTICE Heat accumulation when installing several devices on a vertically mounted top-hat rail Keep sufficient gaps between the individual devices.	
	Environment	
Ambient temperature range	NOTICEThe life-time of the display is shortened when operated in the upper temperature range.► To avoid heat accumulation, always make sure the device is sufficiently cooled.	
	Non-Ex/Ex devices: –20 to 60 °C (–4 to 140 °F)	

UL devices: -20 to 50 °C (-4 to 122 °F)

Altitude	< 2 000 m (6 560 ft) above MSL
Climate class	As per IEC 60654-1, Class B2
Degree of protection	DIN rail housing IP 20
Electrical safety	Protection class II, overvoltage category II, pollution degree 2
Condensation	Not permitted
Electromagnetic compatibility (EMC)	CE compliance
	Electromagnetic compatibility in accordance with all the relevant requirements of the IEC/EN 61326 series and NAMUR Recommendation EMC (NE21). For details refer to the EU Declaration of Conformity.
	<ul> <li>Maximum measured error &lt; 1% of measuring range</li> <li>Interference immunity as per IEC/EN 61326 series, industrial requirements</li> <li>Interference emission as per IEC/EN 61326 series (CISPR 11) Group 1 Class A</li> </ul>
	This unit is not intended for use in residential environments and cannot guarantee adequate protection of the radio reception in such environments.

## Mechanical construction



Weight	Approximately 300 g (10.6 oz)
Material	Housing: plastic PC-GF10
Terminals	Screw terminals, plug-in, 2.5 mm <sup>2</sup> (14 AWG), 0.1 to 4 mm <sup>2</sup> (30 to 12 AWG), torque 0.5 to 0.6 Nm (0.37 to 0.44 lbf ft)

## Operability

#### **On-site** operation





Image: Book and Operating elements of the process transmitter

#### 1 HART<sup>®</sup> connection sockets

- 2 Display
- 3 Operating keys
- 4 PC interface connection socket
- 5 Green LED; on = supply voltage applied
- 6 Red LED; on = fault/alarm
- 7 Yellow LED; on = relay 1 energized
- 8 Yellow LED; on = relay 2 energized



#### ■ 5 Display of the process transmitter

- 1 Channel indicator: 1: analog input 1; 2: analog input 2; 1M: calculated value 1; 2M: calculated value 2
- 2 Measured value display
- 3 Dot matrix display for TAG, bar graph, unit
- 4 Limit value indicators in the bar graph
- 5 "Operation locked" indicator
- 6 Minimum/maximum value indicator

#### Local display

- Display
   5-digit, 7-segment backlit LC display
   Dot matrix for text/bar graph
- Display area
- -99999 to +99999 for measured values
- Signaling
  - Setup security locking (lock)
  - Measuring range overshoot/undershoot
  - 2 x status relay (only if the relay option was selected)

#### **Operating elements**

3 keys: -, +, E

# Remote operation Configuration The device can be configured with the FieldCare PC software. FieldCare Device Setup is included in the Commubox FXA291 and TXU10-AC scope of delivery (see 'Accessories') or can be downloaded free of charge at www.endress.com.

#### Interface

4-pin socket for the connection with a PC via Commubox FXA291 and TXU10-AC interface cable (see 'Accessories').

## **Certificates and approvals**

Current certificates and approvals for the product are available at <a href="www.endress.com">www.endress.com</a> on the relevant product page:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select **Downloads**.

## **Ordering information**

Detailed ordering information is available from your nearest sales organization www.addresses.endress.com or in the Product Configurator at www.endress.com:

1. Select the product using the filters and search field.

- 2. Open the product page.
- 3. Select **Configuration**.

Product Configurator - the tool for individual product configuration

- Up-to-the-minute configuration data
  - Depending on the device: direct input of information specific to the measuring point, such as the measuring range or operating language
  - Automatic verification of exclusion criteria
  - Automatic creation of the order code and its breakdown in PDF or Excel output format
  - Ability to order directly in the Endress+Hauser Online Shop

### Accessories

The accessories currently available for the product can be selected at www.endress.com:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select Spare parts & Accessories.

Communication-specific accessories	Commubox FXA291	
	Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.	
	For more information, please refer to: <a href="https://www.endress.com">www.endress.com</a> Configuration kit TXU10	
	For more information, please refer to: www.endress.com	
	Online tools	Product information over the entire life cycle of the device: www.endress.com/onlinetools

## Documentation

The following types of documentation are available on the product pages and in the Download Area of the Endress+Hauser website (www.endress.com/downloads) (depending on the selected device version):

Document	Purpose and content of the document
Technical Information (TI)	<b>Planning aid for your device</b> The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions (KA)	<b>Guide that takes you quickly to the 1st measured value</b> The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.
Operating Instructions (BA)	<b>Your reference document</b> These Operating Instructions contain all the information that is required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.
Description of Device Parameters (GP)	<b>Reference for your parameters</b> The document provides a detailed explanation of each individual parameter. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.
Safety Instructions (XA)	Safety Instructions (XA) are supplied with the device, depending on the approval. These are an integral part of the Operating Instructions.  The nameplate indicates which Safety Instructions (XA) apply to the device.
Supplementary device-dependent documentation (SD/FY)	Always comply strictly with the instructions in the relevant supplementary documentation. The supplementary documentation is an integral part of the device documentation.



### www.addresses.endress.com

