# Technical Information **Proline Prowirl D 200**

Vortex flowmeter



## Cost-effective wafer flowmeter, available as compact or remote version

#### Application

- Preferred measuring principle for wet steam/saturated steam, superheated steam, gases & liquid (including cryogenic applications)
- For all basic applications and the replacement of orifice plates on a one-for-one basis

#### Device properties

- Installed length of 65 mm (2.56 in)
- No flanges
- Lightweight unit
- Display module with data transfer function
- Robust dual-compartment housing
- Plant safety: worldwide approvals (SIL, Haz. area)

#### Your benefits

- Integrated temperature measurement for mass flow/energy flow of saturated steam
- Easy sensor alignment centering rings supplied
- High availability proven resistance to vibrations, thermal shocks and pressure shocks
- Long-term stability robust, drift-free capacitance sensor
   Convenient wiring separate connection compartment, various Ethernet options
- Safe operation no need to open the device thanks to display with touch control, background lighting
- Built-in verification Heartbeat Technology



## Table of contents

About this document	<b>4</b> 4
Function and system design         Measuring principle         Measuring system	<b>5</b> 8
Input	8 9 14 14
OutputOutput signalSignal on alarmEx connection data	<b>15</b> 17 19 20 26 26 26
Power supply Terminal assignment . Pin assignment, device plug . Supply voltage . Power consumption . Current consumption . Power supply failure . Electrical connection . Potential equalization . Terminals . Cable entries . Cable specification . Overvoltage protection .	29 32 33 34 34 35 38 38 38 38 38 38 38
Performance characteristics	<b>39</b> 39 42 42 42
Installation         Mounting location         Orientation         Inlet and outlet runs         Inlet and outlet runs         Mounting set for disc (wafer version)         Length of connecting cable         Mounting the transmitter housing         Installation for delta heat measurements         Protective cover         Environment         Ambient temperature range         Storage temperature         Climate class	<b>43</b> 43 43 43 45 46 47 47 <b>48</b> 48 48 48

Degree of protection	49
Vibration-resistance and shock resistance	49
Electromagnetic compatibility (EMC)	49
Process	49
Medium temperature range	49
Pressure/temperature ratings	50
Nominal prossure of consor	51
Thermal ingulation	51
	21
Mechanical construction	51
Dimensions in SI units	51
Dimensions in US units	58
Weight	62
Materials	65
Onershilitz	60
	00
Operating concept	68
Languages	68
Onsite operation	68
Remote operation	69
Service interface	71
Supported operating tools	72
Certificates and approvals	73
CF mark	73
UKCA marking	73
RCM marking	73
	73
Europhic and solution	72
Functional Safety	כו אד
EQUIDATION Fieldbug contification	74
	74
	74
PROFINE1 over Ethernet-APL certification	/4
Pressure Equipment Directive	74
Experience	74
External standards and guidelines	75
Ordering information	75
Product generation index	75
	70
Application packages	/6
Diagnostic functionality	76
Heartbeat Technology	76
Accessories	76
Device-specific accessories	77
Communication-specific accessories	78
Service-specific accessories	79
System components	80
- ,	20
De sum entetien	00
	80
Standard documentation	80
Supplementary device-dependent documentation	81

## About this document

#### Symbols

#### Electrical symbols

Symbol	Meaning
	Direct current
$\sim$	Alternating current
$\sim$	Direct current and alternating current
÷	<b>Ground connection</b> A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	<b>Potential equalization connection (PE: Protective earth)</b> Ground terminals that must be connected to ground prior to establishing any other connections.
	<ul><li>The ground terminals are located on the interior and exterior of the device:</li><li>Interior ground terminal: potential equalization connection is connected to the supply network.</li><li>Exterior ground terminal: device is connected to the plant grounding system.</li></ul>

#### Communication-specific symbols

Symbol	Meaning
((1-	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
*	Bluetooth Wireless data transmission between devices over a short distance via radio technology.

#### Symbols for certain types of information

Symbol	Meaning
	<b>Permitted</b> Procedures, processes or actions that are permitted.
	<b>Preferred</b> Procedures, processes or actions that are preferred.
×	<b>Forbidden</b> Procedures, processes or actions that are forbidden.
i	<b>Tip</b> Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Visual inspection

#### Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps

Symbol	Meaning
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area
×	Safe area (non-hazardous area)
≈ <b>→</b>	Flow direction

### Function and system design

#### Measuring principle

Vortex meters work on the principle of the *Karman vortex street*. When fluid flows past a bluff body, vortices are alternately formed on both sides with opposite directions of rotation. These vortices each generate a local low pressure. The pressure fluctuations are recorded by the sensor and converted to electrical pulses. The vortices develop very regularly within the permitted application limits of the device. Therefore, the frequency of vortex shedding is proportional to the volume flow.



The calibration factor (K-factor) is used as the proportional constant:

K-Factor = -

Pulses Unit Volume [m<sup>3</sup>]

A0003939-EN

Within the application limits of the device, the K-factor only depends on the geometry of the device. For Re  $> 20\,000$  it is:

• Independent of the flow velocity and the fluid properties viscosity and density

Independent of the type of substance under measurement: steam, gas or liquid

The primary measuring signal is linear to the flow. After production, the K-factor is determined in the factory by means of calibration. It is not subject to long-time drift or zero-point drift.

The device does not contain any moving parts and does not require any maintenance.

#### The capacitance sensor

The sensor of a vortex flowmeter has a major influence on the performance, robustness and reliability of the entire measuring system.

The robust DSC sensor is:

- burst-tested
- tested against vibrations
- tested against thermal shock (thermal shocks of 150 K/s)

The measuring device uses the tried-and-tested, capacitance measuring technology from Endress+Hauser, which is already in use in over 450 000 measuring points worldwide. Thanks to its design, the capacitance sensor is also particularly mechanically resistant to temperature shocks and pressure shocks in steam pipelines.

#### Temperature measurement

The "mass" option is available under the order code for "Sensor version". With this option the measuring device can also measure the temperature of the medium.

The temperature is measured via Pt 1000 temperature sensors. These are located in the paddle of the DSC sensor and are therefore in the direct vicinity of the fluid.

Order code for "Sensor version; DSC sensor; measuring tube":

- Option AA "volume; 316L; 316L"
- Option BA "volume high-temperature; 316L; 316L"
- Option CA "Mass; 316L; 316L (integrated temperature measurement)"



- 1 Order code for "Sensor version", option "volume" or "volume high-temperature"
- 2 Order code for "Sensor version", option "mass"

#### Lifelong calibration

Experience has shown that recalibrated measuring devices demonstrate a very high degree of stability compared to their original calibration: The recalibration values were all within the original measuring accuracy specifications of the devices. This applies to the measured volume flow, the device's primary measured variable.

Various tests and simulation have shown that once the radii of the edges on the bluff body are less than 1 mm (0.04 in), the resulting effect does not have a negative impact on accuracy.

If the radii of the edges on the bluff body do not exceed 1 mm (0.04 in), the following general statements apply (in the case of non-abrasive and non-corrosive media, such as in most water and steam applications):

- The measuring device does not display an offset in the calibration and the accuracy is still guaranteed.
- All the edges on the bluff body have a radius that is typically smaller in size. As the measuring devices are naturally also calibrated with these radii, the measuring device remains within the specified accuracy rating provided that the additional radius that is produced as a result of wear and tear does not exceed 1 mm (0.04 in).

Consequently, it can be said that the product line offers lifelong calibration if the measuring device is used in non-abrasive and non-corrosive media.

#### Air and industrial gases

The measuring device enables users to calculate the density and energy of air and industrial gases. The calculations are based on time-tested standard calculation methods. It is possible to automatically compensate for the effect of pressure and temperature via an external or constant value. This makes it possible to output the energy flow, standard volume flow and mass flow of the following gases:

- Single gas
- Gas mixture
- Air
- User-specific gas

For detailed information on the parameters, see the Operating Instructions.→ 🗎 80

#### Natural gas

The device enables users to calculate the chemical properties (gross calorific value, net calorific value) of natural gases. The calculations are based on time-tested standard calculation methods. It is possible to automatically compensate for the effect of pressure and temperature via an external or constant value.

This makes it possible to output the energy flow, standard volume flow and mass flow in accordance with the following standard methods:

Energy can be calculated based on the following standards:

- AGA5
- ISO 6976
- GPA 2172

Density can be calculated based on the following standards:

- ISO 12213-2 (AGA8-DC92)
- ISO 12213-3
- AGA NX19
- AGA8 Gross 1
- SGERG 88

For detailed information on the parameters, see the Operating Instructions.  $\rightarrow$  🗎 80

#### Measuring system

The device consists of a transmitter and a sensor.

- Two device versions are available:
- Compact version transmitter and sensor form a mechanical unit.
- Remote version transmitter and sensor are mounted in separate locations.

#### Transmitter



#### Sensor



## Input

Measured variable

Direct measured variables

Order code for "Sensor version; DSC sensor; measuring tube"				
Option	Description	Measured variable		
AA	Volume; 316L; 316L	Volume flow		
BA	Volume high-temperature; 316L; 316L			

Order code for "Sensor version; DSC sensor; measuring tube"			
Option	Description	Measured variable	
CA	Mass; 316L; 316L (integrated temperature measurement)	<ul><li>Volume flow</li><li>Temperature</li></ul>	

#### **Calculated measured variables**

Order code for "Sensor version; DSC sensor; measuring tube"				
Description	Measured variable			
Volume; 316L; 316L	Under constant process conditions:			
Volume high-temperature; 316L; 316L	<ul> <li>Mass flow <sup>1</sup>/</li> <li>Corrected volume flow</li> </ul>			
	The totalized values for: • Volume flow • Mass flow • Corrected volume flow			
	Description         Volume; 316L; 316L         Volume high-temperature; 316L; 316L			

Ordon	anda	fon "Con	aon man	aiom. T	NCC 001		o o uning	tubal
Unner	COLLE	TOP SPH	SOF VED	STOTE 1	JAL SPI	ISOF THE	asurunn	IIIDe.

1) A fixed density must be entered for calculating the mass flow (Setup menu  $\rightarrow$  Advanced setup submenu  $\rightarrow$  External compensation submenu  $\rightarrow$  Fixed density parameter).

Order code for "Sensor version; DSC sensor; measuring tube"				
Option	Description	Measured variable		
CA	Mass; 316L; 316L (integrated temperature measurement)	<ul> <li>Corrected volume flow</li> <li>Mass flow</li> <li>Calculated saturated steam pressure</li> <li>Energy flow</li> <li>Heat flow difference</li> <li>Specific volume</li> <li>Degrees of superheat</li> </ul>		

Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Description	Measured variable
AA	Volume; 316L; 316L	Under constant process conditions:
AB	Volume; Alloy C22; 316L	<ul> <li>Mass flow</li> <li>Corrected volume flow</li> </ul>
AC	Volume; Alloy C22; Alloy C22	The totalized values for:
BA	Volume high-temperature; 316L; 316L	<ul> <li>Volume flow</li> <li>Mass flow</li> </ul>
BB	Volume high-temperature; Alloy C22; 316L	<ul> <li>Corrected volume flow</li> </ul>

A fixed density must be entered for calculating the mass flow (Setup menu → Advanced setup submenu → External compensation submenu → Fixed density parameter).

Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Description	Measured variable
CA	Mass; 316L; 316L (integrated temperature measurement)	<ul> <li>Corrected volume flow</li> </ul>
СВ	Mass; Alloy C22; 316L (integrated temperature measurement)	<ul> <li>Mass flow</li> <li>Calculated saturated steam pressure</li> <li>Energy flow</li> </ul>
CC	Mass; Alloy C22; Alloy C22 (integrated temperature measurement)	<ul> <li>Heat flow difference</li> <li>Specific volume</li> <li>Degrees of superheat</li> </ul>
DA	Mass steam; 316L; 316L (integrated pressure/temperature measurement)	- Degrees of superinear
DB	Mass gas/liquid; 316L; 316L (integrated pressure/ temperature measurement)	

#### Measuring range

The measuring range is dependent on the nominal diameter, the fluid and environmental influences.

The following specified values are the largest possible flow measuring ranges ( $Q_{min}$  to  $Q_{max}$ ) for each nominal diameter. Depending on the fluid properties and environmental influences, the measuring range may be subject to additional restrictions. Additional restrictions apply to both the lower range value and the upper range value.

#### Flow measuring ranges in SI units

DN [mm]	Liquids [m <sup>3</sup> /h]	Gas/steam [m³/h]
15	0.06 to 4.9	0.3 to 25
25	0.18 to 15	0.9 to 125
40	0.45 to 37	2.3 to 308
50	0.75 to 62	3.8 to 821
80	1.7 to 138	8.5 to 1843
100	2.9 to 239	15 to 3 192
150	6.7 to 545	33 to 7262

Flow measuring ranges in US units

DN	Liquids	Gas/steam
[in]	[ft³/min]	[ft³/min]
1/2	0.035 to 2.9	0.18 to 15
1	0.11 to 8.8	0.54 to 74
11/2	0.27 to 22	1.3 to 181
2	0.44 to 36	2.2 to 483
3	1 to 81	5 to 1085
4	1.7 to 140	8.7 to 1879
6	3.9 to 320	20 to 4272

#### Flow velocity



 $D_i$  Internal diameter of measuring tube (corresponds to dimension  $K \rightarrow \square 51$ )

v Velocity in mating pipe

Q Flow

The internal diameter of measuring tube  $D_i$  is denoted in the dimensions as dimension  $K \rightarrow \cong 51$ .

Calculation of flow velocity:

$$v [m/s] = \frac{4 \cdot Q [m^3/h]}{\pi \cdot D_i [m]^2} \cdot \frac{1}{3600 [s/h]}$$
$$v [ft/s] = \frac{4 \cdot Q [ft^3/min]}{\pi \cdot D_i [ft]^2} \cdot \frac{1}{60 [s/min]}$$

A0034301

#### Lower range value

#### Reynolds number

A restriction applies to the lower range value due to the turbulent flow profile, which only occurs with Reynolds numbers greater than 5 000. The Reynolds number is dimensionless and indicates the ratio of the inertia force of a fluid to its viscous force when flowing and is used as a characteristic variable for pipe flows. In the case of pipe flows with Reynolds numbers less than 5 000, periodic vortices are no longer generated and flow rate measurement is no longer possible.

The Reynolds number is calculated as follows:

$$Re = \frac{4 \cdot Q [m^3/s] \cdot \rho [kg/m^3]}{\pi \cdot D_i [m] \cdot \mu [Pa \cdot s]}$$
$$Re = \frac{4 \cdot Q [ft^3/s] \cdot \rho [lbm/ft^3]}{\pi \cdot D_i [ft] \cdot \mu [lbf \cdot s/ft^2]}$$

- Re Reynolds number
- Q Flow
- $D_i$  Internal diameter of measuring tube (corresponds to dimension  $K \rightarrow \square 51$ )
- μ Dynamic viscosity
- ρ Density

The Reynolds number 5 000, together with the density and viscosity of the fluid and the nominal diameter, is used to calculate the corresponding flow rate.

$$Q_{Re=5000} [m^{3}/h] = \frac{5000 \cdot \pi \cdot D_{i} [m] \cdot \mu [Pa \cdot s]}{4 \cdot \rho [kg/m^{3}]} \cdot 3600 [s/h]$$

$$Q_{Re=5000} [ft^{3}/h] = \frac{5000 \cdot \pi \cdot D_{i} [ft] \cdot \mu [lbf \cdot s/ft^{2}]}{4 \cdot \rho [lbm/ft^{3}]} \cdot 60 [s/min]$$

 $Q_{Re=5000}$  Flow rate is dependent on the Reynolds number

 $D_i$  Internal diameter of measuring tube (corresponds to dimension  $K \rightarrow \square 51$ )

μ Dynamic viscosity

ρ Density

Minimum measurable flow velocity based on signal amplitude

The measuring signal must have a certain minimum signal amplitude so that the signals can be evaluated without any errors. Using the nominal diameter, the corresponding flow can also be derived from this amplitude.

The minimum signal amplitude depends on the setting for the sensitivity of the DSC sensor, the steam quality  $\mathbf{x}$  and the force of the vibrations present  $\mathbf{a}$ .

The value  $\mathbf{mf}$  corresponds to the lowest measurable flow velocity without vibration (no wet steam) for a density of 1 kg/m<sup>3</sup> (0.0624 lbm/ft^3).

The value **mf** can be set in the range of 20 to 6 m/s (6 to 1.8 ft/s) (factory setting 12 m/s (3.7 ft/s)) with the **Sensitivity** parameter (value range 1 to 9, factory setting 5).



v <sub>AmpMin</sub>	Minimum measurable flow velocity based on signal amplitude
mf	Sensitivity
х	Steam quality
ρ	Density

Minimum measurable flow rate based on signal amplitude

$$Q_{AmpMin} [m^{3}/h] = \frac{v_{AmpMin} [m/s] \cdot \pi \cdot (D_{i} [m])^{2}}{4} \cdot 3600 [s/h]$$
$$Q_{AmpMin} [ft^{3}/min] = \frac{v_{AmpMin} [ft/s] \cdot \pi \cdot (D_{i} [ft])^{2}}{4} \cdot 60 [s/min]$$

<i>Q<sub>AmpMin</sub></i>	Minimum measurable flow rate based on signal amplitude
V <sub>AmpMin</sub>	Minimum measurable flow velocity based on signal amplitude
D <sub>i</sub>	Internal diameter of measuring tube (corresponds to dimension K $\rightarrow \implies 51$ )
ρ	Density

#### Effective lower range value

The effective lower range value  $Q_{Low}$  is determined using the largest of the three values  $Q_{min},\,Q_{Re}$  =  $_{5000}$  and  $Q_{AmpMin}.$ 

$$\begin{aligned} Q_{Low} [m^{3}/h] &= max \begin{cases} Q_{min} [m^{3}/h] \\ Q_{Re=5000} [m^{3}/h] \\ Q_{AmpMin} [m^{3}/h] \end{cases} \\ \\ Q_{Low} [ft^{3}/min] &= max \end{cases} \begin{cases} Q_{min} [ft^{3}/min] \\ Q_{Re=5000} [ft^{3}/min] \\ Q_{AmpMin} [ft^{3}/min] \end{cases} \end{aligned}$$

A0034304

 Q<sub>Low</sub>
 Effective lower range value

 Q<sub>min</sub>
 Minimum measurable flow rate

 Q<sub>Re = 5000</sub>
 Flow rate is dependent on the Reynolds number

 Q<sub>AmpMin</sub>
 Minimum measurable flow rate based on signal amplitude

The Applicator is available for calculation purposes.

#### Upper range value

Maximum measurable flow rate based on signal amplitude

The measuring signal amplitude must be below a certain limit value to ensure that the signals can be evaluated without error. This results in a maximum permitted flow rate  $Q_{AmpMax}$ .



 $Q_{AmpMax}$  Maximum measurable flow rate based on signal amplitude

 $D_i$  Internal diameter of measuring tube (corresponds to dimension  $K \rightarrow \square 51$ )

#### ρ Density

URV Limit value for determining the maximum flow rate:

- DN 15 to 40: URV = 350
- DN 50 to 300: URV = 600
- NPS ½ to 1½: URV = 1148
- NPS 2 to 12: URV = 1969

Restricted upper range value is dependent on Mach number

For gas applications, an additional restriction applies to the upper range value with regard to the Mach number in the measuring instrument, which must be less than 0.3. The Mach number Ma describes the ratio of the flow velocity v to the sound velocity c in the fluid.

$Ma = \frac{v [m/s]}{c [m/s]}$	
$Ma = \frac{v [ft/s]}{c [ft/s]}$	
	A0034321

- Ma Mach number
- v Flow velocity
- c Speed of sound

The corresponding flow rate can be derived using the nominal diameter.

$$Q_{Ma=0.3} [m^{3}/h] = \frac{0.3 \cdot c [m/s] \cdot \pi \cdot D_{i} [m]^{2}}{4} \cdot 3600 [s/h]$$
$$Q_{Ma=0.3} [ft^{3}/min] = \frac{0.3 \cdot c [ft/s] \cdot \pi \cdot D_{i} [ft]^{2}}{4} \cdot 60 [s/min]$$

 $Q_{Ma=0.3}$  Restricted upper range value is dependent on Mach number

 $D_i$  Internal diameter of measuring tube (corresponds to dimension  $K \rightarrow \square 51$ )

ρ Density

Effective upper range value

The effective upper range value  $Q_{High}$  is determined using the smallest of the three values  $Q_{max}$ ,  $Q_{AmpMax}$  and  $Q_{Ma=0.3}.$ 

$Q_{High} [m^{3}/h] = min \begin{cases} Q_{max} [m^{3}/h] \\ Q_{AmpMax} [m^{3}/h] \\ Q_{Ma=0.3} [m^{3}/h] \end{cases}$
$Q_{High} [ft^3/min] = min \begin{cases} Q_{max} [ft^3/min] \\ Q_{AmpMax} [ft^3/min] \\ Q_{Ma=0.3} [ft^3/min] \end{cases}$
A00343

Q <sub>High</sub> Effective upper range value	1
---	---

*Q<sub>max</sub>* Maximum measurable flow rate

 $Q_{AmpMax}$  Maximum measurable flow rate based on signal amplitude

 $Q_{Ma=0.3}$  Restricted upper range value is dependent on Mach number

For liquids, the occurrence of cavitation may also restrict the upper range value.



#### Operable flow range

The value, which is typically up to 49: 1, may vary depending on the operating conditions (ratio between upper range value and lower range value)

Input signal

Current input

Current input	4-20 mA (passive)
Resolution	1 μΑ
Voltage drop	Typically: 2.2 to 3 V for 3.6 to 22 mA
Maximum voltage	≤ 35 V
Possible input variables	<ul><li>Pressure</li><li>Temperature</li><li>Density</li></ul>

#### External measured values

To increase the measurement accuracy of certain measured variables or to calculate the corrected volume flow, the automation system can continuously write different measured values to the measuring instrument:

- Operating pressure to increase measurement accuracy (Endress+Hauser recommends the use of a pressure measuring instrument for absolute pressure, e.g. Cerabar M or Cerabar S)
- Medium temperature to increase measurement accuracy (e.g. iTEMP)
- Reference density for calculating the corrected volume flow



Various pressure measuring devices can be ordered as accessories from Endress+Hauser.If using pressure measuring devices, pay attention to outlet runs when installing external

devices  $\rightarrow \cong 45$ . If the device does not have temperature compensation, it is recommended that external pressure measurement values be read in so that the following measured variables can be calculated:

- Energy flow
- Mass flow
- Corrected volume flow

#### Current input

The measured values are written from the automation system to the measuring device via the current input  $\Rightarrow \cong 14$ .

#### HART protocol

The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions:

- HART protocol
- Burst mode

#### Digital communication

The measured values can be written from the automation system to the measuring via:

- FOUNDATION Fieldbus
- PROFIBUS PA
- PROFINET over Ethernet-APL

## Output

#### **Output signal**

#### **Current output**

Current output 1	4-20 mA HART (passive)
Current output 2	4-20 mA (passive)
Resolution	< 1 µA
Damping	Configurable: 0.0 to 999.9 s
Assignable measured variables	<ul> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Mass flow</li> <li>Flow velocity</li> <li>Temperature</li> <li>Pressure</li> <li>Calculated saturated steam pressure</li> <li>Total mass flow</li> <li>Energy flow</li> <li>Heat flow difference</li> </ul>

#### Pulse/frequency/switch output

Function	Can be configured as pulse, frequency or switch output
Version	Passive, open collector

Maximum input values	<ul> <li>DC 35 V</li> <li>50 mA</li> <li>For information on the Ex connection values →  <sup>(1)</sup> 20</li> </ul>
Voltage drop	<ul> <li>For ≤ 2 mA: 2 V</li> <li>For 10 mA ⋅ 8 V</li> </ul>
Residual current	≤ 0.05 mA
Pulse output	
Pulse width	Configurable: 5 to 2 000 ms
Maximum pulse rate	100 Impulse/s
Pulse value	Configurable
Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Total mass flow</li> <li>Energy flow</li> <li>Heat flow difference</li> </ul>
Frequency output	
Output frequency	Configurable: 0 to 1000 Hz
Damping	Configurable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	<ul> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Mass flow</li> <li>Flow velocity</li> <li>Temperature</li> <li>Calculated saturated steam pressure</li> <li>Total mass flow</li> <li>Energy flow</li> <li>Heat flow difference</li> <li>Pressure</li> </ul>
Switch output	
Switching behavior	Binary, conductive or non-conductive
Switching delay	Configurable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit value <ul> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Mass flow</li> <li>Flow velocity</li> <li>Temperature</li> <li>Calculated saturated steam pressure</li> <li>Total mass flow</li> <li>Energy flow</li> <li>Heat flow difference</li> <li>Pressure</li> <li>Reynolds number</li> <li>Totalizer 1-3</li> </ul> </li> <li>Status</li> <li>Status of low flow cut off</li> </ul>

#### FOUNDATION Fieldbus

FOUNDATION Fieldbus	H1, IEC 61158-2, galvanically isolated
Data transfer	31.25 kbit/s
Current consumption	15 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

#### PROFIBUS PA

PROFIBUS PA	In accordance with EN 50170 Volume 2, IEC 61158-2 (MBP), galvanically isolated
Data transmission	31.25 kbit/s
Current consumption	16 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

#### **PROFINET** over Ethernet-APL

Device use	<ul> <li>Device connection to an APL field switch The device may only be operated according to the following APL port classifications: <ul> <li>If used in hazardous areas: SLAA or SLAC<sup>1)</sup></li> <li>If used in non-hazardous areas: SLAX</li> <li>Connection values of APL field switch (corresponds to APL port classification SPCC or SPAA): <ul> <li>Maximum input voltage: 15 V<sub>DC</sub></li> <li>Minimum output values: 0.54 W</li> </ul> Device connection to an SPE switch If used in non-hazardous areas: suitable SPE switch</li></ul></li></ul>
	<ul> <li>SPE switch prerequisite:</li> <li>Support of 10BASE-T1L standard</li> <li>Support of PoDL power class 10, 11 or 12</li> <li>Detection of SPE field devices without integrated PoDL module</li> </ul>
	Connection values of SPE switch: • Maximum input voltage: 30 V <sub>DC</sub> • Minimum output values: 1.85 W
PROFINET	According to IEC 61158 and IEC 61784
Ethernet-APL	According to IEEE 802.3cg, APL port profile specification v1.0, galvanically isolated
Data transfer	10 Mbit/s Full-duplex
Current consumption	Transmitter
	Max. 55.56 mA
Permitted supply voltage	<ul> <li>Ex: 9 to 15 V</li> <li>Non-Ex: 9 to 30 V</li> </ul>
Network connection	With integrated reverse polarity protection

1) For more information on using the device in the hazardous area, see the Ex-specific Safety Instructions

Signal on alarm

Depending on the interface, failure information is displayed as follows:

#### HART current output

Device diagnostics
--------------------

Г

Device condition can be read out via HART Command 48

#### **Current output**

Current output 4-20 mA

Failure mode	Choose from: 4 to 20 mA in accordance with NAMUR recommendation NE 43 4 to 20 mA in accordance with US Min. value: 3.59 mA Max. value: 22.5 mA Definable value between: 3.59 to 22.5 mA Actual value Last valid value
--------------	--

#### Pulse/frequency/switch output

Pulse output	
Failure mode	No pulses
Frequency output	
Failure mode	Choose from: • Actual value • 0 Hz • Definable value between: 0 to 1250 Hz
Switch output	
Failure mode	Choose from: • Current status • Open • Closed

#### FOUNDATION Fieldbus

Status and alarm messages	Diagnostics in accordance with FF-891
Failure current FDE (Fault Disconnection Electronic)	0 mA

#### PROFIBUS PA

Status and alarm messages	Diagnostics in accordance with PROFIBUS PA Profile 3.02
Failure current FDE (Fault Disconnection Electronic)	0 mA

#### **PROFINET** over Ethernet-APL

Device diagnostics	Diagnostics according to PROFINET PA Profile 4.02
--------------------	---

#### Local display

Plain text display	With information on cause and remedial measures
Backlight	Additionally for device version with SD03 local display: red lighting indicates a device error.



Status signal as per NAMUR recommendation NE 107

#### Interface/protocol

- Via digital communication:
  - HART protocol
  - FOUNDATION Fieldbus
  - PROFIBUS PA
- PROFINET over Ethernet-APL
- Via service interface

Endress+Hauser CDI service interface (Common Data Interface)

Plain text display	With information on cause and remedial measures
--------------------	---

Additional information on remote operation  $\rightarrow \square 69$ 

#### Light emitting diodes (LED)

The LEDs are only available for PROFINET over Ethernet-APL.

Status information	Status indicated by various light emitting diodes
	<ul> <li>The following information is displayed depending on the device version:</li> <li>Supply voltage active</li> <li>Data transmission active</li> <li>Network available</li> <li>Connection established</li> <li>PROFINET blinking feature <sup>1)</sup></li> </ul>

1) Only available for PROFINET over Ethernet-APL

Load

Load for current output: 0 to 500  $\Omega,$  depending on the external supply voltage of the power supply unit

#### Calculation of the maximum load

Depending on the supply voltage of the power supply unit  $(U_S)$ , the maximum load  $(R_B)$  including line resistance must be observed to ensure adequate terminal voltage at the device. In doing so, observe the minimum terminal voltage

- $R_B \le (U_S U_{term. min}): 0.022 \text{ A}$
- $R_B \le 500 \Omega$



E 2 Load for a compact version without local operation

1 Operating range

- 1.1 For order code for "Output", option A "4-20 mA HART"/option B "4-20 mA HART, pulse/frequency/switch output" with Ex i and option C "4-20 mA HART + 4-20 mA analog"
- 1.2 For order code for "Output", option A "4-20 mA HART"/option B "4-20 mA HART, pulse/frequency/switch output" for non-hazardous area and Ex d

#### Sample calculation

Supply voltage of power supply unit: •  $U_S = 19 \text{ V}$ 

- $U_{term. min} = 12 \text{ V}$  (measuring device) + 1 V (local operation without lighting) = 13 V Maximum load:  $R_B \le$  (19 V - 13 V): 0.022 A = 273  $\Omega$
- The minimum terminal voltage (U  $_{\rm Kl\,min}$  ) increases if local operation is used.. H

#### Ex connection data

#### Safety-related values

Ex d type of protection

Order code for "Output"	Output type	Safety-related values
Option A	4-20mA HART	U <sub>nom</sub> = DC 35 V U <sub>max</sub> = 250 V
Option B	4-20mA HART	U <sub>nom</sub> = DC 35 V U <sub>max</sub> = 250 V
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1)}$
Option C	4-20mA HART	U <sub>nom</sub> = DC 30 V
	4-20mA analog	U <sub>max</sub> = 250 V
Option D	4-20mA HART	U <sub>nom</sub> = DC 35 V U <sub>max</sub> = 250 V
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$
	4 to 20 mA current input	U <sub>nom</sub> = DC 35 V U <sub>max</sub> = 250 V
Option E	FOUNDATION Fieldbus	$U_{nom} = DC 32 V$ $U_{max} = 250 V$ $P_{max} = 0.88 W$
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$
Option G	PROFIBUS PA	$U_{nom} = DC 32 V$ $U_{max} = 250 V$ $P_{max} = 0.88 W$
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$
Option S	PROFINET over Ethernet-APL/SPE, 10Mbit/s	$U_{nom} = DC 17.5 V$ $U_{max} = 250 V$ $P_{nom} = 0.9 W$

1) Internal circuit limited by  $R_i$  = 760.5  $\Omega$ 

#### Type of protection Ex ec

Order code for "Output"	Output type	Safety-related values
Option A	4-20mA HART	$U_{nom} = DC 35 V$ $U_{max} = 250 V$
Option B	4-20mA HART	$U_{nom} = DC 35 V$ $U_{max} = 250 V$

Order code for "Output"	Output type	Safety-related values
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$
Option C	4-20mA HART	U <sub>nom</sub> = DC 30 V
	4-20mA analog	U <sub>max</sub> = 250 V
Option D	4-20mA HART	$U_{nom} = DC 35 V$ $U_{max} = 250 V$
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$
	4 to 20 mA current input	$U_{nom} = DC 35 V$ $U_{max} = 250 V$
Option E	FOUNDATION Fieldbus	$U_{nom} = DC 32 V$ $U_{max} = 250 V$ $P_{max} = 0.88 W$
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$
Option G	PROFIBUS PA	$U_{nom} = DC 32 V$ $U_{max} = 250 V$ $P_{max} = 0.88 W$
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$
Option S <sup>2)</sup>	PROFINET over Ethernet-APL/SPE, 10Mbit/s	2-WISE power load, APL port profile SLAX $U_{nom} = DC 17.5 V$ $U_{max} = 250 V$ $P_{nom} = 0.9 W$

1) Internal circuit limited by  $R_i$  = 760.5  $\Omega$ 

For installation in systems that are restricted to safe extra-low voltages such as SELV, PELV or ES1. Only one wire is permitted per terminal.

Type of protection XP

Order code for "Output"	Output type	Safety-related values
Option A	4-20mA HART	U <sub>nom</sub> = DC 35 V U <sub>max</sub> = 250 V
Option B	4-20mA HART	$U_{nom} = DC 35 V$ $U_{max} = 250 V$
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$
Option C	4-20mA HART	U <sub>nom</sub> = DC 30 V
	4-20mA analog	U <sub>max</sub> = 250 V
Option D	4-20mA HART	U <sub>nom</sub> = DC 35 V U <sub>max</sub> = 250 V
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$
	4 to 20 mA current input	U <sub>nom</sub> = DC 35 V U <sub>max</sub> = 250 V
Option E	FOUNDATION Fieldbus	$U_{nom} = DC 32 V$ $U_{max} = 250 V$ $P_{max} = 0.88 W$

Order code for "Output"	Output type	Safety-related values
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1)}$
Option G	PROFIBUS PA	$U_{nom} = DC 32 V$ $U_{max} = 250 V$ $P_{max} = 0.88 W$
	Pulse/frequency/switch output	$\begin{split} U_{nom} &= DC \ 35 \ V \\ U_{max} &= 250 \ V \\ P_{max} &= 1 \ W^{1)} \end{split}$

1) Internal circuit limited by  $R_i = 760.5 \ \Omega$ 

#### Intrinsically safe values

Ex ia type of protection

Order code for "Output"	Output type	Intrinsically safe values	
Option A	4-20mA HART	$ \begin{array}{l} U_{i} = DC \; 30 \; V \\ I_{i} = \; 300 \; mA \\ P_{i} = \; 1 \; W \\ L_{i} = \; 0 \; \mu H \\ C_{i} = \; 5 \; nF \end{array} $	
Option B	4-20mA HART	$ \begin{array}{l} U_{i} = DC \; 30 \; V \\ I_{i} = \; 300 \; mA \\ P_{i} = \; 1 \; W \\ L_{i} = \; 0 \; \mu H \\ C_{i} = \; 5 \; nF \end{array} $	
	Pulse/frequency/switch output	$\begin{array}{l} U_{i} = DC \; 30 \; V \\ I_{i} = \; 300 \; mA \\ P_{i} = \; 1 \; W \\ L_{i} = \; 0 \; \mu H \\ C_{i} = \; 6 \; nF \end{array}$	
Option C	4-20mA HART	$U_i = DC 30 V$	
	4-20mA analog	$ \begin{array}{l} \hline P_i = 300 \text{ mA} \\ P_i = 1 \text{ W} \\ L_i = 0 \ \mu\text{H} \\ C_i = 30 \ n\text{F} \end{array} $	
Option D	4-20mA HART	$\begin{array}{l} U_{i} = DC \; 30 \; V \\ I_{i} = \; 300 \; mA \\ P_{i} = \; 1 \; W \\ L_{i} = \; 0 \; \mu H \\ C_{i} = \; 5 \; nF \end{array}$	
	Pulse/frequency/switch output	$ \begin{array}{l} U_i = DC \; 30 \; V \\ I_i = \; 300 \; mA \\ P_i = \; 1 \; W \\ L_i = \; 0 \; \mu H \\ C_i = \; 6 \; nF \end{array} $	
	4 to 20 mA current input	$\begin{array}{l} U_{i} = DC \; 30 \; V \\ I_{i} = \; 300 \; mA \\ P_{i} = \; 1 \; W \\ L_{i} = \; 0 \; \mu H \\ C_{i} = \; 5 \; nF \end{array}$	
Option E	FOUNDATION Fieldbus	$ \begin{array}{ll} \mbox{STANDARD} & \mbox{FISCO} \\ U_i = 30 \ V & U_i = 17.5 \ V \\ l_i = 300 \ mA & l_i = 550 \ mA \\ P_i = 1.2 \ W & P_i = 5.5 \ W \\ L_i = 10 \ \mu H & L_i = 10 \ \mu H \\ C_i = 5 \ nF & C_i = 5 \ nF \end{array} $	

Order code for "Output"	Output type	Intrinsically safe values	
	Pulse/frequency/switch output	$ \begin{array}{l} U_i = 30 \ V \\ l_i = 300 \ mA \\ P_i = 1 \ W \\ L_i = 0 \ \mu H \\ C_i = 6 \ nF \end{array} $	
Option G	PROFIBUS PA	$\begin{array}{ll} \text{STANDARD} & \text{FISCO} \\ U_i = 30 \ V & U_i = 17.5 \ V \\ l_i = 300 \ \text{mA} & l_i = 550 \ \text{mA} \\ P_i = 1.2 \ W & P_i = 5.5 \ W \\ L_i = 10 \ \mu\text{H} & L_i = 10 \ \mu\text{H} \\ C_i = 5 \ \text{nF} & C_i = 5 \ \text{nF} \end{array}$	
	Pulse/frequency/switch output		
Option S	PROFINET over Ethernet-APL/SPE, 10Mbit/s	$\begin{array}{l} \mbox{2-WISE power load, APL port} \\ \mbox{profile SLAA}^{1)} \\ \hline \mbox{Ex ia} \\ U_i = 17.5 \ V \\ l_i = 380 \ mA \\ P_i = 5.32 \ W \\ L_i = negligible \\ C_i = 1 \ nF \\ \hline \mbox{Cable requirements as per 2-} \\ \hline \mbox{WISE:} \\ R_c = 15 \ to \ 150 \ \Omega/km \\ L_c = 0.4 \ to \ 1 \ mH/km \\ C_c = 45 \ to \ 200 \ nF/km \\ C_c = 45 \ to \ 200 \ nF/km \\ C_c = C_c \ conductor/conductor + 0.5 \\ C_c \ conductor/shield \ if \ both \\ conductors \ are \ potential-free; \ or \\ C_c = C_c \ conductor/conductor + C_c \\ conductor/shield \ if \ the \ shielding \ is \\ connected \ to \ a \ conductor \\ \ Length \ of \ cable \ (not \ including \ cable \\ stubs): \le 200 \ m \ (656.2) \\ \ Length \ of \ cable \ stubs: \le 1 \ m \ (3.3 \ ft) \end{array}$	

1) Für weitere Optionen siehe Ethernet-APL Installation Drawing HE\_01622.

#### Type of protection Ex ic

Order code for "Output"	Output type	Intrinsically safe values
Option A	4-20mA HART	$ \begin{array}{l} U_i = DC \ 35 \ V \\ I_i = n.a. \\ P_i = 1 \ W \\ L_i = 0 \ \mu H \\ C_i = 5 \ nF \end{array} $
Option B	4-20mA HART	$\begin{array}{l} U_{i} = DC \ 35 \ V \\ I_{i} = n.a. \\ P_{i} = 1 \ W \\ L_{i} = 0 \ \mu H \\ C_{i} = 5 \ nF \end{array}$
	Pulse/frequency/switch output	$\begin{array}{l} U_{i} = DC \ 35 \ V \\ I_{i} = n.a. \\ P_{i} = 1 \ W \\ L_{i} = 0 \ \mu H \\ C_{i} = 6 \ nF \end{array}$

Order code for "Output"	Output type	Intrinsically safe values	
Option C	4-20mA HART 4-20mA analog	$\begin{array}{l} U_{i} = DC \; 30 \; V \\ I_{i} = n.a. \\ P_{i} = 1 \; W \\ L_{i} = 0 \; \mu H \\ C_{i} = 30 \; nF \end{array}$	
Option D	4-20mA HART	$\begin{array}{l} U_{i} = DC \; 35 \; V \\ I_{i} = n.a. \\ P_{i} = 1 \; W \\ L_{i} = 0 \; \mu H \\ C_{i} = 5 \; nF \end{array}$	
	Pulse/frequency/switch output	$\begin{array}{l} U_{i} = DC \; 35 \; V \\ I_{i} = n.a. \\ P_{i} = 1 \; W \\ L_{i} = 0 \; \mu H \\ C_{i} = 6 \; nF \end{array}$	
	4 to 20 mA current input	$\begin{array}{l} U_i = DC \; 35 \; V \\ I_i = n.a. \\ P_i = 1 \; W \\ L_i = 0 \; \mu H \\ C_i = 5 \; nF \end{array}$	
Option E	FOUNDATION Fieldbus	$\begin{array}{llllllllllllllllllllllllllllllllllll$	
	Pulse/frequency/switch output	$\begin{array}{l} U_{i} = 35 \ V \\ l_{i} = 300 \ mA \\ P_{i} = 1 \ W \\ L_{i} = 0 \ \mu H \\ C_{i} = 6 \ nF \end{array}$	

Order code for "Output"	Output type	Intrinsically safe values	
Option G	PROFIBUS PA	$STANDARD \\ U_i = 32 V \\ l_i = 300 mA \\ P_i = n.a. \\ L_i = 10 \mu H \\ C_i = 5 nF$	FISCO $U_i = 17.5 V$ $l_i = n.a.$ $P_i = n.a.$ $L_i = 10 \mu H$ $C_i = 5 nF$
	Pulse/frequency/switch output	$ \begin{array}{l} U_{i} = 35 \ V \\ l_{i} = 300 \ mA \\ P_{i} = 1 \ W \\ L_{i} = 0 \ \mu H \\ C_{i} = 6 \ nF \end{array} $	
Option S	PROFINET over Ethernet-APL/SPE, 10Mbit/s	$\begin{array}{l} L_i = 0 \ \mu H \\ C_i = 6 \ nF \end{array} \\ \hline \begin{array}{l} \textbf{2-WISE power load, APL port} \\ \textbf{profile SLAC}^{1)} \\ \textbf{Ex ic} \\ U_i = 17.5 \ V \\ I_i = 380 \ mA \\ P_i = 5.32 \ W \\ L_i = negligible \\ C_i = 1 \ nF \end{array} \\ \hline \begin{array}{l} \textbf{Cable requirements as per 2-} \\ \textbf{WISE:} \\ R_c = 15 \ to \ 150 \ \Omega/km \\ L_c = 0.4 \ to \ 1 \ mH/km \\ C_c = 45 \ to \ 200 \ nF/km \\ C_c = 45 \ to \ 200 \ nF/km \\ C_c = C_c \ conductor/conductor + 0.5 \\ C_c \ conductor/shield \ if \ both \\ conductors \ are \ potential-free; \ or \\ C_c = C_c \ conductor/conductor + C_c \\ conductor/shield \ if \ the \ shielding \ is \\ connected \ to \ a \ conductor \\ Length \ of \ cable \ (not \ including \ cable \ stubs): \le 200 \ m \ (656.2) \end{array} $	

1) Für weitere Optionen siehe Ethernet-APL Installation Drawing HE\_01622.

#### IS type of protection

Order code for "Output"	Output type	Intrinsically safe values	
Option A	4-20mA HART	$\begin{array}{l} U_i = DC \; 30 \; V \\ I_i = 300 \; mA \\ P_i = 1 \; W \\ L_i = 0 \; \mu H \\ C_i = 5 \; nF \end{array}$	
Option B	4-20mA HART	$\begin{array}{l} U_i = DC \; 30 \; V \\ I_i = 300 \; mA \\ P_i = 1 \; W \\ L_i = 0 \; \mu H \\ C_i = 5 \; nF \end{array}$	
	Pulse/frequency/switch output	$ \begin{array}{l} U_i = DC \; 30 \; V \\ I_i = \; 300 \; mA \\ P_i = \; 1 \; W \\ L_i = \; 0 \; \mu H \\ C_i = \; 6 \; nF \end{array} $	
Option C	4-20mA HART	$U_i = DC 30 V$	
	4-20mA analog	$ \begin{aligned} & I_i = 300 \text{ mA} \\ & P_i = 1 \text{ W} \\ & L_i = 0 \ \mu\text{H} \\ & C_i = 30 \ n\text{F} \end{aligned} $	

Order code for "Output"	Output type	Intrinsically safe values
Option D	4-20mA HART	$ \begin{array}{l} U_i = DC \; 30 \; V \\ I_i = \; 300 \; mA \\ P_i = \; 1 \; W \\ L_i = \; 0 \; \mu H \\ C_i = \; 5 \; nF \end{array} $
	Pulse/frequency/switch output	$ \begin{array}{l} U_i = DC \; 30 \; V \\ I_i = 300 \; mA \\ P_i = 1 \; W \\ L_i = 0 \; \mu H \\ C_i = 6 \; nF \end{array} $
	4 to 20 mA current input	
Option E	FOUNDATION Fieldbus	
	Pulse/frequency/switch output	$ \begin{array}{l} U_i = 30 \ V \\ l_i = 300 \ mA \\ P_i = 1 \ W \\ L_i = 0 \ \mu H \\ C_i = 6 \ nF \end{array} $
Option G	PROFIBUS PA	
	Pulse/frequency/switch output	$ \begin{array}{l} U_i = 30 \ V \\ l_i = 300 \ mA \\ P_i = 1 \ W \\ L_i = 0 \ \mu H \\ C_i = 6 \ nF \end{array} $
Option S	PROFINET over Ethernet-APL 10 Mbit/s	$U_{i} = \overline{17.5 \text{ V}}$ $I_{i} = 380 \text{ mA}$ $P_{i} = 5.32 \text{ W}$ $C_{i} = 5 \text{ nF}$ $L_{i} = 10 \mu \text{H}$

#### Low flow cut off

The switch points for low flow cut off are preset and can be configured.

Galvanic isolation

All inputs and outputs are galvanically isolated from one another.

HART

#### Protocol-specific data

Manufacturer ID	0x11
Device type ID	0x0038
HART protocol revision	7
Device description files (DTM, DD)	Information and files at: www.endress.com → Download Area
HART load	<ul> <li>Min. 250 Ω</li> <li>Max. 500 Ω</li> </ul>
System integration	For information on system integration, see Operating Instructions→   80  Measured variables via HART protocol Burst Mode functionality

#### FOUNDATION Fieldbus

Manufacturer ID	0x452B48		
Ident number	0x1038		
Device revision	2		
DD revision	Information and files at:		
CFF revision	www.endress.com → Download Area     www.fieldcommgroup.org		
Device Tester Version (ITK version)	6.2.0		
ITK Test Campaign Number	Information: • www.endress.com • www.fieldcommgroup.org		
Link Master capability (LAS)	Yes		
Choice of "Link Master" and "Basic Device"	Yes Factory setting: Basic Device		
Node address	Factory setting: 247 (0xF7)		
Supported functions	The following methods are supported: Restart ENP Restart Diagnostic Read events Read trend data		
Virtual Communication Relation	onships (VCRs)		
Number of VCRs	44		
Number of link objects in VFD	50		
Permanent entries	1		
Client VCRs	0		
Server VCRs	10		
Source VCRs	43		
Sink VCRs	0		
Subscriber VCRs	43		
Publisher VCRs	43		
<b>Device Link Capabilities</b>			
Slot time	4		
Min. delay between PDU	8		
Max. response delay	Min. 5		
System integration	For information on system integration, see Operating Instructions $ ightarrow  riangleq 80$		
	<ul> <li>Cyclic data transmission</li> <li>Description of the modules</li> <li>Execution times</li> <li>Methods</li> </ul>		

#### PROFIBUS PA

Manufacturer ID	0x11
Ident number	0x1564
Profile version	3.02
Device description files (GSD, DTM, DD)	Information and files at: • www.endress.com → Download Area • https://www.profibus.com

Supported functions	<ul> <li>Identification &amp; Maintenance Simple device identification via control system and nameplate</li> <li>PROFIBUS upload/download Reading and writing parameters is up to ten times faster with PROFIBUS upload/download</li> <li>Condensed Status Simplest and self-explanatory diagnostic information by categorizing diagnostic messages that occur</li> </ul>
Configuration of the device address	<ul> <li>DIP switches on the I/O electronics module</li> <li>Local display</li> <li>Via operating tools (e.g. FieldCare)</li> </ul>
System integration	<ul> <li>For information on system integration, see Operating Instructions → </li> <li>Cyclic data transmission</li> <li>Block model</li> <li>Description of the modules</li> </ul>

#### **PROFINET** over Ethernet-APL

Protocol	Application layer protocol for decentral device periphery and distributed automation, Version 2.43	
Communication type	Ethernet Advanced Physical Layer 10BASE-T1L	
Conformance Class	Conformance Class B (PA)	
Netload Class	PROFINET Netload Robustness Class 2 10 Mbit/s	
Data transfer	10 Mbit/s Full-duplex	
Cycle times	64 ms	
Polarity	Automatic correction of crossed "APL signal +" and "APL signal -" signal lines	
Media Redundancy Protocol (MRP)	Not possible (point-to-point connection to APL field switch)	
System redundancy support	System redundancy S2 (2 AR with 1 NAP)	
Device profile	PROFINET PA profile 4.02 (Application interface identifier API: 0x9700)	
Manufacturer ID	17	
Device type ID	0xA438	
Device description files (GSD, DTM, FDI)	Information and files available at: • www.endress.com → Downloads area • www.profibus.com	
Supported connections	<ul><li> 2x AR (IO Controller AR)</li><li> 2x AR (IO Supervisor Device AR connection allowed)</li></ul>	
Configuration options for measuring instrument	<ul> <li>Asset management software (FieldCare, DeviceCare, Field Xpert)</li> <li>Integrated Web server via Web browser and IP address</li> <li>Device master file (GSD), can be read out via the integrated Web server of the measuring instrument.</li> <li>Onsite operation</li> </ul>	
Configuration of the device name	<ul> <li>DCP protocol</li> <li>Asset management software (FieldCare, DeviceCare, Field Xpert)</li> <li>Integrated web server</li> </ul>	

Supported functions	<ul> <li>Identification &amp; Maintenance, simple device identifier via:</li> <li>Control system</li> <li>Nameplate</li> <li>Measured value status The process variables are communicated with a measured value status</li> <li>Blinking feature via the local display for simple device identification and assignment</li> <li>Device operation via asset management software (e.g. FieldCare, DeviceCare, SIMATIC PDM with FDI package)</li> </ul>
System integration	Information regarding system integration: Operating Instructions .  Cyclic data transmission  Overview and description of the modules  Status coding  Factory setting

## Power supply

#### Terminal assignment

## Transmitter

#### Connection versions

5 6 3 4 1	2 ()
+ - + - +	- 🕀
	A0033475
Maximum number of terminals Terminals 1 to 6: Without integrated overvoltage protection	Maximum number of terminals for order code for "Accessory mounted", option NA "Overvoltage protection" • Terminals 1 to 4: With integrated overvoltage protection • Terminals 5 to 6: Without integrated overvoltage protection
<ol> <li>Output 1 (passive): supply voltage and signal transmit</li> <li>Output 2 (passive): supply voltage and signal transmit</li> <li>Input (passive): supply voltage and signal transmission</li> <li>Ground terminal for cable shield</li> </ol>	ission ission ission on

Order code for "Output"	Terminal numbers					
	Outŗ	out 1	Output 2		Input	
	1 (+)	2 (-)	3 (+)	4 (-)	5 (+)	6 (-)
Option <b>A</b>	4-20 mA HART (passive)		-		-	
Option <b>B</b> $^{1)}$	4-20 mA HART (passive)		Pulse/frequency/switch output (passive)		-	
Option $C^{1)}$	4-20 mA HART (passive)		4-20 mA ana	log (passive)	-	-
Option $\mathbf{D}^{(1)(2)}$	4-20 mA HART (passive)		Pulse/frequency/switch output (passive)		4-20 mA current input (passive)	
Option $\mathbf{E}^{(1)(3)}$	FOUNDATION Fieldbus		Pulse/freque output (	ency/switch passive)	-	-

Order code for "Output"	Terminal numbers					
	Output 1		Output 2		Input	
	1 (+)	2 (-)	3 (+)	4 (-)	5 (+)	6 (-)
Option $\mathbf{G}^{(1)(4)}$	PROFIBUS PA		Pulse/frequ output (	ency/switch passive)	-	-
Option <b>S</b> <sup>1) 5)</sup>	PROFINET over Ethernet- APL/SPE, 10 Mbit/s			-	-	-

1) Output 1 must always be used; output 2 is optional.

2) The integrated overvoltage protection is not used with option D: Terminals 5 and 6 (current input) are not protected against overvoltage.

- 3) FOUNDATION Fieldbus with integrated reverse polarity protection.
- 4) PROFIBUS PA with integrated reverse polarity protection.
- 5) PROFINET over Ethernet-APL with integrated reverse polarity protection.

#### Connecting cable for remote version

#### Transmitter and sensor connection housing

In the case of the remote version, the sensor and transmitter are mounted separately from on another and connected by a connecting cable. Connection is performed via the sensor connection housing and the transmitter housing.

How the connecting cable is connected in the transmitter housing depends on the measuring instrument approval and the version of the connecting cable used.

In the following versions, only terminals can be used for connection in the transmitter housing:

- Order code for "Electrical connection", option B, C, D, 6
- Certain approvals: Ex nA, Ex ec, Ex tb and Division 1
- Use of reinforced connecting cable

In the following versions, an M12 device connector is used for connection in the transmitter housing:

- All other approvals
- Use of connecting cable (standard)

Terminals are always used to connect the connecting cable in the sensor connection housing (tightening torques for screws for cable strain relief: 1.2 to 1.7 Nm).

Connection via terminals



- 1. Loosen the securing clamp of the transmitter housing.
- 2. Turn the transmitter housing clockwise by approx. 20°.

#### 3. NOTICE

## The connection board of the wall housing is connected to the electronics board of the transmitter via a signal cable!

► Pay attention to the signal cable when lifting the transmitter housing!

Lift the transmitter housing, plug the signal cable out of the connection board of the wall holder and remove the transmitter housing.

- 4. Release the cable gland and insert the connecting cable (use the shorter stripped end of the connecting cable).
- **5.** Wire the connecting cable  $\rightarrow \square 3$ ,  $\square 32$ .
- 6. Reverse the removal procedure to reassemble the transmitter housing.
- 7. Firmly tighten the cable gland.

Connecting cable (standard, reinforced)



🛃 3 Terminals for connection compartment in the transmitter wall holder and the sensor connection housing

- 1 Terminals for connecting cable
- 2 Grounding via the cable strain relief

Terminal number	Assignment	Cable color Connecting cable
1	Supply voltage	Brown
2	Grounding	White
3	RS485 (+)	Yellow
4	RS485 (–)	Green

#### Pin assignment, device plug

**PROFIBUS PA** 



Recommended plug:

Binder, series 713, part no. 99 1430 814 04
Phoenix, part no. 1413934 SACC-FS-4QO SH PBPA SCO

#### **FOUNDATION Fieldbus**

	Pin		Assignment	Coding	Plug/socket
$\bigcirc$ 3	1	+	Signal +	А	Plug
$\bigcirc / 4$	2	-	Signal –		
$\sim$	3		Grounding		
	4		Not used		

**PROFINET** over Ethernet-APL

Pin	Assignment	Coding	Plug/socket
1	APL signal -	А	Socket
2	APL signal +		
3	Cable shield <sup>1</sup>		
4	Not used		

Metal hous	lug Cable 1g	shield	
	<sup>1</sup> If a	cable shield is used	

Recommended plug:

- Binder, series 713, part no. 99 1430 814 04
- Phoenix, part no. 1413934 SACC-FS-4QO SH PBPA SCO

#### Supply voltage

#### Transmitter

An external power supply is required for each output.

0 1 1	<b>C</b> (	• • • • •		1 /
Viinnlii iinltaan	tor a compact	10000100 10000000000000000000000000000	t a local dich	(a) 1 ±/
NUTITIV VUITIN		VPINIII VVIIIIII		<i>(IIV `</i>
117 3	J L		1	

Order code for "Output; input"	Minimum Terminal voltage <sup>2)</sup>	Maximum Terminal voltage
Option A: 4-20 mA HART	≥ DC 12 V	DC 35 V
Option <b>B</b> : 4-20 mA HART, pulse/ frequency/switch output	≥ DC 12 V	DC 35 V
Option <b>C</b> : 4-20 mA HART + 4-20 mA analog	≥ DC 12 V	DC 30 V
Option <b>D</b> : 4-20 mA HART, pulse/ frequency/switch output, 4-20 mA current input <sup>3)</sup>	≥ DC 12 V	DC 35 V
Option <b>E</b> : FOUNDATION Fieldbus, pulse/ frequency/switch output	≥ DC 9 V	DC 32 V
Option <b>G</b> : PROFIBUS PA, pulse/frequency/ switch output	≥ DC 9 V	DC 32 V
Option <b>S</b> : PROFINET over Ethernet-APL/ SPE, 10 Mbit/s	≥ DC 9 V	DC 15 V

1) In event of external supply voltage of the power supply unit with load, the PROFIBUS DP/PA coupler or FOUNDATION Fieldbus power conditioner

2) Increase of minimum terminal voltage with local operation: See the table below.

3) Voltage drop 2.2 to 3 V for 3.59 to 22 mA

#### Increase of minimum terminal voltage with local operation

Order code for "Display; operation"	Increase in minimum Terminal voltage
Option <b>C</b> : Local operation SD02	+ DC 1 V
Option <b>E</b> : Local operation SD03 with lighting ( <b>backlighting</b> not used)	+ DC 1 V
Option <b>E</b> : Local operation SD03 with lighting ( <b>backlighting</b> used)	+ DC 3 V



• For information on the load, see  $\rightarrow \implies 19$ 

• Available as accessory: Power supply unit for power supply  $\rightarrow \boxtimes 80$ 

• For information on the Ex connection values  $\rightarrow \cong 20$ 

#### Power consumption

#### Transmitter

Order code for "Output; input"	Maximum power consumption
Option A: 4-20 mA HART	770 mW
Option B: 4-20 mA HART, pulse/ frequency/switch output	<ul><li>Operation with output 1: 770 mW</li><li>Operation with output 1 and 2: 2 770 mW</li></ul>
Option C: 4-20 mA HART + 4-20 mA analog	<ul><li>Operation with output 1: 660 mW</li><li>Operation with output 1 and 2: 1320 mW</li></ul>
Option D: 4-20 mA HART, pulse/ frequency/switch output, 4-20 mA current input	<ul> <li>Operation with output 1: 770 mW</li> <li>Operation with output 1 and 2: 2770 mW</li> <li>Operation with output 1 and input: 840 mW</li> <li>Operation with output 1, 2 and input: 2840 mW</li> </ul>
Option E: FOUNDATION Fieldbus, pulse/ frequency/switch output	<ul><li>Operation with output 1: 512 mW</li><li>Operation with output 1 and 2: 2512 mW</li></ul>
Option G: PROFIBUS PA, pulse/frequency/ switch output	<ul><li>Operation with output 1: 512 mW</li><li>Operation with output 1 and 2: 2512 mW</li></ul>
Option S: PROFINET over Ethernet-APL/ SPE, 10 Mbit/s	Operation with output 1: Ex: 833 mW Non-Ex: 1.5 W

 $\mathbf{H}$ 

For information on the Ex connection values  $\rightarrow \square 20$ 

#### **Current consumption**

Current output

For every 4-20 mA current output or current output: 3.6 to 22.5 mA

If the option **Defined value** is selected in the **Failure mode** parameter : 3.59 to 22.5 mA

#### **Current** input

3.59 to 22.5 mA

📔 Internal current limiting: max. 26 mA

#### **FOUNDATION Fieldbus**

15 mA

#### **PROFIBUS PA**

15 mA

#### **PROFINET** over Ethernet-APL

20 to 55.56 mA

## Power supply failure Totalizers stop at the last value measured. Depending on the device version, the configuration is retained in the device memory or in the pluggable data memory (HistoROM DAT). Error messages (incl. total operated hours) are stored.

#### **Electrical connection**

#### Transmitter connection



1 Cable entries for inputs/outputs

#### Remote version connection

#### Connecting cable



- 1 Wall holder with connection compartment (transmitter)
- 2 Connecting cable
- 3 Sensor connection housing



How the connecting cable is connected in the transmitter housing depends on the measuring instrument approval and the version of the connecting cable used.

In the following versions, only terminals can be used for connection in the transmitter housing: • Order code for "Electrical connection", option B, C, D, 6

- Certain approvals: Ex nA, Ex ec, Ex tb and Division 1
- Use of reinforced connecting cable

In the following versions, an M12 device connector is used for connection in the transmitter housing:

- All other approvals
- Use of connecting cable (standard)

Terminals are always used to connect the connecting cable in the sensor connection housing (tightening torques for screws for cable strain relief: 1.2 to 1.7 Nm).

#### **Connection examples**

Current output 4 to 20 mA (without HART)



■ 5 Connection example for 4 to 20 mA current output (passive)

- 1 Automation system with current input (e.g. PLC)
- 2 Power supply
- 3 Optional additional display unit: Observe maximum load
- 4 Transmitter with current output (passive)

#### Current input 4 to 20 mA



- 6 Connection example for 4 to 20 mA current input
- 1 Power supply
- 2 External measuring instrument with 4 to 20 mA passive current output. e.g. pressure or temperature)
- *3 Transmitter with 4 to 20 mA current input*

Pulse output/frequency output/switch output



☑ 7 Connection example for pulse output/frequency output/switch output (passive)

- 1 Automation system with pulse input/frequency input/switch input (e.g. PLC)
- 2 Power supply
- 3 Transmitter with pulse output/frequency output/switch output (passive)
#### Current output 4 to 20 mA HART



Connection example for 4 to 20 mA current output with HART (passive)

- 1 Automation system with 4 to 20 mA current input with HART (e.g. PLC)
- 2 Power supply
- 3 Optional display unit: Note maximum load
- 4 Transmitter with 4 to 20 mA current output with HART (passive)
- 5 Ground cable shield at one end. For installations in compliance with NAMUR NE 89, grounding of the cable shield on both sides is required.

#### PROFIBUS PA



See https://www.profibus.com "PROFIBUS Installation Guidelines".

#### FOUNDATION Fieldbus



- Connection example for FOUNDATION Fieldbus
- 1 Automation system (e.g. PLC)
- 2 Power Conditioner (FOUNDATION Fieldbus)
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring instrument
- 6 Local grounding
- 7 Bus terminator
- 8 Potential equalization conductor

Ethernet-APL



See https://www.profibus.com Ethernet-APL White Paper "

Potential equalization	Requirements		
	For potential equalization:		
	<ul> <li>Pay attention to in-house grounding concepts</li> </ul>		
	<ul> <li>Take account of operating conditions, such as the pipe material and grounding</li> <li>Connect the medium, sensor and transmitter to the same electric potential</li> </ul>		
	<ul> <li>Use a ground cable with a minimum cross-section of 6 mm<sup>2</sup> (10 AWG) and a cable lug for</li> </ul>		
	potential equalization connections		
Terminals	• For device version without integrated overvoltage protection: plug-in spring terminals for wire		
	cross-sections 0.5 to 2.5 mm <sup>2</sup> (20 to 14 AWG) • For device version with integrated overvoltage protection: screw terminals for wire cross-sections		
	0.2 to 2.5 $\text{mm}^2$ (24 to 14 AWG)		
Cable entries	The type of cable entry available depends on the specific device version.		
	Cable gland (not for Ex d) $M20 \times 1.5$		
	Thread for cable entry		
	■ NPT ½"		
	■ G ½" ■ M20 × 1.5		
Cable specification	Permitted temperature range		
	<ul><li>The installation guidelines that apply in the country of installation must be observed.</li><li>The cables must be suitable for the minimum and maximum temperatures to be expected.</li></ul>		
	Signal cable		
	4 to 20 mA current output (without HART)		
	Standard installation cable is sufficient.		
	Pulse/frequency/switch output		
	Standard installation cable is sufficient.		
	Current output 4 to 20 mA HART		
	Shielded twisted-pair cable.		
	See https://www.fieldcommgroup.org "HART PROTOCOL SPECIFICATIONS".		
	PROFIBUS PA		
	Shielded twisted-pair cable. Cable type A is recommended.		
	See https://www.profibus.com "PROFIBUS Installation Guidelines".		
	Ethernet-APL		
	Shielded twisted-pair cable. Cable type A is recommended.		
	See https://www.profibus.com Ethernet-APL White Paper "		
	FOUNDATION Fieldbus		
	Twisted, shielded two-wire cable.		
	For further information on planning and installing FOUNDATION Fieldbus networks see:		
	<ul> <li>Operating Instructions for "FOUNDATION Fieldbus Overview" (BA00013S)</li> <li>FOUNDATION Fieldbus Guideline</li> <li>IEC 61158-2 (MBP)</li> </ul>		
Overvoltage protection	The device can be ordered with integrated overvoltage protection: Order code for "Accessory mounted", option NA "Overvoltage protection"		

Input voltage range	Values correspond to supply voltage specifications $\rightarrow$ 🗎 33 $^{1)}$
Resistance per channel	2 · 0.5 Ω max.
DC sparkover voltage	400 to 700 V
Trip surge voltage	< 800 V
Capacitance at 1 MHz	< 1.5 pF
Nominal discharge current (8/20 μs)	10 kA
Temperature range	-40 to +85 °C (-40 to +185 °F)

1) The voltage is reduced by the amount of the internal resistance  $I_{\text{min}} \cdot R_i$ 

H

Depending on the temperature class, restrictions apply to the ambient temperature for device versions with overvoltage protection .

For detailed information on the temperature tables, see the "Safety Instructions" (XA) for the device.

The use of an external overvoltage protection, e.g. HAW 569, is recommended.

## **Performance characteristics**

Reference operating conditions	<ul> <li>Error limits following ISO/DIN 11631</li> <li>+20 to +30 °C (+68 to +86 °F)</li> <li>2 to 4 bar (29 to 58 psi)</li> <li>Calibration system traceable to national standards</li> <li>Calibration with the process connection corresponding to the particular standard</li> </ul>
	<b>1</b> To obtain measured errors, use the <i>Applicator</i> sizing tool $\rightarrow \square$ 79

Maximum measurement	
error	

#### **Base accuracy**

#### o.r. = of reading



Powolds numbers	Incompressible	Compressible
Reynolus humbers	Standard	Standard
Re <sub>1</sub>	5 00	0
Re <sub>2</sub>	2000	00

#### Volume flow

Medium type		Incompressible	Compressible <sup>1)</sup>
Reynolds number range	Measurement error	Standard	Standard
Re <sub>1</sub> to Re <sub>2</sub>	A2	< 10 %	< 10 %
Re <sub>2</sub> to Re <sub>max</sub>	A1	< 0.75 %	< 1.0 %

1) Accuracy specifications valid up to 75 m/s (246 ft/s)

#### Temperature

- Saturated steam and liquids at room temperature if T > 100 °C (212 °F) applies: < 1 °C (1.8 °F)
- Gas:
  - < 1 % o.r. [K]

Rise time 50 % (stirred under water, following IEC 60751): 8 s

Mass flow saturated steam

Process pressure [bar abs.]	Flow velocity [m/s (ft/s)]	Reynolds number range	Measurement error	Standard
> 4.76	20 to 50 (66 to 164)	$Re_2$ to $Re_{max}$	A1	< 1.7 %
> 3.62	10 to 70 (33 to 230)	Re <sub>2</sub> to Re <sub>max</sub>	A1	< 2 %

Mass flow of superheated steam/gases <sup>1) 2)</sup>

Process pressure [bar abs. (psi abs.)]	Reynolds number range	Measurement error	Standard <sup>1)</sup>
< 40 (580)	$Re_2$ to $Re_{max}$	A1	< 1.7 %
< 120 (1740)	$Re_2$ to $Re_{max}$	A1	< 2.6 %

1) The use of a Cerabar S is required for the measurement errors listed in the following section. The measurement error used to calculate the error in the measured pressure is 0.15 %.

#### Water mass flow

Reynolds number range	Measurement error	Standard
Re = Re <sub>2</sub>	A1	< 0.85 %
Re1 to Re2	A2	< 10 %

<sup>1)</sup> Single gas, gas mixture, air: NEL40; natural gas: ISO 12213-2 contains AGA8-DC92, AGA NX-19, ISO 12213-3 contains SGERG-88 and AGA8 Gross Method 1

<sup>2)</sup> The measuring instrument is calibrated with water and has been verified under pressure on gas calibration rigs.

#### Mass flow (user-specific liquids)

To specify the system accuracy, Endress+Hauser requires information about the type of liquid and its operating temperature or information in table form about the dependency between the liquid density and the temperature.

#### Example

- Acetone is to be measured at fluid temperatures from +70 to +90 °C (+158 to +194 °F).
- For this purpose, the Reference temperature parameter (7703) (here 80 °C (176 °F)), Reference density parameter (7700) (here 720.00 kg/m<sup>3</sup>) and Linear expansion coefficient parameter (7621) (here 18.0298 × 10<sup>-4</sup> 1/°C) must be entered in the transmitter.
- The overall system uncertainty, which is less than 0.9 % for the example above, is comprised of the
  following measurement uncertainties: uncertainty of volume flow measurement, uncertainty of
  temperature measurement, uncertainty of the density-temperature correlation used (including the
  resulting uncertainty of density).

#### Mass flow (other media)

Depends on the selected fluid and the pressure value, which is specified in the parameters. Individual error analysis must be performed.

#### Diameter mismatch correction



The measuring device is calibrated according to the ordered process connection. This calibration takes account of the edge at the transition from the mating pipe to the process connection. If the mating pipe used deviates from the ordered process connection, a diameter mismatch correction can compensate for the effects. The difference between the internal diameter of the ordered process connection and the internal diameter of the mating pipe used must be taken into consideration.

The measuring device can correct shifts in the calibration factor which are caused, for example, by a diameter mismatch between the device flange (e.g. ASME B16.5/Sch. 80, DN 50 (2")) and the mating pipe (e.g. ASME B16.5/Sch. 40, DN 50 (2")). Only apply diameter mismatch correction within the following limit values (listed below) for which test measurements have also been performed.

#### Disc (wafer flange):

- DN 15 (1/2"): ±15 % of the internal diameter
- DN 25 (1"): ±12 % of the internal diameter
- DN 40 (1<sup>1</sup>/<sub>2</sub>"): ±9 % of the internal diameter
- DN  $\ge$  50 (2"): ±8 % of the internal diameter

If the standard internal diameter of the ordered process connection differs from the internal diameter of the mating pipe, an additional measuring uncertainty of approx. 2 % o.r. must be expected.

#### Example

Influence of the diameter mismatch without using the correction function:

- Mating pipe DN 100 (4"), Schedule 80
- Device flange DN 100 (4"), Schedule 40
- This installation position results in a diameter mismatch of 5 mm (0.2 in). If the correction function is not used, an additional measuring uncertainty of approx. 2 % o.r. must be expected.
- If the basic conditions are met and the feature is enabled, the additional measuring uncertainty is 1 % o.r.

For detailed information on the parameters for diameter mismatch correction, see the Operating Instructions  $\Rightarrow \cong 80$ 

#### Accuracy of outputs

The outputs have the following base accuracy specifications.

*Current output* 

Accuracy	±10 µA
----------	--------

Pulse/frequency output

o.r. = of reading

Accuracy	Max. ±100 ppm o.r.
----------	--------------------

#### Repeatability

o.r. = of reading





• 10 Repeatability = 0.1 % o.r. with a measured volume  $[m^3]$  of V = 10000  $\cdot D_i^3$ 

The repeatability can be improved if the measured volume is increased. Repeatability is not a device characteristic but a statistical variable that is dependent on the boundary conditions indicated.

If all the configurable functions for filter times (flow damping, display damping, current output time constant, frequency output time constant, status output time constant) are set to 0, in the event of vortex frequencies of 10 Hz and higher a response time of max(T<sub>v</sub>,100 ms) can be expected.

In the event of measuring frequencies < 10 Hz, the response time is > 100 ms and can be up to 10 s.  $T_v$  is the average vortex period duration of the flowing fluid.

## Influence of ambient temperature

**Response time** 

#### Current output

o.r. = of reading

Additional error, in relation to the span of 16 mA:

Temperature coefficient at zero point (4 mA)	0.02 %/10 K
Temperature coefficient with span (20 mA)	0.05 %/10 K

#### Pulse/frequency output

o.r. = of reading

Temperature coefficient	Max. ±100 ppm o.r.
-------------------------	--------------------

## Installation





- 1 Installation suitable for gases and steam
- 2 Installation not suitable for liquids

#### Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Vortex meters require a fully developed flow profile as a prerequisite for correct volume flow measurement. Therefore, please note the following:

Orientation			Recommendation	
			Compact version	Remote version
A	Vertical orientation (liquids)	A0015591	V V <sup>1)</sup>	
A	Vertical orientation (dry gases)			
В	Horizontal orientation, transmitter head up		<b>⊘ ⊘</b> <sup>2)</sup>	
C	Horizontal orientation, transmitter head down	A0015590	<b>X X</b> <sup>3)</sup>	
D	Horizontal orientation, transmitter head at side	A0015592		

1) In the case of liquids, there should be upward flow in vertical pipes to avoid partial pipe filling (Fig. A). Disruption in flow measurement!

2) In the case of hot media (e.g. steam or medium temperature (TM) ≥ 200 °C (392 °F): orientation C or D

3) In the case of very cold media (e.g. liquid nitrogen): orientation B or D

Inlet and outlet runs

To attain the specified level of accuracy of the measuring instrument, the inlet and outlet runs mentioned below must be maintained at the very minimum.



■ 11 Minimum inlet and outlet runs with various flow obstructions

- *h Difference in expansion*
- 1 Reduction by one nominal diameter size
- 2 Single elbow (90° elbow)
- 3 Double elbow  $(2 \times 90^{\circ} \text{ elbows, opposite})$
- 4 Double elbow 3D (2 × 90° elbows, opposite, not on one plane)
- 5 T-piece
- 6 Extension
- 7 Control valve
- 8 Two measuring instruments in a row where  $DN \le 25$  (1"): directly flange on flange
- 9 Two measuring instruments in a row where  $DN \ge 40 (1\frac{1}{2})$ : for spacing, see graphic

• If there are several flow disturbances present, the longest specified inlet run must be maintained.

If the required inlet runs cannot be observed, it is possible to install a specially designed flow conditioner → 
 <sup>(1)</sup>
 <sup>(2)</sup>
 <sup>(2)</sup>

#### Flow conditioner

If the inlet runs cannot be observed, the use of a flow conditioner is recommended.

The flow conditioner is fitted between two pipe flanges and centered by the mounting bolts. Generally this reduces the inlet run needed to  $10 \times DN$  with full measurement accuracy.



Flow conditioner 1

The pressure loss for flow conditioners is calculated as follows:

 $\Delta p \,[mbar] = 0.0085 \cdot \rho \,[kg/m^3] \cdot v^2 \,[m/s]$ 

Example for steam		
p = 10 bar abs.		
t = 240 °C $\rightarrow$ $\rho$ = 4.39 kg/m^3		
v = 40  m/s		
$\Delta p = 0.0085 \cdot 4.39 \cdot 40^2 = 59.7 \text{ mbar}$		

Example for $H_2O$ condensate (80 °C)		
$\rho = 965 \text{ kg/m}^3$		
v = 2.5 m/s		
$\Lambda n = 0.0085 \cdot 965 \cdot 2.5^2 = 51.3 \text{ mbar}$		

 $\boldsymbol{\rho}$  : density of the process medium v: average flow velocity abs. = absolute

Н

A specially designed flow conditioner is available as an accessory → 
Particular and a special provides a special provides and a special provides a

#### Outlet runs when installing external devices

If installing an external device, observe the specified distance.



PT Pressure TT Temperature device

Mounting set for disc (wafer	The centering rings supplied are used to mount and center the wafer-style devices.	
version)	A mounting set comprises:	
	<ul> <li>Tie rods</li> </ul>	
	<ul> <li>Seals</li> </ul>	
	Nuts	

Washers





#### Pipe mounting



#### 14 mm (in)

## Installation for delta heat measurements

The second temperature measurement is taken using a separate temperature sensor. The measuring instrument reads in this value via a communication interface.

- In the case of saturated steam delta heat measurements, the measuring instrument must be installed on the steam side.
- In the case of water delta heat measurements, the device can be installed on the cold or warm side.



15 Layout for delta heat measurement of saturated steam and water

- 1 Measuring instrument
- 2 Temperature sensor
- 3 Heat exchanger
- Q Heat flow

Protective cover

A protective cover is available as an accessory for the device. It is used to protect against direct sunlight, precipitation and ice.

When installing the protective cover, a minimum upward clearance must be maintained: 222 mm (8.74 in)  $\,$ 

The protective cover can be ordered via the product structure together with the device: Order code for "Accessories enclosed" option PB "Protective cover"

 $\square$  Ordered separately as an accessory  $\rightarrow$   $\square$  77

## Environment

#### Ambient temperature range

Compact version

compact version				
Measuring instrument	Non-hazardous area:	-40 to +80 °C (-40 to +176 °F) <sup>1)</sup> -40 to +80 °C (-40 to +176 °F)		
	Ex i, Ex nA, Ex ec:	-40 to +70 °C (-40 to +158 °F) <sup>1)</sup>		
	Ex d, XP:	-40 to +60 °C (-40 to +140 °F) <sup>1)</sup>		
	Ex d, Ex ia:	-40 to +60 °C (-40 to +140 °F) <sup>1)</sup>		
Local display		-40 to +70 °C (-40 to +158 °F) <sup>2) 1)</sup>		

- Additionally available as order code for "Test, certificate", option JN "Transmitter ambient temperature -50 °C (-58 °F)". This option is only available in combination with a "High-temperature sensor -200 to +400 °C(-328 to +750 °F)", see order code 060 for "Sensor version; DSC sensor; measuring tube" with options BA, BB, CA, CB.
- At temperatures below -20 °C (-4 °F), depending on the physical characteristics involved, it may no longer be possible to read the liquid crystal display.

#### Remote version

Transmitter	Non-hazardous area:	-40 to +80 °C (-40 to +176 °F) <sup>1)</sup> -40 to +80 °C (-40 to +176 °F)	
	Ex i, Ex nA, Ex ec:	-40 to +80 °C (-40 to +176 °F) <sup>1)</sup>	
	Ex d:	-40 to +60 °C (-40 to +140 °F) <sup>1)</sup>	
	Ex d, Ex ia:	-40 to +60 °C (-40 to +140 °F) <sup>1)</sup>	
Sensor	Non-hazardous area:	-40 to +85 °C (-40 to +185 °F) <sup>1)</sup>	
	Ex i, Ex nA, Ex ec:	-40 to +85 °C (-40 to +185 °F) <sup>1)</sup>	
	Ex d:	-40 to +85 °C (-40 to +185 °F) <sup>1)</sup>	
	Ex d, Ex ia:	-40 to +85 °C (-40 to +185 °F) <sup>1)</sup>	
Local display		-40 to +70 °C (-40 to +158 °F) <sup>2) 1)</sup>	

- Additionally available as order code for "Test, certificate", option JN "Transmitter ambient temperature -50 °C (-58 °F)". This option is only available in combination with a "High-temperature sensor -200 to +400 °C(-328 to +750 °F)", see order code 060 for "Sensor version; DSC sensor; measuring tube" with options BA, BB, CA, CB.
- 2) At temperatures < -20 °C (-4 °F), depending on the physical characteristics involved, it may no longer be possible to read the liquid crystal display.

►	If operating outdoors:
	Avoid direct sunlight, particularly in warm climatic regions.

You can order a weather protection cover from Endress+Hauser.  $\rightarrow \square$  77.

All components apart from the display modules: −50 to +80 °C (−58 to +176 °F)

#### **Display modules**

-

-40 to +80 °C (-40 to +176 °F) Remote display FHX50: -40 to +80 °C (-40 to +176 °F)

**Climate class** 

Storage temperature

DIN EN 60068-2-38 (test Z/AD)

Degree of protection	<ul> <li>Transmitter</li> <li>Standard: IP66/67, Type 4X enclosure, suitable for pollution degree 4</li> <li>When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2</li> <li>Display module: IP20, Type 1 enclosure, suitable for pollution degree 2</li> </ul>				
	Sensor IP66/67, Type 4X enclosure, suitable for pollution degree 4				
	<b>Device plug</b> IP67, only in screwed situation				
Vibration-resistance and	Vibration sinusoidal, in accordance with IEC 60068-2-6				
shock resistance	Order code for "Housing", option B "GT18 dual compartment, 316L, compact" • 2 to 8.4 Hz, 3.5 mm peak • 8.4 to 500 Hz, 1 g peak				
	Order code for "Housing", option C "GT20 dual compartment, alu, coated, compact" or option J "GT20 dual compartment, alu, coated, remote" or option K "GT18 dual compartment, 316L, remote" • 2 to 8.4 Hz, 7.5 mm peak • 8.4 to 500 Hz, 2 g peak				
	Vibration broad-band random, according to IEC 60068-2-64				
	Order code for "Housing", option B "GT18 dual compartment, 316L, compact" <ul> <li>10 to 200 Hz, 0.003 g<sup>2</sup>/Hz</li> <li>200 to 500 Hz, 0.001 g<sup>2</sup>/Hz</li> <li>Total: 0.93 g rms</li> </ul>				
	Order code for "Housing", option C "GT20 dual compartment, alu, coated, compact" or option J "GT20 dual compartment, alu, coated, remote" or option K "GT18 dual compartment, 316L, remote") • 10 to 200 Hz, 0.01 g <sup>2</sup> /Hz • 200 to 500 Hz, 0.003 g <sup>2</sup> /Hz • Total: 1.67 g rms				
	Half-sine shocks according to IEC 60068-2-27				
	<ul> <li>Order code for "Housing", option B "GT18 dual compartment, 316L, compact"</li> </ul>				
	<ul> <li>6 ms 30 g</li> <li>Order code for "Housing", option C "GT20 dual compartment, alu, coated, compact" or option J "GT20 dual compartment, alu, coated, remote" or option K "GT18 dual compartment, 316L, remote")</li> <li>6 ms 50 g</li> </ul>				
	Rough handling shocks according to IEC 60068-2-31				
Electromagnetic compatibility (EMC)	<ul> <li>As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21), NAMUR Recommendation 21 (NE 21) is fulfilled when installed in accordance with NAMUR Recommendation 98 (NE 98)</li> <li>As per IEC/EN 61000-6-2 and IEC/EN 61000-6-4</li> </ul>				
	Details are provided in the Declaration of Conformity.				
	This unit is not intended for use in residential environments and cannot guarantee adequate protection of the radio reception in such environments.				

## Process

	Order co	Order code for "Sensor version; DSC sensor; measuring tube"		
	Option	Description	Medium temperature range	
	AA	Volume; 316L; 316L	-40 to $+260$ °C ( $-40$ to $+500$ °F), stainless steel	
	BA	Volume high-temperature; 316L; 316L	-200 to +400 °C (-328 to +750 °F), stainless steel	
	CA	Mass; 316L; 316L	-200 to +400 °C (-328 to +750 °F), stainless steel	

#### Seals

Order code for "DSC sensor seal"			
Option	Description	Medium temperature range	
А	Graphite	-200 to +400 °C (-328 to +752 °F)	
В	Viton	–15 to +175 °C (+5 to +347 °F)	
С	Gylon	-200 to +260 °C (-328 to +500 °F)	
D	Kalrez	-20 to +275 °C (-4 to +527 °F)	

## Pressure/temperature ratings

The following pressure/temperature diagrams apply to all pressure-bearing parts of the device and not just the process connection. The diagrams show the maximum permissible medium pressure depending on the specific medium temperature.

The pressure-temperature rating for the specific measuring device is programmed into the software. If values exceed the curve range a warning is displayed. Depending on the system configuration and sensor version, the pressure and temperature are determined by entering, reading in or calculating values.



#### Wafer flange for pressure ratings similar to EN 1092-1, material group 13E0

☑ 16 Material: stainless steel, CF3M/1.4408





☑ 17 Material: stainless steel, CF3M/1.4408

Endress+Hauser

#### Wafer flange for connection to flanges similar to JIS B2220





**Nominal pressure of sensor** The following overpressure resistance values apply to the sensor shaft in the event of a membrane rupture:

Sensor version; DSC sensor; measuring tube	Overpressure, sensor shaft in [bar a]
Volume	200
Volume high-temperature	200
Mass (integrated temperature measurement)	200

Pressure loss

For a precise calculation, use the Applicator  $\rightarrow \square$  79.

Thermal insulation

For optimum temperature measurement and mass calculation, heat transfer at the sensor must be avoided for some fluids. This can be ensured by installing thermal insulation. A wide range of materials can be used for the required insulation.

The maximum insulation height permitted is illustrated in the diagram:



1 Maximum insulation height

▶ When insulating, ensure that a sufficiently large area of the housing support remains exposed.

The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

### Mechanical construction

Dimensions in SI units



Pay attention to the information on diameter mismatch correction  $\rightarrow$  🗎 41.

#### **Compact version**

Order code for "Housing", option J "GT20 dual compartment, aluminum, coated, remote"; option K "GT18 dual compartment, 316L, remote"



#### Intermediate flange similar to:

• EN 1092-1-B1 (DIN 2501): PN 10/16/25/40

- ASME B16.5: Class 150/300, Schedule 40
- JIS B2220: 10/20K, Schedule 40

#### 1.4404/F316/F316L

Order code for "Process connection", option DDS/DES/D1S/D2S/AAS/ABS/NDS/NES

DN	A 1)	В	C 1)	D	E <sup>2)3)</sup>	F <sup>2)3)</sup>	G	Н	I <sup>4)</sup>	K (D <sub>i</sub> )	L <sup>5)</sup>	м
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
15 <sup>6)</sup>	140.2	51.7	88.5	23.4	252.5	275.9	159.9	58.2	101.7	16.5	65	45
25 <sup>6)</sup>	140.2	51.7	88.5	32.4	262.0	294.4	159.9	58.2	101.7	27.6	65	64
40 <sup>6)</sup>	140.2	51.7	88.5	41.5	270.5	312.0	159.9	58.2	101.7	42	65	82
50	140.2	51.7	88.5	46.5	277.5	324.0	159.9	58.2	101.7	53.5	65	92
80	140.2	51.7	88.5	64.0	291.5	355.5	159.9	58.2	101.7	80.3	65	127
100 7)	140.2	51.7	88.5	79.1	304.0	383.1	159.9	58.2	101.7	104.8	65	157.2
100 8)	140.2	51.7	88.5	79.1	303.2	382.3	159.9	58.2	101.7	102.3	65	157.2
150	140.2	51.7	88.5	108.5	330.0	438.5	159.9	58.2	101.7	156.8	65	215.9

1) For version with overvoltage protection: values + 8 mm

2) For version without local display: values - 10 mm

3) For high-temperature/low-temperature version: values + 29 mm

4) For version without local display: values - 7 mm

5) ±0.5 mm

6) Not available for JIS B2220, 10K

7) EN (DIN), ASME

8) JIS

#### Intermediate flange similar to:

ASME B16.5: Class 150/300, Schedule 80

JIS B2220: 10/20K, Schedule 80

#### 1.4404/F316/F316L

Order code for "Process connection", option AFS/AGS/NFS/NGS

DN	A <sup>1)</sup>	В	С	D	E <sup>2)3)</sup>	F	G	Н	I <sup>4)</sup>	K (D <sub>i</sub> )	L <sup>5)</sup>	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
15 <sup>6) 7)</sup>	140.2	51.7	88.5	23.4	252.5	275.9	159.9	58.2	101.7	13.9	65	45
25 <sup>6)</sup>	140.2	51.7	88.5	32.4	262.0	294.4	159.9	58.2	101.7	24.3	65	64
40	140.2	51.7	88.5	41.5	270.5	312.0	159.9	58.2	101.7	38.1	65	82
50	140.2	51.7	88.5	46.5	277.5	324.0	159.9	58.2	101.7	49.3	65	92

- Intermediate flange similar to:
- ASME B16.5: Class 150/300, Schedule 80
- JIS B2220: 10/20K, Schedule 80
- 1.4404/F316/F316L

Order code for "Process connection", option AFS/AGS/NFS/NGS

DN	A 1)	В	С	D	E <sup>2)3)</sup>	F	G	Н	I <sup>4)</sup>	K (D <sub>i</sub> )	L <sup>5)</sup>	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
80	140.2	51.7	88.5	64.0	291.5	355.5	159.9	58.2	101.7	73.7	65	127
100 8)	140.2	51.7	88.5	79.1	304.0	383.1	159.9	58.2	101.7	97.2	65	157.2
100 9)	140.2	51.7	88.5	79.1	303.2	382.3	159.9	58.2	101.7	97.2	65	157.2
150	140.2	51.7	88.5	108.5	330.0	438.5	159.9	58.2	101.7	146.3	65	215.9

1) For version with overvoltage protection: values + 8 mm

2) For version without local display: values - 10 mm

3) For high-temperature/low-temperature version: values + 29 mm

4) For version without local display: values - 7 mm

- 5) ±0.5 mm
- 6) Not available for JIS B2220, 10K
- 7)
- 8) EN (DIN), ASME
- 9) JIS

#### Transmitter remote version

Order code for "Housing", option J "GT20 dual compartment, aluminum, coated, remote"; option K "GT18 dual compartment, 316L, remote"



A <sup>1)</sup>	В	C 1)	F <sup>2)</sup>	G <sup>3)</sup>	Q	T <sup>3)</sup>
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
140.2	51.7	88.5	254	159.9	107	191

1) For version with overvoltage protection: value + 8 mm

2) For version without local display: value - 10 mm

3) For version without local display: value - 7 mm

#### Sensor remote version

Order code for "Housing", option J "GT20 dual compartment, aluminum, coated, remote"; option K "GT18 dual compartment, 316L, remote"



#### Intermediate flange similar to:

EN 1092-1-B1 (DIN 2501): PN 10/16/25/40
ASME B16.5: Class 150/300, Schedule 40

• JIS B2220: 10/20K, Schedule 40

1.4404/F316/F316L

#### Order code for "Process connection", option DDS/DES/D1S/D2S/AAS/ABS/NDS/NES

DN	А	В	С	D	E <sup>1)</sup>	F <sup>1)</sup>	G	K (D <sub>i</sub> )	L <sup>2)</sup>	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
15 <sup>3)</sup>	107.3	60	47.3	23.4	222.8	246.2	94.5	16.5	65	45
25 <sup>3)</sup>	107.3	60	47.3	32.4	232.3	264.7	94.5	27.6	65	64
40 <sup>3)</sup>	107.3	60	47.3	41.5	240.8	282.3	94.5	42	65	82
50	107.3	60	47.3	46.5	247.8	294.3	94.5	53.5	65	92
80	107.3	60	47.3	64.0	261.8	325.8	94.5	80.3	65	127
100 4)	107.3	60	47.3	79.1	274.3	353.4	94.5	104.8	65	157.2
100 5)	107.3	60	47.3	79.1	273.5	352.6	94.5	102.3	65	157.2
150	107.3	60	47.3	108.5	300.3	408.8	94.5	156.8	65	215.9

1) For high-temperature/low-temperature version: values +29 mm

2) ±0.5 mm

Not available for JIS B2220, 10K 3)

4) EN (DIN), ASME

5) JIS

Intermediate flange similar to:

ASME B16.5: Class 150/300, Schedule 80
JIS B2220: 10/20K, Schedule 80

1.4404/F316/F316L

0	Order coo	le for	"Process	connection"	, option .	AFS/AGS	S/NFS/	NGS
---	-----------	--------	----------	-------------	------------	---------	--------	-----

DN	A	В	С	D	E 1)	F	G	K (D <sub>i</sub> )	L <sup>2)</sup>	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
15 <sup>3)</sup>	107.3	60	47.3	23.4	222.8	246.2	94.5	13.9	65	45
25 <sup>3)</sup>	107.3	60	47.3	32.4	232.3	264.7	94.5	24.3	65	64
40 <sup>3)</sup>	107.3	60	47.3	41.5	240.8	282.3	94.5	38.1	65	82
50	107.3	60	47.3	46.5	247.8	294.3	94.5	49.3	65	92
80	107.3	60	47.3	64.0	261.8	325.8	94.5	73.7	65	127
100 4)	107.3	60	47.3	79.1	274.3	353.4	94.5	97.2	65	157.2

- ASME B16.5: Class 150/300, Schedule 80
- JIS B2220: 10/20K, Schedule 80

```
1.4404/F316/F316L
```

Order code for "Process connection", option AFS/AGS/NFS/NGS

DN	А	В	С	D	E 1)	F	G	K (D <sub>i</sub> )	L <sup>2)</sup>	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
100 5)	107.3	60	47.3	79.1	273.5	352.6	94.5	97.2	65	157.2
150	107.3	60	47.3	108.5	300.3	408.8	94.5	146.3	65	215.9

1) For high-temperature/low-temperature version: values +29 mm

2) ±0.5 mm

3) Not available for JIS B2220, 10K

4) EN (DIN), ASME

5) JIS

#### Accessories

Flow conditioner



Jsed in combination with flanges similar to DIN EN 1092-1: PN 10 1.4404 (316, 316L) Drder code for "Accessory enclosed", option PF								
DN [mm]	Centering diameter [mm]	D1 <sup>1)</sup> /D2 <sup>2)</sup>	s [mm]					
15	54.3	D2	2.0					
25	74.3	D1	3.5					
40	95.3	D1	5.3					
50	110.0	D2	6.8					
80	145.3	D2	10.1					
100	165.3	D2	13.3					
150	221.0	D2	20.0					

1) The flow conditioner is fitted at the outer diameter between the bolts.

Used in combination with flanges similar to DIN EN 1092-1: PN 16 1.4404 (316, 316L) Order code for "Accessory enclosed", option PF								
DN [mm]	Centering diameter [mm]	D1 <sup>1)</sup> /D2 <sup>2)</sup>	s [mm]					
15	54.3	D2	2.0					
25	74.3	D1	3.5					
40	95.3	D1	5.3					
50	110.0	D2	6.8					
80	145.3	D2	10.1					
100	165.3	D2	13.3					
150	221.0	D2	20.0					

1) The flow conditioner is fitted at the outer diameter between the bolts.

2) The flow conditioner is fitted at the indentations between the bolts.

Used in combination with flanges similar to DIN EN 1092-1: PN 25 1.4404 (316, 316L) Order code for "Accessory enclosed", option PF								
DN [mm]	Centering diameter [mm]	D1 <sup>1)</sup> /D2 <sup>2)</sup>	s [mm]					
15	54.3	D2	2.0					
25	74.3	D1	3.5					
40	95.3	D1	5.3					
50	110.0	D2	6.8					
80	145.3	D2	10.1					
100 171.3 D1 13.3								
150	227.0	D2	20.0					

1) The flow conditioner is fitted at the outer diameter between the bolts.

2) The flow conditioner is fitted at the indentations between the bolts.

Used in combination with flanges similar to DIN EN 1092-1: PN 40 1.4404 (316, 316L) Order code for "Accessory enclosed", option PF									
DN [mm]	Centering diameter [mm]	D1 <sup>1)</sup> /D2 <sup>2)</sup>	s [mm]						
15	54.3	D2	2.0						
25	74.3	D1	3.5						
40	95.3	D1	5.3						
50	110.0	D2	6.8						
80	145.3	D2	10.1						
100	171.3	D1	13.3						
150	227.0	D2	20.0						

1) The flow conditioner is fitted at the outer diameter between the bolts.

#### Used in combination with flanges similar to ASME B16.5: Class 150 1.4404 (316, 316L) Order code for "Accessery enclosed", entire PE

Order code for "Acc	cessory enclosed", option PF		
DN [mm]	Centering diameter [mm]	D1 <sup>1)</sup> /D2 <sup>2)</sup>	s [mm]
15	50.1	D1	2.0
25	69.2	D2	3.5
40	88.2	D2	5.3
50	106.6	D2	6.8
80	138.4	D1	10.1
100	176.5	D2	13.3
150	223.5	D1	20.0

1) The flow conditioner is fitted at the outer diameter between the bolts.

2) The flow conditioner is fitted at the indentations between the bolts.

## Used in combination with flanges similar to ASME B16.5: Class 300 1.4404 (316, 316L)

Order code for "Accessory enclosed", option PF

DN [mm]	Centering diameter [mm]	D1 <sup>1)</sup> /D2 <sup>2)</sup>	s [mm]
15	56.5	D1	2.0
25	74.3	D1	3.5
40	97.7	D2	5.3
50	113.0	D1	6.8
80	151.3	D1	10.1
100	182.6	D1	13.3
150	252.0	D1	20.0

1) The flow conditioner is fitted at the outer diameter between the bolts.

2) The flow conditioner is fitted at the indentations between the bolts.

Used in combination with flanges similar to JIS B2220: 10K 1.4404 (316, 316L) Order code for "Accessory enclosed", option PF									
DN [mm]	Centering diameter [mm]	D1 <sup>1)</sup> /D2 <sup>2)</sup>	s [mm]						
15	60.3	D2	2.0						
25	76.3	D2	3.5						
40	91.3	D2	5.3						
50	106.6	D2	6.8						
80	136.3	D2	10.1						
100	161.3	D2	13.3						
150	221.0	D2	20.0						

1) The flow conditioner is fitted at the outer diameter between the bolts.

Used in combination with flanges similar to JIS B2220: 20K 1.4404 (316, 316L) Order code for "Accessory enclosed", option PF									
DN [mm]	Centering diameter [mm]	D1 <sup>1)</sup> /D2 <sup>2)</sup>	s [mm]						
15	60.3	D2	2.0						
25	76.3	D2	3.5						
40	91.3	D2	5.3						
50	106.6	D2	6.8						
80	142.3	D1	10.1						
100	167.3	D1	13.3						
150	240.0	D1	20.0						

1) The flow conditioner is fitted at the outer diameter between the bolts.

2) The flow conditioner is fitted at the indentations between the bolts.

Dimensions in US units

Pay attention to the information on diameter mismatch correction  $\rightarrow \square$  41.

#### **Compact version**

i

Order code for "Housing", option B "GT18, two-chamber, 316L, compact"; option C "GT20, two-chamber, aluminum, coated, compact"



Intermediate flange similar to:

- EN 1092-1-B1 (DIN 2501): PN 10/16/25/40
- ASME B16.5: Class 150/300, Schedule 40

• JIS B2220: 10/20K, Schedule 40

1.4404/F316/F316L

Order code for "Process connection", option DDS/DES/D1S/D2S/AAS/ABS/NDS/NES

DN	A 1)	В	C 1)	D	E <sup>2)3)</sup>	F <sup>2)3)</sup>	G	Н	4)	K (D <sub>i</sub> )	L <sup>5)</sup>	М
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
1/2	5.52	2.04	3.48	0.92	9.94	10.9	6.3	2.29	4	0.65	2.56	1.77
1	5.52	2.04	3.48	1.28	10.3	11.6	6.3	2.29	4	1.09	2.56	2.52
1 ½	5.52	2.04	3.48	1.63	10.6	12.3	6.3	2.29	4	1.65	2.56	3.23
2	5.52	2.04	3.48	1.83	10.9	12.8	6.3	2.29	4	2.11	2.56	3.62
3	5.52	2.04	3.48	2.52	11.5	14	6.3	2.29	4	3.16	2.56	5

#### Intermediate flange similar to:

- EN 1092-1-B1 (DIN 2501): PN 10/16/25/40
- ASME B16.5: Class 150/300, Schedule 40
- JIS B2220: 10/20K, Schedule 40

#### 1.4404/F316/F316L

Order code for "Process connection", option DDS/DES/D1S/D2S/AAS/ABS/NDS/NES

DN	A 1)	В	C 1)	D	E <sup>2)3)</sup>	F <sup>2)3)</sup>	G	Н	4)	K (D <sub>i</sub> )	L <sup>5)</sup>	М
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
4	5.52	2.04	3.48	3.11	12	15.1	6.3	2.29	4	4.13	2.56	6.19
6	5.52	2.04	3.48	4.27	13	17.3	6.3	2.29	4	6.17	2.56	8.5

1) For version with overvoltage protection: values + 0.31 in

2) For version without local display: values - 0.39 in

3) For high-temperature/low-temperature version: values + 1.14 in

4) For version without local display: values - 0.28 in

5) ±0.02 in

Intermediate flange similar to:

ASME B16.5: Class 150/300, Schedule 80

JIS B2220: 10/20K, Schedule 80

1.4404/F316/F316L

Order code for "Process connection", option AFS/AGS/NFS/NGS

DN	A 1)	В	С	D	E <sup>2)3)</sup>	F	G	Н	4)	K (D <sub>i</sub> )	L <sup>5)</sup>	М
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
1/2	5.52	2.04	3.48	0.92	9.94	10.9	6.3	2.29	4	0.55	2.56	1.77
1	5.52	2.04	3.48	1.28	10.3	11.6	6.3	2.29	4	0.96	2.56	2.52
1 1/2	5.52	2.04	3.48	1.63	10.6	12.3	6.3	2.29	4	1.5	2.56	3.23
2	5.52	2.04	3.48	1.83	10.9	12.8	6.3	2.29	4	1.94	2.56	3.62
3	5.52	2.04	3.48	2.52	11.5	14	6.3	2.29	4	2.9	2.56	5
4	5.52	2.04	3.48	3.11	12	15.1	6.3	2.29	4	3.83	2.56	6.19
6	5.52	2.04	3.48	4.27	13	17.3	6.3	2.29	4	5.76	2.56	8.5

1) For version with overvoltage protection: values + 0.31 in

2) For version without local display: values - 0.39 in

3) For high-temperature/low-temperature version: values + 1.14 in

4) For version without local display: values - 0.28 in

5) ±0.02 in

#### Transmitter remote version

Order code for "Housing", option J "GT20 dual compartment, aluminum, coated, remote"; option K "GT18 dual compartment, 316L, remote"



A 1)	В	C 1)	F <sup>2)</sup>	G <sup>3)</sup>	Q	T <sup>3)</sup>
[in]	[in]	[in]	[in]	[in]	[in]	[in]
5.52	2.04	3.48	10	6.3	4.21	7.52

1) For version with overvoltage protection: value + 0.31 in

2) For version without local display: value - 0.39 in

3) For version without local display: value - 0.28 in

#### Sensor remote version

Order code for "Housing", option J "GT20 dual compartment, aluminum, coated, remote"; option K "GT18 dual compartment, 316L, remote"



#### Intermediate flange similar to:

- EN 1092-1-B1 (DIN 2501): PN 10/16/25/40
- ASME B16.5: Class 150/300, Schedule 40
- JIS B2220: 10/20K, Schedule 40

#### 1.4404/F316/F316L

#### Order code for "Process connection", option DDS/DES/D1S/D2S/AAS/ABS/NDS/NES

DN	A	В	С	D	E 1)	F <sup>1)</sup>	G	K (D <sub>i</sub> )	L <sup>2)</sup>	М
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
1/2	4.22	2.36	1.86	0.92	8.77	9.69	3.72	0.65	2.56	1.77
1	4.22	2.36	1.86	1.28	9.15	10.4	3.72	1.09	2.56	2.52
1 1⁄2	4.22	2.36	1.86	1.63	9.48	11.1	3.72	1.65	2.56	3.23
2	4.22	2.36	1.86	1.83	9.76	11.6	3.72	2.11	2.56	3.62
3	4.22	2.36	1.86	2.52	10.3	12.8	3.72	3.16	2.56	5
4	4.22	2.36	1.86	3.11	10.8	13.9	3.72	4.13	2.56	6.19
6	4.22	2.36	1.86	4.27	11.8	16.1	3.72	6.17	2.56	8.5

1) For high-temperature/low-temperature version: values + 1.14 in

2) ±0.02 in

- ASME B16.5: Class 150/300, Schedule 80
- JIS B2220: 10/20K, Schedule 80

1.4404/F316/F316L

Order code for "Process connection", option AFS/AGS/NFS/NGS

DN	A	В	С	D	E 1)	F	G	K (D <sub>i</sub> )	L <sup>2)</sup>	м
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
1/2	4.22	2.36	1.86	0.92	8.77	9.69	3.72	0.55	2.56	1.77
1	4.22	2.36	1.86	1.28	9.15	10.4	3.72	0.96	2.56	2.52
1 1/2	4.22	2.36	1.86	1.63	9.48	11.1	3.72	1.5	2.56	3.23
2	4.22	2.36	1.86	1.83	9.76	11.6	3.72	1.94	2.56	3.62
3	4.22	2.36	1.86	2.52	10.3	12.8	3.72	2.9	2.56	5
4	4.22	2.36	1.86	3.11	10.8	13.9	3.72	3.83	2.56	6.19
6	4.22	2.36	1.86	4.27	11.8	16.1	3.72	5.76	2.56	8.5

1) For high-temperature/low-temperature version: values + 1.14 in

2) ±0.02 in

#### Accessories

Flow conditioner



		1) 2)	
DN [in]	Centering diameter [in]	D1 <sup>1</sup> /D2 <sup>2</sup>	s [in]
1/2	1.97	D1	0.08
1	2.72	D2	0.14
11/2	3.47	D2	0.21
2	4.09	D2	0.27
3	5.45	D1	0.40
4	6.95	D2	0.52
6	8.81	D1	0.79

1) The flow conditioner is fitted at the outer diameter between the bolts.

Used in combination with flanges similar to ASME B16.5: Class 300 1.4404 (316, 316L) Order code for "Accessory enclosed", option PF			
DN [in]	Centering diameter [in]	D1 <sup>1)</sup> /D2 <sup>2)</sup>	s [in]
1/2	2.22	D1	0.08
1	2.93	D1	0.14
1½	3.85	D2	0.21
2	4.45	D1	0.27
3	5.96	D1	0.40
4	7.19	D1	0.52
6	9.92	D1	0.79

1) The flow conditioner is fitted at the outer diameter between the bolts.

2) The flow conditioner is fitted at the indentations between the bolts.

#### Weight

#### **Compact version**

Weight data:

- Including the transmitter:
  - Order code for "Housing", option C "GT20, two-chamber, aluminum, coated, compact" 1.8 kg (4.0 lb):
  - Order code for "Housing", option B "GT18 two-chamber, 316L, compact"4.5 kg (9.9 lb):
- Excluding packaging material

Weight in SI units

DN	Weight [kg]		
[mm]	Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact" <sup>1)</sup>	Order code for "Housing", option B "GT18 two-chamber, 316L, compact" <sup>1)</sup>	
15	3.1	5.8	
25	3.3	6.0	
40	3.9	6.6	
50	4.2	6.9	
80	5.6	8.3	
100	6.6	9.3	
150	9.1	11.8	

1) For high-temperature/low-temperature version: values + 0.2 kg

#### Weight in US units

DN	Weight [lbs]		
[in]	Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact" <sup>1)</sup>	Order code for "Housing", option B "GT18 two-chamber, 316L, compact" <sup>1)</sup>	
1/2	6.9	12.9	
1	7.4	13.3	
11/2	8.7	14.6	
2	9.4	15.3	
3	12.4	18.4	

DN	DN Weight [lbs]		
[in]	Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact" <sup>1)</sup>	Order code for "Housing", option B "GT18 two-chamber, 316L, compact" <sup>1)</sup>	
4	14.6	20.6	
6	20.2	26.1	

1) For high-temperature/low-temperature version: values +0.4 lbs

#### Transmitter remote version

#### Wall-mount housing

Dependent on the material of wall-mount housing:

- Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote"2.4 kg (5.2 lb):
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote"6.0 kg (13.2 lb):

#### Sensor remote version

Weight data:

- Including sensor connection housing:
  - Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote"0.8 kg (1.8 lb):
  - Order code for "Housing", option K "GT18 two-chamber, 316L, remote"2.0 kg (4.4 lb):
- Excluding the connecting cable
- Excluding packaging material

#### Weight in SI units

DN	Weight [kg]		
[mm]	sensor connection housing Order code for "Housing", option J "GT20 two-chamber, aluminum, coated, remote" <sup>1)</sup>	sensor connection housing Order code for "Housing", option K "GT18 two-chamber, 316L, remote" <sup>1)</sup>	
15	2.1	3.3	
25	2.3	3.5	
40	2.9	4.1	
50	3.2	4.4	
80	4.6	5.8	
100	5.6	6.8	
150	8.1	9.3	

1) For high-temperature/low-temperature version: values + 0.2 kg

#### Weight in US units

DN	Weight [lbs]		
[in]	sensor connection housing Order code for "Housing", option J "GT20 two-chamber, aluminum, coated, remote" <sup>1)</sup>	sensor connection housing Order code for "Housing", option K "GT18 two-chamber, 316L, remote" <sup>1)</sup>	
1/2	4.5	7.3	
1	5.0	7.8	
1½	6.3	9.1	
2	7.0	9.7	
3	10.0	12.8	

DN	Weight [lbs]	
[in]	sensor connection housing Order code for "Housing", option J "GT20 two-chamber, aluminum, coated, remote" <sup>1)</sup>	sensor connection housing Order code for "Housing", option K "GT18 two-chamber, 316L, remote" <sup>1)</sup>
4	12.3	15.0
6	17.3	20.5

1) For high-temperature/low-temperature version: values +0.4 lbs

#### Accessories

Flow conditioner

Weight in SI units

DN <sup>1)</sup> [mm]	Pressure rating	Weight [kg]
15	PN 10 to 40	0.04
25	PN 10 to 40	0.1
40	PN 10 to 40	0.3
50	PN 10 to 40	0.5
80	PN 10 to 40	1.4
100	PN10 to 40	2.4
150	PN 10/16 PN 25/40	6.3 7.8

#### 1) EN (DIN)

DN <sup>1)</sup> [mm]	Pressure rating	Weight [kg]
15	Class 150 Class 300	0.03 0.04
25	Class 150 Class 300	0.1
40	Class 150 Class 300	0.3
50	Class 150 Class 300	0.5
80	Class 150 Class 300	1.2 1.4
100	Class 150 Class 300	2.7
150	Class 150 Class 300	6.3 7.8

1) ASME

DN <sup>1)</sup> [mm]	Pressure rating	Weight [kg]
15	20К	0.06
25	20К	0.1
40	20K	0.3

DN <sup>1)</sup> [mm]	Pressure rating	Weight [kg]
50	10K 20K	0.5
80	10K 20K	1.1
100	10K 20K	1.80
150	10K 20K	4.5 5.5

1) JIS

Weight in US units

DN <sup>1)</sup> [in]	Pressure rating	Weight [lbs]
1/2	Class 150 Class 300	0.07 0.09
1	Class 150 Class 300	0.3
1½	Class 150 Class 300	0.7
2	Class 150 Class 300	1.1
3	Class 150 Class 300	2.6 3.1
4	Class 150 Class 300	6.0
6	Class 150 Class 300	14.0 16.0

1) ASME

Materials

#### Transmitter housing

Compact version

- Order code for "Housing", option B "GT18 two-chamber, 316L, compact": Stainless steel, CF3M
- Order code for "Housing", option C "GT20, two-chamber, aluminum, coated, compact": Aluminum, AlSi10Mg, coated
- Window material: glass

Remote version

- Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote": Aluminum, AlSi10Mg, coated
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote": For maximum corrosion resistance: Stainless steel, CF3M
- Window material: glass

#### Cable entries/cable glands



#### 19 Possible cable entries/cable glands

- 1 Internal thread M20 × 1.5
- 2 Cable gland  $M20 \times 1.5$
- 3 Adapter for cable entry with internal thread G <sup>1</sup>/<sub>2</sub>" or NPT <sup>1</sup>/<sub>2</sub>"
- 4 Device plug

Order code for "Housing", option B "GT18 dual compartment, 316L, compact" option K "GT18 dual compartment, 316L, remote"

Cable entry/cable gland	Type of protection	Material
Cable gland M20 × 1.5	<ul> <li>Non-hazardous area</li> <li>Ex ia</li> <li>Ex ic</li> <li>Ex nA, Ex ec</li> <li>Ex tb</li> </ul>	Stainless steel ,1.4404
Adapter for cable entry with internal thread G ½"	Non-hazardous area and hazardous area (except for XP)	Stainless steel, 1.4404 (316L)
Adapter for cable entry with internal thread NPT ½"	Non-hazardous area and hazardous area	

Order code for "Housing": option C "GT20 dual compartment, aluminum, coated, compact", option J "GT20 dual compartment, aluminum, coated remote"

Cable entry/cable gland	Type of protection	Material
Cable gland M20 × 1.5	<ul><li>Non-hazardous area</li><li>Ex ia</li><li>Ex ic</li></ul>	Plastic
	Adapter for cable entry with internal thread G ½"	Nickel-plated brass
Adapter for cable entry with internal thread NPT ½"	Non-hazardous area and hazardous area (except for XP)	Nickel-plated brass
Thread NPT ½" via adapter	Non-hazardous area and hazardous area	

#### Connecting cable for remote version

- Standard cable: PVC cable with copper shield
- Reinforced cable: PVC cable with copper shield and additional steel wire braided jacket

#### Sensor connection housing

The material of the sensor connection housing is dependent on the material selected for the transmitter housing.

- Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote": Coated aluminum AlSi10Mg
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote": Stainless cast steel, 1.4408 (CF3M)
  - Compliant with:
  - NACE MR0175
  - NACE MR0103

#### Measuring tubes

DN 15 to 150 (½ to 6"), pressure ratingsPN 10/16/25/40, Class 150/300 , and JIS 10K/20K • Stainless cast steel, CF3M/1.4408

- Complies with:
  - NACE MR0175-2003
  - NACE MR0103-2003

#### DSC sensor

Order code for "Sensor version; DSC sensor; measuring tube", option AA, BA, CA

#### Pressure ratings PN 10/16/25/40, Class 150/300, as well as JIS 10K/20K:

Parts in contact with medium (marked as "wet" on the DSC sensor flange):

Stainless steel 1.4404 and 316 and 316L

- Compliant with:
  - NACE MR0175/ISO 15156-2015
  - NACE MR0103/ISO 17945-2015

Parts not in contact with medium: Stainless steel 1.4301 (304)

#### Seals

- Graphite
- Sigraflex foil Z<sup>TM</sup> (BAM-certified for oxygen applications)
- FPM (Viton<sup>TM</sup>)
- Kalrez 6375<sup>TM</sup>
- Gylon 3504<sup>TM</sup> (BAM-certified for oxygen applications)

#### Housing support

Stainless steel, 1.4408 (CF3M)

#### Screws for DSC sensor

- Order code for "Sensor version", option AA "Stainless steel, A4-80 according to ISO 3506-1 (316)"
- Order code for "Sensor version", option BA, CA Stainless steel, A2 as per ISO 3506-1 (304)

#### Accessories

#### Protective cover

Stainless steel, 1.4404 (316L)

#### Flow conditioner

- Stainless steel, multiple certifications, 1.4404 (316, 316L)
- Compliant with:
  - NACE MR0175-2003
  - NACE MR0103-2003

Operating concept	Operator-oriented menu structure for user-specific tasks <ul> <li>Commissioning</li> <li>Operation</li> <li>Diagnostics</li> <li>Expert level</li> </ul>			
	<ul> <li>Quick and safe commissioning</li> <li>Guided menus ("Make-it-run" wizards) for applications</li> <li>Menu guidance with brief descriptions of the individual parameter functions</li> </ul>			
	<ul> <li>Reliable operation</li> <li>Operation in the following languages: <ul> <li>Via local display:</li> <li>English, German, French, Spanish, Italian, Portuguese, Polish, Russian, Turkish, Chinese, Bahasa (Indonesian)</li> <li>Via "FieldCare" operating tool:</li> <li>English, German, French, Spanish, Italian, Chinese</li> </ul> </li> <li>Uniform operating philosophy applied to device and operating tools</li> <li>If replacing the electronic module, transfer the device configuration via the integrated memory (integrated HistoROM) which contains the process and measuring device data. No need to reconfigure.</li> </ul>			
	<ul> <li>Efficient diagnostic behavior increases measure</li> <li>Troubleshooting measures can be called up via t</li> <li>Diverse simulation options for events that occur</li> </ul>	ement availability he device and in the operating tools and optional line recorder functions		
Languages	<ul> <li>Can be operated in the following languages:</li> <li>Via local display: English, German, French, Spanish, Italian, Portuguese, Polish, Russian, Turkish, Chinese, Bahasa (Indonesian)</li> <li>Via "FieldCare" operating tool: English, German, French, Spanish, Italian, Chinese</li> </ul>			
Onsite operation	Via display module			
	Two display modules are available:			
	Order code for "Display; Operation", option C "SD02"	Order code for "Display; Operation", option E "SD03"		

## Operability

A0032219 A0032221 1 1 Operation with pushbuttons Operation with touch control

Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
  Format for displaying measured variables and status variables can be individually configured

#### **Operating elements**

■ Operation with 3 push buttons with open housing: +, , , ,

or

- External operation via touch control (3 optical keys) without opening the housing: 🗄, 🖃, 🗉
- Operating elements also accessible in the various zones of the hazardous area

#### Additional functionality

- Data backup function
- The device configuration can be saved in the display module.
- Data comparison function
- The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function
  - The transmitter configuration can be transmitted to another device using the display module.

#### Via remote display FHX50

The remote display FHX50 can be ordered as an optional extra  $\rightarrow \square$  77.



☑ 20 FHX50 operating options

- 1 SD02 display and operating module, push buttons: cover must be opened for operation
- 2 SD03 display and operating module, optical buttons: operation possible through cover glass

#### Display and operating elements

The display and operating elements correspond to those of the display module .

**Remote operation** 

#### Via HART protocol

This communication interface is available in device versions with a HART output.



21 Options for remote operation via HART protocol (passive)

- 1 Automation system (e.g. PLC)
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- 3 Connection for Commubox FXA195 and Field Communicator 475
- 4 Field Communicator 475
- 5 Computer with Web browser (e.g. Internet Explorer) for accessing computers with an operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, AMS TREX Device Communicator, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 6 Commubox FXA195 (USB)
- 7 Field Xpert SFX350 or SFX370
- 8 Field Xpert SMT50 (or 70 or 77)
- 9 VIATOR Bluetooth modem with connecting cable
- 10 Transmitter

#### Via PROFIBUS PA network

This communication interface is available in device versions with PROFIBUS PA.



■ 22 Options for remote operation via PROFIBUS PA network

- 1 Automation system
- 2 Computer with PROFIBUS network card
- 3 PROFIBUS DP network
- 4 Segment coupler PROFIBUS DP/PA
- 5 PROFIBUS PA network
- 6 T-box
- 7 Measuring instrument

#### Via FOUNDATION Fieldbus network

This communication interface is available in device versions with FOUNDATION Fieldbus.



23 Options for remote operation via FOUNDATION Fieldbus network

- 1 Automation system
- 2 Computer with FOUNDATION Fieldbus network card
- 3 Industry network
- 4 High Speed Ethernet FF-HSE network
- 5 Segment coupler FF-HSE/FF-H1
- 6 FOUNDATION Fieldbus FF-H1 network
- 7 Power supply FF-H1 network
- 8 T-box
- 9 Measuring instrument

#### Service interface

#### Via service interface (CDI)



- 1 Service interface (CDI = Endress+Hauser Common Data Interface) of the measuring instrument
- 2 Commubox FXA291
- 3 Computer with operating tool (e.g. FieldCare or DeviceCare) and (CDI) DeviceDTM

#### Via PROFINET over Ethernet-APL/SPE 10 Mbit/s



- 1 Automation system, e.g. Simatic S7 (Siemens)
- 2 Ethernet Switch, e.g. Scalance X204 (Siemens)
- 3 Computer with operating tool (e.g. FieldCare or DeviceCare) and (CDI) DeviceDTM
- 4 Ethernet cable with RJ45 plug
- 5 APL field switch
- 6 2-wire fieldbus cable type A
- 7 Measuring instrument

## Supported operating tools Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

Supported operating tools	Operating unit	Interface	Additional information
DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows system	CDI service interface	→ 🗎 79
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	CDI service interface	→ 🗎 79
Field Xpert	SMT70/77/50	CDI service interface	Operating Instructions BA01202S
			Device description files: Use update function of handheld terminal

# Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:

- FactoryTalk AssetCentre (FTAC) from Rockwell Automation → www.rockwellautomation.com
- Process Device Manager (PDM) from Siemens → www.siemens.com
- Asset Management Solutions (AMS) from Emerson  $\rightarrow$  www.emersonprocess.com
- FieldCommunicator 375/475 from Emerson → www.emersonprocess.com
- Emersons TREX → www.emerson.com
- Field Device Manager (FDM) from Honeywell  $\rightarrow$  www.process.honeywell.com
- FieldMate from Yokogawa → www.yokogawa.com
- PACTWare → www.pactware.com

The related device description files are available: www.endress.com  $\rightarrow$  Download Area
#### Web server

With the integrated Web server, the device can be operated and configured via a Web browser and PROFINET over Ethernet-APL. In addition to the measured values, status information on the device is displayed and can be used to monitor device health. Furthermore the device data can be managed and the network parameters can be configured.

Access to the network is required for the APL connection.

#### Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring instrument:

- Upload the configuration from the measuring instrument (XML format, configuration backup)
- Save the configuration to the measuring instrument (XML format, restore configuration)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Download driver (GSD) for system integration

Special Documentation for Web server

# **Certificates and approvals**

Current certificates and approvals for the product are available at <u>www.endress.com</u> on the relevant product page:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select **Downloads**.

CE mark	The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.		
	Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.		
UKCA marking	The device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards. By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.		
	Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com		
RCM marking	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".		
Ex approval	The measuring device is certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.		
	The separate Ex documentation (XA) containing all the relevant explosion protection data is available from your Endress+Hauser sales center.		
Functional safety	The measuring instrument can be used for flow monitoring systems (min., max., range) up to SIL 2 (single-channel architecture; order code for "Additional approval", option LA) and SIL 3 (multi- channel architecture with homogeneous redundancy) and is independently evaluated and certified in accordance with IEC 61508.		
	The following types of monitoring in safety equipment are possible:		
	Functional safety manual with information for the SIL device		

HART certification	HART interface			
	<ul> <li>The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:</li> <li>Certified according to HART</li> <li>The device can also be operated with certified devices of other manufacturers (interoperability)</li> </ul>			
FOUNDATION Fieldbus	FOUNDATION Fieldbus interface			
certification	<ul> <li>The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:</li> <li>Certified in accordance with FOUNDATION Fieldbus H1</li> <li>Interoperability Test Kit (ITK), revision version 6.2.0 (certificate available on request)</li> <li>Physical Layer Conformance Test</li> <li>The device can also be operated with certified devices of other manufacturers (interoperability)</li> </ul>			
Certification PROFIBUS	PROFIBUS interface			
	<ul> <li>The measuring device is certified and registered by the PNO (PROFIBUS Nutzerorganisation e.V./PROFIBUS User Organization). The measuring system meets all the requirements of the following specifications:</li> <li>Certified according to PA Profile 3.02</li> <li>The device can also be operated with certified devices of other manufacturers (interoperability)</li> </ul>			
PROFINET over Ethernet-	PROFINET interface			
APL certification	<ul> <li>The measuring instrument is certified and registered by the PROFIBUS Nutzerorganisation e.V. (PNO). The measuring system meets all the requirements of the following specifications:</li> <li>Certified according to: <ul> <li>Test specification for PROFINET devices</li> <li>PROFINET PA Profile 4.02</li> <li>PROFINET Netload Robustness Class 2 10 Mbit/s</li> <li>APL conformance test</li> </ul> </li> <li>The device can also be operated with certified devices of other manufacturers (interoperability)</li> <li>The device supports PROFINET S2 system redundancy.</li> </ul>			
Pressure Equipment Directive	The measuring devices can be ordered with or without PED or PESR. If a device with PED or PESR is required, this must be ordered explicitly. A UK order option must be selected for PESR under the order code for "Approvals".			
	<ul> <li>With the marking <ul> <li>a) PED/G1/x (x = category) or</li> <li>b) PESR/G1/x (x = category)</li> <li>on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" <ul> <li>a) specified in Annex I of the Pressure Equipment Directive 2014/68/EU or</li> <li>b) Schedule 2 of Statutory Instruments 2016 No. 1105.</li> </ul> </li> <li>Devices bearing this marking (PED or PESR) are suitable for the following types of medium: Media in Group 1 and 2 with a vapor pressure greater than, or smaller and equal to 0.5 bar (7.3 psi)</li> <li>Devices not bearing this marking (without PED or PESR) are designed and manufactured according to sound engineering practice. They meet the requirements of <ul> <li>a) Art. 4 Para. 3 of the Pressure Equipment Directive 2014/68/EU or</li> <li>b) Part 1, Para. 8 of Statutory Instruments 2016 No. 1105.</li> </ul> </li> <li>The scope of application is indicated <ul> <li>a) in diagrams 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU or</li> <li>b) Schedule 3, Para. 2 of Statutory Instruments 2016 No. 1105.</li> </ul> </li> </ul></li></ul>			
Experience	The Prowirl 200 measuring system is the successor model of the Prowirl 72 and Prowirl 73.			

External standards and guidelines	<ul> <li>EN 60529 Degrees of protection provided by enclosure (IP code)</li> <li>DIN ISO 13359 Measurement of conductive liquid flow in closed conduits - Flanged-type electromagnetic flowmeters - Overall length</li> <li>ISO 12764:2017 Measurement of fluid flow in closed conduits – Flow rate measurement by means of vortex shedding flowmeters inserted in circular cross-section conduits running full</li> <li>EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements</li> <li>EN 61326-1/-2-3 EMC requirements for electrical equipment for measurement, control and laboratory use</li> <li>NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment</li> <li>NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors</li> <li>NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.</li> <li>NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics</li> <li>NAMUR NE 107 Self-monitoring and diagnosis of field devices</li> <li>NAMUR NE 131 Requirements for field devices for standard applications</li> <li>ETSI EN 300 328 Guidelines for 2.4 GHz radio components.</li> <li>EN 301489 Electromagnetic compatibility and radio spectrum matters (ERM).</li> </ul>
	<ul> <li>Ordering information</li> <li>Detailed ordering information is available from your nearest sales organization</li> <li>www.addresses.endress.com or in the Product Configurator at www.endress.com:</li> <li>Select the product using the filters and search field.</li> <li>Open the product page.</li> </ul>
	3. Select <b>Configuration</b> .  Product Configurator - the tool for individual product configuration

- Up-to-the-minute configuration data
  Depending on the device: direct input of information specific to the measuring point, such as the measuring range or operating language
  - Automatic verification of exclusion criteria
  - Automatic creation of the order code and its breakdown in PDF or Excel output format
  - Ability to order directly in the Endress+Hauser Online Shop

Product generation index	Release date	Product root	Change
	01.09.2013	7D2B	TI01083D
	01.11.2017	7D2C	TI01332D
	01.09.2025	7D2C	TI01332D

More information is available from your Sales Center or at:

www.service.endress.com  $\rightarrow$  Downloads

# **Application packages**

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Detailed information on the application packages: Special Documentation  $\rightarrow \cong 81$ 

Diagnostic functionality	Order code for "Application package", option EA "Extended HistoROM"			
	Comprises extended functions concerning the event log and the activation of the measured value memory.			
	Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.			
	<ul> <li>Data logging (line recorder):</li> <li>Memory capacity for up to 1000 measured values is activated.</li> <li>250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.</li> <li>Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.</li> </ul>			
	For detailed information, see the Operating Instructions for the device.			
Heartbeat Technology	Order code for "Application package", option EB "Heartbeat Verification"			
	<ul> <li>Heartbeat Verification</li> <li>Meets the requirement for traceable verification in accordance with DIN ISO 9001:2008</li> <li>Clause 7.6 a) "Control of monitoring and measuring equipment".</li> <li>Functional testing in the installed state without interrupting the process.</li> <li>Traceable verification results on request, including a report.</li> <li>Simple testing process via local operation or other operating interfaces.</li> <li>Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications.</li> <li>Extension of calibration intervals according to operator's risk assessment.</li> </ul>			
	Detailed information on Heartbeat Technology: Special Documentation → <a>B1</a>			

# Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

# Device-specific accessories

# For the transmitter

Accessories	Description			
Prowirl 200 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications: <ul> <li>Approvals</li> <li>Output, input</li> <li>Display/operation</li> <li>Housing</li> <li>Software</li> </ul> <li>Installation Instructions EA01056D</li> <li>(Order number: 7X2CXX)</li>			
Remote display FHX50	<ul> <li>FHX50 housing for accommodating a display module .</li> <li>FHX50 housing suitable for: <ul> <li>SD02 display module (push buttons)</li> </ul> </li> </ul>			
	<ul> <li>SD03 display module (touch control)</li> <li>Length of connecting cable: up to max. 60 m (196 ft) (cable lengths available for order: 5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft))</li> </ul>			
	<ul> <li>The measuring instrument can be ordered with the FHX50 housing and a display module. The following options must be selected in the separate order codes:</li> <li>Order code for measuring instrument, feature 030: Option L or M "Prepared for FHX50 display"</li> <li>Order code for FHX50 housing, feature 050 (device version):</li> </ul>			
	<ul> <li>Option A "Prepared for FHX50 display"</li> <li>Order code for FHX50 housing, depends on the desired display module in feature 020 (display, operation):</li> <li>Option C: for an SD02 display module (push buttons)</li> <li>Option E: for an SD03 display module (touch control)</li> </ul>			
	<ul> <li>The FHX50 housing can also be ordered as a retrofit kit. The measuring instrument display module is used in the FHX50 housing. The following options must be selected in the order code for the FHX50 housing:</li> <li>Feature 050 (measuring instrument version): option B "Not prepared for FHX50 display"</li> <li>Feature 020 (display, operation): option A "None, existing displayed used"</li> </ul>			
	Special Documentation SD01007F			
	(Order number: FHX50)			
Overvoltage protection for 2-wire devices	Ideally, the overvoltage protection module should be ordered directly with the device. See product structure, feature 610 "Accessory mounted", option NA "Overvoltage protection". Separate order necessary only if retrofitting.			
	<ul> <li>OVP10: For 1-channel devices (feature 020, option A):</li> <li>OVP20: For 2-channel devices (feature 020, options B, C, E or G)</li> </ul>			
	Special Documentation SD01090F			
	(Order number OVP10: 71128617) (Order number OVP20: 71128619)			
Overvoltage protection for 2-wire devices	The use of an external overvoltage protection, e.g. HAW 569, is recommended.			
Protective cover	The protective cover is used to protect against direct sunlight, precipitation and ice. It can be ordered together with the device via the product structure: Order code for "Accessories enclosed" option PB "Protective cover"			
	Special Documentation SD00333F			
	(Order number: 71162242)			
Transmitter holder (pipe mounting)	To secure the remote version to the pipe DN 20 to 80 (3/4 to 3") Order code for "Accessory enclosed", option PM			

### For the sensor

Accessories	Description		
Mounting set	Mounting set for disc (wafer version) comprising: • Tie rods • Seals • Nuts • Washers Installation Instructions EA00075D (Order number: DK7D)		
Flow conditioner	Is used to shorten the necessary inlet run. (Order number: DK7ST) Dimensions of flow conditioner		

#### Communication-specific Accessories Description accessories Commubox FXA195 For intrinsically safe HART communication with FieldCare via the USB interface. HART Technical Information TI00404F Commubox FXA291 Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop. Technical Information TI00405C **Fi** HART loop converter Is used to evaluate and convert dynamic HART process variables to analog current HMX50 signals or limit values. Technical Information TI00429F Î Operating Instructions BA00371F Wireless HART adapter Is used for the wireless connection of field devices. SWA70 The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks with minimum cabling complexity. Operating Instructions BA00061S **Fi** Transmission of the measured values of connected 4 to 20 mA analog measuring Fieldgate FXA42 instruments, as well as digital measuring instruments Technical Information TI01297S i Operating Instructions BA01778S Product page: www.endress.com/fxa42 Field Xpert SMT50 The Field Xpert SMT50 tablet PC for device configuration enables mobile plant asset management in non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle. Technical Information TI01555S I Operating Instructions BA02053S Product page: www.endress.com/smt50

Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.
	<ul> <li>Technical Information TI01342S</li> <li>Operating Instructions BA01709S</li> <li>Product page: www.endress.com/smt70</li> </ul>
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.
	<ul> <li>Technical Information TI01418S</li> <li>Operating Instructions BA01923S</li> <li>Product page: www.endress.com/smt77</li> </ul>

Service-specific accessories	Accessories	Description	
	Applicator	<ul> <li>Software for selecting and sizing Endress+Hauser measuring instruments:</li> <li>Choice of measuring instruments for industrial requirements</li> <li>Calculation of all the necessary data for identifying the optimum flowmeter:</li> <li>e.g. nominal diameter, pressure loss, flow velocity and accuracy.</li> <li>Graphic display of the calculation results</li> <li>Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.</li> <li>Applicator is available:</li> <li>Via the Internet: https://portal.endress.com/webapn/applicator</li> </ul>	
	Netilion	lloT ecosystem: Unlock knowledge With the Netilion IIoT ecosystem,Endress+Hauser allows you to optimize your plant performance, digitize workflows, share knowledge, and enhance collaboration. Drawing upon decades of experience in process automation, Endress+Hauser offers the process industry an IIoT ecosystem designed to effortlessly extract insights from data. These insights allow process optimization, leading to increased plant availability, efficiency, and reliability - ultimately resulting in a more profitable plant. www.netilion.endress.com	
	FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all intelligent field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.	
	DeviceCare	Tool to connect and configure Endress+Hauser field devices.	

System components

Accessories	Description		
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.		
	<ul> <li>Technical Information TI00133R</li> <li>Operating Instructions BA00247R</li> </ul>		
RN221N	Active barrier with power supply for safe separation of 4-20 mA standard signal circuits. Offers bidirectional HART transmission.		
	<ul> <li>Technical Information TI00073R</li> <li>Operating Instructions BA00202R</li> </ul>		
RNS221	Supply unit for powering two 2-wire measuring devices solely in the non- hazardous area. Bidirectional communication is possible via the HART communication jacks.		
	<ul> <li>Technical Information TI00081R</li> <li>Brief Operating Instructions KA00110R</li> </ul>		

# Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
   Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
  - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

Standard documentation

Supplementary information on the semi-standard options is available in the relevant Special Documentation in the TSP database.

#### **Brief Operating Instructions**

Brief Operating Instructions for the sensor

Measuring device	Documentation code
Prowirl D 200	KA01322D

Brief Operating Instructions for the transmitter

Measuring	Documentation code			
instrument	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFINET over Ethernet-APL
Proline 200	KA01326D	KA01327D	KA01328D	KA01323D

#### **Operating Instructions**

Measuring instrument	Documentation code				
	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFINET over Ethernet-APL	Modbus TCP over Ethernet-APL
Prowirl D 200	BA01685D	BA01693D	BA01689D	BA02133D	BA02397D

### **Description of Device Parameters**

Measuring	Documentation code				
instrument	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFINET over Ethernet-APL	
Prowirl 200	GP01109D	GP01111D	GP01110D	GP01170D	

#### Supplementary deviceion

# Safety instructions

dependent (	documentati
-------------	-------------

Contents	Documentation code
ATEX/IECEx Ex d	XA01635D
ATEX/IECEx Ex ia	XA01636D
ATEX/IECEx Ex ec, Ex ic	XA01637D
<sub>C</sub> CSA <sub>US</sub> XP	XA01638D
<sub>C</sub> CSA <sub>US</sub> IS	XA01639D
EAC Ex d	XA01684D
EAC Ex ia	XA01782D
EAC Ex ec, Ex ic	XA01685D
INMETRO Ex d	XA01642D
INMETRO Ex ia	XA01640D
INMETRO Ex ec, Ex ic	XA01641D
JPN Ex d	XA01766D
NEPSI Ex d	XA01643D
NEPSI Ex ia	XA01644D
NEPSI Ex ec, Ex ic	XA01645D
UKEX Ex d	XA02630D
UKEX Ex ia	XA02631D
UKEX Ex ec, Ex ic	XA02632D

# Functional Safety Manual

Contents	Documentation code
Proline Prowirl 200	SD02025D

# **Special Documentation**

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Protective cover	SD00333F

Contents	Documentation code			
	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFINET over Ethernet-APL
Heartbeat Technology	SD02029D	SD02030D	SD02031D	SD02759D
Web server	-	-	-	SD02834D

#### Installation Instructions

Contents	Note
Installation instructions for spare part sets and accessories	Documentation code: specified for each individual accessory $\rightarrow \square$ 77.

# **Registered trademarks**

#### HART®

Registered trademark of the FieldComm Group, Austin, Texas USA

#### **PROFIBUS®**

Registered trademark of the PROFIBUS Nutzerorganisation e.V. (PROFIBUS User Organization), Karlsruhe, Germany

### FOUNDATION™ Fieldbus

Registration-pending trademark of the FieldComm Group, Austin, Texas, USA

#### Ethernet-APL™

Registered trademark of the PROFIBUS Nutzerorganisation e.V. (PROFIBUS User Organization), Karlsruhe, Germany

#### KALREZ<sup>®</sup>, VITON<sup>®</sup>

Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

#### **GYLON**<sup>®</sup>

Registered trademark of Garlock Sealing Technologies, Palmyar, NY, USA



www.addresses.endress.com

