EAC: [Ex ia Ga] IIC [Ex ia Ga] IIB

Products



Document: XA01679F-A

Safety instructions for electrical apparatus for explosion-hazardous areas $\rightarrow \square 3$

Nivotester FTC325 XA01679F-A

Nivotester FTC325

Table of contents

Associated documentation	4
Supplementary documentation	4
Manufacturer's certificates	4
Manufacturer address	4
Extended order code	4
Safety instructions: General	5
Safety instructions: Installation	6
Temperature tables	7
Connection data	7

XA01679F-A Nivotester FTC325

Associated documentation

This document is an integral part of the following Operating Instructions:

TI00380F/00, KA00221F/00

Supplementary documentation

Explosion-protection brochure: CP00021Z/11

The Explosion-protection brochure is available:

- In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Media Type: Documentation -> Documentation Type: Brochures and catalogs -> Text Search: CP00021Z
- On the CD for devices with CD-based documentation

Manufacturer's certificates

Certificate of Conformity TP TC 012/2011

Inspection authority:

NANIO CCVE (НАНИО «ЦСВЭ»)

Certificate number:

TC RU C-DE.GB05.B.00034

Affixing the certificate number certifies conformity with the following standards (depending on the device version):

- GOST R 51330.10-99 (IEC 60079-11-99)
- GOST 30852.10-2002 (IEC 60079-11:1999)

Manufacturer address

Endress+Hauser GmbH+Co. KG

Hauptstraße 1

79689 Maulburg, Germany

Address of the manufacturing plant: See nameplate.

Extended order code

The extended order code is indicated on the nameplate, which is affixed to the device in such a way that it is clearly visible. Additional information about the nameplate is provided in the associated Operating Instructions.

Structure of the extended order code

FTC325 - ********* + A*B*C*D*E*F*G*..

(Device type) (Basic specifications) (Optional specifications)

* = Placeholder

At this position, an option (number or letter) selected from the specification is displayed instead of the placeholders.

Basic specifications

The features that are absolutely essential for the device (mandatory features) are specified in the basic specifications. The number of positions depends on the number of features available. The selected option of a feature can consist of several positions.

Optional specifications

The optional specifications describe additional features for the device (optional features). The number of positions depends on the number of features available. The features have a 2-digit structure to aid identification (e.g. JA). The first digit (ID) stands for the feature group and consists of a number or a letter (e.g. J = Test, Certificate). The second digit constitutes the value that stands for the feature within the group (e.g. A = 3.1 material (wetted parts), inspection certificate).

Nivotester FTC325 XA01679F-A

More detailed information about the device is provided in the following tables. These tables describe the individual positions and IDs in the extended order code which are relevant to hazardous locations.

Extended order code: Nivotester



The following specifications reproduce an extract from the product structure and are used to assign:

- This documentation to the device (using the extended order code on the nameplate).
- The device options cited in the document.

Device type

FTC325

Basic specifications

Position 1 (Approval)			
Selected option		Description	
FTC325	8	EAC [Ex ia Ga] IIC EAC [Ex ia Ga] IIB	

Position 2 (Input; Housing)			
Gewählte Option		Beschreibung	
FTC325	1	2-wire PFM; 45mm, DIN Rail	

Position 3 (Power Supply)			
Selected option		Description	
FTC325	A	85-253 VAC	
	В	20-30 VAC / 20-60 VDC	

Position 4 (Switch Output)		
Selected option		Description
FTC325	1	1x SPDT level + 1x SPST alarm N.C. (normal closed)
	2	1x SPDT level + 1x SPST alarm N.O. (normal open)
	3	1x SPDT level + 1x SPDT alarm

Optional specifications


No options specific to hazardous locations are available.

Safety instructions: General

- Staff must meet the following conditions for mounting, electrical installation, commissioning and maintenance of the device:
 - Be suitably qualified for their role and the tasks they perform
 - Be trained in explosion protection
 - Be familiar with national regulations
- Comply with the installation and safety instructions in the Operating Instructions.
- Install the device according to the manufacturer's instructions and national regulations.
- Do not operate the device outside the specified electrical, thermal and mechanical parameters.
- Avoid electrostatic charging.


XA01679F-A Nivotester FTC325

Safety instructions: Installation



₽ 1

- 1 PFM sensor, Limit level Ex ia IIC/IIB
- 2 PFM sensor
- 3 Level relay
- 4 Fault signal relay/Level relay
- 5 Power supply



A003467

₽ 2

- A Min. 6 mm
- 1 Intrinsically safe contacts
- 2 Nivotester FTC325
- *3 Other type, other product*
- To achieve an ingress protection of at least IP55: Protect the device from dust and humidity, e.g. in control rooms, or located in a suitable protective housing.
- The device is an associated apparatus: Only use the device outside explosion hazardous areas.
- If an intrinsically safe circuit is connected to the device passes through dust explosion-hazardous areas of Zones 20 or Zone 21, make sure that the devices connected to this circuit meet the requirements of categories 1 D or 2 D and are certified accordingly.

Nivotester FTC325 XA01679F-A

- There must be a distance (thread measure) of at least 50 mm between intrinsically safe and nonintrinsically safe terminals.
- When combining the device with other types and products on the same top-hat rail: Keep the distances comply to the relevant standards and rules.
- When combining with devices from other manufacturers: Observe ingress protection of the housing.

Intrinsic safety

- Observe the pertinent guidelines when interconnecting intrinsically safe circuits.
- The intrinsically-safe input circuits are galvanically isolated from other circuits up to a peak value of the nominal voltage of 375 V.

Temperature tables

Ambient temperature range		
Individual installation	$-20^{\circ}\text{C} \le \text{T}_{\text{a}} \le +60^{\circ}\text{C}$	
Series installation	$-20^{\circ}\text{C} \le \text{T}_{\text{a}} \le +50^{\circ}\text{C}$	

Connection data

Power circuit				
Terminal connections: 1, 2	AC	$U = 85 \text{ to } 253 \text{ V}_{AC}, 50/60 \text{ Hz}$ $P \le 6.0 \text{ VA}$		
	DC	$U = 20 \text{ to } 60 \text{ V}_{DC}$ $U = 20 \text{ to } 30 \text{ V}_{AC}, 50/60 \text{ Hz}$ $P \le 2.0 \text{ W}$		

Contact circuit			
Level relay Terminal connections: 22, 23, 24	$U \leq 250~V_{AC},~I \leq 2~A,~P \leq 500~VA~at~cos~\phi \geq 0.7$ $U \leq 40~V_{DC},~I \leq 2~A,~P \leq 80~W$		
Fault signal relay Terminal connections: 15, 16	$\begin{array}{l} U \leq 250 \ V_{AC}, I \leq 2 \ A, P \leq 500 \ VA \ at \cos \phi \geq 0.7 \\ U \leq 40 \ V_{DC}, I \leq 2 \ A, P \leq 80 \ W \\ optionally \ NC \ or \ NO, \rightarrow \ \blacksquare \ 1, \ \trianglerighteq \ 6 \end{array}$		

Sensor circuit					
Terminal connections: 11, 12	Connection data	$U_o \le 13.9 \text{ V}$ $I_o \le 99 \text{ mA}$ $P_o \le 874 \text{ mW}$		$R_i \ge 391~\Omega$ $C_i = 138~nF$ $L_i = 0.13~mH$	
		Trapezium-shaped characteristic			
		[Ex ia Ga] IIC		[Ex ia Ga] IIB	
		Lo	Co	Lo	Co
	Max. external capacitance at max. external inductance Max. external capacitance or max. external inductance	0.85 mH	0.18 μF	0.85 mH	2.06 μF
		0.35 mH	0.26 µF	4.85 mH	1.06 μF
		3.50 mH	0.60 µF	14.3 mH	4.56 μF
If using explosion protection		[Ex ib Gb] IIC		[Ex ib Gb] IIB	
group [Ex ib Gb] IIC/IIB the application is limited to II (2) G		Lo	Co	Lo	Co
	Max. external capacitance or max. external inductance	3.50 mH	0.60 μF	14.3 mH	4.56 μF



www.addresses.endress.com