Safety Instructions **Micropilot FMR67**

4-20 mA HART

ATEX, IECEx: Ex ta IIIC Da

Ex ta/tb IIIC Da/Db







Micropilot FMR67

4-20 mA HART

Table of contents

About this document
Associated documentation
Supplementary documentation
Manufacturer's certificates
Manufacturer address 5
Other standards 5
Extended order code 5
Safety instructions: General
Safety instructions: Special conditions
Safety instructions: Installation
Temperature tables
Connection data

About this document



This document has been translated into several languages. Legally determined is solely the English source text.

The document translated into EU languages is available:

- In the download area of the Endress+Hauser website:
 www.endress.com -> Downloads -> Manuals and Datasheets ->
 Type: Ex Safety Instruction (XA) -> Text Search: ...
- In the Device Viewer: www.endress.com -> Product tools -> Access device specific information -> Check device features



If not yet available, the document can be ordered.

Associated documentation

This document is an integral part of the following Operating Instructions:

BA01620F/00

Supplementary documentation

Explosion-protection brochure: CP00021Z/11

The Explosion-protection brochure is available:

- In the download area of the Endress+Hauser website:
 www.endress.com -> Downloads -> Brochures and Catalogs -> Text Search: CP00021Z
- On the CD for devices with CD-based documentation

Manufacturer's certificates

EU Declaration of Conformity

Declaration Number:

EC 00477

The EU Declaration of Conformity is available: In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Declaration -> Type: EU Declaration -> Product Code: ...

EU type-examination certificate

Certificate number: IBExU16ATEX1194 X

List of applied standards: See EU Declaration of Conformity.

IEC Declaration of Conformity

Certificate number: IECEx IBE16 0035 X

Affixing the certificate number certifies conformity with the following standards (depending on the device version):

IEC 60079-0:2017IEC 60079-11:2011IEC 60079-31:2013

Manufacturer address

Endress+Hauser SE+Co. KG Hauptstraße 1 79689 Maulburg, Germany

Address of the manufacturing plant: See nameplate.

Other standards

Among other things, the following standards shall be observed in their current version for proper installation:

- IEC/EN 60079-14: "Explosive atmospheres Part 14: Electrical installations design, selection and erection"
- EN 1127-1: "Explosive atmospheres Explosion prevention and protection - Part 1: Basic concepts and methodology"

Extended order code

The extended order code is indicated on the nameplate, which is affixed to the device in such a way that it is clearly visible. Additional information about the nameplate is provided in the associated Operating Instructions.

Structure of the extended order code

FMR67	_	******	+	A*B*C*D*E*F*G*
(Device		(Basic		(Optional
type)		specifications)		specifications)

* = Placeholder

At this position, an option (number or letter) selected from the specification is displayed instead of the placeholders.

Basic specifications

The features that are absolutely essential for the device (mandatory features) are specified in the basic specifications. The number of

positions depends on the number of features available. The selected option of a feature can consist of several positions.

Optional specifications

The optional specifications describe additional features for the device (optional features). The number of positions depends on the number of features available. The features have a 2-digit structure to aid identification (e.g. JA). The first digit (ID) stands for the feature group and consists of a number or a letter (e.g. J = Test, Certificate). The second digit constitutes the value that stands for the feature within the group (e.g. A = 3.1 material (wetted parts), inspection certificate).

More detailed information about the device is provided in the following tables. These tables describe the individual positions and IDs in the extended order code which are relevant to hazardous locations.

Extended order code: Micropilot



The following specifications reproduce an extract from the product structure and are used to assign:

- This documentation to the device (using the extended order code on the nameplate).
- The device options cited in the document.

Device type FMR67

Basic specifications

Position 1, 2 (Approval)			
Selected option		Description	
FMR67	BE 1)	ATEX II 1 D Ex ta IIIC T ₅₀₀ 125°C Da	
	BF ²⁾	ATEX II 1/2 D Ex ta/tb IIIC T85°C Da/Db	
	IE 3)	IECEx Exta IIIC T ₅₀₀ 125°C Da	
	IF 4)	IECEx Ex ta/tb IIIC T85°C Da/Db	

- 1) The designation changes in connection with Position 4 = L, M, N: II 1 D Ex ta [ia Da] IIIC T_{500} 125°C Da
- The designation changes in connection with Position 4 = L, M, N: II 1/2 D Ex ta/tb | ia Da| IIIC T85°C Da/Db
- 3) The designation changes in connection with Position 4 = L, M, N: Ex ta [ia Da] IIIC T₅₀₀ 125°C Da
- 4) The designation changes in connection with Position 4 = L, M, N: Ex ta/tb |ia Da| IIIC T85°C Da/Db

Position 3 (Power Supply, Output)		
Selected option		Description
FMR67	A	2-wire, 4-20 mA HART
	В	2-wire, 4-20 mA HART, switch output (PFS)
	С	2-wire, 4-20 mA HART, 4 to 20 mA

Position 4 (Display, Operation)			
Selected option		Description	
FMR67	А	Without, via communication	
	С	SD02, 4-line, push buttons + data backup function	
	E	SD03, 4-line, illum., touch control + data backup function	
	L 1)	Prepared for display FHX50 + M12 connection	
	M 1)	Prepared for display FHX50 + custom connection	
	N 1)	Prepared for display FHX50 + NPT1/2"	

1) FHX50 is approved according to DEK12.0046X or DEKRA 12ATEX0151X.

Position 5 (Housing)			
Selected option		Description	
FMR67	В	GT18 dual compartment, 316L	
	С	GT20 dual compartment, Alu, coated	

Position 6 (Electrical Connection)			
Selected option		Description	
FMR6x	A 1)	Gland M20, IP66/68 NEMA4X/6P	
	В	Thread M20, IP66/68 NEMA4X/6P	
	С	Thread G1/2, IP66/68 NEMA4X/6P	
	D	Thread NPT1/2, IP66/68 NEMA4X/6P	

1) Only in connection with Position 1, 2 = BF, IF

Position 7, 8 (Antenna)			
Selected option		Description	
FMR67	GA	Drip-off, PTFE DN50	
	GP	PTFE flush mount DN80	
	in the te	mperature tables Illows:	

Position 9, 1	Position 9, 10 (Seal)			
Selected option		Description		
FMR67	А3	FKM Viton GLT, -4080°C/-40176°F		
	A5	FKM Viton GLT, -40150°C/-40302°F		
	A6	FKM Viton GLT, -40200°C/-40392°F		
1 1	n in the te plary as fo	mperature tables Illows:		

Position 11-13 (Process Connection)			
Selected op	tion	Description	
FMR67	AxJ	Flange (different sizes), 316/316L	
	CxJ	Flange (different sizes), 316L	
	GGJ	Thread ISO228 G1-1/2, 316L	
	KxJ	Flange (different sizes), 316L	
	RGJ	Thread ANSI MNPT1-1/2, 316L	
	XxA	Align. device (different sizes)	
	XxG	Flange (different sizes), PP	
	XxJ	Flange (different sizes), 316L	

Position 14 (Air Purge Connection)			
Selected option		Description	
FMR67	A 1)	W/o	
	1 2)	G1/4	
	2 2)	NPT1/4	
	3 1)	Adapter G1/4	
	4 1)	Adapter NPT1/4	

- 1) Only in connection with Position 7, 8 = GA
- Only in connection with Position 7, 8 = GP

Optional specifications

ID Nx (Acco	essory Mou	unted)
Selected or	ption	Description
FMR6x	NF 1)	Bluetooth

1) Only in connection with Position 4 = C, E

Safety instructions: General

- The device is intended to be used in explosive atmospheres as defined in the scope of IEC 60079-0 or equivalent national standards. If no potentially explosive atmospheres are present or if additional protective measures have been taken: The device may be operated according to the manufacturer's specifications.
- Staff must meet the following conditions for mounting, electrical installation, commissioning and maintenance of the device:
 - Be suitably qualified for their role and the tasks they perform
 - Be trained in explosion protection
 - Be familiar with national regulations
- Install the device according to the manufacturer's instructions and national regulations.
- Do not operate the device outside the specified electrical, thermal and mechanical parameters.
- Only use the device in media to which the wetted materials have sufficient durability.

- Avoid electrostatic charging:
 - Of plastic surfaces (e.g. enclosure, sensor element, special varnishing, attached additional plates, ..)
 - Of isolated capacities (e.g. isolated metallic plates)
- Modifications to the device can affect the explosion protection and must be carried out by staff authorized to perform such work by Endress+Hauser.
- Refer to the temperature tables for the relationship between the permitted ambient temperature for the sensor and/or transmitter, depending on the range of application and the temperature class.

Safety instructions: Special conditions

Permitted ambient temperature range at the electronics enclosure: $-40\,^{\circ}\text{C} \le T_a \le +80\,^{\circ}\text{C}$

- Observe the information in the temperature tables.
- In the case of process connections made of polymeric material or with polymeric coatings, avoid electrostatic charging of the plastic surfaces.
- To avoid electrostatic charging: Do not rub surfaces with a dry cloth.
- In the event of additional or alternative special varnishing on the enclosure or other metal parts or for adhesive plates:
 - Observe the danger of electrostatic charging and discharge.
 - Do not install in the vicinity of processes (≤ 0.5 m) generating strong electrostatic charges.
- Avoid electrostatic charging of the sensor (e.g. do not rub dry and install outside the filling flow).


Device type FMR67 and Basic specification, Position 11-13 = XxA

- Changing the position of the alignment device must be impossible:
 - After the alignment of the antenna via the pivot bracket
 - After tightening of the clamping flange
 - After setting the damping ring (torque 10 to 11 Nm)
- Degree of protection IP67 must be fulfilled.

Device type FMR67 and Basic specification, Position 14 = 1, 2

- If equipment with Ga/Gb or Da/Db is required: In the closed state the minimum degree of protection of the installation must be IP67.
- After removing the air purge connection: Lock the opening with a suitable plug.
 - Torque: 6-7 Nm
 - For Da/Db: thread engagement > 5 turns
- Degree of protection IP67 must be fulfilled.

Safety instructions: Installation



A002553

- A Zone 20, Zone 21
- 1 Tank; Zone 20, Zone 21
- 2 Electronics compartment Ex ia; Electronic insert
- 3 Connection compartment Ex tb
- 4 Power supply
- 5 Potential equalization line
- 6 Potential equalization
- After aligning (rotating) the enclosure, retighten the fixing screw (see Operating Instructions).
- Install the device to exclude any mechanical damage or friction during the application. Pay particular attention to flow conditions and tank fittings.
- Only use certified cable entries or sealing plugs. The metal sealing plugs supplied meet this requirement.
- Before operation:
 - Screw in the cover all the way.
 - Tighten the securing clamp on the cover.
- After mounting and connecting the antenna, ingress protection of the enclosure must be at least IP65.
- Perform the following to achieve the degree of protection:
 - Screw the cover tight.
 - Mount the cable entry correctly.
- Continuous service temperature of the connecting cable: $-40\,^{\circ}\text{C}$ to $\geq +85\,^{\circ}\text{C}$; in accordance with the range of service temperature taking into account additional influences of the process conditions $(T_{a,\text{min}})$, $(T_{a,\text{max}} + 20\,\text{K})$.

Basic specification, Position 4 = N

Observe the requirements according to IEC/EN 60079-14 for conduit systems and the wiring- and installation instructions of the suitable Safety Instructions (XA). In addition, observe national regulations and standards for conduit systems.

Intrinsic safety

- The device can be connected to the Endress+Hauser FXA291 service tool: refer to the Operating Instructions.
- The device can be equipped with the Bluetooth® module: refer to the Operating Instructions and specifications in the "Bluetooth® module" chapter.

Bluetooth® module

Optional specification, ID Nx = NF

- With Bluetooth[®] module installed: Use of external hardware not allowed (e.g. external display, service interface).
- The intrinsically safe input power circuit of the Bluetooth® module is isolated from ground.

Temperature tables

Description notes



Unless otherwise indicated, the positions always refer to the basic specification.

Zone 2.0

1st column: Position 5 = A, B, ...

2nd column: Calculation of temperature values and maximum

permissible ambient temperature in °C


3rd column: Maximum surface temperature in °C



 T_a : Ambient temperature in ${}^{\circ}\!C$

 T_{500} : Deposited material with a layer of 500 mm

Example table



Zone 20, Zone 21

1st column: Position 5 = A, B, ...

2nd column: Process temperature

Column P1 to P5: Position (temperature value) on the axes of the derating $\$

T_a: Ambient temperature in °C
 T_n: Process temperature in °C

Column P2+ is only relevant for version B of the derating.

Example table

		P1		P2		P2+		Р3		P4		P5	
= C		T _p	Ta	T _p	Ta	T _p	T _a	T _p	T _a	T _p	Ta	T _p	Ta
	100	-40	75	75	75	-	-	100	60	100	-40	-40	-40
	135	-40	75	75	75	-	-	135	56	135	-40	-40	-40
	150	-40	75	75	75	-	-	150	54	150	-40	-40	-40

Zone 21

1st column: Position 5 = A, B, ...

2nd column: Calculation of temperature values and maximum

permissible ambient temperature in °C


3rd column: Maximum surface temperature in °C

T_a: Ambient temperature in °C


Example table



Example diagrams of possible deratings




Zone 20




FMR67

= B, C				
	$T = T_a + 10 \text{ K}$ $T_{500} = T_a + 42 \text{ K}$	$T_a = 75$ $T_a = 43$	125	

Zone 20, Zone 21





FMR67



		P1		P2		P2+		P3		P4		P5	
= B, C		T _p	Ta	Tp	T _a	T _p	Ta						
	75	-40	75	75	75	-	-	75	75	75	-40	-40	-40

FMR67







		P1		P2		P2+		Р3		P4		P5	
= B		T _p	T _a	T _p	Ta	T _p	T _a	T _p	Ta	T _p	Ta	T _p	Ta
	100	-40	75	75	75	-	-	100	58	100	-40	-40	-40
	135	-40	75	75	75	-	-	135	52	135	-40	-40	-40
	150	-40	75	75	75	-	-	150	47	150	-40	-40	-40

		P1		P2		P2+		P3		P4		P5	
= C		T _p	Ta	T _p	Ta								
	100	-40	75	75	75	-	-	100	60	100	-40	-40	-40
	135	-40	75	75	75	-	-	135	56	135	-40	-40	-40
	150	-40	75	75	75	-	-	150	54	150	-40	-40	-40


FMR67





		P1		P2		P2+		P3		P4		P5	
= B, C		T _p	T _a	T _p	Ta	T _p	Ta						
	100	-40	75	75	75	-	-	100	61	100	-40	-40	-40
	135	-40	75	75	75	-	-	135	58	135	-40	-40	-40
	200	-40	75	75	75	-	-	200	53	200	-40	-40	-40

Zone 21



FMR67



Connection data Cable entry: Connection compartment

Ex ta

Basic specification, Position 1, 2 = BE, IE Cable gland: No cable gland available.

Ex tb

Basic specification, Position 1, 2 = BF, IF

Cable gland: Basic specification, Position 6 = A

Basic specification, Position 5 = B, C

preferably for Position 5 = B

Thread	Clamping range	Material	Sealing insert	O-ring
M20x1,5	ø 7 to 12 mm	1.4404	NBR	EPDM (ø 17x2)

preferably for Position 5 = C

Thread	Clamping range	Material	Sealing insert	O-ring
M20x1,5	ø 8 to 10.5 mm ¹⁾ (ø 6.5 to 13 mm) ²⁾	Ms, nickel-plated	Silicone	EPDM (ø 17x2)

- 1) Standard
- 2) Separate clamping inserts available

- Only suitable for fixed installation. The operator must pay attention to a suitable strain relief of the cable.
- The cable glands are suitable for a low risk of mechanical danger (4 Joule) and must be mounted in a protected position if larger impact energy levels are expected.
- To maintain the ingress protection of the enclosure: Install the enclosure cover, cable glands and blind plugs correctly.

Cable entry: Electronics compartment

Cable gland: Basic specification, Position 4 = M

Basic specification, Position 5 = B, C

preferably for Position 5 = B

Thread	Clamping range	Material	Sealing insert	O-ring
M16x1,5	ø 5 to 10 mm	1.4404	PA/NBR	NBR

preferably for Position 5 = C

Thread	Clamping range	Material	Sealing insert	0-ring
M16x1,5	ø 5 to 10 mm	Ms, nickel-plated	PA/NBR	NBR

- Only suitable for fixed installation. The operator must pay attention to a suitable strain relief of the cable.
- The cable glands are suitable for a low risk of mechanical danger (4 Joule) and must be mounted in a protected position if larger impact energy levels are expected.
- To maintain the ingress protection of the enclosure: Install the enclosure cover, cable glands and blind plugs correctly.

Terminals: Connection compartment

Optional specification, ID Nx = NF

When using the Bluetooth® module: No changes to the connection values.

Ex ta

Basic specification, Position 3 = A

Terminal 1 (+), 2 (-) Power supply 1 : $U_{N} = 35 V_{DC}$ $U_{m} = 250 V$ $I_{Fault} = 54 mA$

Basic specification, Position 3 = B

Terminal 1 (+), 2 (-)	Terminal 3 (+), 4 (-)
Power supply ¹⁾ :	Switch output (PFS) ²⁾ :
$\begin{aligned} &U_{N}=35\ V_{DC}\\ &U_{m}=250\ V\\ &I_{Fault}=54\ mA \end{aligned}$	$U_{N} = 35 V_{DC}$ $U_{m} = 250 V$

- 1) Observe "Power limitation 4 to 20 mA", → 🖺 21
- 2) Observe "Power limitation Switch output (PFS)", → 🖺 23

Basic specification, Position 3 = C

Terminal 1 (+), 2 (-)	Terminal 3 (+), 4 (-)				
Power supply ¹⁾ :	Output 4 to 20 mA ¹⁾ :				
$\begin{aligned} &U_{N}=30\ V_{DC}\\ &U_{m}=250\ V\\ &I_{Fault}=54\ mA \end{aligned}$	$\begin{aligned} &U_N = 30 \ V_{DC} \\ &U_m = 250 \ V \\ &I_{Fault} = 54 \ mA \end{aligned}$				

1) Observe "Power limitation 4 to 20 mA", →

□ 21

Power limitation 4 to 20 mA

Basic specification, Position 3 = A, B, C

The power consumption of each 4 to 20 mA channel has to be limited to a defined value.

This is achieved by:

- using a power supply with power limitation:
 - $I_{\text{max}} = 54 \text{ mA} \text{ and } 15.74 \text{ V}$
 - Basic specification, Position 3 = A, B: $U \le 35 \text{ V}$
 - Basic specification, Position 3 = C: $U \le 30 \text{ V}$
- monitoring the current and cutting off the supply when 22 mA are exceeded.
- reducing the maximum voltage at the terminals of the device depending on U_N and each channel used (by using a suitable power supply, a limiting resistor or both).
- The limiting resistor is installed outside the device and may be a load/communication resistor or a relay coil. When using it, pay attention to correct load and temperature effects.

Table for minimum external resistors necessary to limit the power consumption in dependence on the supply source: $\frac{1}{2} \sum_{i=1}^{n} \frac{1}{2} \sum$

Power load	0.85 W
Terminal voltage U	15.74 V
I _{Fault}	0.054 A

U _N [V]	R _V min
35	356.7 Ω
34	338.1 Ω
33	319.6 Ω
32	301.1 Ω
31	282.6 Ω
30	264.1 Ω
29	245.5 Ω
28	227.0 Ω
27	208.5 Ω
26	190.0 Ω
25	171.5 Ω
24	152.9 Ω
23	134.4 Ω
22	115.9 Ω
21	97.4 Ω
20	78.9 Ω
19	60.4 Ω
18	41.8 Ω
17	23.3 Ω
16	4.8 Ω
15	0 Ω

Power limitation Switch output (PFS)

Basic specification, Position 3 = B

To limit the temperature rise it is necessary to limit the power consumption of the Switch output (PFS).

This is achieved by:

- using a supply voltage by consideration of Ri_{Fault} and terminal voltage U = 19.5 V.
- using a power supply with power limitation:
 - I_{max} = 51.3 mA and 19.5 V
 - Basic specification, Position 3 = B: U ≤ 35 V
- using an external resistor.
- reducing the maximum voltage at the terminals of the device depending on U_N and the channel used (by using a suitable power supply, a limiting resistor or both).
- The limiting resistor is installed outside the device and may be a load/communication resistor or a relay coil. When using it, pay attention to correct load and temperature effects.

Table of external resistors depending on power load and supply voltage:

Power load	1.0 W
Terminal voltage U	19.5 V
I _{Fault}	0.0513 A
Ri _{Fault}	380.3 Ω

U _N [V]	R _V min
35	302 Ω
34	283 Ω
33	263 Ω
32	244 Ω
31	224 Ω
30	205 Ω
29	185 Ω
28	166 Ω
27	146 Ω
26	127 Ω
25	107 Ω

U _N [V]	R _V min
24	88 Ω
23	68 Ω
22	49 Ω
21	29 Ω
20	10 Ω
19	0 Ω

Ex tb

Basic specification, Position 3 = A

Terminal 1 (+), 2 (-)
Power supply
$\begin{array}{l} U_N = 35 \ V_{DC} \\ U_m = 250 \ V \\ I_N = 4 \ to \ 20 \ mA \\ I_{max} = 22 \ mA \\ P_N = 0.7 \ W \end{array}$

Basic specification, Position 3 = B

The power consumption of I/O modules with passive PFS output can be limited for certain applications.

- Recommended: Power consumption = 1 W. This is obtained for a supply voltage at the terminals of 27 V_{DC}.
- For higher supply voltages (U_{max}) : Insert a serial resistance (R_V) in order to limit the power consumption, see table below.

Table for the PFS serial resistance (R_V):

Power consumption	1.0 W
Total power consumption	1.88 W
Internal resistance R _I	760 Ω

U _{max} [V]	R _V min
35	205 Ω
34	177 Ω
33	150 Ω
32	122 Ω
31	95 Ω
30	67 Ω
29	39 Ω
28	12 Ω
27	0 Ω

For values associated with a higher or lower internal power consumption please contact Endress+Hauser.

Terminal 1 (+), 2 (-)	Terminal 3 (+), 4 (-)
Power supply	Switch output (PFS)
$\begin{array}{l} U_{N} = 35 \ V_{DC} \\ U_{m} = 250 \ V \\ I_{N} = 4 \ to \ 20 \ mA \\ I_{max} = 22 \ mA \\ P_{N} = 0.7 \ W \end{array}$	$\begin{aligned} &U_{N} = 35 \ V_{DC} \\ &U_{m} = 250 \ V \\ &P_{N} = 0.7 \ W \end{aligned}$

Basic specification, Position 3 = C

Terminal 1 (+), 2 (-)	Terminal 3 (+), 4 (-)				
Power supply	Output 4 to 20 mA				
$\begin{array}{l} U_{N} = 30 \; V_{DC} \\ U_{m} = 250 \; V \\ I_{N} = 4 \; to \; 20 \; mA \\ I_{max} = 22 \; mA \\ P_{N} = 0.7 \; W \end{array}$	$\begin{array}{l} U_{N} = 30 \; V_{DC} \\ U_{m} = 250 \; V \\ I_{N} = 4 \; to \; 20 \; mA \\ I_{max} = 22 \; mA \\ P_{N} = 0.7 \; W \end{array}$				

Terminals: Electronics compartment

Ex ia

Service interface (CDI)

Taking the following values into consideration, the device can be connected to the certified Endress+Hauser FXA291 service tool or a similar interface:

Service interface

 $U_i = 7.3 \text{ V}$

effective inner inductance L_i = negligible effective inner capacitance C_i = negligible

 $U_0 = 7.3 \text{ V}$

 $I_0 = 60 \text{ mA}$

 $P_0 = 110 \text{ mW}$

_													
L_o (mH) =	5.00	2.00	1.00	0.50	0.20	0.15	0.10	0.05	0.02	0.01	0.005	0.002	0.001
C _o (µF) ¹⁾ =	0.73	1.20	1.60	2.00	2.60	-	3.20	4.00	5.50	7.30	10.00	12.70	12.70
$C_o (\mu F)^{2)} =$	-	0.49	0.90	1.40	-	2.00	-	-	-	-	-	-	-

- 1) Values according to PTB "ispark" program
- 2) Values according to IEC/EN 60079-25, Annex C





www.addresses.endress.com