Safety Instructions **Deltapilot S FMB70**

4-20 mA HART, PROFIBUS PA, FOUNDATION Fieldbus

II 1/2 G Ex ia IIC T6...T4 Ga/Gb







Deltapilot S FMB70 XA02669P-A

Deltapilot S FMB70

4-20 mA HART, PROFIBUS PA, FOUNDATION Fieldbus

Table of contents

Associated documentation	4
Supplementary documentation	4
Manufacturer's certificates	4
Manufacturer address	4
Other standards	5
Extended order code	5
Safety instructions: General	7
Safety instructions: Special conditions	7
Safety instructions: Installation	8
Safety instructions: Zone 0	9
Temperature tables	9
Connection data	9

XA02669P-A Deltapilot S FMB70

Associated documentation

This document is an integral part of the following Operating Instructions:

HART

- BA00332P/00
- BA00274P/00

PROFIBUS PA

- BA00356P/00
- BA00296P/00

FOUNDATION Fieldbus

- BA00372P/00
- BA00303P/00

Supplementary documentation

Explosion-protection brochure: CP00021Z/11

The Explosion-protection brochure is available:

- In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Brochures and Catalogs -> Text Search: CP00021Z
- On the CD for devices with CD-based documentation

Manufacturer's certificates

UK Declaration of Conformity

Declaration Number:

UK_00234

The UK Declaration of Conformity is available: In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Declaration -> Type: UKCA Declaration -> Product Code: ...

UKCA type-examination certificate

Certificate number: CML 21UKEX2437X

List of applied standards: See UK Declaration of Conformity.

Manufacturer address

Endress+Hauser SE+Co. KG

Hauptstraße 1

79689 Maulburg, Germany

Address of the manufacturing plant: See nameplate.

Deltapilot S FMB70 XA02669P-A

Other standards

Among other things, the following standards shall be observed in their current version for proper installation:

- IEC/EN 60079-14: "Explosive atmospheres Part 14: Electrical installations design, selection and erection"
- EN 1127-1: "Explosive atmospheres Explosion prevention and protection - Part 1: Basic concepts and methodology"

Extended order code

The extended order code is indicated on the nameplate, which is affixed to the device in such a way that it is clearly visible. Additional information about the nameplate is provided in the associated Operating Instructions.

Structure of the extended order code

FMB70	-	******	+	A*B*C*D*E*F*G*
(Device		(Basic		(Optional
type)		specifications)		specifications)

* = Placeholder
At this position, an option (number or letter) selected from the specification is displayed instead of the placeholders.

Basic specifications

The features that are absolutely essential for the device (mandatory features) are specified in the basic specifications. The number of positions depends on the number of features available.

The selected option of a feature can consist of several positions.

Optional specifications

The optional specifications describe additional features for the device (optional features). The number of positions depends on the number of features available. The features have a 2-digit structure to aid identification (e.g. JA). The first digit (ID) stands for the feature group and consists of a number or a letter (e.g. J = Test, Certificate). The second digit constitutes the value that stands for the feature within the group (e.g. A = 3.1 material (wetted parts), inspection certificate).

More detailed information about the device is provided in the following tables. These tables describe the individual positions and IDs in the extended order code which are relevant to hazardous locations.

XA02669P-A Deltapilot S FMB70

Extended order code: Deltapilot S

Device type FMB70

Basic specifications

Position 1 (Approval)			
Selected option		Description	
FMB70 1		ATEX II 1/2 G Ex ia IIC T6T4 Ga/Gb	
	6 ¹⁾	ATEX II 1/2 G Ex ia IIC T6T4 Ga/Gb, WHG	

1) Only in connection with Position 2 = A, B, C, D, E, F

Position 2 (Output, Operating)			
Selected option		Description	
FMB70 A, B, C		4-20 mA HART	
	D, E, F	4-20 mA HART, L _i = 0	
	M, N, O	PROFIBUS PA	
	P, Q, R	FOUNDATION Fieldbus	

Position 11 (Additional Option 1)			
Selected option		Description	
FMB70	M	Overvoltage protection	

Position 12 (Additional Option 2)			
Selected option		Description	
FMB70	G	Separate enclosure, cable length see additional spec. + enclosure mounting bracket, wall/pipe, 316L	
	M	Overvoltage protection	

Optional specifications

ID Lx (Additional Approval)			
Selected option		Description	
FMB70	LU	UK marking	

Deltapilot S FMB70 XA02669P-A

Safety instructions: General

 Comply with the installation and safety instructions in the Operating Instructions.


- Staff must meet the following conditions for mounting, electrical installation, commissioning and maintenance of the device:
 - Be suitably qualified for their role and the tasks they perform
 - Be trained in explosion protection
 - Be familiar with national regulations
- Install the device according to the manufacturer's instructions and national regulations.
- Only use the device in media to which the wetted materials have sufficient durability.
- Avoid electrostatic charging:
 - Of plastic surfaces (e.g. enclosure, sensor element, special varnishing, attached additional plates, ..)
 - Of isolated capacities (e.g. isolated metallic plates)

Safety instructions: Special conditions

- In the case of process connections made of polymeric material or with polymeric coatings, avoid electrostatic charging of the plastic surfaces.
- For light metal flanges or flange faces (e.g. titanium, zirconium), avoid sparks caused by impact and friction.
- To avoid electrostatic charging: Do not rub surfaces with a dry cloth.
- In the event of additional or alternative special varnishing on the enclosure or other metal parts or for adhesive plates:
 - Observe the danger of electrostatic charging and discharge.
 - Do not install in the vicinity of processes (≤ 0.5 m) generating strong electrostatic charges.

XA02669P-A Deltapilot S FMB70

Safety instructions: Installation



- A Zone 1. Electronic
- B Zone O, Process
- 1 Certified associated apparatus
- 2 FMB70

After aligning (rotating) the enclosure, retighten the fixing screw.

Intrinsic safety

- \blacksquare The intrinsically safe input power circuit of the device is isolated from ground. The dielectric strength is at least 500 $V_{\rm rms}.$
- When the device is connected to certified intrinsically safe circuits of Category Ex ib for Equipment Groups IIC and IIB, the type of protection changes to Ex ib IIC and Ex ib IIB. Do not operate the in Zone 0 if connecting to an intrinsically safe circuit of Category Ex ib.

Overvoltage protection

Basic specification, Position 11 + 12 = M

The intrinsically safe input power circuit of the device is isolated from ground. The dielectric strength is at least 290 $V_{rms}.\,$

Deltapilot S FMB70 XA02669P-A

Safety instructions: Zone 0

- In the event of potentially explosive vapor/air mixtures, only operate the device under atmospheric conditions.
 - Temperature: -20 to +60 °C
 - Pressure: 80 to 110 kPa (0.8 to 1.1 bar)
 - Air with normal oxygen content, usually 21 % (V/V)
- If no potentially explosive mixtures are present, or if additional protective measures have been taken, the device may also be operated under non-atmospheric conditions in accordance with the manufacturer's specifications.
- Associated devices with galvanic isolation between the intrinsically safe and non-intrinsically safe circuits are preferred.
- Overvoltage protection is not required depending on the design of this device.

Temperature tables

Temperature class	Process temperature T _p (process)	Ambient temperature T_a (ambient): enclosure
T6	2° 08 ≥	$-40 ^{\circ}\text{C} \le T_a \le +40 ^{\circ}\text{C}$
T4	≤ 100 °C	-40 °C ≤ T _a ≤ +70 °C



- The process temperatures refer to the temperature at the separation membrane.
 - Do not exceed the max. ambient temperature at the enclosure.

Connection data

Basic specification, Position 2 = A, B, C, D, E, F

Power supply
$\begin{split} &U_{l} \leq 30 \ V_{DC} \\ &I_{i} \leq 300 \ mA \\ &P_{i} \leq 1 \ W \\ &C_{l} \leq 11.8 \ nF \\ &L_{i} \leq 225 \ \mu H^{1)} or L_{i} = 0^{\ 2)} \end{split}$

- Basic specification. Position 2 = A. B. C. 1)
- 2) Basic specification, Position 2 = D, E, F

Basic specification, Position 2 = M, N, O, P, Q, R

Power supply	
FISCO	Entity
$\begin{split} &U_{l} \leq 17.5 \ V_{DC} \\ &I_{i} \leq 500 \ mA \\ &P_{i} \leq 5.5 \ W \\ &C_{i} \leq 5 \ nF \\ &L_{i} \leq 10 \ \mu H \end{split}$	$\begin{split} &U_l \leq 24 \ V_{DC} \\ &I_i \leq 250 \ mA \\ &P_i \leq 1.2 \ W \\ &C_i \leq 5 \ nF \\ &L_i \leq 10 \ \mu H \end{split}$





www.addresses.endress.com