# Technical Information **OUSBT66**

NIR absorption sensor for the measurement of cell growth and biomass



#### **Application**

- Cell growth in bacterial fermentation and applications in mammalian cell cultures
- Biomass in fermentation processes
- Monitoring of algae concentration
- Monitoring of crystallization processes
- Measurement of solids

#### Your benefits

- Increased product yield thanks to fast and reliable absorption measurement in fermentation and crystallization applications
   Highest linearity and wide measuring range with LED lamp
- Suitable for pharmaceutical use:
  - Stainless steel 1.4435 (AISI 316L)
  - Sealless sapphire window without gaps
- High degree of product safety:
  - Sterilizable and autoclavable
  - CIP/SIP-resistant
- Cost-effective, time-efficient calibration with traceable plug-on filters
- For use in a wide range of applications:
  - Variety of optical path lengths for different cell cultures and concentrations
  - Process connection Pg 13.5 for installation in assemblies or head plates
  - $\, \blacksquare \,$  Suitable for lab-scale, pilot-scale and production-scale bioreactors
  - Available in different lengths for different immersion depths

# Function and system design

#### Measuring principle

#### Light absorption

The measuring principle is based on the Lambert-Beer law.

There is a linear dependency between the absorption of light and the concentration of the absorbing substance:

$$A = -log(T) = \varepsilon \cdot c \cdot OPL$$

 $T = I/I_0$ 

 $T\dots Transmission$ 

*I ... Intensity of received light at detector* 

 $I_0$  ... Intensity of transmitted light of light source

A ... Absorption

 $\varepsilon$  ... Extinction coefficient


c ... Concentration

OPL ... Optical path length

A light source emits radiation through the medium and the incident radiation is measured on the detector side.

The intensity of the light is determined by a photodiode and converted to a photocurrent.

The subsequent conversion to absorbance units (AU, OD) is performed in the associated transmitter.



A00294


■ 1 Absorption measurement

- 1 Light source
- 2 Optical windows of the sensor
- 3 Detector
- 4 Measurement filter (depends on sensor, not provided on all sensors)
- 5 Medium flov

## Measuring system

An optical measuring system comprises:

- OUSBT66 sensor (photometer)
- Transmitter, for example Liquiline CM44P
- Sensor cable, for example CUK80



- $\blacksquare$  2 Example of a measuring system with a photometer sensor
- 1 Bioreactor (example)
- 2 OUSBT66 sensor
- 3 CM44P transmitter
- 4 CUK80 sensor cable


# Input

Measured variable	NIR-absorption	
Measuring range	<ul> <li>0 to 4 AU</li> <li>0 to 8 OD (depending on the optical path length)</li> </ul>	
Wavelength	880 nm	
Optical path length	5, 10 or 20 mm	

# **Power supply**

**Electrical connection** 

The sensor is connected to the transmitter using the pre-terminated or labeled sensor fixed cable.



■ 3 Sensor cable

CM44P terminal	Cable color	Assignment
P+	BN	Lamp voltage +
S+	BN	Detection of lamp voltage +
S-	BK	Detection of lamp voltage -
P-	BK	Lamp voltage -
A (1)	RD	Sensor +
C(1)	OG	Sensor -
SH (1)	TP	Shield

Cable length

Maximum 20 m (65 ft)


Lamp voltage

Sensor version	Lamp type	Lamp voltage [V]
OUSBT66-xxxxx	LED	7.5 ± 0.1

# Mounting


## **Installation instructions**

The sensor can be installed up to the horizontal in an assembly, support or suitable process connection. Other angles of inclination are not recommended.



 $\blacksquare$  4 Permitted mounting angle

# Mounting in pipes



■ 5 Permitted and unacceptable installation positions in pipes

Comply with the following conditions. Otherwise you run the risk of damaging the measuring point or obtaining incorrect measured values.

- ► The diameter of the pipe must be at least 50 mm (2").
- ► Install the sensor in places with consistent flow conditions.
- ▶ The best installation location is in the ascending pipe (item 1).
- ▶ Installation in the horizontal pipe (item 5) is also possible.
- ▶ Do not install the sensor in places where air pockets or bubbles occur ( $\rightarrow$  🖸 5, item 3) or where sedimentation may occur (item 2).
- ► Avoid installation in the down pipe (item 4).
- ► Align the sensor in such a way that the medium flows through the measuring gap (self-cleaning effect).

## **Environment**


Ambient temperature	0 to 55 °C (32 to 131 °F)	
Storage temperature	0 to 70 °C (32 to 160 °F)	
Humidity	5 to 95 %	
Degree of protection	IP 68, Fischer connector (up to 2 m (6.6 ft) water column for 24 h)	

# **Process**

Process temperature	0 to 90 °C (32 to 194 °F) continuous
	Max. 135 °C (275 °F) for 2 hours maximum
Process pressure	Max. 10 bar (150 psi) absolute, at 90 °C (194 °F)

# Mechanical construction

## Design, dimensions



- 6 Dimensions in mm (inch)
- A Version with shaft length 120 mm (4.72")
- B Version with shaft length 225 mm (8.86")
- C Version with shaft length 360 mm (14.17")
- D Optical path length: 5, 10 or 20 mm

Weight	Approx. 0.2 kg (0.44 lbs)		
Materials	Sensor	Stainless steel 1.4435 (316L)	
	Window	Sapphire, borosilicate	
	O-ring	EPDM	
Process connections	Pg 13.5		
Surface roughness	R <sub>a</sub> < 0.38 μm		
Light source	LED		

# Certificates and approvals

Current certificates and approvals that are available for the product can be selected via the Product Configurator at <a href="https://www.endress.com">www.endress.com</a>:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select **Configuration**.

# **Ordering information**

Product page	www.endress.com/ousbt66
Product Configurator	1. Configure: Click this button on the product page.
	2. Select Extended selection.
	The Configurator opens in a separate window.
	3. Configure the device according to your requirements by selecting the desired option for each feature.
	☐ In this way, you receive a valid and complete order code for the device.

- 4. **Apply**: Add the configured product to the shopping cart.
- For many products, you also have the option of downloading CAD or 2D drawings of the selected product version.
- 5. **Show details**: Open this tab for the product in the shopping cart.
  - The link to the CAD drawing is displayed. If selected, the 3D display format is displayed along with the option to download various formats.

#### Scope of delivery

The scope of delivery comprises the following,:

- Sensor OUSBT66
- Life sciences package certificates
  - Inspection certificate 3.1
  - Pharma CoC

Certificate of conformity to pharmaceutical requirements, conformity to bioreactivity test USP Class VI, FDA material conformity, TSE-/BSE-free, surface roughness

- Operating Instructions
- Ordering the sensor together with a transmitter:

If you select the calibration option in the **Product Configurator for the transmitter**, the complete measuring system (transmitter, sensor, cable) is factory-calibrated and shipped as one package.

If you have any queries:Please contact your supplier or local sales center.

## Accessories

The following are the most important accessories available at the time this documentation was issued.

Listed accessories are technically compatible with the product in the instructions.

- Application-specific restrictions of the product combination are possible.
   Ensure conformity of the measuring point to the application. This is the responsibility of the operator of the measuring point.
- 2. Pay attention to the information in the instructions for all products, particularly the technical
- 3. For accessories not listed here, please contact your Service or Sales Center.

#### Assembly

#### **Unifit CPA842**

- $\,\blacksquare\,$  Installation assembly for food, biotechnology and pharmaceutics
- With EHEDG and 3A certificate
- Product Configurator on the product page: www.endress.com/cpa842



Technical Information TI00306C

## Cleanfit CPA875

- Retractable process assembly for sterile and hygienic applications
- ullet For in-line measurement with standard sensors with 12 mm diameter, e.g. for pH, ORP, oxygen
- Product Configurator on the product page: www.endress.com/cpa875



Technical Information TI01168C

#### Calibration

#### **OUSBT66** calibration kit

- 2/0.35 AU
- Order no.: 71128340



/1596234

www.addresses.endress.com

